

TABLE OF CONTENTS

Precautions	00-i
Precautions	00-1
General Information	0-i
General Information	0A-1
Maintenance and Lubrication	0B-1
Service Data.....	0C-1
Engine	1-i
Precautions	1-1
Engine General Information and Diagnosis	1A-1
Emission Control Devices	1B-1
Engine Electrical Devices.....	1C-1
Engine Mechanical.....	1D-1
Engine Lubrication System	1E-1
Engine Cooling System.....	1F-1
Fuel System	1G-1
Ignition System.....	1H-1
Starting System.....	1I-1
Charging System.....	1J-1
Exhaust System	1K-1
Suspension	2-i
Precautions	2-1
Suspension General Diagnosis.....	2A-1
Front Suspension	2B-1
Rear Suspension.....	2C-1
Wheels and Tires	2D-1
Driveline / Axle	3-i
Precautions	3-1
Drive Chain / Drive Train / Drive Shaft	3A-1
Brakes	4-i
Precautions	4-1
Brake Control System and Diagnosis	4A-1
Front Brakes.....	4B-1
Rear Brakes	4C-1
ABS	4E-1
Transmission / Transaxle	5-i
Precautions	5-1
Manual Transmission	5B-1
Clutch	5C-1
Steering	6-i
Precautions	6-1
Steering General Diagnosis	6A-1
Steering / Handlebar	6B-1
Body and Accessories	9-i
Precautions	9-1
Wiring Systems	9A-1
Lighting Systems.....	9B-1
Combination Meter / Fuel Meter / Horn.....	9C-1
Exterior Parts	9D-1
Body Structure	9E-1

Section 0

General Information

CONTENTS

General Information	0A-1	Exhaust Pipe Bolts and Muffler Bolts	
General Description	0A-1	Inspection	0B-4
Symbols	0A-1	Valve Clearance Inspection and Adjustment	0B-4
Abbreviations	0A-2	Spark Plug Replacement	0B-9
SAE-to-Former SUZUKI Term	0A-3	Spark Plug Inspection and Cleaning	0B-9
Vehicle Side View	0A-4	Fuel Line Inspection	0B-10
Vehicle Identification Number	0A-4	Evaporative Emission Control System	
Fuel and Oil Recommendation	0A-5	Inspection (E-33 Only)	0B-10
Engine Coolant Recommendation	0A-6	Engine Oil and Filter Replacement	0B-10
BREAK-IN Procedures	0A-6	Throttle Cable Play Inspection and	
Cylinder Identification	0A-6	Adjustment	0B-12
Country and Area Codes	0A-7	Throttle Valve Synchronization	0B-12
Wire Color Symbols	0A-7	Cooling System Inspection	0B-12
Warning, Caution and Information Labels		Clutch System Inspection	0B-14
Location	0A-8	Drive Chain Inspection and Adjustment	0B-15
Component Location	0A-9	Drive Chain Cleaning and Lubricating	0B-17
Electrical Components Location	0A-9	Brake System Inspection	0B-17
Specifications	0A-11	Tire Inspection	0B-19
Specifications	0A-11	Steering System Inspection	0B-20
Special Tools and Equipment	0A-13	Front Fork Inspection	0B-20
Special Tool	0A-13	Rear Suspension Inspection	0B-20
Maintenance and Lubrication	0B-1	Chassis Bolt and Nut Inspection	0B-21
Precautions	0B-1	Compression Pressure Check	0B-23
Precautions for Maintenance	0B-1	Oil Pressure Check	0B-23
General Description	0B-1	SDS Check	0B-23
Recommended Fluids and Lubricants	0B-1	Specifications	0B-24
Scheduled Maintenance	0B-1	Tightening Torque Specifications	0B-24
Periodic Maintenance Schedule Chart	0B-1	Special Tools and Equipment	0B-24
Lubrication Points	0B-2	Recommended Service Material	0B-24
Repair Instructions	0B-3	Special Tool	0B-24
Air Cleaner Element Replacement	0B-3	Service Data	0C-1
Air Cleaner Element Inspection and Cleaning	0B-3	Specifications	0C-1
		Service Data	0C-1
		Tightening Torque List	0C-7

General Information

General Description

Symbols

BENC11J10101001

Listed in the table below are the symbols indicating instructions and other information necessary for servicing.
The meaning of each symbol is also included in the table.

Symbol	Definition
	Torque control required. Data beside it indicates specified torque.
	Apply oil. Use engine oil unless otherwise specified.
	Apply molybdenum oil solution. (Mixture of engine oil and SUZUKI MOLY PASTE in a ratio of 1:1).
	Apply SUZUKI SUPER GREASE "A" or equivalent. 99000-25010
	Apply SUZUKI MOLYBDENUM GREASE "L" or equivalent. 99000-25280
	Apply SUZUKI MOLY PASTE or equivalent. 99000-25140
	Apply SUZUKI SILICONE GREASE or equivalent. 99000-25100
	Apply SUZUKI BOND "1207B" or equivalent. 99000-31140
	Apply SUZUKI BOND "1215" or equivalent. 99000-31110
	Apply THREAD LOCK SUPER "1303" or equivalent. 99000-32030
	Apply THREAD LOCK SUPER "1322" or equivalent. 99000-32110
	Apply THREAD LOCK SUPER "1360" or equivalent. 99000-32130
	Use SUZUKI SUPER LONG LIFE COOLANT (BLUE). 99000-99032-20X Use SUZUKI LONG LIFE COOLANT (GREEN) or equivalent. 99000-99032-12X
	Use SUZUKI FORK OIL SS-8 or equivalent. 99000-99001-SS8
	Apply MUFFLER SEAL LOCTITE "5920" (commercially available) or equivalent.
	Apply or use brake fluid.
	Use special tool.
	Do not reuse.
	Note on reassembly.

Abbreviations

BENC11J10101002

A: NOT

ABDC: After Bottom Dead Center

ABS: Anti-lock Brake System

AC: Alternating Current

ACL: Air Cleaner, Air Cleaner Box

API: American Petroleum Institute

ATDC: After Top Dead Center

A/F: Air Fuel Mixture

B:

BBDC: Before Bottom Dead Center

BTDC: Before Top Dead Center

B+: Battery Positive Voltage

C:

CKP Sensor: Crankshaft Position Sensor (CKPS)

CKT: Circuit

CLP Switch: Clutch Lever Position Switch (Clutch Switch)

CO: Carbon Monoxide

CPU: Central Processing Unit

D:

DC: Direct Current

DMC: Dealer Mode Coupler

DOHC: Double Over Head Camshaft

DRL: Daytime Running Light

DTC: Diagnostic Trouble code

E:

ECM: Engine Control Module Engine Control Unit (ECU) (FI Control Unit)

ECT Sensor: Engine Coolant Temperature Sensor (ECTS)
Water Temp. Sensor (WTS)

F:

FI: Fuel Injection, Fuel Injector

FP: Fuel pump

FPR: Fuel Pressure Regulator

FP Relay: Fuel Pump Relay

G:

GEN: Generator

GND: Ground

GP Switch: Gear Position Switch

H:

HC: Hydrocarbons

HO2 sensor: Heated Oxygen Sensor (HO2S)

I:

IAP Sensor: Intake Air Pressure Sensor (IAPS)

IAT Sensor: Intake Air Temperature Sensor (IATS)

IG: Ignition

ISC Valve: Idle Speed Control Valve (ISCV)

J:

JASO: Japanese Automobile Standards Organization

L:

LCD: Liquid Crystal Display

LED: Light Emitting Diode (Malfunction Indicator Lamp)

LH: Left Hand

M:

MAL-CODE: Malfunction Code (Diagnostic Code)

Max: Maximum

MIL: Malfunction Indicator Lamp (LED)

Min: Minimum

N:

NOx: Nitrogen Oxides

O:

OHC: Over Head Camshaft

OPS: Oil Pressure Switch

P:

PCV: Positive Crankcase Ventilation (Crankcase Breather)

R:

RH: Right Hand

ROM: Read Only Memory

S:

SAE: Society of Automotive Engineers

SDS: Suzuki Diagnosis System

STC System: Secondary Throttle Control System (STCS)

STP Sensor: Secondary Throttle Position Sensor (STPS)

ST Valve: Secondary Throttle Valve (STV)

STV Actuator: Secondary Throttle Valve Actuator (STVA)

T:

TO Sensor: Tip-over Sensor (TOS)

TP Sensor: Throttle Position Sensor (TPS)

SAE-to-Former SUZUKI Term

BENC11J10101003

This list shows SAE (Society of Automotive Engineers) J1930 terms and abbreviations which may be used in this manual in compliance with SAE recommendations, as well as their former SUZUKI names.

Ex. SAE term (Abbreviation): Former SUZUKI term

A:

Air Cleaner (ACL): Air Cleaner, Air Cleaner Box

B:

Battery Positive Voltage (B+): Battery Voltage, +B

C:

Crankshaft Position Sensor (CKP Sensor):

Crankshaft Position Sensor (CKPS), Crank Angle

D:

Data Link Connector (DLC): Dealer Mode Coupler

Diagnostic Test Mode (DTM): —

Diagnostic Trouble Code (DTC): Diagnostic Code, Malfunction Code

E:

Electronic Ignition (EI): —

Engine Control Module (ECM): Engine Control Module (ECM), FI Control Unit, Engine Control Unit (ECU)

Engine Coolant Level (ECL): Coolant Level

Engine Coolant Temperature (ECT): Coolant Temperature, Engine Coolant Temperature, Water Temperature

Engine Speed (RPM): Engine Speed (RPM)

Evaporative Emission (EVAP): Evaporative Emission

Evaporative Emission Canister (EVAP Canister): — (Canister)

Evaporative Emission (EVAP): Evaporative Emission

Evaporative Emission Canister (EVAP Canister): — (Canister)

F:

Fan Control (FC): —

Fuel Level Sensor: Fuel Level Sensor, Fuel Level Gauge

Fuel Pump (FP): Fuel Pump (FP)

G:

Generator (GEN): Generator

Ground (GND): Ground (GND, GRD)

H:

Hydrocarbons (HC): Hydrocarbons

Heated Oxygen Sensor (HO2S): Heated Oxygen Sensor (HO2S), O2 sensor

I:

Ignition Control Module (ICM): —

Intake Air Temperature (IAT): Intake Air Temperature (IAT), Air Temperature

Idle Speed Control (ISC): —

Ignition Control (IC): Electronic Spark Advance (ESA)

Ignition Control Module (ICM): —

M:

Malfunction Indicator Lamp (MIL): LED Lamp, Malfunction Indicator Lamp (MIL)

Manifold Absolute Pressure (MAP): Intake Air Pressure (IAP), Intake Vacuum

Mass Air Flow (MAF): Air Flow

O:

On-Board Diagnostic (OBD): Self-Diagnosis Function, Diagnostic

Open Loop (OL): —

P:

Programmable Read Only Memory (PROM): —

Purge Valve (Purge Valve): Purge Valve (SP Valve)

R:

Random Access Memory (RAM): —

Read Only Memory (ROM): ROM

S:

Secondary Air Injection (AIR): —

Secondary Throttle Control System (STCS): STC System (STCS)

Secondary Throttle Valve (STV): ST Valve (STV)

Secondary Throttle Valve Actuator (STVA): STV Actuator (STVA)

T:

Throttle Body (TB): Throttle Body (TB)

Throttle Body Fuel Injection (TBI): Throttle Body Fuel Injection (TBI)

Throttle Position Sensor (TP Sensor): TP Sensor (TPS)

V:

Voltage Regulator (VR): Voltage Regulator

Volume Air Flow (VAF): Air Flow

Vehicle Side View

BENC11J10101004

NOTE

Difference between illustration and actual motorcycles may exist depending on the markets.

SUZUKI DL650 A/AUE (2012-model)

Right Side



IC11J1010001-01

Left Side




IC11J1010002-01


Vehicle Identification Number

BENC11J10101005

The frame serial number or V.I.N. (Vehicle Identification Number) "A" is stamped on the right side of the steering head pipe. The engine serial number "B" is located on the left side of the crankcase. These numbers are required especially for registering the machine and ordering spare parts.



IC11J1010003-01



IC11J1010004-01

Fuel and Oil Recommendation

BENC11J10101006

Fuel (For USA and Canada)

Use unleaded gasoline with a minimum pump octane rating of 87 ((R+M)/2 method).

Gasoline containing MTBE (Methyl Tertiary Butyl Ether), less than 10% ethanol, or less than 5% methanol with appropriate cosolvents and corrosion inhibitor is permissible.

Fuel (For Other Countries)

Use unleaded gasoline with an octane rating of 91 or higher (Research method).


Engine Oil (For USA)

Oil quality is a major contributor to your engine's performance and life. Always select good quality engine oil. Suzuki recommends the use of SUZUKI PERFORMANCE 4 MOTOR OIL or equivalent engine oil.

Use oil with an API (American Petroleum Institute) classification of SF/SG or SH/SJ, or with a JASO classification of MA.


SAE	API	JASO
10W-40	SF or SG	—
10W-40	SH or SJ	MA

If SAE 10W-40 engine oil is not available, select an alternative according to the chart.



I310G1010005-01

Suzuki does not recommend the use of "ENERGY CONSERVING" oils.



IB08J1010009-01

[A]: Not recommend	[B]: Recommend
--------------------	----------------


Engine Oil (For Other Countries)

Oil quality is a major contributor to your engine's performance and life. Always select good quality engine oil.

Suzuki recommends the use of engine oil as follows.


SAE	API	JASO
10W-40	SF or SG	—
10W-40	SH or SJ	MA

If SAE 10W-40 engine oil is not available, select an alternative according to the chart.



I310G1010005-01

Suzuki does not recommend the use of "ENERGY CONSERVING" oils.



IB08J1010009-01

[A]: Not recommend	[B]: Recommend
--------------------	----------------

Brake Fluid

Specification and classification: DOT 4

▲ WARNING

Since the brake system of this motorcycle is filled with a glycol-based brake fluid by the manufacturer, do not use or mix different types of fluid such as silicone-based and petroleum-based fluid for refilling the system, otherwise serious damage will result.

Do not use any brake fluid taken from old or used or unsealed containers.

Never reuse brake fluid left over from a previous servicing, which has been stored for a long period.

Front Fork Oil

Use SUZUKI FORK OIL SS-8 or equivalent.

Engine Coolant Recommendation

BENC11J10101007

Recommended Engine Coolant

The factory filled engine coolant of this vehicle is SUZUKI super long life coolant (Coolant color: Blue). It is recommended to use this SUZUKI super long life coolant when replenishing or changing the engine coolant. SUZUKI super long life coolant (Coolant color: Blue) as supply part is already diluted to the 50 percentage with deionized water. Use it as it is without diluting. SUZUKI recommends to use following coolants in that order.

- 1) SUZUKI super long life coolant (Coolant color: Blue)
- 2) SUZUKI long life coolant (Coolant color: Green) or equivalent

Engine Coolant

- Use an anti-freeze/engine coolant compatible with an aluminum radiator.
- There are two types of engine coolant: one used after diluting with distilled water and the other used as it is (without diluting). SUZUKI super long life coolant is the latter type and SUZUKI long life coolant is the former type.

Anti-freeze / Engine coolant

The engine coolant performs as a corrosion and rust inhibitor as well as anti-freeze. Therefore, the engine coolant should be used at all times even though the atmospheric temperature in your area does not go down to freezing point.

Water for mixing (for coolant requiring water dilution)

Use distilled water only. Water other than distilled water can corrode and clog the aluminum radiator.

Liquid amount of water / Engine coolant mixture (for coolant requiring water dilution)

Solution capacity (total)

1 950 ml (2.0/1.7 US/Imp qt)

For engine coolant mixture information, refer to "Engine Coolant Description" in Section 1F (Page 1F-1).

▲ CAUTION

Mixing of anti-freeze/engine coolant should be limited to 60%. Mixing beyond it would reduce its efficiency. If the anti-freeze/engine coolant mixing ratio is below 50%, rust inhabiting performance is greatly reduced. Be sure to mix it above 50% even though the atmospheric temperature does not go down to the freezing point.

BREAK-IN Procedures

BENC11J10101008

During manufacture only the best possible materials are used and all machined parts are finished to a very high standard but it is still necessary to allow the moving parts to "BREAK-IN" before subjecting the engine to maximum stresses. The future performance and reliability of the engine depends on the care and restraint exercised during its early life. The general rules are as follows.

- 1) Keep to these break-in engine speed limits:

Speed limits

Initial 800 km (500 miles): Below 5 000 r/min

Up to 1 600 km (1 000 miles): Below 7 500 r/min


Over 1 600 km (1 000 miles): Below 10 000 r/min

- 2) Upon reaching an odometer reading of 1 600 km (1 000 miles) you can subject the motorcycle to full throttle operation. However, do not exceed 10 000 r/min at any time.

Cylinder Identification

BENC11J10101009

The two cylinders of this engine are identified as #1 and #2 cylinder, as counted from front to rear (as viewed by the rider on the seat).



IC11J1010005-01

Country and Area Codes

BENC11J10101010

The following codes stand for the applicable country(-ies) and area(-s).

Code	Country or Area	Effective Frame No.
DL650A L2 (E-03)	U.S.A (Except for California)	JS1VP56A C2100001 –
DL650A L2 (E-21)	E.U.	JS1C7111100100001 –
DL650A L2 (E-24)	Australia	JS1C7111200100001 –
DL650A L2 (E-28)	Canada	JS1VP56A C2100001 –
DL650A L2 (E-33)	California (U.S.A)	JS1VP56A C2100001 –
DL650AUE L2 (E-21)	E.U.	JS1C7211100100001 –


Wire Color Symbols

BENC11J10101011

Symbol	Wire Color	Symbol	Wire Color
B	Black	Br/B	Brown with Black tracer
Bl	Blue	Br/W	Brown with White tracer
Br	Brown	G/B	Green with Black tracer
Dbr	Dark brown	G/R	Green with Red tracer
Dg	Dark green	G/Y	Green with Yellow tracer
G	Green	Gr/B	Gray with Black tracer
Gr	Gray	Gr/R	Gray with Red tracer
Lbl	Light blue	Gr/W	Gray with White tracer
Lg	Light green	O/B	Orange with Black tracer
O	Orange	O/Bl	Orange with Blue tracer
P	Pink	O/G	Orange with Green tracer
R	Red	O/R	Orange with Red tracer
W	White	O/W	Orange with White tracer
Y	Yellow	O/Y	Orange with Yellow tracer
B/Bl	Black with Blue tracer	P/W	Pink with White tracer
B/Br	Black with Brown tracer	R/B	Red with Black tracer
B/G	Black with Green tracer	R/W	Red with White tracer
B/Lg	Black with Light green tracer	W/B	White with Black tracer
B/O	Black with Orange tracer	W/Bl	White with Blue tracer
B/R	Black with Red tracer	W/G	White with Green tracer
B/W	Black with White tracer	W/R	White with Red tracer
B/Y	Black with Yellow tracer	Y/B	Yellow with Black tracer
Bl/B	Blue with Black tracer	Y/Bl	Yellow with Blue tracer
Bl/G	Blue with Green tracer	Y/G	Yellow with Green tracer
Bl/W	Blue with White tracer	Y/R	Yellow with Red tracer
Bl/Y	Blue with Yellow tracer	Y/W	Yellow with White tracer

Warning, Caution and Information Labels Location

BENC11J10101012



IC11J1010008-01




1. Noise label [ADR] (English) (For E-24)	22. Steering warning label (English) (For E-03, 33)
2. Noise label [EPA] (English) (For E-03, 33)	23. Steering warning label (English/French/German) (For E-21, 24, 28)
3. Information label [EPA] (English) (For E-03)	24. Steering warning label (Russian) (For DL650A E-21)
4. Information label [EPA] (English/French) (For E-28)	25. Screen label (English) (For E-03, 21, 24, 28, 33)
5. Information label [EPA & CARB] (English) (For E-33)	26. Screen label (French) (For DL650A E-21, 28)
6. ICES Canada label (English/French) (For E-28)	27. Screen label (German) (For DL650A E-21)
7. Vacuum hose routing label (English) (For E-33)	28. Screen label (Italian) (For DL650A E-21)
8. Manual notice label (English) (For E-03, 33)	29. Screen label (Swedish) (For DL650A E-21)
9. Tire information label (English) (For E-03, 33)	30. Screen label (Spanish) (For DL650A E-21)
10. Tire information label (English/French/German) (For E-21, 24, 28)	31. Screen label (Russian) (For DL650A E-21)
11. Tire information label (Russian) (For DL650A E-21)	32. I.D. label (For E-21)
12. General warning label (English) (For E-03, 21, 24, 33)	33. I.D. plate (For E-24)
13. General warning label (French) (For DL650A E-21)	34. Safety plate (English) (For E-03, 33)
14. General warning label (German) (For DL650A E-21)	35. Safety plate (English) (with Canada mark) (For E-28)
15. General warning label (Italian) (For DL650A E-21)	36. Brake fluid information mark (For DL650A E-21)
16. General warning label (Swedish) (For DL650A E-21)	37. Brake approval mark (For DL650A E-21)
17. General warning label (Spanish) (For DL650A E-21)	38. Radiator cap label Russian (For E-21)
18. General warning label (Russian) (For DL650A E-21)	[A]: Rear front fender
19. General warning label (English/French) (For E-28)	[B]: Meter panel
20. Rear carrier warning label (English) (For E-03, 21, 24, 33)	[C]: Frame (RH)
21. Rear carrier warning label (English/French) (For E-28)	[D]: Radiator cap

Component Location

Country and Area Codes


Electrical Components Location

BENC11J10103001



IC11J1010006-02

1. Fuel pump/Fuel level gauge	6. Regulator/rectifier	11. ECT sensor
2. Fuel injector (#1)	7. Cooling fan	12. Ignition coil (#2)
3. Fuel injector (#2)	8. Rear wheel speed sensor	13. Starter motor
4. EVAP system purge control solenoid valve (E-33 only)	9. Front wheel speed sensor	14. Oil pressure switch
5. Immobilizer antenna (E21, E24 only)	10. HO2 sensor	



IC11J1010007-03

15. Ambient air temp sensor	22. Battery	29. ABS valve fuse	36. Horn
16. IAP sensor (#1)	23. ECM	30. ABS motor fuse	37. Generator
17. IAP sensor (#2)	24. Cooling fan relay	31. Fuel pump relay	38. CKP sensor
18. IAT sensor	25. Fuse box	32. Mode select coupler	39. Speed sensor
19. TP sensor	26. Turn signal/Side-stand relay	33. Ignition coil (#1)	40. GP switch
20. STP sensor	27. Starter relay/main fuse	34. Mode select coupler	41. Side-stand switch
21. STV/ISC actuator	28. TO sensor	35. ABS control unit / HU	

Specifications

Specifications

BENC11J10107001

NOTE

These specifications are subject to change without notice.

Dimensions and curb mass

Item	Specification	Remark
Overall length	2 290 mm (90.2 in)	
Overall width	835 mm (32.9 in)	
Overall height	1 405 mm (55.3 in)	
Wheelbase	1 560 mm (61.4 in)	
Ground clearance	175 mm (6.9 in)	
Seat height	835 mm (32.9 in)	
Curb mass	214 kg (472 lbs)	

Engine

Item	Specification	Remark
Type	4-stroke, liquid-cooled, DOHC, 90° V-twin	
Number of cylinders	2	
Bore	81.0 mm (3.189 in)	
Stroke	62.6 mm (2.465 in)	
Displacement	645 cm ³ (39.4 cu. in)	
Compression ratio	11.2 : 1	
Fuel system	Fuel injection	
Air cleaner	Non-woven fabric element	
Starter system	Electric	
Lubrication system	Wet sump	
Idle speed	1 300 ± 100 r/min	

Drive train

Item	Specification	Remark
Clutch	Wet multi-plate type	
Transmission	6-speed constant mesh	
Gearshift pattern	1-down, 5-up	
Primary reduction ratio	2.088 (71/34)	
Gear ratios	Low	2.461 (32/13)
	2nd	1.777 (32/18)
	3rd	1.380 (29/21)
	4th	1.125 (27/24)
	5th	0.961 (25/26)
	Top	0.851 (23/27)
Final reduction ratio	3.133 (47/15)	
Drive chain	RK 525SMOZ8, 118 links	

Chassis

Item	Specification	Remark
Front suspension	Telescopic, coil spring, oil damped	
Rear suspension	Link type, coil spring, oil damped	
Front suspension stroke	150 mm (5.9 in)	
Rear wheel travel	159 mm (6.3 in)	
Caster	26°	
Trail	110 mm (4.3 in)	
Steering angle	40° (right & left)	
Turning radius	2.7 m (8.9 ft)	
Front brake	Disc brake, twin	
Rear brake	Disc brake	
Front tire size	110/80R19M/C 59H, tubeless	
Rear tire size	150/70R17M/C 69H, tubeless	

Electrical

Item	Specification	Remark
Ignition type	Electronic ignition (Transistorized)	
Ignition timing	8° B.T.D.C. at 1 300 r/min	
Spark plug	NGK CR8EIA-9 or DENSO IU24D	
Battery	12 V 36.0 kC (10 Ah)/10 HR	
Generator	Three-phase A.C. generator	
Main fuse	30 A	
Fuse	15/15/10/10/15/15 A	
Headlight	12 V 60/55 W (H4) x 2	
Position light	12 V 5 W x 2	
Brake light/Taillight	12 V 21/5 W	
Turn signal light	12 V 21 W	
License plate light	12 V 5 W	
Speedometer light	LED	
Tachometer light	LED	
Neutral indicator light	LED	
High beam indicator light	LED	
Turn signal indicator light	LED	
Oil pressure/Coolant temperature indicator light	LED	
FI indicator light	LED	
Freeze indicator light	LED	
ABS indicator light	LED	
Immobilizer indicator light	LED	E-21, 24










Capacities

Item	Specification	Remark
Fuel tank	20.0 L (5.3/4.4 US/Imp gal)	
Engine oil	Oil change	2 400 ml (2.5/2.1 US/Imp qt)
	With filter change	2 750 ml (2.9/2.4 US/Imp qt)
	Overhaul	3 000 ml (3.2/2.6 US/Imp qt)
Coolant	1 950 ml (2.0/1.7 US/Imp qt)	

Special Tools and Equipment

Special Tool

BENC11J10108002

				
09900-06107 Snap ring pliers (Open type)	09900-06108 Snap ring pliers (Close type)	09900-18710 Hexagon socket (12 mm)	09900-20101 Vernier calipers (150 mm)	09900-20102 Vernier calipers (200 mm)
				
09900-20202 Micrometer (25 - 50 mm)	09900-20204 Micrometer (75 - 100 mm)	09900-20205 Micrometer (0 - 25 mm)	09900-20530 Cylinder gauge set	09900-20602 Dial gauge
				
09900-20607 Dial gauge	09900-20701 Dial gauge chuck	09900-20804 Thickness gauge	09900-20805 Tire depth gauge	09900-20806 Thickness gauge
				
09900-21304 V blocks	09900-22301 Plastigage (0.025 - 0.076 mm)	09900-22302 Plastigage (0.051 - 0.152 mm)	09900-22403 Small bore gauge (18 - 35 mm)	09900-25008 Multi circuit tester set
				
09900-25009 Needle-point probe set	09900-28630 TP Sensor test lead	09904-41010 SUZUKI Diagnostic system set	09910-60611 Universal clamp wrench	09913-50121 Oil seal remover

 <p>09913-60221 Journal bearing installer & holder</p>	 <p>09913-70210 Bearing installing set (10 - 75 Φ)</p>	 <p>09915-40620 Oil filter wrench</p>	 <p>09915-63311 Compression gauge attachment</p>	 <p>09915-64512 Compression gauge</p>
 <p>09915-70610 Oil pressure gauge attachment</p>	 <p>09915-74521 Adapter hose</p>	 <p>09915-77331 Oil pressure gauge (1000 kPa)</p>	 <p>09916-10911 Valve lapper set</p>	 <p>09916-14510 Valve lifter</p>
 <p>09916-14522 Valve lifter attachment</p>	 <p>09916-33210 Valve guide reamer (4.5 mm)</p>	 <p>09916-34542 Reamer handle</p>	 <p>09916-34580 Valve guide reamer (10.8 mm)</p>	 <p>09916-43211 Valve guide installer & remover</p>
 <p>09916-53330 Valve guide installer attachment</p>	 <p>09916-84511 Tweezer</p>	 <p>09917-47011 Vacuum pump gauge set</p>	 <p>09919-28620 Sleeve protector</p>	 <p>09920-13120 Crankshaft remover</p>
 <p>09920-53740 Clutch sleeve hub holder</p>	 <p>09921-20240 Bearing remover set</p>	 <p>09922-22711 Drive chain cutting and joint tool set</p>	 <p>09925-18011 Bearing installer</p>	 <p>09930-10121 Spark plug wrench set</p>

0A-15 General Information:

 <p>09930-11920 Torx® bit (JT40H)</p>	 <p>09930-11940 Torx® bit holder (3/8 sq.)</p>	 <p>09930-11950 Torx® wrench (T25H)</p>	 <p>09930-30450 Rotor remover bolt</p>	 <p>09930-40113 Flywheel rotor holder</p>
 <p>09930-44530 Rotor holder</p>	 <p>09930-82710 Mode select switch</p>	 <p>09930-82720 Mode selection switch</p>	 <p>09940-14911 Steering stem nut socket wrench</p>	 <p>09940-14940 Swingarm pivot thrust adjuster wrench</p>
 <p>09940-14960 Steering stem nut socket wrench</p>	 <p>09940-14990 Engine mounting adjust wrench</p>	 <p>09940-34520 T type handle</p>	 <p>09940-34531 Front fork assembling attachment (A)</p>	 <p>09940-40211 Fuel pressure gauge adapter</p>
 <p>09940-40220 Fuel pressure gauge attachment</p>	 <p>09940-52861 Front fork oil seal installer set</p>	 <p>09940-92720 Spring scale</p>	 <p>09941-34513 Bearing installer</p>	 <p>09943-74111 Front fork oil level gauge</p>
 <p>09944-28320 Hexagon socket (19 mm)</p>	 <p>99565-01010-024 CD-ROM Ver.24</p>			

Torx® is the registered trademark of Camcar Division of Textron inc. U.S.A.

Maintenance and Lubrication

Precautions

Precautions for Maintenance

BENC11J1020001

The "Periodic Maintenance Schedule Chart" lists the recommended intervals for all the required periodic service work necessary to keep the motorcycle operating at peak performance and economy. Maintenance intervals are expressed in terms of kilometers, miles and months for your convenience.

IMPORTANT: The periodic maintenance intervals and service requirements have been established in accordance with EPA regulations. Following these instructions will ensure that the motorcycle will not exceed emission standards and it will also ensure the reliability and performance of the motorcycle.

NOTE

More frequent servicing may be required on motorcycles that are used under severe conditions.

General Description

Recommended Fluids and Lubricants

BENC11J10201001

Refer to "Fuel and Oil Recommendation" in Section 0A (Page 0A-5) and "Engine Coolant Recommendation" in Section 0A (Page 0A-6).

Scheduled Maintenance

Periodic Maintenance Schedule Chart

BENC11J10205001

NOTE

I = Inspect and clean, adjust, replace or lubricate as necessary.

R = Replace.

T = Tighten.

Item	Interval					
	km	1 000	6 000	12 000	18 000	24 000
	miles	600	4 000	7 500	11 000	14 500
	months	2	12	24	36	48
Air cleaner element		—	I	I	R	I
Exhaust pipe bolts and muffler bolts		T	T	T	T	T
Valve clearance		—	—	—	—	I
Spark plugs		—	I	R	I	R
Fuel line		—	I	I	I	I
Evaporative emission control system (E-33 only)		—	—	I	—	I
Engine oil		R	R	R	R	R
Engine oil filter		R	—	—	R	—
Throttle cable play		I	I	I	I	I
Throttle valve synchronization		I (E-33 only)	—	I	—	I
Engine coolant	SUZUKI SUPER LONG LIFE COOLANT (BLUE)	—	—	—	—	R
	SUZUKI LONG LIFE COOLANT (GREEN) or an engine coolant other than SUZUKI SUPER LONG LIFE COOLANT (BLUE)	—	—	R	—	R
Radiator hose		—	I	I	I	I
Clutch cable play		—	I	I	I	I
Drive chain		I	I	I	I	I
		Clean and lubricate every 1 000 km (600 miles).				

0B-2 Maintenance and Lubrication:

Item	Interval					
	km	1 000	6 000	12 000	18 000	24 000
	miles	600	4 000	7 500	11 000	14 500
	months	2	12	24	36	48
Brakes						
Brake fluid	—					
Brake hose	Replace every 2 years.					
	—					
Tires	Replace every 4 years.					
	—					
Steering		—		—		
Front forks	—	—		—		
Rear suspension	—	—		—		
Chassis bolts and nuts	T	T	T	T	T	


Lubrication Points

BENC11J10205002

Proper lubrication is important for smooth operation and long life of each working part of the motorcycle. Major lubrication points are indicated as follows.

NOTE

- Before lubricating each part, clean off any rusty spots and wipe off any grease, oil, dirt or grime.
- Lubricate exposed parts which are subject to rust, with a rust preventative spray whenever the motorcycle has been operated under wet or rainy conditions.



IC11J1020001-03

1. Clutch lever holder	5. Drive chain	: Apply grease.
2. Gearshift lever pivot	6. Brake lever holder	: Apply silicone grease.
3. Side-stand pivot and spring hook	7. Brake pedal pivot and footrest pivot	
4. Footrest pivot	: Apply oil.	

Repair Instructions

Air Cleaner Element Replacement

BENC11J10206001

Replace air cleaner element

Every 18 000 km (11 000 miles, 36 months)

Refer to "Air Cleaner Element Removal and Installation" in Section 1D (Page 1D-6).

Air Cleaner Element Inspection and Cleaning

BENC11J10206002

Inspect air cleaner element

Every 6 000 km (4 000 miles, 12 months)

Inspection

- 1) Remove the air cleaner element. Refer to "Air Cleaner Element Removal and Installation" in Section 1D (Page 1D-6).
- 2) Inspect the air cleaner element for clogging. If it is clogged with dirt, replace it with a new one.

NOTICE

Do not blow the air cleaner element with compressed air.

NOTE

If driving under dusty conditions, replace the air cleaner element more frequently. Make sure that the air cleaner is in good condition at all times. The life of the engine depends largely on this component.



IC11J1020002-01


- 3) After finishing the air cleaner element inspection, reinstall the removed parts.

Cleaning

- 1) Remove the air cleaner element. Refer to "Air Cleaner Element Removal and Installation" in Section 1D (Page 1D-6).
- 2) Carefully use compressed air to clean the air cleaner element.

▲ CAUTION

Always apply compressed air to the inside of the air cleaner element. If compressed air is applied to the outside, dirt will be forced into the pores of the air cleaner element, restricting air flow through the air cleaner element.



IC11J1020003-01

- 3) After cleaning the air cleaner element, reinstall the removed parts.
- 4) Drain water from the air cleaner by removing the drain plug (1).



IC11J1020004-01

- 5) Reinstall the drain plug.

Exhaust Pipe Bolts and Muffler Bolts Inspection

BENC11J10206003

Tighten exhaust pipe bolts, muffler bolts and nut
Initially at 1 000 km (600 miles, 2 months) and every 6 000 km (4 000 miles, 12 months) thereafter

Check the exhaust pipe bolts, muffler bolts and nut to the specified torque.


Tightening torque

Exhaust pipe bolt (a): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)

Muffler mounting bolt (b): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)

Exhaust pipe connecting bolt (c): 18 N·m (1.8 kgf-m, 13.0 lbf-ft)

Muffler mounting nut (d): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



IC11J1020005-04

Valve Clearance Inspection and Adjustment

BENC11J10206004

Inspect valve clearance


Every 24 000 km (14 500 miles, 48 months) thereafter

Inspection

Valve clearance adjustment must be checked and adjusted, a) at the time of periodic inspection, b) when the valve mechanism is serviced, and c) when the camshafts are removed for servicing.


- 1) Remove the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 2) Remove the radiator reservoir tank. Refer to "Radiator Reservoir Tank Removal and Installation" in Section 1F (Page 1F-9).
- 3) Remove the spark plug caps (1). Refer to "Spark Plug Cap and Spark Plug Removal and Installation" in Section 1H (Page 1H-6).
- 4) Remove the cylinder head covers (2) by removing the bolts (3).

Front



IC11J1020006-01

Rear



IC11J1020007-01

NOTE

The valve clearance specification is different for both intake and exhaust valves.


Valve clearance (When cold)

IN.: 0.10 – 0.20 mm (0.004 – 0.008 in)

EX.: 0.20 – 0.30 mm (0.008 – 0.012 in)


NOTE

- The valve clearance should be taken when each cylinder is at Top Dead Center (TDC) of compression stroke.
- The cams (IN. & EX.) on the front cylinder at position "A" show the front cylinder at TDC of compression stroke.
- The cams (IN. & EX.) on the rear cylinder at position "B" show the rear cylinder at TDC of compression stroke.
- The clearance specification is for COLD state.
- To turn the crankshaft for clearance checking, be sure to use a wrench, and rotate in the normal running direction. All spark plugs should be removed.




IC11J1020067-01

5) Remove the generator cover plug (4) and timing inspection plug (5).




IC11J1020008-01

6) Turn the crankshaft to set the #1 (Front) cylinder at TDC of compression stroke. (Align the "I F" line on the generator rotor to the center of timing inspection hole and also bring the camshafts to the position "A" as shown in the figure.)



IC11J1020009-01




IC11J1020023-01

7) To inspect the #1 (Front) cylinder valve clearance, use a thickness gauge between the tappet and the cam. If the clearance is out of specification, adjust it into the specified range.


Special tool

 (A): 09900-20804 (Thickness gauge)




IC11J1020010-01

- Turn the crankshaft 270 degrees (3/4 turns) to set the #2 (Rear) cylinder at TDC of compression stroke. (Align the "R" line on the generator rotor to the center of timing inspection hole and also bring the camshafts to the position "B" as shown in the figure.)




IC11J1020011-01



18229H1020022-01

- Inspect the #2 (Rear) cylinder valve clearance as the same manner of #1 (Front) cylinder and adjust the clearance if necessary.

Special tool

 (A): 09900-20804 (Thickness gauge)




IC11J1020012-01

- After finishing the valve clearance inspection, reinstall the removed parts. Refer to "Engine Top Side Reassembly" in Section 1D (Page 1D-32), "Spark Plug Cap and Spark Plug Removal and Installation" in Section 1H (Page 1H-6), "Radiator Reservoir Tank Removal and Installation" in Section 1F (Page 1F-9) and "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).

Adjustment


The clearance is adjusted by replacing the existing tappet shim by a thicker or thinner shim.

- Remove the intake or exhaust camshafts. Refer to "Engine Top Side Disassembly" in Section 1D (Page 1D-27).
- Remove the tappet (1) and shim (2) by fingers or magnetic hand.



I944H1020016-0

- Check the figures printed on the shim. These figures indicate the thickness of the shim, as illustrated.



I944H1020017-0

- Select a replacement shim that will provide a clearance within the specified range. For the purpose of this adjustment, a total of 21 sizes of tappet shim are available ranging from 1.20 to 2.20 mm in steps of 0.05 mm.


CAUTION

Both the right and left valve clearances should be as closely as possible.

- Fit the selected shim (2) to the valve stem end, with numbers toward tappet. Be sure to check shim size with micrometer to ensure its size.

NOTE

- Be sure to apply engine oil to tappet shim top and bottom faces.
- When seating the tappet shim, be sure the figure printed surface faces the tappet.



I944H1020018-0

TAPPET SHIM SELECTION TABLE [INTAKE]
TAPPET SHIM NO. (12892-05C00-XXX)

TAPPET SHIM SET (12800-05820)

MEASURED TAPPET CLEARANCE (mm)	SUFFIX NO.	SPECIFIED CLEARANCE/ADJUSTMENT REQUIRED																				
		120	125	130	135	140	145	150	155	160	165	170	175	180	185	190	195	200	205	210	215	220
0.00-0.04																						
0.05-0.09																						
0.10-0.20																						
0.21-0.25																						
0.26-0.30																						
0.31-0.35																						
0.36-0.40																						
0.41-0.45																						
0.46-0.50																						
0.51-0.55																						
0.56-0.60																						
0.61-0.65																						
0.66-0.70																						
0.71-0.75																						
0.76-0.80																						
0.81-0.85																						
0.86-0.90																						
0.91-0.95																						
0.96-1.00																						
1.01-1.05																						
1.06-1.10																						
1.11-1.15																						

(INTAKE SIDE)

HOW TO USE THIS CHART:

- I. Measure tappet clearance. "ENGINE IS COLD"
- II. Measure present shim size.
- III. Match clearance in vertical column with present shim size in horizontal column.

EXAMPLE

Tappet clearance is 0.23 mm
Present shim size 1.65 mm
Shim size to be used 1.75 mm

(EXHAUST SIDE)

TAPPET SHIM SELECTION TABLE [EXHAUST]
TAPPET SHIM NO. (12892-05C00-XXX)

TAPPET SHIM SET (12800-05820)

MEASURED TAPPET CLEARANCE (mm)	SUFFIX NO.	SPECIFIED CLEARANCE/NO ADJUSTMENT REQUIRED																				
		120	125	130	135	140	145	150	155	160	165	170	175	180	185	190	195	200	205	210	215	220
0.05-0.09	PRESENT SHIM SIZE (mm)	1.20	1.25	1.30	1.35	1.40	1.45	1.50	1.55	1.60	1.65	1.70	1.75	1.80	1.85	1.90	1.95	2.00	2.05	2.10	2.15	2.20
0.10-0.14		1.20	1.25	1.30	1.35	1.40	1.45	1.50	1.55	1.60	1.65	1.70	1.75	1.80	1.85	1.90	1.95	2.00	2.05	2.10	2.15	2.20
0.15-0.19		1.20	1.25	1.30	1.35	1.40	1.45	1.50	1.55	1.60	1.65	1.70	1.75	1.80	1.85	1.90	1.95	2.00	2.05	2.10	2.15	2.20
0.20-0.30		1.20	1.25	1.30	1.35	1.40	1.45	1.50	1.55	1.60	1.65	1.70	1.75	1.80	1.85	1.90	1.95	2.00	2.05	2.10	2.15	2.20
0.31-0.35		1.30	1.35	1.40	1.45	1.50	1.55	1.60	1.65	1.70	1.75	1.80	1.85	1.90	1.95	2.00	2.05	2.10	2.15	2.20	2.20	2.20
0.36-0.40		1.35	1.40	1.45	1.50	1.55	1.60	1.65	1.70	1.75	1.80	1.85	1.90	1.95	2.00	2.05	2.10	2.15	2.20	2.20	2.20	2.20
0.41-0.45		1.40	1.45	1.50	1.55	1.60	1.65	1.70	1.75	1.80	1.85	1.90	1.95	2.00	2.05	2.10	2.15	2.20	2.20	2.20	2.20	2.20
0.46-0.50		1.45	1.50	1.55	1.60	1.65	1.70	1.75	1.80	1.85	1.90	1.95	2.00	2.05	2.10	2.15	2.20	2.20	2.20	2.20	2.20	2.20
0.51-0.55		1.50	1.55	1.60	1.65	1.70	1.75	1.80	1.85	1.90	1.95	2.00	2.05	2.10	2.15	2.20	2.20	2.20	2.20	2.20	2.20	2.20
0.56-0.60		1.55	1.60	1.65	1.70	1.75	1.80	1.85	1.90	1.95	2.00	2.05	2.10	2.15	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20
0.61-0.65		1.60	1.65	1.70	1.75	1.80	1.85	1.90	1.95	2.00	2.05	2.10	2.15	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20
0.66-0.70		1.65	1.70	1.75	1.80	1.85	1.90	1.95	2.00	2.05	2.10	2.15	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20
0.71-0.75		1.70	1.75	1.80	1.85	1.90	1.95	2.00	2.05	2.10	2.15	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20
0.76-0.80		1.75	1.80	1.85	1.90	1.95	2.00	2.05	2.10	2.15	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20
0.81-0.85		1.80	1.85	1.90	1.95	2.00	2.05	2.10	2.15	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20
0.86-0.90		1.85	1.90	1.95	2.00	2.05	2.10	2.15	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20
0.91-0.95		1.90	1.95	2.00	2.05	2.10	2.15	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20
0.96-1.00		1.95	2.00	2.05	2.10	2.15	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20
1.01-1.05		2.00	2.05	2.10	2.15	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20
1.06-1.10		2.05	2.10	2.15	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20
1.11-1.15		2.10	2.15	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20
1.16-1.20		2.15	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20
1.21-1.25		2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20

HOW TO USE THIS CHART:

- I. Measure tappet clearance. "ENGINE IS COLD"
- II. Measure present shim size.
- III. Match clearance in vertical column with present shim size in horizontal column.

EXAMPLE

Tappet clearance is 0.33 mm
Present shim size 1.65 mm
Shim size to be used 1.75 mm

- 6) Install the intake or exhaust camshafts and cam chain tension adjuster. Refer to "Engine Top Side Reassembly" in Section 1D (Page 1D-32).
- 7) Rotate the engine so that the tappet is depressed fully. This will squeeze out oil trapped between the shim and the tappet that could cause an incorrect measurement, then check the clearance again to confirm that it is within the specified range.
- 8) After finishing the valve clearance adjustment, reinstall the removed parts. Refer to "Engine Top Side Reassembly" in Section 1D (Page 1D-32).

Spark Plug Replacement

BENC11J10206005

Replace spark plug

Every 12 000 km (7 500 miles, 24 months)

Refer to "Spark Plug Cap and Spark Plug Removal and Installation" in Section 1H (Page 1H-6).

Spark Plug Inspection and Cleaning

BENC11J10206006

Inspect spark plug

Every 6 000 km (4 000 miles, 12 months)

Heat Range

- 1) Remove the spark plugs. Refer to "Spark Plug Cap and Spark Plug Removal and Installation" in Section 1H (Page 1H-6).
- 2) Check spark plug heat range by observing electrode color. If the electrode of the spark plug is wet appearing or dark color, replace the spark plug with hotter type one. If it is white or glazed appearing, replace the spark plug with colder type one.

Heat range

	Standard	Cold type	Hot type
NGK	CR8EIA-9	CR9EIA-9	CR7EIA-9
DENSO	IU24D	IU27D	—

- 3) After finishing the spark plug inspection, reinstall the removed parts.

Spark Plug Gap

- 1) Remove the spark plugs. Refer to "Spark Plug Cap and Spark Plug Removal and Installation" in Section 1H (Page 1H-6).
- 2) Measure the spark plug gap using a wire gauge. If it is not within the specification, replace the spark plug.

NOTICE

- To prevent the damage of iridium center electrode, use a wire gauge to check the gap.
- Never adjust the spark plug gap.

Spark plug gap

0.8 – 0.9 mm (0.031 – 0.035 in)



I944H1020064-01

- 3) After finishing the spark plug inspection, reinstall the removed parts.

Electrodes Condition

- 1) Remove the spark plugs. Refer to "Spark Plug Cap and Spark Plug Removal and Installation" in Section 1H (Page 1H-6).
- 2) Check to see the worn or burnt condition of the electrodes.
If it is extremely worn or burnt, replace the plug. And also replace the plug if it has a broken insulator, or damaged thread.

NOTICE

Confirm the thread size and reach when replacing the plug. If the reach is too short, carbon will be deposited on the screw portion of the plug hole and engine damage may result.

- 3) After finishing the spark plug inspection, reinstall the removed parts.

Fuel Line Inspection

BENC11J10206007

Inspect fuel line

Every 6 000 km (4 000 miles, 12 months)

Inspect the fuel line in the following procedures:

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 2) Inspect the fuel feed hoses for damage and fuel leakage. If any defects are found, the fuel feed hoses must be replaced.



IC11J1020013-01

- 3) After finishing the Fuel feed hoses Inspection, reinstall the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).

Evaporative Emission Control System Inspection (E-33 Only)

BENC11J10206008

Inspect evaporative emission control system

Every 12 000 km (7 500 miles, 24 months)

Inspect the evaporative emission control system periodically (E-33 only).

Engine Oil and Filter Replacement

BENC11J10206009

Replace engine oil

Initially at 1 000 km (600 miles, 2 months) and every 6 000 km (4 000 miles, 12 months) thereafter


Replace oil filter

Initially at 1 000 km (600 miles, 2 months) and every 18 000 km (11 000 miles, 36 months) thereafter

Oil should be changed while the engine is warm. Oil filter replacement at the above intervals, should be done together with the engine oil change.

Engine Oil Replacement

- 1) Keep the motorcycle upright.
- 2) Place an oil pan below the engine, and drain engine oil by removing the oil drain plug (1) and filler cap (2).



IC11J1020014-01




IC11J1020015-01

- 3) Install the new gasket washer and tighten the oil drain plug (1) to the specified torque.

Tightening torque


Oil drain plug (a): 21 N·m (2.1 kgf-m, 15.0 lbf-ft)



IC11J1020016-01

- 4) Pour new oil through the oil filler. When performing an oil change (without oil filter replacement), the engine will hold about 2.4 L (2.5/2.1 US/Imp qt) of oil. Use of SF/SG or SH/SJ in API with MA in JASO.
- 5) Start up the engine and allow it to run for few minutes at idling speed.

- 6) Turn off the engine and wait about three minutes, then check the oil level through the inspection window (3). If the oil level is below the "L" mark, add oil to the "F" mark. If the level is above the "F" mark, drain the oil until the level reaches the "F" mark.



IC11J1020017-01

Oil Level Inspection

- 1) Keep the motorcycle upright.
- 2) Start up the engine and allow it to run for few minutes at idle speed.
- 3) Turn off the engine and wait about three minutes, then check the oil level through the inspection window (1). If the level is below mark "L", add oil to "F" mark. If the level is above mark "F", drain oil to "F" mark.



IC11J1020018-01

Oil Filter Replacement


- 1) Drain engine oil as described in the engine oil replacement procedure.
- 2) Remove the oil filter (1) using the special tool.

Special tool

(A): 09915-40620 (Oil filter wrench)

Tightening torque

Engine coolant drain plug (a) 13 N·m (1.1 kgf-m, 9.5 lbf-ft)



IC11J1020019-01

- 3) Apply engine oil lightly to the O-ring of new oil filter, before installation.

NOTICE

ONLY USE A GENUINE SUZUKI MOTORCYCLE OIL FILTER.

Other manufacturer's oil filters may differ in thread specifications (thread diameter and pitch), filtering performance and durability which may lead to engine damage or oil leaks. Also, do not use a genuine Suzuki automobile oil filter on this motorcycle.

- 4) Install a new oil filter. Turn it by hand until you feel that the oil filter O-ring contacts the oil filter mounting surface. Then, tighten the oil filter two full turns (or to specified torque) using the special tool.

NOTE


To properly tighten the oil filter, use the special tool. Never tighten the oil filter by hand only.

Special tool

(A): 09915-40620 (Oil filter wrench)

Tightening torque

Oil filter (a): 20 N·m (2.0 kgf-m, 14.5 lbf-ft)



I718H1020026-01

- 5) Add new engine oil and check the oil level is as described in the engine oil replacement procedure.

Necessary amount of engine oil

Oil change: 2 400 ml (2.5/2.1 US/Imp qt)

Oil and filter change: 2 750 ml (2.9/2.4 US/Imp qt)

Engine overhaul: 3 000 ml (3.2/2.6 US/Imp qt)

Throttle Cable Play Inspection and Adjustment

BENC11J10206010

Inspect throttle cable play

Initially at 1 000 km (6 000 miles, 2 months) and every 6 000 km (4 000 miles, 12 months) thereafter

Inspect and adjust the throttle cable play "a" as follows.


Throttle cable play "a"

2.0 – 4.0 mm (0.08 – 0.16 in)



IC11J1020020-01

- 1) Remove the rubber boot (1).
- 2) Loosen the lock-nut (2) of the throttle pulling cable (3).
- 3) Turn the adjuster (4) in or out until the throttle cable play "a" (at the throttle grip) is between 2.0 – 4.0 mm (0.08 – 0.16 in).
- 4) Tighten the lock-nut (2) while holding the adjuster (4).



IC11J1020021-01

- 5) Install the rubber boot (1) firmly.

▲ WARNING

After the adjustment is completed, check that handlebar movement does not raise the engine idle speed and that the throttle grip returns smoothly and automatically.

Throttle Valve Synchronization

BENC11J1020601

Inspect throttle valve synchronization

Initially 1 000 km (600 miles, 2 months) (E-33 only) and every 12 000 km (7 500 miles, 24 months)

Inspect the throttle valve synchronization periodically. Refer to "Throttle Valve Synchronization" in Section 1D (Page 1D-15).

Cooling System Inspection

BENC11J1020601

Inspect cooling system

Every 6 000 km (4 000 miles, 12 months)

Replace engine coolant (Coolant color: Blue)


Every 24 000 km (14 500 miles, 48 months)

Replace engine coolant (Coolant color: Green)

Every 12 000 km (75 000 miles, 24 months)

Engine Coolant Level Inspection

- 1) Keep the motorcycle upright.
- 2) Remove the right frame side cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Check the engine coolant level by observing the "F" and "L" lines on the engine coolant reservoir tank. If the level is below the "L" line, add engine coolant to the "F" line from the engine coolant reservoir tank filler, after lift up the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).



IC11J1020022-01

- 4) After finishing the engine coolant level inspection, reinstall the removed parts.


Engine Coolant Change

Refer to "Engine Coolant Description" in Section 1F (Page 1F-1).

▲ WARNING


Do not open the radiator cap when the engine is hot, as you may be injured by escaping hot liquid or vapor. Engine coolant may be harmful if swallowed or if it comes in contact with skin or eyes. If engine coolant gets into the eyes or in contact with the skin, flush thoroughly with plenty of water. If swallowed, induce vomiting and call physician immediately.

- 1) Remove the body cowling assembly. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Remove the radiator cap (1).



IC11J1020023-01

- 3) Drain engine coolant by removing the drain bolt (2).




IC11J1020024-01

- 4) Flush the radiator with fresh water if necessary.
- 5) Install the new gasket and tighten the drain plug (2) to the specified torque.

Tightening torque


Engine coolant drain plug (a): 13 N·m (1.3 kgf-m, 9.5 lbf-ft)



IC11J1020025-01

- 6) Pour the specified engine coolant up to the radiator inlet.

Engine coolant capacity (excluding reservoir)
1 700 ml (1.8/1.5 US/lmp qt)



IC11J1020026-01

- 7) Bleed air from the cooling circuit.
- 8) After changing engine coolant, reinstall the removed parts.

Air Bleeding From the Cooling Circuit

- 1) Support the motorcycle upright.
- 2) Remove the radiator cap and pour engine coolant up to the radiator inlet. Refer to "Engine Coolant Change" (Page 0B-13).
- 3) Slowly swing the motorcycle, right and left, to bleed the air trapped in the cooling circuit.
- 4) Add engine coolant up to the radiator inlet.
- 5) Start up the engine and bleed air from the radiator inlet completely.
- 6) Add engine coolant up to the radiator inlet.
- 7) Repeat the 4), 5) procedures until no air bleeds from the thermostat connector inlet.
- 8) Close the radiator cap securely.

- After warming up and cooling down the engine several times, add the engine coolant up to the full level of the reservoir tank. Refer to "Engine Coolant Change" (Page 0B-13).

NOTICE

Make sure that the radiator is filled with engine coolant up to the reservoir tank full level.

- Reinstall the removed parts.

Radiator Hose Inspection

Check the radiator hoses for crack, damage or engine coolant leakage. Refer to "Water Hose Inspection" in Section 1F (Page 1F-7).

Clutch System Inspection

BENC11J10206013


Inspect clutch cable play

Every 6 000 km (4 000 miles, 12 months)

Inspect and adjust the clutch cable play "a" as follows.


Clutch cable play "a"

10 – 15 mm (0.4 – 0.6 in)



IC11J1020029-01

- Turn the adjuster (1) all the way into the clutch lever assembly.



IC11J1020064-01

- Remove the clutch cover. Refer to "Clutch Removal" in Section 5C (Page 5C-7).
- Loosen the lock-nut (2) and turn in the release screw (3) to feel resistance.

- From that position, turn out the release screw (3) 1 turn and tighten the lock-nut (2) to the specified torque by holding the release screw (3).

Clutch release screw

1 turn back

Tightening torque

Release screw lock-nut (a): 5 N·m (0.5 kgf-m, 3.7 lbf-ft)




IC11J1020030-01

- Install the clutch cover. Refer to "Clutch Removal" in Section 5C (Page 5C-7).
- Loosen the lock-nut (4).

NOTE


The adjustment of clutch cable play should be made on the adjuster on which the clutch cable cap is installed with 3 – 5 mm (0.12 – 0.20 in) of threads left on the clutch lever adjuster.

- Turn the adjuster (5) in or out until the clutch cable play "a" is between 10 – 15 mm (0.4 – 0.6 in).
- Tighten the lock-nut (4) while holding the adjuster (5).



IC11J1020031-01

- 9) Tighten the adjuster lock-nut (6).



IC11J1020065-01

- 10) Pour engine oil and coolant. Refer to "Engine Oil and Filter Replacement" (Page 0B-10) and "Cooling System Inspection" (Page 0B-12).

Drive Chain Inspection and Adjustment

BENC11J10206014

Inspect drive chain

Initially at 1 000 km (600 miles, 2 months) and every 6 000 km (4 000 miles, 12 months) thereafter

Drive Chain Visual Check

- 1) With the transmission in neutral, support the motorcycle a jack and turn the rear wheel slowly by hand.

▲ CAUTION

Make sure that the motorcycle is supported securely.

NOTICE


Do not support the motorcycle with the exhaust pipes.

- 2) Visually check the drive chain for the possible defects listed as follows. If any defects are found, the drive chain must be replaced. Refer to "Drive Chain Replacement" in Section 3A (Page 3A-7).

- Loose pins
- Damaged rollers
- Dry or rusted links
- Kinked or binding links
- Excessive wear
- Improper chain adjustment
- Missing O-ring seals

NOTE

When replacing the drive chain, replace the drive chain and sprockets as a set.




I649G1020032-02

1. O-ring seal

2. Grease

Drive Chain Length Inspection


- 1) Loosen the rear axle nut (1).
- 2) Give tension to the drive chain fully by turning both chain adjuster bolts (2).



IC11J1020032-01

- 3) Count out 21 pins (20 pitches) on the chain and measure the distance between the two points. If the distance exceeds the service limit, the chain must be replaced.

Drive chain 20-pitch length
Service limit: 319.4 mm (12.57 in)



I649G1020034-02

- 4) After finishing the drive chain length inspection, adjust the drive chain slack.

Drive Chain Slack Adjustment

- 1) Support the motorcycle with a jack.

CAUTION

Make sure that the motorcycle is supported securely.

NOTICE


Do not support the motorcycle with the exhaust pipes.

- 2) Loosen the rear axle nut (1).
- 3) Loosen or tighten both chain adjuster bolts (2) until there is 20 – 30 mm (0.8 – 1.2 in) "a" of slack at the middle of the chain between the engine and rear sprockets as shown in the figure.


NOTICE

The reference marks "A" on both sides of the swingarm and the edge of each chain adjuster must be aligned to ensure that the front and rear wheels are correctly aligned.

Drive chain slack "a"
Standard 20 – 30 mm (0.8 – 1.2 in)



IC11J1020033-01



I649G1020036-02

- 4) After adjusting the drive chain, tighten the rear axle nut to the specified torque.

Tightening torque

Rear axle nut: 100 N·m (10.0 kgf-m, 72.5 lbf-ft)

- 5) Recheck the drive chain slack after tightening the axle nut.

Drive Chain Cleaning and Lubricating

BENC11J10206015

Clean and lubricate drive chain**Every 1 000 km (600 miles)**

Clean and lubricate the drive chain in the following procedures:

- 1) Clean the drive chain with kerosine. If the drive chain tends to rust quickly, the intervals must be shortened.

NOTICE

Do not use trichloroethylene, gasoline or any similar solvent.

These fluids have too great a dissolving power for this chain and they can damage the O-rings. Use only kerosine to clean the drive chain.


- 2) After cleaning and drying the chain, oil it with a heavyweight motor oil.

NOTICE

Do not use any oil sold commercially as "drive chain oil". Such oil can damage the O-rings.

NOTE

The standard drive chain is a RK 525SMOZ8. SUZUKI recommends to use this standard drive chain as a replacement.



IC11J1020034-01

Brake System Inspection

BENC11J10206016

Inspect brake system

Initially at 1 000 km (600 miles, 2 months) and every 6 000 km (4 000 miles, 12 months) thereafter

Inspect brake hose and brake fluid

Every 6 000 km (4 000 miles, 12 months)

▲ WARNING

The brake system of this motorcycle is filled with a glycol-based brake fluid. Do not use or mix different types of fluid such as silicone-based and petroleum-based fluids. Do not use any brake fluid taken from old, used or unsealed containers. Never reuse brake fluid left over from the last servicing or stored for a long period of time.

NOTICE

Brake fluid, if it leaks, will interfere with safe running and immediately discolor painted surfaces. Check the brake hoses and hose joints for cracks and oil leakage before riding.


Brake Fluid Level Check

- 1) Keep the motorcycle upright and place the handlebars straight.
- 2) Check the brake fluid level by observing the lower limit lines on the front and rear brake fluid reservoirs. When the brake fluid level is below the lower limit line, replenish with brake fluid that meets the following specification.

BF: Brake fluid (DOT 4)



IC11J1020035-01




IC11J1020036-01

Brake Pads Check


The extent of brake pad wear can be checked by observing the grooved limit line "A" on the pad. When the wear exceeds the grooved limit line, replace the pads with new ones. Refer to "Front Brake Pad Replacement" in Section 4B (Page 4B-2) and "Rear Brake Pad Replacement" in Section 4C (Page 4C-2).

NOTICE

Replace the brake pad as a set, otherwise braking performance will be adversely affected.




IC11J1020037-01



IC11J1020038-01

Front and Rear Brake Hose Inspection

Inspect the brake hoses and hose joints for crack, damage or brake oil leakage. If any defects are found, replace the brake hose with a new one. Refer to "Front Brake Hose Removal and Installation" in Section 4A (Page 4A-16) and "Rear Brake Hose Removal and Installation" in Section 4A (Page 4A-17).



IC11J1020039-01



IC11J1020040-01



IC11J1020041-01




IC11J1020042-01

Brake Pedal Height Inspection and Adjustment

- 1) Inspect the brake pedal height "a" between the pedal top face and footrest.
Adjust the brake pedal height if necessary.

Brake pedal height "a"

Standard: 23 – 33 mm (0.9 – 1.3 in)




IC11J1020043-01

- 2) Loosen the lock-nut (1).
- 3) Turn the push rod (2) until the brake pedal becomes 23 – 33 mm (0.9 – 1.3 in) "a" below the top of the footrest.
- 4) Tighten the lock-nut (1) securely.

Tightening torque

Rear brake master cylinder rod lock-nut (a): 18 N·m (1.8 kgf·m, 13.0 lbf·ft)



IC11J1020044-01

- 5) After finishing the brake pedal height inspection and adjustment, check the rear brake light switch. Refer to "Rear Brake Light Switch Inspection and Adjustment" in Section 4A (Page 4A-5).

Brake Fluid Replacement

Replace brake fluid

Every 2 years

Refer to "Brake Fluid Replacement" in Section 4A (Page 4A-7).

Air Bleeding from Brake Fluid Circuit

Refer to "Air Bleeding from Brake Fluid Circuit" in Section 4A (Page 4A-5).

Rear Brake Light Switch Adjustment

Refer to "Rear Brake Light Switch Inspection and Adjustment" in Section 4A (Page 4A-5).

Brake Hose Replacement

Replace brake hose

Every 4 years

Refer to "Front Brake Hose Removal and Installation" in Section 4A (Page 4A-16) and "Rear Brake Hose Removal and Installation" in Section 4A (Page 4A-17).

Tire Inspection

BENC11J10206017


Inspect tire

Every 6 000 km (4 000 miles, 12 months)

Tire Tread Condition

Operating the motorcycle with excessively worn tires will decrease riding stability and consequently invite a dangerous situation. It is highly recommended to replace a tire when the remaining depth of tire tread reaches the following specification.


Special tool

 : 09900-20805 (Tire depth gauge)

Tire tread depth (Service limit)

Front: 1.6 mm (0.06 in)

Rear: 2.0 mm (0.08 in)



I310G1020068-02

Tire Pressure

If the tire pressure is too high or too low, steering will be adversely affected and tire wear increased. Therefore, maintain the correct tire pressure for good roadability or shorter tire life will result. Cold inflation tire pressure is as follows.

Cold inflation tire pressure

	Solo riding			Dual riding		
	kPa	kgf/cm ²	psi	kPa	kgf/cm ²	psi
Front	225	2.25	33	225	2.25	33
Rear	250	2.50	36	280	2.80	41



I310G1020069-02

NOTICE

The standard tire fitted on this motorcycle is 110/80 R19 M/C 59H for front and 150/70 R17 M/C 69H for rear. The use of tires other than those specified may cause instability. It is highly recommended to use the specified tires.

Tire type

BRIDGESTONE

- Front: TW101 RADIAL J
- Rear: TW152 RADIAL F

Steering System Inspection

BENC11J10206018

Inspect steering system

Initially at 1 000 km (600 miles, 2 months) and every 12 000 km (7 500 miles, 24 months) thereafter

Steering should be adjusted properly for smooth turning of handlebars and safe running. Overtighten steering prevents smooth turning of the handlebars and too loose steering will cause poor stability.

- 1) Check that there is no play in the front fork.
- 2) Support the motorcycle so that the front wheel is off the ground, with the wheel facing straight ahead, grasp the lower fork tubes near the axle and pull forward.

If play is found, readjust the steering. Refer to "Steering Tension Adjustment" in Section 6B (Page 6B-10).

▲ CAUTION

Make sure that the motorcycle is supported securely.

NOTICE

Do not support the motorcycle with the exhaust pipes.



IC11J1020045-01

Front Fork Inspection

BENC11J102060

Inspect front fork

Every 12 000 km (7 500 miles, 24 months)

Inspect the front forks for oil leakage, scoring or scratches on the outer surface of the inner tubes. Replace any defective parts, if necessary. Refer to "Front Fork Disassembly and Assembly" in Section 2B (Page 2B-4).



IC11J1020046-0

Rear Suspension Inspection

BENC11J1020602


Inspect rear suspension

Every 12 000 km (7 500 miles, 24 months)

Inspect the rear shock absorbers for oil leakage and check that there is no play in the swingarm. Replace any defective parts, if necessary. Refer to "Rear Shock Absorber Removal and Installation" in Section 2C (Page 2C-3), "Cushion Lever / Cushion Rod Removal and Installation" in Section 2C (Page 2C-6) and "Swingarm Removal and Installation" in Section 2C (Page 2C-8).



IC11J1020047-01



IC11J1020048-01


Chassis Bolt and Nut Inspection

BENC11J10206021

Tighten chassis bolt and nut


Initially at 1 000 km (600 miles, 2 months) and every 6 000 km (4 000 miles, 12 months) thereafter

Check that all chassis bolts and nuts are tightened to their specified torque.




IC11J1020049-01

- | | | |
|---|-----|--|
| 1 | (a) | Steering stem head nut 90 N·m (9.0 kgf·m, 65.0 lbf·ft) |
| 2 | (b) | Handlebar holder bolt 23 N·m (2.3 kgf·m, 16.5 lbf·ft) |




IC11J1020050-01

- | | | |
|---|-----|--|
| 3 | (b) | Front brake hose union bolt 23 N·m (2.3 kgf·m, 16.5 lbf·ft) |
| 4 | (c) | Front brake master cylinder mounting bolt 10 N·m (1.0 kgf·m, 7.0 lbf·ft) |



IC11J1020051-02

- | | | |
|---|-----|---|
| 3 | (b) | Front brake hose union bolt 23 N·m (2.3 kgf·m, 16.5 lbf·ft) |
| 5 | (d) | Front brake caliper mounting bolt 39 N·m (3.9 kgf·m, 28.0 lbf·ft) |
| 6 | (e) | Front axle 65 N·m (6.5 kgf·m, 47.0 lbf·ft) |
| 7 | (b) | Front axle pinch bolt 23 N·m (2.3 kgf·m, 16.5 lbf·ft) |
| 8 | (b) | Front brake disc bolt 23 N·m (2.3 kgf·m, 16.5 lbf·ft) |
| 9 | (f) | Front brake air bleeder valve 7.5 N·m (0.75 kgf·m, 5.5 lbf·ft) |




IC11J1020052-02

- | | | |
|----|-----|--|
| 10 | (g) | Brake pipe flare nut 16 N·m (1.6 kgf·m, 11.5 lbf·ft) |
|----|-----|--|




IC11J1020053-01

- | | | |
|----|-----|---|
| 11 | (b) | Front fork upper clamp bolt 23 N·m (2.3 kgf·m, 16.5 lbf·ft) |
|----|-----|---|




IC11J1020054-01

- 12 (b) Front fork lower clamp bolt 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



IC11J1020055-01


- | | |
|--------|--|
| 13 (b) | Rear brake caliper mounting bolt 23 N·m (2.3 kgf-m, 16.5 lbf-ft) |
| 14 (b) | Rear brake hose union bolt 23 N·m (2.3 kgf-m, 16.5 lbf-ft) |
| 15 (b) | Rear brake disc bolt 23 N·m (2.3 kgf-m, 16.5 lbf-ft) |
| 16 (h) | Rear brake air bleeder valve 6 N·m (0.6 kgf-m, 4.3 lbf-ft) |
| 17 (l) | Rear axle nut 100 N·m (10.0 kgf-m, 72.5 lbf-ft) |



IC11J1020056-01


- 18 (l) Rear sprocket nut 60 N·m (6.0 kgf-m, 43.5 lbf-ft)

Front Fork Inspection




IC11J1020057-01

- | | |
|--------|---|
| 14 (b) | Rear brake hose union bolt 23 N·m (2.3 kgf-m, 16.5 lbf-ft) |
| 19 (c) | Rear brake master cylinder mounting bolt 10 N·m (1.0 kgf-m, 7.0 lbf-ft) |




IC11J1020058-01

- | | |
|--------|---|
| 20 (k) | Rear brake master cylinder rod lock-nut 18 N·m (1.8 kgf-m, 13.0 lbf-ft) |
| 21 (l) | Front footrest bracket bolt 26 N·m (2.6 kgf-m, 19.0 lbf-ft) |




IC11J1020059-01

- 10 (g) Brake pipe flare nut 16 N·m (1.6 kgf-m, 11.5 lbf-ft)




IC11J1020060-01

22 Swingarm pivot nut 100 N·m (10.0 kgf·m, 72.5 lbf·ft)




IC11J1020063-02

27 Seat rail bolt 50 N·m (5.0 kgf·m, 36.0 lbf·ft)



IC11J1020061-01

23 Rear shock absorber mounting nut (Upper) 50 N·m (5.0 kgf·m, 36.0 lbf·ft)



IC11J1020062-01

- 24 Rear shock absorber mounting nut (Lower) 50 N·m (5.0 kgf·m, 36.0 lbf·ft)
- 25 Cushion lever mounting nut 78 N·m (7.8 kgf·m, 56.5 lbf·ft)
- 26 Cushion rod mounting nut 78 N·m (7.8 kgf·m, 56.5 lbf·ft)

Compression Pressure Check

BENC11J10206022

Refer to "Compression Pressure Check" in Section 1D (Page 1D-3).

Oil Pressure Check

BENC11J10206023

Refer to "Oil Pressure Check" in Section 1E (Page 1E-5).

SDS Check

BENC11J10206024

Refer to "SDS Check" in Section 1A (Page 1A-18).

Specifications

Tightening Torque Specifications

BENC11J10207001

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Exhaust pipe bolt	23	2.3	16.5	☞ (Page 0B-4)
Muffler mounting bolt	23	2.3	16.5	☞ (Page 0B-4)
Exhaust pipe connecting bolt	18	1.8	13.0	☞ (Page 0B-4)
Muffler mounting nut	23	2.3	16.5	☞ (Page 0B-4)
Oil drain plug	21	2.1	15.0	☞ (Page 0B-10)
Oil filter	20	2.0	14.5	☞ (Page 0B-11)
Engine coolant drain plug	13	1.3	9.5	☞ (Page 0B-13)
Release screw lock-nut	5	0.5	3.7	☞ (Page 0B-14)
Rear axle nut	100	10.0	72.5	☞ (Page 0B-16)
Rear brake master cylinder rod lock-nut	18	1.8	13.0	☞ (Page 0B-19)

NOTE

The tightening torque(s) also specified in:
 "Chassis Bolt and Nut Inspection" (Page 0B-21)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J10208001




Material	SUZUKI recommended product or Specification	Note
Brake fluid	DOT 4	☞ (Page 0B-17)

NOTE

Required service material(s) also described in:
 "Lubrication Points" (Page 0B-2)

Special Tool

BENC11J10208001

09900-20804 Thickness gauge ☞ (Page 0B-5) / ☞ (Page 0B-6) 	09900-20805 Tire depth gauge ☞ (Page 0B-19) 
09915-40620 Oil filter wrench ☞ (Page 0B-11) / ☞ (Page 0B-11) 	

Service Data

Specifications

Service Data

BENC11J10307001

Valve + Guide

Unit: mm (in)

Item	Standard		Limit
Valve diam.	IN.	31.0 (1.22)	—
	EX.	25.5 (1.00)	—
Valve clearance (when cold)	IN.	0.10 – 0.20 (0.004 – 0.008)	—
	EX.	0.20 – 0.30 (0.008 – 0.012)	—
Valve guide to valve stem clearance	IN.	0.010 – 0.037 (0.0004 – 0.0015)	—
	EX.	0.030 – 0.057 (0.0012 – 0.0022)	—
Valve guide I.D.	IN. & EX.	4.500 – 4.512 (0.1772 – 0.1776)	—
Valve stem O.D.	IN.	4.475 – 4.490 (0.1762 – 0.1768)	—
	EX.	4.455 – 4.470 (0.1754 – 0.1760)	—
Valve stem deflection	IN. & EX.	—	0.35 (0.014)
Valve stem runout	IN. & EX.	—	0.05 (0.002)
Valve head thickness	IN. & EX.	—	0.5 (0.02)
Valve seat width	IN. & EX.	0.9 – 1.1 (0.035 – 0.043)	—
Valve head radial runout	IN. & EX.	—	0.03 (0.001)
Valve spring free length	IN. & EX.	—	37.1 (1.46)
Valve spring tension	IN. & EX.	127 – 147 N (12.7 – 14.7 kgf, 28.5 – 33.0 lbs) at length 33.4 mm (1.31 in)	—

Camshaft + Cylinder Head

Unit: mm (in)

Item	Standard		Limit
Cam height	IN.	35.48 – 35.55 (1.397 – 1.400)	35.18 (1.385)
	EX.	33.48 – 33.55 (1.318 – 1.321)	33.18 (1.306)
Camshaft journal oil clearance	IN. & EX.	0.027 – 0.069 (0.0011 – 0.0027)	0.150 (0.0059)
Camshaft journal holder I.D.	IN. & EX.	22.007 – 22.028 (0.8664 – 0.8672)	—
Camshaft journal O.D.	IN. & EX.	21.959 – 21.980 (0.8645 – 0.8654)	—
Camshaft runout	IN. & EX.	—	0.10 (0.004)
Cam chain pin (at arrow "3")		16th pin	—
Cylinder head distortion		—	0.05 (0.002)

0C-2 Service Data:**Cylinder + Piston + Piston Ring**

Unit: mm (in)

Item	Standard		Limit
Compression pressure	1 300 – 1 700 kPa (13 – 17 kgf/cm ² , 185 – 242 psi)		1 100 kPa (11 kgf/cm ² , 156 psi)
Compression pressure difference	—		200 kPa (2.0 kgf/cm ² , 28 psi)
Piston-to-cylinder clearance	0.025 – 0.035 (0.0010 – 0.0014)		0.120 (0.0047)
Cylinder bore	81.000 – 81.015 (3.1890 – 3.1896)		No nicks or Scratches
Piston diam.	80.970 – 80.985 (3.1878 – 3.1884) Measure 20 mm (0.8 in) from the skirt end.		80.880 (3.1842)
Cylinder distortion	—		0.05 (0.002)
Piston ring free end gap	1st	—	Approx. 6.5 (0.26)
	2nd	2T	Approx. 9.0 (0.35)
Piston ring end gap	1st	—	0.06 – 0.18 (0.002 – 0.007)
	2nd	2T	0.06 – 0.18 (0.002 – 0.007)
Piston ring-to-groove clearance	1st	—	0.180 (0.0071)
	2nd	—	0.150 (0.0059)
Piston ring groove width	1st	—	0.83 – 0.85 (0.0327 – 0.0335)
		2T	1.30 – 1.32 (0.0512 – 0.0520)
	Oil	—	1.01 – 1.03 (0.0398 – 0.0406)
Piston ring thickness	1st	—	2.01 – 2.03 (0.0791 – 0.0799)
		2T	0.76 – 0.81 (0.0299 – 0.0319)
	2nd	—	1.08 – 1.10 (0.0425 – 0.0433)
Piston pin bore I.D.	20.002 – 20.008 (0.7875 – 0.7877)		20.030 (0.7886)
Piston pin O.D.	19.992 – 20.000 (0.7871 – 0.7874)		19.980 (0.7866)

Conrod + Crankshaft

Unit: mm (in)

Item	Standard		Limit
Conrod small end I.D.	20.010 – 20.018 (0.7878 – 0.7881)		20.040 (0.7890)
Conrod big end side clearance	0.170 – 0.320 (0.0067 – 0.0126)		0.5 (0.020)
Conrod big end width	20.95 – 21.00 (0.825 – 0.827)		—
Crank pin width	42.17 – 42.22 (1.660 – 1.662)		—
Conrod big end oil clearance	0.032 – 0.056 (0.0013 – 0.0022)		0.080 (0.0031)
Crank pin O.D.	37.976 – 38.000 (1.4951 – 1.4961)		—
Crankshaft journal O.D.	41.985 – 42.000 (1.6529 – 1.6535)		—
Crankshaft runout	—		0.05 (0.002)

Oil Pump

Item	Standard		Limit
Oil pressure (at 60 °C, 140 °F)	200 – 600 kPa (2.0 – 6.0 kgf/cm ² , 28 – 85 psi) at 3 000 r/min.		—

Clutch

Unit: mm (in)

Item	Standard		Limit
Clutch cable play	10 – 15 (0.4 – 0.6)		—
Clutch release screw	1 turn counterclockwise		—
Clutch drive plate thickness	No. 1, 2	2.92 – 3.08 (0.115 – 0.121)	2.62 (0.103)
Clutch drive plate claw width	No. 1, 2	13.7 – 13.8 (0.539 – 0.543)	12.9 (0.508)
Clutch driven plate distortion	—		0.10 (0.004)
Clutch spring free length	60.6 (2.39)		57.6 (2.27)

Transmission + Drive Chain

Unit: mm (in) Except ratio

Item	Standard		Limit
Primary reduction ratio	2.088 (71/34)		—
Final reduction ratio	3.133 (47/15)		—
Gear ratios	1st	2.461 (32/13)	—
	2nd	1.777 (32/18)	—
	3rd	1.380 (29/21)	—
	4th	1.125 (27/24)	—
	5th	0.961 (25/26)	—
	Top	0.851 (23/27)	—
Shift fork to groove clearance	No. 1, 2, 3	0.1 – 0.3 (0.004 – 0.012)	0.5 (0.020)
Shift fork groove width	No. 1, 2, 3	5.5 – 5.6 (0.217 – 0.220)	—
Shift fork thickness	No. 1, 2, 3	5.3 – 5.4 (0.209 – 0.213)	—
Drive chain	Type	RK 525SMOZ8	
	Links	118 links	
	20-pitch length	—	319.4 (12.57)
Drive chain slack (on side-stand)	20 – 30 (0.8 – 1.2)		—
Shift lever height	20 – 30 (0.8 – 1.2)		—

Thermostat + Radiator + Fan + Coolant

Item	Standard/Specification		Note
Thermostat valve opening temperature	Approx. 82 °C (180 °F)		—
Thermostat valve lift	8 mm (0.31 in) and over at 95 °C (203 °F)		—
ECT sensor resistance	20 °C (68 °F)	Approx. 2.45 kΩ	—
	50 °C (122 °F)	Approx. 0.811 kΩ	—
	80 °C (176 °F)	Approx. 0.318 kΩ	—
	110 °C (230 °F)	Approx. 0.142 kΩ	—
Radiator cap valve opening pressure	93 – 123 kPa (0.93 – 1.23 kgf/cm ² , 13.2 – 17.5 psi)		—
Cooling fan operating temperature	OFF→ON	Approx. 105 °C (221 °F)	—
	ON→OFF	Approx. 99 °C (210 °F)	—
Engine coolant type	Use an antifreeze/coolant compatible with aluminum radiator.		—
Engine coolant	Reservoir tank side	Approx. 250 ml (0.3/0.2 US/Imp qt)	—
	Engine side	Approx. 1 700 ml (1.8/1.5 US/Imp qt)	—

Injector + Fuel Pump + Fuel Pressure Regulator

Item	Specification	Note
Injector resistance	11.5 – 12.5 Ω at 20 °C (68 °F)	
Fuel pump discharge amount	167 ml (5.6/5.9 US/Imp oz) or more/10 seconds, at 300 kPa (3.0 kgf/cm ² , 43 psi)	
Fuel pressure regulator operating set pressure	Approx. 300 kPa (3.0 kgf/cm ² , 43 psi)	

0C-4 Service Data:
FI Sensors + Secondary Throttle Valve Actuator

Item	Standard/Specification		Note
CKP sensor resistance	130 – 240 Ω		
CKP sensor peak voltage	3.7 V or more		When cranking
IAP sensor (#1 & #2) input voltage	4.5 – 5.5 V		
IAP sensor (#1 & #2) output voltage	Approx. 2.5 V at idle speed		
TP sensor input voltage	4.5 – 5.5 V		
TP sensor output voltage	Closed	Approx. 1.1 V	
	Opened	Approx. 4.3 V	
ECT sensor input voltage	4.5 – 5.5 V		
ECT sensor resistance	Approx. 2.45 k Ω at 20 °C (68 °F)		
IAT sensor input voltage	4.5 – 5.5 V		
IAT sensor resistance	Approx. 2.6 k Ω at 20 °C (68 °F)		
TO sensor resistance	16.5 – 22.3 k Ω		
TO sensor voltage	Normal	0.4 – 1.4 V	
	Leaning	3.7 – 4.4 V	When leaning 65°
GP switch voltage	0.6 V or more		From 1st to Top
Injector voltage	Battery voltage		
Ignition coil primary peak voltage	150 V or more		When cranking
STP sensor input voltage	4.5 – 5.5 V		
STP sensor output voltage	Closed	Approx. 0.6 V	
	Opened	Approx. 4.5 V	
STV actuator resistance	Approx. 7 Ω		
HO2 sensor heater resistance	Approx. 8 Ω at 23 °C (73 °F)		
HO2 sensor output voltage	Approx. 0.45 V or less at idle speed		
	0.6 V or more at 6 000 r/min.		
EVAP system purge control solenoid valve resistance	Approx. 32 Ω at 20 °C (68 °F)		E-33 only

Throttle Body

Item	Specification
Bore size	39 mm (1.53 in)
I.D. No.	11J1 (E-33), 11J0 (Others)
Idle r/min.	1 300 \pm 100 r/min.
Fast idle r/min.	Approx. 2 000 r/min. (When cold engine)
Throttle cable play	2.0 – 4.0 mm (0.08 – 0.16 in)

Electrical

Unit: mm (in)

Item		Specification		Note	
Firing order		1 · 2			
Spark plug	Type	NGK: CR8EIA-9 DENSO: IU24D			
	Gap	0.8 – 0.9 (0.031 – 0.035)			
Spark performance		Over 8 (0.3) at 1 atm.			
CKP sensor resistance		130 – 240 Ω			
CKP sensor peak voltage		3.7 V or more		When cranking	
Ignition coil resistance	Primary	1 – 3 Ω		Terminal – Terminal	
	Secondary	25 – 40 kΩ		Plug cap – Plug cap	
Ignition coil primary peak voltage		150 V or more		When cranking	
Generator coil resistance		0.2 – 0.7 Ω			
Generator maximum output		Approx. 375 W at 5 000 r/min.			
Generator no-load voltage (When engine is cold)		60 V (AC) or more at 5 000 r/min.			
Regulated voltage		14.0 – 15.5 V at 5 000 r/min.			
Starter motor brush length	Standard	12 (0.47)			
	Limit	6.5 (0.26)			
Starter relay resistance		3 – 6 Ω			
Battery	Type designation	FTX12-BS			
	Capacity	12 V 36.0 kC (10 Ah)/10 HR			
	Standard electrolyte S.G.	1.320 at 20 °C (68 °F)			
Fuse size	Headlight	HI	15 A		
		LO	15 A		
	Fuel	10 A			
	Ignition	10 A			
	Signal	15 A			
	Fan	15 A			
	Main	30 A			
	ABS motor	25 A			
ABS valve	15 A				

Wattage

Unit: W

Item		Specification	
		E03, 28, 33	E21, 24
Headlight	HI	60 x 2	←
	LO	55 x 2	←
Position/Parking light		5 x 2	←
Brake light/Taillight		21/5	←
Turn signal light		21 x 4	←
License plate light		5	←
Speedometer light		LCD	←
Tachometer light		LED	←
Turn signal indicator light		LED	←
High beam indicator light		LED	←
Neutral position indicator light		LED	←
Oil pressure/Engine coolant temp indicator light		LED	←
FI indicator light		LED	←
Freeze indicator light		LED	←
ABS indicator light		LED	←
Immobilizer indicator light		—	LED

0C-6 Service Data:**Brake + Wheel**

Unit: mm (in)

Item	Standard		Limit
Rear brake pedal height	23 – 33 (0.9 – 1.3)		—
Brake disc thickness	Front	4.8 – 5.2 (0.19 – 0.20)	4.5 (0.18)
	Rear	4.8 – 5.2 (0.19 – 0.20)	4.5 (0.18)
Brake disc runout	—		0.30 (0.012)
Master cylinder bore	Front	Approx. 14.0 (0.55)	—
	Rear	Approx. 14.0 (0.55)	—
Master cylinder piston diam.	Front	Approx. 14.0 (0.55)	—
	Rear	Approx. 14.0 (0.55)	—
Brake caliper cylinder bore	Front	Approx. 27.0 (1.06)	—
	Rear	Approx. 38.2 (1.50)	—
Brake caliper piston diam.	Front	Approx. 27.0 (1.06)	—
	Rear	Approx. 38.2 (1.50)	—
Brake fluid type	DOT 4		—
Wheel rim runout	Axial	—	2.0 (0.08)
	Radial	—	2.0 (0.08)
Wheel axle runout	Front	—	0.25 (0.010)
	Rear	—	0.25 (0.010)
Wheel rim size	Front	19 M/C x MT 2.50	—
	Rear	17 M/C x MT 4.00	—

Tire

Item	Standard		Limit
Cold inflation tire pressure (Solo riding)	Front	225 kPa (2.25 kgf/cm ² , 33 psi)	—
	Rear	250 kPa (2.50 kgf/cm ² , 36 psi)	—
Cold inflation tire pressure (Dual riding)	Front	225 kPa (2.25 kgf/cm ² , 33 psi)	—
	Rear	280 kPa (2.80 kgf/cm ² , 41 psi)	—
Tire size	Front	110/80 R19 M/C 59 H	—
	Rear	150/70 R17 M/C 69 H	—
Tire type	Front	BRIDGESTONE: TW101 RADIAL J	—
	Rear	BRIDGESTONE: TW152 RADIAL F	—
Tire tread depth (Recommended depth)	Front	—	1.6 mm (0.06 in)
	Rear	—	2.0 mm (0.08 in)

Suspension

Unit: mm (in)

Item	Standard	Limit
Front fork stroke	150 (5.9)	—
Front fork inner tube O.D.	43 (1.69)	—
Front fork spring free length	451.1 (17.8)	442 (17.4)
Front fork oil level (Without spring, inner tube fully compressed)	139 (5.47)	—
Front fork oil type	SUZUKI FORK OIL SS-8 or equivalent	—
Front fork oil capacity (Each leg)	530 ml (17.9/18.7 US/Imp oz)	—
Front fork spring adjuster	2nd groove from top	—
Rear shock absorber spring pre-set position	2nd position	—
Rear shock absorber damping force adjuster	2 turn from stiffest position	—
Rear wheel travel	159 (6.3)	—
Swingarm pivot shaft runout	—	0.3 (0.01)

Fuel + Oil

Item	Specification	Note
Fuel type	Use unleaded gasoline with a minimum pump octane rating of 87 ((R+M)/2 method). Gasoline containing MTBE (Methyl Tertiary Butyl Ether), less than 10% ethanol, or less than 5% methanol with appropriate cosolvents and corrosion inhibitor is permissible.	E-03, 28, 33
	Use unleaded gasoline with an octane rating of 91 or higher (Research method).	E-21, 24
Fuel tank capacity	Including reserve 20.0 L (5.3/4.4 US/Imp gal)	
Engine oil type	SAE 10 W-40, API SF/SG or SH/SJ with JASO MA	
Engine oil capacity	Change	2 400 ml (2.5/2.1 US/Imp qt)
	Filter change	2 750 ml (2.9/2.4 US/Imp qt)
	Overhaul	3 000 ml (3.2/2.6 US/Imp qt)

Tightening Torque List

BENC11J10307002

Engine

Item	N-m	kgf-m	lbf-ft
Exhaust pipe bolt	23	2.3	16.5
Exhaust pipe connecting bolt	18	1.8	13.0
Muffler mounting bolt	23	2.3	16.5
Muffler mounting nut	23	2.3	16.5
Muffler cover bolt	10	1.0	7.0
Exhaust cover bolt	10	1.0	7.0
Speed sensor rotor bolt	28	2.8	20.5
Speed sensor mounting bolt	4.5	0.45	3.3
Engine sprocket nut	145	14.5	105.0
Engine mounting nut	Front upper	93	9.3
	Rear upper	55	5.5
Engine mounting bolt	55	5.5	40.0
Engine mounting pinch bolt	25	2.5	18.0
Engine mounting thrust adjuster	12	1.2	8.5
Engine mounting thrust adjuster lock-nut	45	4.5	32.5
Engine mounting bracket bolt	35	3.5	25.5
Cylinder head cover bolt	14	1.4	10.0
Intake pipe screw	8.5	0.85	6.0
Spark plug	11	1.1	8.0
Camshaft journal holder bolt	10	1.0	7.0
Oil pipe mounting bolt	10	1.0	7.0
Cam chain tensioner adjuster cap bolt	23	2.3	16.5
Cam chain tensioner adjuster mounting bolt	10	1.0	7.0
Cylinder head bolt	[M10]	25 → 42	2.5 → 4.2
	[M6]	10	1.0
Cylinder nut [M6]	10	1.0	7.0
Clutch sleeve hub nut	50	5.0	36.0
Clutch spring set bolt	10	1.0	7.0
Primary drive gear bolt	70	7.0	50.5
Starter clutch bolt	25	2.5	18.0
Generator rotor bolt	140	14.0	101.5
Generator stator set bolt	11	1.1	8.0
Generator cover bolt	10	1.0	7.0
Generator cover plug	11	1.1	8.0
Gearshift cam stopper bolt	10	1.0	7.0
Gearshift cam stopper plate bolt	13	1.3	9.5
Gearshift arm stopper	19	1.9	13.5
Gearshift lever bolt	40	4.0	29.0
Clutch release arm bolt	9	0.9	6.5
Gear position switch mounting bolt	6.5	0.65	4.7

0C-8 Service Data:

Item		N·m	kgf·m	lbf·ft
Throttle cable lock-nut		4.5	0.45	3.3
Engine sprocket cover bolt		5.5	0.55	4.0
Oil pressure switch		14	1.4	10.0
Oil pressure switch lead wire bolt		1.5	0.15	1.0
Crankcase bolt	[M6]	11	1.1	8.0
	[M8]	26	2.6	19.0
Oil gallery plug	(Cylinder head)	10	1.0	7.0
	[M6]	10	1.0	7.0
	[M8]	18	1.8	13.0
	[M12]	21	2.1	15.0
	[M16]	35	3.5	25.5
Oil drain plug		21	2.1	15.0
Piston cooling oil jet bolt		10	1.0	7.0
Conrod cap bolt		21 N·m (2.1 kgf·m, 15.0 lbf·ft) → turn clockwise 90°		
Oil cooler union bolt		70	7.0	50.5
Oil filter		20	2.0	14.5
Oil pipe stopper screw		8	0.8	5.7
Oil plate bolt		10	1.0	7.0
Oil pressure regulator		27	2.7	19.5
Oil pump mounting bolt		10	1.0	7.0
Starter motor lead wire mounting bolt		6	0.6	4.5
Starter motor mounting bolt		10	1.0	7.0
Starter motor housing bolt		5	0.5	3.5

FI System and Intake Air System

Item		N·m	kgf·m	lbf·ft
CKP sensor mounting bolt		6.5	0.65	4.7
Fuel delivery pipe mounting screw		3.5	0.35	2.5
Fuel pump mounting bolt		10	1.0	7.0
TP sensor mounting screw		3.5	0.35	2.5
STP sensor mounting screw		3.5	0.35	2.5
ECT sensor		18	1.8	13.0
IAT sensor screw		1.5	0.15	1.0
GP switch mounting bolt		6.5	0.65	4.7
HO2 sensor		25	2.5	18.0
EVAP system purge control solenoid valve mounting nut (E-33 only)		7	0.7	5.0
EVAP system purge control valve bracket screw		5	0.5	3.5

Cooling System


Item		N·m	kgf·m	lbf·ft
Water pump cover screw		4.5	0.45	32.5
Engine coolant drain plug		13	1.3	9.5
Water hose clamp bolt		1.5	0.15	1.0
Cooling fan assembly mounting bolt		5	0.5	3.5


Chassis


Item	N·m	kgf·m	lbf·ft
Steering stem head nut	90	9.0	65.0
Steering stem nut	45 N·m (4.5 kgf·m, 32.5 lbf·ft) → turn counterclockwise 1/4 – 1/2.		
Steering stem lock-nut	80	8.0	58.0
Front fork upper clamp bolt	23	2.3	16.5
Front fork lower clamp bolt	23	2.3	16.5
Front fork cap bolt	23	2.3	16.5
Front fork cylinder bolt	20	2.0	14.5
Front axle	65	6.5	47.0
Front axle pinch bolt	23	2.3	16.5
Front footrest bracket bolt	26	2.6	19.0
Handlebar holder bolt	23	2.3	16.5
Front brake master cylinder mounting bolt	10	1.0	7.0
Front brake caliper mounting bolt	39	3.9	28.0
Brake hose union bolt	23	2.3	16.5
Brake disc bolt (Front and Rear)	23	2.3	16.5
Air bleeder valve (Front brake caliper)	7.5	0.75	5.5
Air bleeder valve (Rear brake caliper)	6	0.6	4.5
Rear brake caliper mounting bolt	23	2.3	16.5
Rear brake caliper sliding pin	27	2.7	19.5
Rear brake pad mounting pin	17	1.7	12.5
Pad pin plug	2.5	0.25	1.8
Rear brake master cylinder mounting bolt	10	1.0	7.0
Rear brake master cylinder rod lock-nut	18	1.8	13.0
Wheel speed sensor rotor bolt	6.5	0.65	4.7
Rear axle nut	100	10.0	72.5
Rear sprocket nut	60	6.0	43.5
Side-stand bolt	100	10.0	72.5
Side-stand pivot bolt	50	5.0	36.0
Side-stand pivot nut	40	4.0	29.0
Side-stand switch mounting bolt	14	1.4	10.0
Swingarm pivot nut	100	10.0	72.5
Swingarm pivot lock-nut	90	9.0	65.0
Swingarm pivot shaft	15	1.5	11.0
Rear shock absorber mounting upper nut	50	5.0	36.0
Rear shock absorber mounting lower nut	50	5.0	36.0
Cushion lever mounting nut	78	7.8	56.5
Cushion rod mounting nut	78	7.8	56.5
Brake lever pivot bolt	6	0.6	4.3
Brake lever pivot bolt lock-nut	6	0.6	4.3
Clutch lever pivot bolt	6.5	0.65	4.7
Clutch lever pivot bolt lock-nut	6.5	0.65	4.7
Combination meter bolt	4.5	0.45	3.3
Combination meter screw	1.5	0.15	1.0
Rear combination light mounting screw	1.8	0.18	1.5
Turn signal light mounting nut (Front)	1.3	0.13	1.0
Turn signal light mounting nut (Rear)	2.3	0.23	1.7
License plate light mounting nut	5	0.5	3.5
Reflex reflector	2	0.2	1.5
Reflex reflector bolt	4.5	0.45	3.3
Reflex reflector nut	1.8	0.18	1.5
Sport carrier bolt	29	2.9	21.0
Bank sensor bolt	18	1.8	13.0
Brake pipe flare nut	16	1.6	11.5

Tightening Torque Chart


Each fastener should be tightened to the torque specified in "Tightening Torque List". If no description or specification is provided, refer to the following tightening torque chart for the applicable torque for each fastener.

Bolt type	Thread diameter "a" [mm]	Unit		
		N-m	kgf-m	lbf-ft
 IB14J1030007-02	4	1.5	0.15	1.0
	5	3.0	0.30	2.0
	6	5.5	0.55	4.0
	8	13	1.3	9.5
	10	29	2.9	21.0
	12	45	4.5	32.5
A equivalent of 4T strength fastener without flange	14	65	6.5	47.0
	16	105	10.5	76.0
	18	160	16.0	115.5

Bolt type	Thread diameter "a" [mm]	Unit		
		N-m	kgf-m	lbf-ft
 IB14J1030007-02	4	1.7	0.17	1.0
	5	3.3	0.33	2.5
	6	6	0.6	4.5
	8	14	1.4	10.0
	10	32	3.2	23.0
	12	50	5.0	36.0
A equivalent of 4T strength fastener with flange	14	72	7.2	52.0
	16	116	11.6	84.0
	18	176	17.6	127.5

Bolt type	Thread diameter "a" [mm]	Unit		
		N-m	kgf-m	lbf-ft
 IC11J1030001-01	4	2.3	0.23	1.5
	5	4.5	0.45	3.5
	6	10	1.0	7.0
	8	23	2.3	16.5
	10	50	5.0	36.0
	12	85	8.5	61.5
	14	135	13.5	97.5
	16	210	21.0	152.0
	18	240	24.0	173.5
A equivalent of 7T strength fastener without flange and small crown shape bolt *1				

*1: Small crown shape bolt (crown shape bolt with flange either "a" = 5 and "b" = 7 or "a" = 6 and "b" = 8)

Bolt type	Thread diameter "a" [mm]	Unit		
		N-m	kgf-m	lbf-ft
 IC11J1030002-01	4	2.5	0.25	2.0
	5	5	0.5	3.5
	6	11	1.1	8.0
	8	25	2.5	18.0
	10	55	5.5	40.0
	12	94	9.4	68.0
	14	149	14.9	107.5
	16	231	23.1	167.0
A equivalent of 7T strength fastener with flange except small crown shape bolt				
	18	264	26.4	191.0

Section 1

Engine

CONTENTS

Precautions	1-1	DTC "C31" (P0705): GP Switch Circuit Malfunction	1A-63
Precautions	1-1	DTC "C32" (P0201), "C33" (P0202): Fuel Injector Circuit Malfunction.....	1A-66
Precautions for Engine.....	1-1	DTC "C40" (P0505): ISC Valve Circuit Malfunction.....	1A-68
Engine General Information and Diagnosis	1A-1	DTC "C41" (P0230): FP Relay Circuit Malfunction.....	1A-70
General Description	1A-1	DTC "C42" (P1650): IG Switch Circuit Malfunction.....	1A-73
Injection Timing Description	1A-1	DTC "C44" (P0130 / P0135): HO2 Sensor (HO2S) Circuit Malfunction	1A-73
Self-Diagnosis Function	1A-3	DTC "C60" (P0480): Cooling Fan Relay Circuit Malfunction.....	1A-78
Schematic and Routing Diagram	1A-5	DTC "C62" (P0443): EVAP System Purge Control Solenoid Valve Circuit Malfunction (E-33 only).....	1A-82
FI System Wiring Diagram	1A-5	DTC "C65" (P0506 / P0507): Idle Speed Malfunction.....	1A-85
Terminal Alignment of ECM Coupler.....	1A-6	Specifications	1A-87
Component Location	1A-7	Service Data.....	1A-87
FI System Parts Location.....	1A-7	Special Tools and Equipment	1A-88
Diagnostic Information and Procedures	1A-9	Special Tool	1A-88
Engine Symptom Diagnosis	1A-9	Emission Control Devices	1B-1
Self-Diagnostic Procedures	1A-13	Precautions	1B-1
Use of SDS Diagnosis Reset Procedures.....	1A-15	Precautions for Emission Control Devices	1B-1
Show Data When Trouble (Displaying Data at the Time of DTC)	1A-16	General Description	1B-1
SDS Check	1A-18	Fuel Injection System Description	1B-1
DTC Table.....	1A-22	Crankcase Emission Control System Description	1B-2
Fail-Safe Function Table	1A-23	Noise Emission Control System Description	1B-3
FI System Troubleshooting	1A-24	Evaporative Emission Control System Diagram (Only for E-33).....	1B-4
Malfunction Code and Defective Condition Table	1A-25	Schematic and Routing Diagram	1B-5
DTC "C12" (P0335): CKP Sensor Circuit Malfunction.....	1A-27	EVAP Canister Hose Routing Diagram (Only for E-33).....	1B-5
DTC "C13" (P1750) or "C17" (P0105): IAP Sensor Circuit Malfunction	1A-30	Repair Instructions	1B-6
DTC "C14" (P0120-H/L): TP Sensor Circuit Malfunction.....	1A-33	Heated Oxygen Sensor (HO2S) Removal and Installation	1B-6
DTC "C15" (P0115-H/L): ECT Sensor Circuit Malfunction.....	1A-39	Heated Oxygen Sensor (HO2S) Inspection	1B-6
DTC "C21" (P0110-H/L): IAT Sensor Circuit Malfunction.....	1A-43	Crankcase Breather (PCV) Hose Inspection.....	1B-6
DTC "C23" (P1651-H/L): TO Sensor Circuit Malfunction.....	1A-47	Crankcase Breather (PCV) Hose Removal and Installation	1B-7
DTC "C24" (P0351) or "C25" (P0352): Ignition System Malfunction.....	1A-52		
DTC "C28" (P1655): Secondary Throttle Valve Actuator (STVA) Malfunction	1A-52		
DTC "C29" (P1654-H/L): Secondary Throttle Position Sensor (STPS) Circuit Malfunction ...	1A-56		

Evaporative Emission Control System Removal and Installation (Only for E-33)	1B-7	Compression Pressure Check	1D-3
Evaporative Emission Control System Inspection (Only for E-33)	1B-8	Repair Instructions	1D-4
Specifications	1B-10	Engine Components Removable with the Engine in Place	1D-4
Service Data	1B-10	Air Cleaner Element Removal and Installation	1D-6
Tightening Torque Specifications	1B-10	Air Cleaner Element Inspection and Cleaning	1D-6
Special Tools and Equipment	1B-10	Air Cleaner Box Removal and Installation	1D-6
Special Tool	1B-10	Throttle Body Components	1D-7
Engine Electrical Devices	1C-1	Throttle Body Construction	1D-8
Precautions	1C-1	Throttle Body Removal and Installation	1D-9
Precautions for Engine Electrical Device	1C-1	Throttle Body Disassembly and Assembly	1D-11
Component Location	1C-1	Throttle Body Inspection and Cleaning	1D-15
Engine Electrical Components Location	1C-1	Throttle Valve Synchronization	1D-15
Diagnostic Information and Procedures	1C-1	ISC Learned Value Reset	1D-17
Engine Symptom Diagnosis	1C-1	Engine Assembly Removal	1D-17
Repair Instructions	1C-1	Engine Assembly Installation	1D-23
ECM Removal and Installation	1C-1	Engine Top Side Disassembly	1D-27
CKP Sensor Inspection	1C-1	Engine Top Side Reassembly	1D-32
CKP Sensor Removal and Installation	1C-1	Valve Clearance Inspection and Adjustment	1D-44
IAP Sensor Inspection	1C-1	Camshaft Inspection	1D-45
IAP Sensor Removal and Installation	1C-2	Cam Chain Tension Adjuster Inspection	1D-47
TP Sensor Inspection	1C-2	Cam Chain Guide Inspection	1D-47
TP Sensor Removal and Installation	1C-2	Cam Chain Tensioner Inspection	1D-47
TP Sensor Adjustment	1C-2	Cylinder Head Disassembly and Assembly	1D-47
IAT Sensor Removal and Installation	1C-3	Cylinder Head Related Parts Inspection	1D-50
IAT Sensor Inspection	1C-3	Valve Guide Replacement	1D-53
ECT Sensor Removal and Installation	1C-3	Valve Seat Repair	1D-54
ECT Sensor Inspection	1C-4	Cylinder Inspection	1D-55
TO Sensor Removal and Installation	1C-5	Piston Ring Removal and Installation	1D-56
TO Sensor Inspection	1C-5	Piston and Piston Ring Inspection	1D-57
STP Sensor Inspection	1C-5	Engine Bottom Side Disassembly	1D-59
STP Sensor Adjustment	1C-5	Engine Bottom Side Reassembly	1D-66
STP Sensor Removal and Installation	1C-6	Conrod Removal and Installation	1D-80
STV Actuator Inspection	1C-7	Conrod / Crankshaft Inspection	1D-82
STV Actuator Removal and Installation	1C-7	Conrod Crank Pin Bearing Inspection and Selection	1D-82
ISC Valve Inspection	1C-7	Crankshaft Journal Bearing Inspection and Selection	1D-84
ISC Learned Value Reset and Opening Initialization	1C-7	Specifications	1D-86
HO2 Sensor Inspection	1C-8	Service Data	1D-86
HO2 Sensor Removal and Installation	1C-8	Tightening Torque Specifications	1D-87
GP Switch Inspection	1C-8	Special Tools and Equipment	1D-89
GP Switch Removal and Installation	1C-8	Recommended Service Material	1D-89
Specifications	1C-8	Special Tool	1D-89
Service Data	1C-8	Engine Lubrication System	1E-1
Tightening Torque Specifications	1C-8	Precautions	1E-1
Special Tools and Equipment	1C-9	Precautions for Engine Oil	1E-1
Recommended Service Material	1C-9	Schematic and Routing Diagram	1E-2
Special Tool	1C-9	Engine Lubrication System Chart Diagram	1E-2
Engine Mechanical	1D-1	Engine Lubrication Circuit Diagram	1E-3
General Description	1D-1	Diagnostic Information and Procedures	1E-5
ISC Valve System Description	1D-1	Engine Lubrication Symptom Diagnosis	1E-5
Schematic and Routing Diagram	1D-1	Oil Pressure Check	1E-5
Camshaft and Sprocket Assembly Diagram	1D-1	Repair Instructions	1E-6
Throttle Cable Routing Diagram	1D-2	Engine Oil and Filter Replacement	1E-6
Diagnostic Information and Procedures	1D-3	Engine Oil Level Inspection	1E-6
Engine Mechanical Symptom Diagnosis	1D-3	Oil Strainer / Oil Pressure Regulator Removal and Installation	1E-6

Oil Strainer Inspection and Cleaning	1E-7	Fuel System	1G-1
Oil Pressure Regulator Inspection	1E-7	Precautions	1G-1
Oil Cooler Removal and Installation	1E-8	Precautions for Fuel System	1G-1
Oil Pressure Switch Removal and Installation	1E-8	General Description	1G-2
Oil Pressure Switch Inspection	1E-9	Fuel System Description	1G-2
Oil Jet Removal and Installation	1E-9	Diagnostic Information and Procedures	1G-3
Oil Jet / Oil Gallery Jet Inspection	1E-11	Fuel System Diagnosis	1G-3
Oil Pump Removal and Installation	1E-12	Repair Instructions	1G-4
Oil Pump Inspection	1E-13	Fuel Pressure Inspection	1G-4
Oil Pipe Removal and Installation	1E-13	Fuel Pump Inspection	1G-5
Oil Pipe Inspection	1E-14	Fuel Discharge Amount Inspection	1G-5
Specifications	1E-14	Fuel Pump Relay Inspection	1G-5
Service Data	1E-14	Fuel Hose Inspection	1G-6
Tightening Torque Specifications	1E-14	Fuel Hose Removal and Installation	1G-6
Special Tools and Equipment	1E-15	Fuel Tank Removal and Installation	1G-6
Recommended Service Material	1E-15	Fuel Pump Components	1G-8
Special Tool	1E-15	Fuel Pump Assembly Removal and Installation	1G-9
Engine Cooling System	1F-1	Fuel Level Gauge Inspection	1G-9
Precautions	1F-1	Fuel Pump Disassembly and Assembly	1G-9
Precautions for Engine Cooling System	1F-1	Fuel Mesh Filter Inspection and Cleaning	1G-11
Precautions for Engine Coolant	1F-1	Fuel Injector / Fuel Delivery Pipe Removal and Installation	1G-11
General Description	1F-1	Fuel Injector Inspection and Cleaning	1G-13
Engine Coolant Description	1F-1	Specifications	1G-13
Schematic and Routing Diagram	1F-2	Service Data	1G-13
Cooling Circuit Diagram	1F-2	Tightening Torque Specifications	1G-13
Water Hose Routing Diagram	1F-3	Special Tools and Equipment	1G-14
Diagnostic Information and Procedures	1F-4	Recommended Service Material	1G-14
Engine Cooling Symptom Diagnosis	1F-4	Special Tool	1G-14
Repair Instructions	1F-5	Ignition System	1H-1
Cooling Circuit Inspection	1F-5	General Description	1H-1
Radiator Cap Inspection	1F-5	Immobilizer Description (For E-21, 24)	1H-1
Radiator Inspection and Cleaning	1F-5	Schematic and Routing Diagram	1H-2
Radiator / Cooling Fan Motor Removal and Installation	1F-6	Ignition System Diagram	1H-2
Water Hose Inspection	1F-7	Component Location	1H-3
Water Hose Removal and Installation	1F-8	Ignition System Components Location	1H-3
Radiator Reservoir Tank Inspection	1F-8	Diagnostic Information and Procedures	1H-3
Radiator Reservoir Tank Removal and Installation	1F-9	Ignition System Symptom Diagnosis	1H-3
Cooling Fan Inspection	1F-9	No Spark or Poor Spark	1H-4
Cooling Fan Relay Inspection	1F-10	Repair Instructions	1H-5
ECT Sensor Removal and Installation	1F-10	Ignition Coil Construction	1H-5
ECT Sensor Inspection	1F-10	Spark Plug Cap and Spark Plug Removal and Installation	1H-6
Engine Coolant Temperature Indicator Inspection	1F-10	Ignition Coil Removal and Installation	1H-7
Thermostat Removal and Installation	1F-11	Spark Plug Inspection and Cleaning	1H-7
Thermostat Inspection	1F-11	Ignition Coil and Plug Cap Inspection	1H-7
Water Pump Components	1F-13	CKP Sensor Inspection	1H-9
Water Pump Removal and Installation	1F-14	CKP Sensor Removal and Installation	1H-10
Water Pump Disassembly and Assembly	1F-15	Engine Stop Switch Inspection	1H-10
Water Pump Related Parts Inspection	1F-18	Immobilizer Antenna Removal and Installation (for E-21, 24)	1H-10
Specifications	1F-19	Ignition Switch Inspection	1H-11
Service Data	1F-19	Ignition Switch Removal and Installation (for E-21)	1H-11
Tightening Torque Specifications	1F-19	Ignition Switch Removal and Installation (for E-03, 24, 28, 33)	1H-11
Special Tools and Equipment	1F-20		
Recommended Service Material	1F-20		
Special Tool	1F-20		

Specifications	1H-12	Charging System Diagram.....	1J-1
Service Data.....	1H-12	Component Location	1J-1
Tightening Torque Specifications.....	1H-12	Charging System Components Location.....	1J-1
Special Tools and Equipment	1H-13	Diagnostic Information and Procedures	1J-1
Recommended Service Material.....	1H-13	Charging System Symptom Diagnosis.....	1J-1
Special Tool.....	1H-13	Battery Runs Down Quickly.....	1J-2
Starting System	1I-1	Repair Instructions	1J-3
Schematic and Routing Diagram	1I-1	Battery Current Leakage Inspection.....	1J-3
Starting System Diagram.....	1I-1	Regulated Voltage Inspection.....	1J-3
Component Location	1I-1	Generator Inspection.....	1J-4
Starting System Components Location.....	1I-1	Generator Removal and Installation.....	1J-4
Diagnostic Information and Procedures	1I-1	Regulator / Rectifier Construction.....	1J-8
Starting System Symptom Diagnosis.....	1I-1	Regulator / Rectifier Inspection.....	1J-8
Starter Motor will not Run.....	1I-2	Regulator / Rectifier Removal and Installation....	1J-9
Starter Motor Runs but Does not Crank the Engine.....	1I-2	Battery Components.....	1J-10
Repair Instructions	1I-3	Battery Charging.....	1J-10
Starter Motor Components.....	1I-3	Battery Removal and Installation.....	1J-12
Starter Motor Removal and Installation.....	1I-4	Battery Visual Inspection.....	1J-12
Starter Motor Disassembly and Assembly.....	1I-5	Specifications	1J-13
Starter Motor Related Parts Inspection.....	1I-5	Service Data.....	1J-13
Starter Relay Removal and Installation.....	1I-6	Tightening Torque Specifications.....	1J-13
Starter Relay Inspection.....	1I-7	Special Tools and Equipment	1J-14
Turn Signal / Side-stand Relay Removal and Installation.....	1I-8	Recommended Service Material.....	1J-14
Side-stand / Ignition Interlock System Parts Inspection.....	1I-8	Special Tool.....	1J-14
Starter Clutch Removal and Installation.....	1I-10	Exhaust System	1K-1
Starter Clutch Inspection.....	1I-12	Precautions	1K-1
Starter Button Inspection.....	1I-12	Precautions for Exhaust System.....	1K-1
Specifications	1I-13	Diagnostic Information and Procedures	1K-1
Service Data.....	1I-13	Engine Symptom Diagnosis.....	1K-1
Tightening Torque Specifications.....	1I-13	Repair Instructions	1K-2
Special Tools and Equipment	1I-14	Exhaust System Construction.....	1K-2
Recommended Service Material.....	1I-14	Exhaust Pipe / Muffler Removal and Installation.....	1K-3
Special Tool.....	1I-14	Exhaust System Inspection.....	1K-6
Charging System	1J-1	Specifications	1K-7
Schematic and Routing Diagram	1J-1	Tightening Torque Specifications.....	1K-7
		Special Tools and Equipment	1K-7
		Recommended Service Material.....	1K-7

Precautions

Precautions

Precautions for Engine

Refer to "General Precautions" in Section 00 (Page 00-1) and "Precautions for Electrical Circuit Service" in Section 00 (Page 00-2).

BENC11J11000001



NOTICE

Do not touch the engine or any other parts through the fuel system. It is extremely dangerous to touch the engine or any other parts through the fuel system. It is extremely dangerous to touch the engine or any other parts through the fuel system.

Engine General Information and Diagnosis


General Description

Injection Timing Description

BENC11J11101001

Injection Time (Injection Volume)

The factors to determine the injection time include the basic fuel injection time, which is calculated on the basis of the intake air pressure, engine speed and throttle opening angle, and various compensations. These compensations are determined according to the signals from various sensors that detect the engine and driving conditions.



IC11J1110001-01

Compensation of Injection Time (Volume)

The following different signals are output from the respective sensors for compensation of the fuel injection time (volume).

Signal	Descriptions
ENGINE COOLANT TEMPERATURE SENSOR SIGNAL	When engine coolant temperature is low, injection time (volume) is increased.
INTAKE AIR TEMPERATURE SENSOR SIGNAL	When intake air temperature is low, injection time (volume) is increased.
HEATED OXYGEN SENSOR SIGNAL	Air/fuel ratio is compensated to the theoretical ratio from density of oxygen in exhaust gasses. The compensation occurs in such a way that more fuel is supplied if detected air/fuel ratio is lean or less fuel is supplied if it is rich.
BATTERY VOLTAGE SIGNAL	ECM operates on the battery voltage and at the same time, it monitors the voltage signal for compensation of the fuel injection time (volume). A longer injection time is needed to adjust injection volume in the case of low voltage.
ENGINE RPM SIGNAL	At high speed, the injection time (volume) is increased.
STARTING SIGNAL	When starting engine, additional fuel is injected during cranking engine.
ACCELERATION SIGNAL/DECELERATION SIGNAL	During acceleration, the fuel injection time (volume) is increased, in accordance with the throttle opening speed and engine rpm. During deceleration, the fuel injection time (volume) is decreased.

Injection Stop Control

Signal	Descriptions
TIP-OVER SENSOR SIGNAL (FUEL SHUT-OFF)	When the motorcycle tips over, the tip-over sensor sends a signal to the ECM. Then, this signal cuts OFF current supplied to the fuel pump, fuel injectors and ignition coils.
OVER-REV. LIMITER SIGNAL	<p>The fuel injector stops operation when engine rpm reaches rev. limit rpm.</p> <p>The fuel cut-off circuit is incorporated in this ECM in order to prevent over-running of engine. When engine speed reaches 10 200 r/min, this circuit cuts off fuel at the fuel injector. But under no load, the clutch lever is pulled or the gear position is neutral, this circuit cuts off fuel when engine speed reaches 10 200 r/min.</p> <p>NOTICE</p> <p>Under no load, the engine can run over 11 000 r/min though the fuel cut-off circuit is effective, which may possibly cause engine damage. Do not run the engine without load over 11 000 r/min at anytime.</p>

Self-Diagnosis Function

The self-diagnosis function is incorporated in the ECM. The function has two modes, "User mode" and "Dealer mode". The user can only be notified by the LCD (DISPLAY) panel and LED (FI indicator light). To check the function of the individual FI system devices, the dealer mode is provided. In this check, the special tool is necessary to read the code of the malfunction items.

User Mode

Malfunction		LCD (display) indication "A"	FI indicator light indication "B"	Indication mode
"NO"		Odometer *1	—	—
"YES"	Engine can start	Odometer (*1) and "FI" letters *2	FI indicator light turns ON.	Each 2 sec. Odometer (*1) and "FI" is indicated alternately.
	Engine can not start	"FI" letters *3	FI indicator light turns ON and blinks.	"FI" is indicated continuously.

***1**
Current letter displayed any one of the odometer, tripmeter 1 or tripmeter 2.

***2**
When one of the signals is not received by ECM, the fail-safe circuit works and injection is not stopped. In this case, "FI" and odometer (*1) are indicated in the LCD panel and motorcycle can run.

***3**
The injection signal is stopped, when the crankshaft position sensor signal, tip-over sensor signal, ignition signal, #1 and #2 injector signals, fuel pump relay signal or ignition switch signal is not sent to ECM. In this case, "FI" is indicated in the LCD panel. Motorcycle does not run.


"CHEC":
The LCD panel indicates "CHEC" when no communication signal from the ECM is received for 3 seconds or more.

For Example:
The ignition switch is turned ON, and the engine stop switch is turned OFF. In this case, the speedometer does not receive any signal from the ECM, and the panel indicates "CHEC".
If CHEC is indicated, the LCD does not indicate the trouble code. It is necessary to check the wiring harness between ECM and speedometer couplers.

The possible cause of this indication is as follows:
Engine stop switch is in OFF position. Side-Stand/ignition inter-lock system is not working. Ignition fuse is burnt.

NOTE

The FI indicator light "B" turns ON about 3 seconds after turning the ignition switch ON.



Dealer Mode


The defective function is memorized in the computer. Use the special tool's coupler to connect to the mode select switch. The memorized malfunction code is displayed on LCD (DISPLAY) panel. Malfunction means that the ECM does not receive signal from the devices. These affected devices are indicated in the code form.


NOTE

Before checking the malfunction code, do not disconnect the ECM coupler.

If the coupler from the ECM is disconnected, the malfunction code memory is erased and the malfunction code can not be checked.

Special tool

 (A): 09930-82720 (Mode selection switch)




Malfunction	LCD (display) indication	FI indicator light indication	Indication mode
"NO"	C00 "C"		—
"YES"	C** code is indicated from small numeral to large one.	FI indicator light turns OFF.	For each 2 sec., code is indicated.

Schematic and Routing Diagram


FI System Wiring Diagram

BENC11J11102001



Terminal Alignment of ECM Coupler

BENC11J11102002




1944H1110003-01

TERMINAL NO.	CIRCUIT	TERMINAL NO.	CIRCUIT
1	GP switch signal (GP)	27	CKP sensor signal (CKP+)
2	IAT sensor signal (IAT)	28	—
3	IAP sensor signal #1 (IAP.F)	29	—
4	STP sensor signal (STP)	30	—
5	Power source for sensors (VCC)	31	Serial data for speedometer (TECH)
6	HO2 sensor signal (HO2S)	32	Serial data for self-diagnosis
7	Clutch lever position switch (CLT)	33	—
8	CKP sensor signal (CKP-)	34	Immobilizer communication (for E-21, 24)
9	Power source for fuel injector (VM)	35	STVA signal (STVA. 1B)
10	Power source for back-up	36	STVA signal (STVA. 2B)
11	Power source	37	HO2 sensor heater (HO2SH)
12	Sensor ground (E2)	38	—
13	ECM ground (E1)	39	EVAP system purge control solenoid valve (for E-33)
14	—	40	Tachometer
15	—	41	Ground
16	—	42	Fuel injector #2 (R)
17	Immobilizer communication (for E-21, 24)	43	Ignition coil #2 (R)
18	Immobilizer indicator (for E-21, 24) / Ignition switch signal (for E-03, 28, 33)	44	STVA signal (STVA. 1A)
19	ECT sensor signal (ECT)	45	STVA signal (STVA. 2A)
20	TO sensor signal (TOS)	46	Fuel pump relay (FP Relay)
21	TP sensor signal (TP)	47	—
22	IAP sensor signal #2 (IAP.R)	48	—
23	—	49	—
24	Cooling fan relay	50	Ground
25	Starter switch signal	51	Fuel injector #1 (F)
26	Neutral switch signal	52	Ignition coil #1 (F)

Component Location


FI System Parts Location

BENC11J11103001



1C11J1110006-02

A: ECM	*G*: Secondary throttle valve actuator (STVA)
B: Combination meter	*H*: Throttle position sensor (TPS)
C: Intake air pressure sensor #2 (IAPS)	*I*: Crankshaft position sensor (CKPS)
D: EVAP system purge control solenoid valve (E-33 only)	*J*: Speedometer sensor
E: Intake air temperature sensor (IATS)	*K*: Gear position switch (GP switch)
F: Secondary throttle position sensor (STPS)	*L*: Ignition coil (Front)



IC11J1110007-01

A: ECM	*R*: Fuel pump relay (FP relay)
M: Cooling fan	*S*: Fuel injector (Front)
N: Intake air pressure sensor #1 (IAPS)	*T*: Fuel injector (Rear)
O: Fuel pump	*U*: Engine coolant temperature sensor (ECTS)
P: Tip-over sensor (TOS)	*V*: Ignition coil (Rear)
Q: Cooling fan relay	*W*: Heated oxygen sensor (HO2S)

Diagnostic Information and Procedures

Engine Symptom Diagnosis

BENC11J11104001

Condition	Possible cause	Correction / Reference Item
Engine will not start or is hard to start (Compression too low)	Valve clearance out of adjustment.	<i>Adjust.</i>
	Worn valve guide or poor seating of valve.	<i>Repair or replace.</i>
	Mistimed valve.	<i>Adjust.</i>
	Excessively worn piston rings.	<i>Replace.</i>
	Worn-down cylinder bores.	<i>Replace.</i>
	Too slow starter motor cranking.	<i>Refer to "Starting System Diagram" in Section 11 (Page 11-1).</i>
	Poor seating of spark plugs.	<i>Retighten.</i>
	Defective cylinder head gasket.	<i>Replace.</i>
Engine will not start or is hard to start (Plug not sparking)	Fouled spark plugs.	<i>Clean.</i>
	Wet spark plugs.	<i>Clean and dry.</i>
	Defective ignition coil.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Open-circuited wiring connection.	<i>Repair or replace.</i>
	Open or short in high-tension cords.	<i>Replace.</i>
Engine will not start or is hard to start (No fuel reaching the intake manifold)	Clogged fuel filter or fuel hose.	<i>Clean or replace.</i>
	Defective fuel pump.	<i>Replace.</i>
	Defective fuel pressure regulator.	<i>Replace.</i>
	Defective fuel injectors.	<i>Replace.</i>
	Defective fuel pump relay.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Open-circuited wiring connection.	<i>Check and repair.</i>
Engine will not start or is hard to start (Incorrect fuel/air mixture)	TP sensor out of adjustment.	<i>Adjust.</i>
	Defective fuel pump.	<i>Replace.</i>
	Defective fuel pressure regulator.	<i>Replace.</i>
	Defective TP sensor.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective IAP sensors.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Defective ECT sensor.	<i>Replace.</i>
	Defective IAT sensor.	<i>Replace.</i>
	Clogged ISC valve air passage way.	<i>Repair or replace.</i>
Engine idles poorly	Valve clearance out of adjustment.	<i>Adjust.</i>
	Poor seating of valves.	<i>Replace or repair.</i>
	Defective valve guides.	<i>Replace.</i>
	Worn down camshafts.	<i>Replace.</i>
	Too wide spark plug gaps.	<i>Adjust or replace.</i>
	Defective ignition coil.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Defective TP sensor.	<i>Replace.</i>
	Defective fuel pump.	<i>Replace.</i>
	Imbalanced throttle valve.	<i>Adjust.</i>
	Damaged or cranked vacuum hose.	<i>Replace.</i>
	Damaged or clogged ISC valve.	<i>Repair or replace.</i>
	ISC incorrect leaning.	<i>Reset learned value.</i>
	Dirty throttle body.	<i>Clean.</i>
	Sucking air from throttle valve or intake pipe.	<i>Retighten or replace.</i>

Condition	Possible cause	Correction / Reference Item
Engine stalls often (Incorrect fuel/air mixture)	Defective IAP sensors or circuit.	<i>Repair or replace.</i>
	Clogged fuel filter.	<i>Clean or replace.</i>
	Defective fuel pump.	<i>Replace.</i>
	Defective fuel pressure regulator.	<i>Replace.</i>
	Defective ECT sensor.	<i>Replace.</i>
	Defective thermostat.	<i>Replace.</i>
	Defective IAT sensor.	<i>Replace.</i>
	Damaged or cracked vacuum hose. Damaged or clogged ISC valve.	<i>Replace. Replace or repair.</i>
Engine stalls often (Fuel injector improperly operating)	Defective fuel injectors.	<i>Replace.</i>
	No injection signal from ECM.	<i>Repair or replace.</i>
	Open or short circuited wiring connection.	<i>Repair or replace.</i>
	Defective battery or low battery voltage.	<i>Replace or recharge.</i>
Engine stalls often (Control circuit or sensor improperly operating)	Defective ECM.	<i>Replace.</i>
	Defective fuel pressure regulator.	<i>Replace.</i>
	Defective TP sensor.	<i>Replace.</i>
	Defective IAT sensor.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective ECT sensor.	<i>Replace.</i>
	Defective fuel pump relay.	<i>Replace.</i>
	Defective ISC valve. ISC incorrect learning.	<i>Replace. Reset learned value.</i>
Engine stalls often (Engine internal parts improperly operating)	Fouled spark plug.	<i>Clean.</i>
	Defective CKP sensor or ECM.	<i>Replace.</i>
	Clogged fuel hose.	<i>Clean.</i>
	Valve clearance out of adjustment.	<i>Adjust.</i>
	Dirty throttle body.	<i>Clean.</i>
Noisy engine (Excessive valve chatter)	Too large valve clearance.	<i>Adjust.</i>
	Weakened or broken valve springs.	<i>Replace.</i>
	Worn tappet or cam surface.	<i>Replace.</i>
	Worn or burnt camshaft journal.	<i>Replace.</i>
Noisy engine (Noise seems to come from piston)	Worn down pistons or cylinders.	<i>Replace.</i>
	Combustion chamber fouled with carbon.	<i>Clean.</i>
	Worn piston pins or piston pin bore.	<i>Replace.</i>
	Worn piston rings or ring grooves.	<i>Replace.</i>
Noisy engine (Noise seems to come from cam chain)	Stretched cam chain.	<i>Replace.</i>
	Worn sprockets.	<i>Replace.</i>
	Cam chain tension adjuster not working.	<i>Repair or replace.</i>
Noisy engine (Noise seems to come from clutch)	Worn splines of countershaft or hub.	<i>Replace.</i>
	Worn teeth of clutch plates.	<i>Replace.</i>
	Distorted clutch plates, driven and drive.	<i>Replace.</i>
	Worn clutch release bearing.	<i>Replace.</i>
	Weakened clutch dampers.	<i>Replace the primary driven gear.</i>
Noisy engine (Noise seems to come from crankshaft)	Rattling bearing due to wear.	<i>Replace.</i>
	Worn or burnt big-end bearings.	<i>Replace.</i>
	Worn or burnt journal bearings.	<i>Replace.</i>
	Too large thrust clearance.	<i>Replace thrust bearing.</i>
Noisy engine (Noise seems to come from transmission)	Worn or rubbing gears.	<i>Replace.</i>
	Worn splines.	<i>Replace.</i>
	Worn or rubbing primary gears.	<i>Replace.</i>
	Worn bearings.	<i>Replace.</i>
Noisy engine (Noise seems to come from water pump)	Too much play on pump shaft bearing.	<i>Replace.</i>
	Worn or damaged impeller shaft.	<i>Replace.</i>
	Worn or damaged mechanical seal.	<i>Replace.</i>
	Contact between pump case and impeller.	<i>Replace.</i>

1A-11 Engine General Information and Diagnosis:

Condition	Possible cause	Correction / Reference Item
Engine runs poorly in high speed range (Defective engine internal/electrical parts)	Weakened valve spring.	<i>Replace.</i>
	Worn camshafts.	<i>Replace.</i>
	Valve timing out of adjustment.	<i>Adjust.</i>
	Too narrow spark plug gaps.	<i>Adjust.</i>
	Ignition not advanced sufficiently due to poorly working timing advance circuit.	<i>Replace ECM.</i>
	Defective ignition coils.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Clogged air cleaner element.	<i>Clean.</i>
	Clogged fuel hose, resulting in inadequate fuel supply to injector.	<i>Clean and prime.</i>
	Defective fuel pump.	<i>Replace.</i>
	Defective TP sensor.	<i>Replace.</i>
	Defective STP sensor or STVA.	<i>Replace.</i>
	Engine runs poorly in high speed range (Defective air flow system)	Clogged air cleaner element.
Sucking air from throttle body joint.		<i>Repair or replace.</i>
Defective ECM.		<i>Replace.</i>
Imbalancing throttle valve synchronization.		<i>Adjust.</i>
Defective STP sensor or STVA.		<i>Replace.</i>
Engine runs poorly in high speed range (Defective control circuit or sensor)	Low fuel pressure.	<i>Repair or replace.</i>
	Defective TP sensor.	<i>Replace.</i>
	Defective IAT sensor.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective GP switch.	<i>Replace.</i>
	Defective IAP sensors.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	TP sensor out of adjustment.	<i>Adjust.</i>
Defective STP sensor and/or STVA.	<i>Replace.</i>	
Engine lacks power (Defective engine internal/electrical parts)	Loss of valve clearance.	<i>Adjust.</i>
	Weakened valve springs.	<i>Replace.</i>
	Valve timing out of adjustment.	<i>Adjust.</i>
	Worn piston rings or cylinders.	<i>Replace.</i>
	Poor seating of valves.	<i>Repair.</i>
	Fouled spark plugs.	<i>Clean or replace.</i>
	Incorrect spark plugs.	<i>Adjust or replace.</i>
	Clogged fuel injectors.	<i>Replace.</i>
	TP sensor out of adjustment.	<i>Adjust.</i>
	Clogged air cleaner element.	<i>Replace.</i>
	Imbalancing throttle valve synchronization.	<i>Adjust.</i>
	Sucking air from throttle valve or vacuum hose.	<i>Retighten or replace.</i>
	Too much engine oil.	<i>Drain out excess oil.</i>
	Defective fuel pump or ECM.	<i>Replace.</i>
	Defective CKP sensor and ignition coils.	<i>Replace.</i>
Defective STP sensor or STVA.	<i>Replace.</i>	
Engine lacks power (Defective control circuit or sensor)	Low fuel pressure.	<i>Repair or replace.</i>
	Defective TP sensor.	<i>Replace.</i>
	Defective IAT sensor.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective GP sensor.	<i>Replace.</i>
	Defective IAP sensors.	<i>Replace.</i>
	TP sensor out of adjustment.	<i>Adjust.</i>
Defective STP sensor and/or STVA.	<i>Replace.</i>	

Condition	Possible cause	Correction / Reference Item
Engine overheats (Defective engine internal parts)	Heavy carbon deposit on piston crown.	<i>Clean.</i>
	Not enough oil in the engine.	<i>Add oil.</i>
	Defective oil pump or clogged oil circuit.	<i>Replace or clean.</i>
	Sucking air from intake pipes.	<i>Retighten or replace.</i>
	Use of incorrect engine oil.	<i>Change.</i>
	Defective cooling system.	<i>See radiator section.</i>
Engine overheats (Lean fuel/air mixture)	Short-circuited IAP sensors/lead wires.	<i>Repair or replace.</i>
	Short-circuited IAT sensor/lead wire.	<i>Repair or replace.</i>
	Sucking air from intake pipe joint.	<i>Repair or replace.</i>
	Defective fuel injectors.	<i>Replace.</i>
	Defective ECT sensor.	<i>Replace.</i>
Engine overheats (Other factors)	Ignition timing is too advanced due to defective timing advance system (ECT sensor, GP switch, CKP sensor or ECM).	<i>Replace.</i>
	ISC valve incorrect learning.	<i>Reset learned value.</i>
Dirty or heavy exhaust smoke	Too much engine oil.	<i>Check with inspection window, drain out excess oil.</i>
	Worn piston rings or cylinders.	<i>Replace.</i>
	Worn valve guides.	<i>Replace.</i>
	Scored or scuffed cylinder walls.	<i>Replace.</i>
	Worn valve stems.	<i>Replace.</i>
	Defective stem seal.	<i>Replace.</i>
	Worn oil ring side rails.	<i>Replace.</i>

Self-Diagnostic Procedures

BENC11J11104002


Use of Mode Select Switch


NOTE

- Do not disconnect the coupler from ECM, battery cable from battery, ECM ground wire from engine or main fuse before confirming DTC (Diagnostic Trouble Code) stored in memory. Such disconnection may erase memorized information in ECM memory.
- DTC stored in ECM memory can be checked by the special tool.
- Before checking DTC, read self-diagnosis function "User mode and dealer mode" (Refer to "Self-Diagnosis Function" (Page 1A-3).) carefully to have good understanding as to what functions are available and how to use it.
- Be sure to read "Precautions for Electrical Circuit Service" (Refer to "Precautions for Electrical Circuit Service" in Section 00 (Page 00-2).) before inspection and observe what is written there.

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Connect the special tool to the mode select coupler at the wiring harness.

Special tool

 (A): 09930-82720 (Mode selection switch)





IC11J1110008-01

- 3) Start the engine or crank the engine for more than 4 seconds.
- 4) Turn the special tool's switch ON.

- 5) Check the DTC "A" to determine the malfunction part. Refer to "DTC Table" (Page 1A-22).

Special tool

 (A): 09930-82720 (Mode selection switch)



1718H1110006-04



IC11J1110009-01

- 6) After repairing the trouble, turn OFF the ignition switch and turn ON again. If DTC is indicated (C00), the malfunction is cleared.

NOTE

- Even though DTC (C00) is indicated, the previous malfunction history DTC still remains stored in the ECM. Therefore, erase the history DTC memorized in the ECM using SDS.
- DTC is memorized in the ECM also when the lead wire coupler of any sensor is disconnected. Therefore, when a lead wire coupler has been disconnected at the time of diagnosis, erase the stored history DTC using SDS. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

- 7) Turn the ignition switch OFF and disconnect the special tool from the mode select coupler.
- 8) Reinstall the removed parts.



Use of SDS

NOTE

- Do not disconnect the coupler from ECM, battery cable from battery, ECM ground wire from the engine or main fuse before confirming DTC (Diagnostic Trouble Code) stored in memory. Such disconnection may erase the memorized information in ECM memory.
- DTC stored in ECM memory can be checked by SDS.
- Be sure to read "Precautions for Electrical Circuit Service" in Section 00 (Page 00-2) before inspection and observe what is written there.


- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Set up the SDS tools. (Refer to the SDS operation manual for further details.)

Special tool

-  (A): 09904-41010 (SUZUKI Diagnostic system set)
-  (B): 99565-01010-024 (CD-ROM Ver.24)




IC11J1110010-01



I705H1110116-03

- 3) Click the DTC inspection button (1).



I705H1110003-01

1A-15 Engine General Information and Diagnosis:

- 4) Start the engine or crank the engine for more than 4 seconds.
- 5) Check the DTC to determine the malfunction part. Refer to "DTC Table" (Page 1A-22).

NOTE

- Read the DTC (Diagnostic Trouble Code) and show data when trouble (displaying data at the time of DTC) according to instructions displayed on SDS.
 - Not only SDS is used for detecting Diagnostic Trouble Codes but also for reproducing and checking on screen the failure condition as described by customers using the trigger. (Refer to "Show Data When Trouble (Displaying Data at the Time of DTC)" (Page 1A-16).)
 - How to use trigger. (Refer to the SDS operation manual for further details.)
- 6) After repairing the trouble, clear to delete history code (Past DTC). Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).
 - 7) Close the SDS tool and turn the ignition switch OFF.
 - 8) Disconnect the SDS tool.
 - 9) Reinstall the removed parts.

Use of SDS Diagnosis Reset Procedures


BENC11J11104003

NOTE

The malfunction code is memorized in the ECM also when the lead wire coupler of any sensor is disconnected. Therefore, when a lead wire coupler has been disconnected at the time of diagnosis, erase the stored malfunction history code using SDS.


- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Set up the SDS tools. (Refer to the SDS operation manual for further details.)
- 3) After repairing the trouble, turn OFF the ignition switch and turn ON again.

- 4) Click the DTC inspection button (1).




I705H1110003-01

- 5) Check the DTC.
- 6) The previous malfunction history code (Past DTC) still remains stored in the ECM. Therefore, erase the history code memorized in the ECM using SDS tool.
- 7) Click "Clear" (2) to delete history code (Past DTC).




I944H1110006-01

- 8) Follow the displayed instructions.




I705H1110006-01



I705H1110009-01

9) Check that both "Current DTC" (3) and "Past DTC" (4) are deleted (NIL).



I705H1110008-01

- 10) Close the SDS tool and turn the ignition switch OFF.
- 11) Disconnect the SDS tool.
- 12) Reinstall the removed parts.

Show Data When Trouble (Displaying Data at the Time of DTC)

BENC11J11104004


Use of SDS
 ECM stores the engine and driving conditions (in the form of data as shown in the figure) at the moment of the detection of a malfunction in its memory. This data is called "Show data when trouble".
 Therefore, it is possible to know engine and driving conditions (e.g., whether the engine was warm or not, where the motorcycle was running or stopped) when a malfunction was detected by checking the show data when trouble. This show data when trouble function can record the maximum of two Diagnostic Trouble Codes in the ECM.
 Also, ECM has a function to store each show data when trouble for two different malfunctions in the order of occurrence as the malfunction is detected. Utilizing this function, it is possible to know the order of malfunctions that have been detected. Its use is helpful when rechecking or diagnosing a trouble.

Failure #1			
P0105 Manifold absolute pressure circuit malfunction 1			
Item	Pre-detect	Detect poi...	Post-dete...
Engine speed	0	0	0
Throttle position	27.0	27.0	27.0
Manifold absolute pressure 1	126.4	126.4	126.4
Engine coolant / oil temperature	18.0	18.0	18.0
Gear position	Neutral pos	Neutral pos	Neutral pos
Secondary throttle actuator position sensor	38.4	38.4	38.4
Manifold absolute pressure 2	101.6	101.6	101.6

I944H11101005-01


1A-17 Engine General Information and Diagnosis:

- 1) Click "Show data when trouble" (1) to display the data.



1718H1110269-02

- 2) Click the drop down button (2), either "Failure #1" or "Failure #2" can be selected.



1718H1110270-01

SDS Check

Using SDS, sample the data at the time of new and periodic vehicle inspections.

After saving the sampled data in the computer, file them by model and by user.

The periodically filed data help improve the accuracy of troubleshooting since they can indicate the condition of vehicle functions that has changed with time.


For example, when a vehicle is brought in for service but the troubleshooting of a failure is not easy, comparing the current data value to past filed data value at time of normal condition can allow the specific engine failure to be determined.

Also, in the case of a customer vehicle which is not periodically brought in for service with no past data value having been saved, if the data value of a good vehicle condition have been already saved as a master (STD), comparison between the same models helps to facilitate the troubleshooting.

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Set up the SDS tool. (Refer to the SDS operation manual for further details.)

Special tool

 : 09904-41010 (SUZUKI Diagnostic system set)


 : 99565-01010-024 (CD-ROM Ver.24)

NOTE

- Before taking the sample of data, check and clear the Past DTC.
- A number of different data under a fixed condition as shown should be saved or filed as sample.


Sample

Data sampled from cold starting through warm-up




1A-19 Engine General Information and Diagnosis:

Data at 3 000 r/min under no load




IC11J1110079-03

Data at the time of racing




IC11J1110080-03

Data of intake negative pressure during idling (100 °C)



IC11J1110081-03

Data of manifold absolute pressure operation at the time of starting




IC11J1110082-03

Example of Trouble

Three data; value 3 (current data 3), value 1 (past data 1) and value 2 (past data 2); can be made in comparison by showing them in the graph. Read the change of value by comparing the current data to the past data that have been saved under the same condition, then you may determine how changes have occurred with the passing of time and identify what problem is currently occurring.

NOTE

With DTC not output, if the engine idling speed and secondary throttle actuator position are found to be abnormal than the data saved previously, the possible cause may probably lie in the hardware side such as ISC valve air bypass passage clogged, secondary throttle valve stuck, etc.



DTC Table

Code	Malfunction Part	Remarks
C00	None	No defective part
C12 (P0335) ☞(Page 1A-27)	Crankshaft position sensor (CKPS)	Pick-up coil signal, signal generator
C13 (P1750) ☞(Page 1A-30)	Intake air pressure sensor #2 (IAPS)	For #2 cylinder
C14 (P0120-H/L) ☞(Page 1A-33)	Throttle position sensor (TPS)	*1
C15 (P0115-H/L) ☞(Page 1A-39)	Engine coolant temperature sensor (ECTS)	
C17 (P0105) ☞(Page 1A-30)	Intake air pressure sensor #1 (IAPS)	For #1 cylinder
C21 (P0110-H/L) ☞(Page 1A-43)	Intake air temperature sensor (IATS)	
C23 (P1651-H/L) ☞(Page 1A-47)	Tip-over sensor (TOS)	
C24 (P0351) ☞(Page 1A-52)	Ignition signal #1 (IG coil #1)	For #1 cylinder
C25 (P0352) ☞(Page 1A-52)	Ignition signal #2 (IG coil #2)	For #2 cylinder
C28 (P1655) ☞(Page 1A-52)	Secondary throttle valve actuator (STVA)	
C29 (P1654-H/L) ☞(Page 1A-56)	Secondary throttle position sensor (STPS)	
C31 (P0705) ☞(Page 1A-63)	Gear position signal (GP switch)	
C32 (P0201) ☞(Page 1A-66)	Injector signal #1	For #1 cylinder
C33 (P0202) ☞(Page 1A-66)	Injector signal #2	For #2 cylinder
C40 (P0505) ☞(Page 1A-68)	Idle speed control valve (ISC valve)	
C41 (P0230) ☞(Page 1A-70)	Fuel pump control system (FP control system)	Fuel pump, fuel pump relay
C42 (P1650) ☞(Page 1A-73)	Ignition switch signal (Anti-theft)	Ignition switch for E-03, 28, 33/immobilizer for E-21, 24
C44 (P0130/P0135) ☞(Page 1A-73)	Heated oxygen sensor (HO2S)	
C60 (P0480) ☞(Page 1A-78)	Cooling fan control system	Cooling fan relay
C62 (P0443) ☞(Page 1A-82)	EVAP system purge control solenoid valve (E-33 only)	
C65 (P0506/P0507) ☞(Page 1A-85)	Idle speed control system	

In the LCD (DISPLAY) panel, the malfunction code is indicated from small code to large code.

*1 To get the proper signal from the throttle position sensor, the sensor basic position is indicated in the LCD (DISPLAY) panel. The malfunction code is indicated in three digits. In front of the three digits, a line appears in any of the three positions, upper, middle or lower line. If the indication is upper or lower line when engine rpm is 1 300 r/min, slightly turn the throttle position sensor and bring the line to the middle.

Fail-Safe Function Table

FI system is provided with fail-safe function to allow the engine to start and the motorcycle to run in a minimum performance necessary even under malfunction condition.

Item	Fail-Safe Mode	Starting Ability	Running Ability
IAP sensor	Intake air pressure value is fixed to 101 kPa (760 mmHg).	"YES"	"YES"
TP sensor	The throttle opening is fixed to full open position. Ignition timing is also fixed.	"YES"	"YES"
ECT sensor	Engine coolant temperature value is fixed to 70 °C (176 °F). Cooling fan is fixed on position.	"YES"	"YES"
IAT sensor	Intake air temperature value is fixed to 25 °C (104 °F).	"YES"	"YES"
Ignition signal	#1 fuel-cut	"YES"	"YES"
	#2 fuel-cut	"YES"	"YES"
Injection signal	#1 fuel-cut	"YES"	"YES"
	#2 fuel-cut	"YES"	"YES"
STV actuator	Secondary throttle valve is fixed to full close position. When motor disconnection or lock occurs, power from ECM is shut off.	"YES"	"YES"
STP sensor	Secondary throttle valve is fixed to full close position.	"YES"	"YES"
Gear position signal	Gear position signal is fixed to 6th gear.	"YES"	"YES"
HO2 sensor	Feedback compensation is inhibited. (Air/fuel ratio is fixed to normal.)	"YES"	"YES"
ISC valve	When motor disconnection or lock occurs, power from ECM is shut off.	"YES"	"YES"
EVAP system purge control solenoid valve (E-33 only)	ECM stops controlling EVAP system purge control solenoid valve.	"YES"	"YES"

The engine can start and can run even if the signal in the table is not received from each sensor. But, the engine running condition is not complete, providing only emergency help (by fail-safe circuit). In this case, it is necessary to bring the motorcycle to the workshop for complete repair.

When two ignition signals or two injector signals are not received by ECM, the fail-safe circuit can not work and ignition or injection is stopped.

FI System Troubleshooting

BENC11J11104008

Customer Complaint Analysis

Record details of the problem (failure, complaint) and how it occurred as described by the customer. For this purpose, use of such an inspection form such as following will facilitate collecting information to the point required for proper analysis and diagnosis.

NOTE

This form is a standard sample. The form should be modified according to conditions and characteristic of each market.

EXAMPLE: CUSTOMER PROBLEM INSPECTION FORM

User name:	Model:	VIN:	
Date of issue:	Date Reg.:	Date of problem:	Mileage:

Malfunction indicator light condition (LED)	<input type="checkbox"/> Always ON / <input type="checkbox"/> Sometimes ON / <input type="checkbox"/> Always OFF / <input type="checkbox"/> Good condition
Malfunction display/code (LCD)	User mode: <input type="checkbox"/> No display / <input type="checkbox"/> Malfunction display ()
	Dealer mode: <input type="checkbox"/> No code / <input type="checkbox"/> Malfunction code ()

PROBLEM SYMPTOMS	
<input type="checkbox"/> Difficult Starting <input type="checkbox"/> No cranking <input type="checkbox"/> No initial combustion <input type="checkbox"/> No combustion <input type="checkbox"/> Poor starting at <input type="checkbox"/> cold / <input type="checkbox"/> warm / <input type="checkbox"/> always <input type="checkbox"/> Other	<input type="checkbox"/> Poor Driveability <input type="checkbox"/> Hesitation on acceleration <input type="checkbox"/> Back fire / <input type="checkbox"/> After fire <input type="checkbox"/> Lack of power <input type="checkbox"/> Surging <input type="checkbox"/> Abnormal knocking <input type="checkbox"/> Engine rpm jumps briefly <input type="checkbox"/> Other
<input type="checkbox"/> Poor Idling <input type="checkbox"/> Poor fast Idle <input type="checkbox"/> Abnormal idling speed <input type="checkbox"/> High / <input type="checkbox"/> Low) (r/min) <input type="checkbox"/> Unstable <input type="checkbox"/> Hunting (r/min to r/min) <input type="checkbox"/> Other	<input type="checkbox"/> Engine Stall when <input type="checkbox"/> Immediately after start <input type="checkbox"/> Throttle valve is opened <input type="checkbox"/> Throttle valve is closed <input type="checkbox"/> Load is applied <input type="checkbox"/> Other
<input type="checkbox"/> OTHERS:	

MOTORCYCLE/ENVIRONMENTAL CONDITION WHEN PROBLEM OCCURS	
Environmental condition	
Weather	<input type="checkbox"/> Fair / <input type="checkbox"/> Cloudy / <input type="checkbox"/> Rain / <input type="checkbox"/> Snow / <input type="checkbox"/> Always / <input type="checkbox"/> Other
Temperature	<input type="checkbox"/> Hot / <input type="checkbox"/> Warm / <input type="checkbox"/> Cool / <input type="checkbox"/> Cold (°C / °F) / <input type="checkbox"/> Always
Frequency	<input type="checkbox"/> Always / <input type="checkbox"/> Sometimes (times / day, month) / <input type="checkbox"/> Only once <input type="checkbox"/> Under certain condition
Road	<input type="checkbox"/> Urban / <input type="checkbox"/> Suburb / <input type="checkbox"/> Highway / <input type="checkbox"/> Mountainous (<input type="checkbox"/> Uphill / <input type="checkbox"/> Downhill) <input type="checkbox"/> Tarmacadam / <input type="checkbox"/> Gravel / <input type="checkbox"/> Other
Motorcycle condition	
Engine condition	<input type="checkbox"/> Cold / <input type="checkbox"/> Warming up phase / <input type="checkbox"/> Warmed up / <input type="checkbox"/> Always / <input type="checkbox"/> Other at starting <input type="checkbox"/> Immediately after start / <input type="checkbox"/> Racing without load / <input type="checkbox"/> Engine speed (r/min)
Motorcycle condition	During driving: <input type="checkbox"/> Constant speed / <input type="checkbox"/> Accelerating / <input type="checkbox"/> Decelerating <input type="checkbox"/> Right hand corner / <input type="checkbox"/> Left hand corner <input type="checkbox"/> At stop / <input type="checkbox"/> Motorcycle speed when problem occurs (km/h, mile/h) <input type="checkbox"/> Other:

Visual Inspection

Prior to diagnosis using the mode select switch or SDS, perform the following visual inspections. The reason for visual inspection is that mechanical failures (such as oil leakage) cannot be displayed on the screen with the use of mode select switch or SDS.

- Engine oil level and leakage. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).
- Engine coolant level and leakage. Refer to "Cooling Circuit Inspection" in Section 1F (Page 1F-5).
- Fuel level and leakage. Refer to "Fuel Line Inspection" in Section 0B (Page 0B-10).
- Clogged air cleaner element. Refer to "Air Cleaner Element Inspection and Cleaning" in Section 0B (Page 0B-3).
- Battery condition.
- Throttle cable play. Refer to "Throttle Cable Play Inspection and Adjustment" in Section 0B (Page 0B-12).
- Vacuum hose looseness, bend and disconnection.
- Broken fuse.
- FI indicator light operation. Refer to "Combination Meter Inspection" in Section 9C (Page 9C-3).
- Each warning indicator light operation. Refer to "Combination Meter Inspection" in Section 9C (Page 9C-3).
- Speedometer operation. Refer to "Speedometer Inspection" in Section 9C (Page 9C-7).
- Exhaust gas leakage and noise. Refer to "Exhaust System Construction" in Section 1K (Page 1K-2).
- Each coupler disconnection.
- Clogged radiator fins. Refer to "Radiator Inspection and Cleaning" in Section 1F (Page 1F-5).

Malfunction Code and Defective Condition Table

BENC11J11104009

Malfunction Code	Detected Item	Detected Failure Condition	Check For		
C00	NO FAULT	—	—		
C12	CKP sensor	The signal does not reach ECM for 3 seconds or more, after receiving the starter signal.	CKP sensor wiring and mechanical parts CKP sensor, lead wire/coupler connection		
P0335					
C13/C17	IAP sensor	The sensor should produce following voltage. 0.1 V ≤ Sensor voltage < 4.8 V In other than the above range, C13 (P1750) or C17 (P0105) is indicated.	IAP sensor, lead wire/coupler connection		
P1750/P0105					
C14	TP sensor	The sensor should produce following voltage. 0.1 V ≤ Sensor voltage < 4.8 V In other than the above range, C14 (P0120) is indicated.	TP sensor, lead wire/coupler connection		
P0120				H	TP sensor circuit shorted to VCC or ground circuit open
				L	TP sensor circuit open or shorted to ground or VCC circuit open
C15	ECT sensor	The sensor voltage should be the following. 0.1 V ≤ Sensor voltage < 4.85 V In other than the above range, C15 (P0115) is indicated.	ECT sensor, lead wire/coupler connection		
P0115				H	ECT sensor circuit open or ground circuit open
				L	ECT sensor circuit shorted to ground
C21	IAT sensor	The sensor voltage should be the following. 0.1 V ≤ Sensor voltage < 4.6 V In other than the above range, C21 (P0110) is indicated.	IAT sensor, lead wire/coupler connection		
P0110				H	IAT sensor circuit open or ground circuit open
				L	IAT sensor circuit shorted to ground

Malfunction Code	Detected Item	Detected Failure Condition	Check For	
C23	TO sensor	The sensor voltage should be the following. $0.2\text{ V} \leq \text{Sensor voltage} < 4.8\text{ V}$ In other than the above value, C23 (P1651) is indicated.	TO sensor, lead wire/coupler connection	
P1651		H	Sensor voltage is higher than specified value.	TO sensor circuit shorted to VCC or ground circuit open
		L	Sensor voltage is lower than specified value.	TO sensor circuit open or shorted to ground or VCC circuit open
C24/C25 P0351/P0352	Ignition signal	CKP sensor (pick-up coil) signal is produced, but signal from ignition coil is interrupted 8 times or more continuously. In this case, the code C24 (P0351) or C25 (P0352) is indicated.	Ignition coil, wiring/coupler connection, power supply from the battery	
C28 P1655	STV actuator	When no actuator control signal is supplied from the ECM, communication signal does not reach ECM or operation voltage does not reach STVA motor, C28 (P1655) is indicated. STVA can not operate properly.	STVA motor, STVA lead wire/coupler connection	
C29	STP sensor	The sensor should produce following voltage. $0.1\text{ V} < \text{Sensor voltage} < 4.8\text{ V}$ In other than the above range, C29 (P1654) is indicated.	STP sensor, lead wire/coupler connection	
P1654		H	Sensor voltage is higher than specified value.	STP sensor circuit shorted to VCC or ground circuit open
		L	Sensor voltage is lower than specified value.	STP sensor circuit open or shorted to ground or VCC circuit open
C31 P0705	Gear position signal	Gear position signal voltage should be higher than the following. Gear position sensor voltage $\geq 0.2\text{ V}$ If lower than the above value for 3 seconds or more, C31 (P0705) is indicated.	GP switch, wiring/coupler connection, gearshift cam, etc.	
C32/C33 P0201/P0202	Fuel injector	CKP sensor (pickup coil) signal is produced, but fuel injector signal is interrupted 8 times or more continuously. In this case, the code C32 (P0201), C33 (P0202) is indicated.	Fuel injector, wiring/coupler connection, power supply to the injector	
C40 P0505	ISC valve	ISC valve circuit malfunction.	Secondary throttle valve is fixed in opening position.	
C41 P0230	FP relay	No voltage is applied to the fuel pump, although fuel pump relay is turned ON, or voltage is applied to fuel pump although fuel pump relay is turned OFF.	Fuel pump relay, lead wire/coupler connection, power source to fuel pump relay and fuel injectors	
C42 P1650	Ignition switch	Ignition switch signal is not input to the ECM. *When the I.D. agreement is not verified. *ECM does not receive communication signal from the immobilizer antenna.	Ignition switch, lead wire/coupler, etc. *Immobilizer/anti-theft system	
C44 P0130	HO2 sensor	After engine is started few minutes. (Sensor output voltage $\geq 2.5\text{ V}$) Engine is cold and stopped. (Sensor output voltage $< 0.1\text{ V}$) In other than the above value, C44 (P0130) is indicated.	HO2 sensor is circuit open or shorted to ground	
C44		The heater can not operate so that heater operation voltage is not supply to the oxygen heater circuit, C44 (P0135) is indicated.	HO2 sensor lead wire/coupler connection	
P0135			Battery voltage supply to the HO2 sensor	

1A-27 Engine General Information and Diagnosis:

Malfunction Code	Detected Item	Detected Failure Condition	Check For
C60 P0480	Cooling fan relay	Cooling fan relay signal is not input to ECM.	Cooling fan relay, lead wire/ coupler connection
C62 P0443	EVAP system purge control solenoid valve (E-33 only)	EVAP system purge control solenoid valve voltage is not input to ECM.	EVAP system purge control solenoid valve, lead wire/ coupler connection
C65 P0506	ISC valve (Idle speed)	Idle speed dropped lower than desired idle speed by more than specified range.	Air passage clogged STVA is fixed STVA preset position is incorrect
C65 P0507		Idle speed rose higher than desired idle speed by more than specified range.	STVA is fixed STVA preset position is incorrect

*: Immobilizer system equipped model only. (E-21, 24)


DTC "C12" (P0335): CKP Sensor Circuit Malfunction

BENC11J11104010

Detected Condition and Possible Cause


Detected Condition	Possible Cause
The signal does not reach ECM for 3 seconds. or more, after receiving the starter signal.	<ul style="list-style-type: none"> • Metal particles or foreign material being stuck on the CKP sensor and rotor tip. • CKP sensor circuit open or short. • CKP sensor malfunction. • ECM malfunction.

Wiring Diagram



IC11J1110011-01

ECM coupler (Harness side)



IS44H1110008-01

Troubleshooting

NOTICE

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

Step 1

- 1) Turn the ignition switch OFF.
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 3) Disconnect the CKP sensor lead wire coupler (1).



IC11J1110012-04

- 4) Turn the ignition switch ON, and measure the voltage between the W wire and ground.

Special tool

Tool (A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage (V)

CKP sensor input voltage

0.5 V or more

(+) terminal: W - (-) terminal: Ground



IC11J1110013-02

Is the voltage OK?

- Yes Go to Step 2.
- No Open or short circuit in the W wire.

Troubleshooting


NOTICE

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.

Step 2

- 1) Turn the ignition switch OFF.
- 2) Disconnect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 3) Insert the needle pointed probes to the lead wire coupler.
- 4) Check there is continuity between the W wire "A" and ECM terminal "27", G/BI wire "B" and ECM terminal "8". Also, there is no continuity among the W wire "A" and ECM terminals, G/BI wire "B" and ECM terminals.


Special tool

 (A): 09900-25008 (Multi circuit tester set)

 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity (•)))




- 5) If OK, check there is no continuity between the W wire "A" and ground, G/BI wire "B" and ground.

Special tool

 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•)))




Is the continuity OK?

- Yes Go to Step 3.
- No Open or short circuit in the W or G/BI wire.

Step 3

- 1) Measure the CKP sensor resistance.

Special tool


 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Resistance (Ω)

CKP sensor resistance

130 – 240 Ω (W – G)



IC11J1110016-03

Is the resistance OK?

- Yes Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- No
 - Inspect that metal particles or foreign material stuck on the CKP sensor and rotor tip.
 - If there are no metal particles and foreign material, then replace the CKP sensor with a new one. Refer to "CKP Sensor Removal and Installation" in Section 1C (Page 1C-1).


DTC "C13" (P1750) or "C17" (P0105): IAP Sensor Circuit Malfunction

BENC11J11104011

Detected Condition and Possible Cause


Detected Condition		Possible Cause
C13/P1750	IAP sensor voltage is not within the following range. 0.1 V ≤ Sensor voltage < 4.8 V	<ul style="list-style-type: none"> • Clogged vacuum passage between throttle body and IAP sensor (#2). • Air being drawn from vacuum passage between throttle body and IAP sensor (#2). • IAP sensor (#2) circuit open or short. • IAP sensor (#2) malfunction. • ECM malfunction.
C17/P0105	<p>NOTE</p> <p>Note that atmospheric pressure varies depending on weather conditions as well as altitude. Take that into consideration when inspecting voltage.</p>	

Wiring Diagram



I944H1110013-04

ECM coupler (Harness side)



I944H1110014-01

Troubleshooting

NOTICE


When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

Step 1

- 1) Turn the ignition switch OFF.
- 2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 3) Check the IAP sensor couplers (#1 cylinder (1) or #2 cylinder (2)) for loose or poor contacts. If OK, then measure the IAP sensor input voltage.



IC11J1110017-01

- 4) Disconnect the IAP sensor couplers.
- 5) Turn the ignition switch ON.
- 6) Measure the voltage between the R wire and ground. If OK, then measure the voltage between the R wire and B/Br wire.

Special tool

(A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage (V)

IAP sensor input voltage

4.5 – 5.5 V

(+) terminal: R – (-) terminal: Ground, (+) terminal: R – (-) terminal: B/Br)



IB23H1110016-05

Is the voltage OK?

- Yes Go to Step 2.
 No Open or short circuit in the R or B/Br wire.

Step 2


- 1) Turn the ignition switch OFF.
- 2) Disconnect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 3) Insert the needle pointed probes to the lead wire coupler.
- 4) Check there is no continuity between the R wire "A" and ground. Also the R wire "A" and another wire.

Special tool

(A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•))



IG44H1110189-01

Is there continuity?

- Yes Go to Step 3.
 No Short circuit in the R wire.

Step 3

- 1) Insert the needle pointed probes to the lead wire coupler.
- 2) Check there is continuity between the G/B wire "A" and ECM terminal "3" (#1). Also the G/Y wire "B" and ECM terminal "22" (#2).

Special tool


(A): 09900-25008 (Multi circuit tester set)

(B): 09900-25009 (Needle-point probe set)


Tester knob indication

Continuity (•))

#1 Cylinder



#2 Cylinder




- 3) If there is continuity, check there is no continuity between the G/B wire "A" and ground, G/Y wire "B" and ground. Also the G/B wire "A" and another wire, G/Y wire "B" and another wire.

Special tool

(A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•)))



Is the continuity OK?

- Yes Go to Step 4.
 No • Open or short circuit in the G/B wire (#1 cylinder).
 • Open or short circuit in the G/Y wire (#2 cylinder).

Step 4

- 1) Remove the IAP sensor. Refer to "IAP Sensor Removal and Installation" in Section 1C (Page 1C-2).
- 2) Connect the vacuum pump gauge to the vacuum port of the IAP sensor.
- 3) Arrange 3 new 1.5 V batteries in series (1) (check that total - voltage is 4.5 – 5.0 V) and connect (-) terminal to ground - terminal "A" and (+) terminal to the VCC terminal "B".
- 4) Check the voltage between Vout terminal "C" and ground.
 Also, check if voltage reduces when vacuum is applied up to 400 mmHg by using vacuum pump gauge.


Special tool

(A): 09917-47011 (Vacuum pump gauge set)

(B): 09900-25008 (Multi circuit tester set)

Tester knob indication

Voltage (---)



ALTITUDE (Reference)		ATMOSPHERIC PRESSURE		OUTPUT VOLTAGE
m	ft	kPa	mmHg	V
0 - 610	0 - 2 000	100 - 95	760 - 708	3.4 - 4.0
611 - 1 524	2 001 - 5 000	94 - 86	707 - 635	3.0 - 3.7
1 525 - 2 438	5 001 - 8 000	85 - 77	634 - 568	2.6 - 3.4
2 439 - 3 048	8 001 - 10 000	76 - 70	567 - 526	2.4 - 3.1

I822H1110025-01

Is the voltage OK?

- Yes Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- No If check result is not satisfactory, replace the IAP sensor with a new one.


DTC "C14" (P0120-H/L): TP Sensor Circuit Malfunction

BENC11J11104012

Detected Condition and Possible Cause


Detected Condition		Possible Cause
C14	Output voltage is not within the following range. $0.1\text{ V} \leq \text{Sensor voltage} < 4.8\text{ V}$	<ul style="list-style-type: none"> TP sensor maladjusted. TP sensor circuit open or short. TP sensor malfunction. ECM malfunction.
P0120	H Sensor voltage is higher than specified value.	<ul style="list-style-type: none"> TP sensor circuit is shorted to VCC or ground circuit is open. TP sensor circuit is open or shorted to ground or VCC circuit is open or shorted to ground.
	L Sensor voltage is lower than specified value.	

Wiring Diagram



I944H1110019-04

ECM coupler (Harness side)



I944H1110020-01

Troubleshooting

NOTICE

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.


NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

C14 (Use of mode select switch)

Step 1

- 1) Turn the ignition switch OFF.
- 2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 3) Check the TP sensor coupler (1) for loose or poor contacts.
If OK, then measure the TP sensor input voltage.



IC11J1110018-01

- 4) Disconnect the TP sensor coupler.
- 5) Turn the ignition switch ON.
- 6) Measure the input voltage between the R wire "A" and ground.
If OK, then measure the input voltage between the R wire "A" and B/Br wire "B".

Special tool

(A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage ()

TP sensor input voltage

4.5 – 5.5 V

((+) terminal: R – (-) terminal: Ground, (+) terminal: R – (-) terminal: B/Br)



IG44H1110119-01

Is the voltage OK?

- Yes Go to Step 2.
No Open or short circuit in the R or B/Br wire.

Step 2


- 1) Turn the ignition switch OFF.
- 2) Disconnect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 3) Check there is no continuity between the R wire "A" and ground.
Also, the R wire "A" and another wire.

Special tool

(A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity ()



IG44H1110120-01

Is there no continuity?

- Yes Go to Step 3.
No Short circuit in the R wire.

Step 3

- 1) Check the continuity between the P/W wire "A" and terminal "21".

Special tool


(A): 09900-25008 (Multi circuit tester set)

(B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity ()


ECM coupler (Harness side)



IG44H1110123-01


- If the sound is heard from the tester, then check there is no continuity among the P/W wire "A" and another wire.

Special tool

 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•••)



I944H1110124-01


Is the continuity OK?

- Yes Go to Step 4.
- No Open or short circuit in the P/W wire.

Step 4

- Turn the ignition switch OFF.
- Connect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- Connect the special tool between the TP sensor and its coupler.
- Turn the ignition switch ON.
- Measure the TP sensor output voltage between the P/W wire terminal (+) and B/Br wire terminal (-) with turning the throttle grip open and close.

Special tool

 (C): 09900-28630 (TPS test wire harness)


 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Voltage (---)

TP sensor output voltage

Throttle valve is closed: Approx. 1.1 V
 Throttle valve is opened: Approx. 4.3 V
 ((+) terminal: P/W – (-) terminal: B/Br)



I944H1110028-01


Is the voltage OK?

- Yes Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- No If check result is not satisfactory, replace TP sensor with a new one. Refer to "Throttle Body Disassembly and Assembly" in Section 1D (Page 1D-11).

P0120-H (Use of SDS)

Step 1

- 1) Turn the ignition switch OFF.
- 2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 3) Check the TP sensor coupler (1) for loose or poor contacts.
If OK, then check the TP sensor lead wire continuity.



IC11J1110018-01

- 4) Disconnect the TP sensor coupler.
- 5) Turn the ignition switch ON.
- 6) Measure the input voltage between the R wire "A" and B/Br wire "B".
If OK, then measure the input voltage between the R wire "A" and B/Br wire "B".

Special tool

 (A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage (V)

TP sensor input voltage

4.5 – 5.5 V

((+) terminal: R – (-) terminal: Ground, (+) terminal: R – (-) terminal: B/Br)



1944H1110121-01


Is the voltage OK?

- Yes Go to Step 2.
No Open circuit in the B/Br wire.

Step 2


- 1) Disconnect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 2) Check there is no continuity among the P/W wire "A" and another wire.

Special tool

 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•••)



1944H1110124-01

Is the continuity OK?

- Yes Go to Step 3.
No Short circuit in the P/W wire.

Step 3

- 1) Turn the ignition switch OFF.
- 2) Connect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 3) Connect the special tool between the TP sensor and its coupler.
- 4) Turn the ignition switch ON.
- 5) Measure the TP sensor output voltage between the P/W wire terminal (+) and B/Br wire terminal (-) with turning the throttle grip open and close.

Special tool

-  (C): 09900-28630 (TPS test wire harness)
-  : 09900-25008 (Multi circuit tester set)

Tester knob indication


Voltage (---)

TP sensor output voltage

Throttle valve is closed: Approx. 1.1 V

Throttle valve is opened: Approx. 4.3 V

(+) terminal: P/W - (-) terminal: B/Br



1944H1110028-01


Is the voltage OK?

- Yes Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- No If check result is not satisfactory, replace TP sensor with a new one. Refer to "Throttle Body Disassembly and Assembly" in Section 1D (Page 1D-11).

P0120-L (Use of SDS)

Step 1



- 1) Turn the ignition switch OFF.
- 2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 3) Check the TP sensor coupler (1) for loose or poor contacts. If OK, then check the TP sensor lead wire continuity.



IC11J1110018-01

- 4) Disconnect the TP sensor coupler and ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 5) Check the continuity between the R wire "A" and terminal "5".


Special tool

-  (A): 09900-25008 (Multi circuit tester set)
-  (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity (•))


ECM coupler (Harness side)




IC11J1110019-01


- 6) If the sound is heard from the tester, then check there is no continuity between the R wire "A" and ground.
Also the R wire "A" and another wire.

Special tool

 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity ()



1944H1110122-01


Is there no continuity?

- Yes Go to Step 2.
No Open or short circuit in the R wire.

Step 2


- 1) Check the continuity between the P/W wire "A" and terminal "21".

Special tool


 (A): 09900-25008 (Multi circuit tester set)

 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity ()


ECM coupler (Harness side)




1944H1110123-01


- 2) If the sound is heard from the tester, then check there is no continuity among the P/W wire "A" and another wire.

Special tool

 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity ()



1944H1110124-01


Is the continuity OK?

- Yes Go to Step 3.
No Open or short circuit in the P/W wire.

Step 3


- 1) Turn the ignition switch OFF.
- 2) Connect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 3) Connect the special tool between the TP sensor and its coupler.
- 4) Turn the ignition switch ON.
- 5) Measure the TP sensor output voltage between the P/W wire terminal (+) and B/Br wire terminal (-) with turning the throttle grip open and close.

Special tool

 (C): 09900-28630 (TPS test wire harness)


 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Voltage ()

TP sensor output voltage

Throttle valve is closed: Approx. 1.1 V
Throttle valve is opened: Approx. 4.3 V
(+) terminal: P/W - (-) terminal: B/Br



1944H1110028-01

Is the voltage OK?

- Yes Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- No If check result is not satisfactory, replace TP sensor with a new one. Refer to "Throttle Body Disassembly and Assembly" in Section 1D (Page 1D-11).


DTC "C15" (P0115-H/L): ECT Sensor Circuit Malfunction

BENC11J11104013

Detected Condition and Possible Cause


Detected Condition		Possible Cause
C15	Output voltage is not with in the following range. $0.1\text{ V} \leq \text{Sensor voltage} < 4.85\text{ V}$	<ul style="list-style-type: none"> ECT sensor circuit open or short. ECT sensor malfunction. ECM malfunction.
P0115	H Sensor voltage is higher than specified value.	<ul style="list-style-type: none"> ECT sensor circuit is open or shorted to VCC or ground circuit open.
	L Sensor voltage is lower than specified value.	<ul style="list-style-type: none"> ECT sensor circuit shorted to ground.

Wiring Diagram



1944H1110029-01

ECM coupler (Harness side)



1944H1110030-01

Troubleshooting

NOTICE

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

C15 (Use of mode select switch)

Step 1

- 1) Turn the ignition switch OFF.
- 2) Check the ECT sensor coupler (1) for loose or poor contacts.
If OK, then measure the ECT sensor input voltage.



IC11J1110020-02

- 3) Disconnect the ECT sensor coupler and turn the ignition switch ON.
- 4) Measure the input voltage between the B/BI wire "A" and ground.
Also the B/BI wire "A" and B/Br wire "B".

Special tool

(A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage (V)

ECT sensor input voltage

4.5 – 5.5 V

((+) terminal: B/BI – (-) terminal: Ground, (+) terminal: B/BI – (-) terminal: B/Br)



IC11J1110021-02

- 5) If OK, then check there is ECT sensor lead wire no continuity.
- 6) Turn the ignition switch OFF.
- 7) Disconnect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).


- 8) Check there is no continuity between the B/BI wire "A" and ground, B/Br wire "B" and ground, B/BI wire "A" and B/Br wire "B".

Special tool


(A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•))



IC11J1110022-01



IC11J1110023-02

Is there no continuity?

- | | |
|-----|--|
| Yes | Go to Step 2. |
| No | Open or short circuit in the B/BI wire or B/Br wire. |

P0115-H (Use of SDS)

Step 1

- 1) Turn the ignition switch OFF.
- 2) Check the ECT sensor coupler (1) for loose or poor contacts.
If OK, then check the ECT sensor lead wire continuity.



IC11J1110020-02

- 3) Disconnect the ECT sensor coupler and turn the ignition switch ON.
- 4) Measure the input voltage between the B/BI wire and ground.
If OK, then measure the input voltage between the B/BI wire and B/Br wire.

Special tool

(A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage (---)

ECT sensor input voltage

4.5 – 5.5 V

(+) terminal: B/BI – (-) terminal: Ground, (+) terminal: B/BI – (-) terminal: B/Br



IC11J1110024-02

Is the voltage OK?

- Yes Go to Step 2.
No Open or short circuit in the B/BI or B/Br wire.

P0115-L (Use of SDS)

Step 1

- 1) Turn the ignition switch OFF.
- 2) Check the ECT sensor coupler (1) for loose or poor contacts.
If OK, then check the ECT sensor lead wire continuity.



IC11J1110020-02


- 3) Disconnect the ECT sensor coupler and ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 4) Check there is no continuity between the B/BI wire "A" and ground, B/Br wire "B" and ground, B/BI wire "A" and B/Br wire "B".

Special tool


(A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•))



IC11J1110075-01



IC11J1110023-02


Is there no continuity?

- Yes Go to Step 2.
No Short circuit in the B/BI or B/Br wire.

Step 2

- 1) Turn the ignition switch OFF.
- 2) Measure the ECT sensor resistance.

Special tool


 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Resistance (Ω)

ECT sensor resistance

Approx. 2.45 k Ω at 20 °C (68 °F)
(Terminal – Terminal)



I944H1110036-01

NOTE

Refer to "ECT Sensor Inspection" in Section 1C (Page 1C-4) for details.

Is the resistance OK?

- | | |
|-----|--|
| Yes | Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1). |
| No | Replace the ECT sensor with a new one. Refer to "ECT Sensor Removal and Installation" in Section 1C (Page 1C-3). |


DTC "C21" (P0110-H/L): IAT Sensor Circuit Malfunction

BENC11J11104014


Detected Condition and Possible Cause

Detected Condition		Possible Cause
C21	Output voltage is not with in the following range. $0.1\text{ V} \leq \text{Sensor voltage} < 4.6\text{ V}$	<ul style="list-style-type: none"> IAT sensor circuit open or short. IAT sensor malfunction. ECM malfunction. IAT sensor circuit open or shorted to VCC or ground circuit open. IAT sensor circuit shorted to ground.
P0110	H Sensor voltage is higher than specified value.	
	L Sensor voltage is lower than specified value.	

Wiring Diagram



ECM coupler (Harness side)



Troubleshooting

NOTICE

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.


NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

C21 (Use of mode select switch)

Step 1

- 1) Turn the ignition switch OFF.
- 2) Remove the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 3) Check the IAT sensor coupler (1) for loose or poor contacts.
If OK, then measure the IAT sensor input voltage.



IC11J1110025-01

- 4) Disconnect the IAT sensor coupler and turn the ignition switch ON.
- 5) Measure the input voltage between the Dg wire "A" and ground.
If OK, then measure the input voltage between the Dg wire "A" and B/Br wire "B".

Special tool

(A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage ()

IAT sensor input voltage

4.5 – 5.5 V

((+) terminal: Dg – (-) terminal: Ground, (+) terminal: Dg – (-) terminal: B/Br)



I944H1110173-01


- 6) If OK, then check there is IAT sensor lead wire no continuity.
- 7) Turn the ignition switch OFF.
- 8) Disconnect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 9) Check there is no continuity between the Dg wire "A" and ground, B/Br wire "B" and ground, Dg wire "A" and B/Br wire "B".

Special tool


(A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity ()



I944H1110129-01



I944H1110130-01


Is there no continuity?

- | | |
|-----|--|
| Yes | Go to Step 2. |
| No | Open or short circuit in the Dg wire or B/Br wire. |

P0110-H (Use of SDS)

Step 1

- 1) Turn the ignition switch OFF.
- 2) Remove the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 3) Check the IAT sensor coupler (1) for loose or poor contacts.
If OK, then check the IAT sensor lead wire continuity.



IC11J1110025-01

- 4) Disconnect the IAT sensor coupler and turn the ignition switch ON.
- 5) Measure the input voltage between the Dg wire "A" and ground.
If OK, then measure the input voltage between the Dg wire "A" and B/Br wire "B".

Special tool

(A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage (V)

IAT sensor input voltage

4.5 – 5.5 V

((+) terminal: Dg – (-) terminal: Ground, (+) terminal: Dg – (-) terminal: B/Br)



8944H1110174-01

Is the voltage OK?

- Yes Go to Step 2.
- No Open or short circuit in the Dg or B/Br wire.

P0110-L (Use of SDS)

Step 1

- 1) Turn the ignition switch OFF.
- 2) Remove the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 3) Check the IAT sensor coupler (1) for loose or poor contacts.
If OK, then check the IAT sensor lead wire continuity.




IC11J1110025-01

- 4) Disconnect the IAT sensor coupler and ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).


- 5) Check there is no continuity between the Dg wire "A" and ground, B/Br wire "B" and ground, Dg wire "A" and B/Br wire "B".

Special tool


 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•)))



1944H1110132-01



1944H1110133-01


Is there no continuity?

- Yes Go to Step 2.
- No Short circuit in the Dg wire.

Step 2

- 1) Turn the ignition switch OFF.
- 2) Measure the IAT sensor resistance.

Special tool


 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Resistance (Ω)

IAT sensor resistance

Approx. 2.6 k Ω at 20 °C (68 °F)
(Terminal – Terminal)



1C11J1110026-01

NOTE

IAT sensor resistance measurement method is the same way as that of the ECT sensor. Refer to "ECT Sensor Inspection" in Section 1C (Page 1C-4).

Is the resistance OK?

- Yes Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- No Replace the IAT sensor with a new one. Refer to "IAT Sensor Removal and Installation" in Section 1C (Page 1C-3).


DTC "C23" (P1651-H/L): TO Sensor Circuit Malfunction

BENC11J11104015

Detected Condition and Possible Cause


Detected Condition		Possible Cause
C23	The sensor voltage should be the following. $0.2\text{ V} \leq \text{Sensor voltage} < 4.6\text{ V}$	<ul style="list-style-type: none"> • TO sensor circuit open or short. • TO sensor malfunction. • ECM malfunction.
P1651	H Sensor voltage is higher than specified value.	• TO sensor circuit is open or shorted to VCC or ground circuit open.
	L Sensor voltage is lower than specified value.	• TO sensor circuit is shorted to ground or VCC circuit open or shorted ground.

Wiring Diagram



I944H1110045-01

ECM coupler (Harness side)



I944H1110046-01

Troubleshooting

NOTICE

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.


NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

C23 (Use of mode select switch)

Step 1

- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Check the TO sensor coupler (1) for loose or poor contacts.
If OK, then measure the TO sensor voltage.



IC11J1110027-03

- 4) Disconnect the TO sensor coupler.
- 5) Turn the ignition switch ON.
- 6) Measure the TO sensor input voltage between the R wire "A" and B/Br wire "B".

Special tool

(A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage (V)

TO sensor input voltage

4.5 – 5.5 V

((+) Terminal: R – (-) terminal: B/Br)



1944H1110134-01


- 7) If OK, then measure the voltage between the R wire "A" and ground.

Special tool

(A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Voltage (V)



1944H1110135-01

Is the voltage OK?

- Yes Go to Step 2.
- No Open or short circuit in the R wire or B/Br wire.

Step 2


- 1) Turn the ignition switch OFF.
- 2) Disconnect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 3) Check there is no continuity among the R wire "A" and another wire.

Special tool

(A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•))



1944H1110136-01

Is there no continuity?

- Yes Go to Step 3.
- No Short circuit in the R wire.

P1651-H (Use of SDS)

Step 1

- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Check the TO sensor coupler (1) for loose or poor contacts.
If OK, then check the TO sensor lead wire continuity.



IC11J1110027-03

- 4) Disconnect the TO sensor coupler and ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 5) Insert the needle pointed probes to the lead wire coupler.
- 6) Check the continuity between the B/Br wire "A" and terminal "12".


Special tool

- (A): 09900-25008 (Multi circuit tester set)
- (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity (●))

ECM coupler (Harness side)



IC11J1110028-01

Is the continuity OK?

- Yes Go to Step 2.
- No Open circuit in the B/Br wire.

Step 2

- 1) Insert the needle pointed probes to the lead wire coupler.
- 2) Check the continuity between the Br/W wire "A" and terminal "20".


Special tool

- (A): 09900-25008 (Multi circuit tester set)
- (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity (●))

ECM coupler (Harness side)



IG44H1110138-01


- 3) If the sound is heard from the tester, then check there is no continuity among the Br/W wire "A" and another wire.

Special tool

- (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (●))



IC11J1110029-01


Is there no continuity?

- Yes Go to Step 3.
- No Open or short circuit in the Br/W wire.

P1651-L (Use of SDS)

Step 1

- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Check the TO sensor coupler (1) for loose or poor contacts.
If OK, then check the TO sensor lead wire continuity.



IC11J1110027-03

- 4) Disconnect the TO sensor coupler and ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 5) Check the continuity between the R wire "A" and terminal "5".


Special tool

- (A): 09900-25008 (Multi circuit tester set)
- (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity (●)))

ECM coupler (Harness side)



IC11J1110030-01


- 6) If the sound is heard from the tester, then check there is no continuity between the R wire "A" and ground.
Also the R wire "A" and another wire.

Special tool

- (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (●)))



IS944H1110175-01

Is there no continuity?

- Yes Go to Step 2.
- No Open or short circuit in the R wire.

Step 2


- 1) Check there is no continuity between the Br/W wire "B" and ground.
Also the Br/W wire "B" and another wire.

Special tool

- (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (●)))



IS944H1110176-01


Is there no continuity?


- Yes Go to Stop 3.
- No Short circuit in the Br/W wire.

Step 3

- 1) Connect the ECM coupler and TO sensor coupler.
- 2) Remove the TO sensor. Refer to "TO Sensor Removal and Installation" in Section 1C (Page 1C-5).
- 3) Insert the needle pointed probes to the lead wire coupler.
- 4) Turn the ignition switch ON.
- 5) Measure the voltage at the wire side coupler between Br/W wire and B/Br wire.

Special tool

 (A): 09900-25008 (Multi circuit tester set)

 (B): 09900-25009 (Needle-point probe set)


Tester knob indication

Voltage (---)

TO sensor voltage (Normal)

0.4 – 1.4 V

(+) terminal: Br/W – (-) terminal: B/Br)




IC11J1110031-01

- 6) Measure the voltage when it is leaned 65° or more to left and right, from the horizontal level.

TO sensor voltage (Leaning)

3.7 – 4.4 V

(+) terminal: Br/W – (-) terminal: B/Br)



IC11J1110032-01

Is the voltage OK?

- Yes** Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- No** Replace the TO sensor with a new one. Refer to "TO Sensor Removal and Installation" in Section 1C (Page 1C-5).

DTC "C24" (P0351) or "C25" (P0352): Ignition System Malfunction

BENC11J11104016

NOTE

- Refer to "No Spark or Poor Spark" in Section 1H (Page 1H-4) for details.
- When indicating "C24" (P0351) for #1 front cylinder side.
- When indicating "C25" (P0352) for #2 rear cylinder side.


DTC "C28" (P1655): Secondary Throttle Valve Actuator (STVA) Malfunction

BENC11J11104017


Detected Condition and Possible Cause

Detected Condition	Possible Cause
The operation voltage does not reach the STVA. ECM does not receive communication signal from the STVA. STVA can not operate properly.	<ul style="list-style-type: none"> • STVA malfunction. • STVA circuit open or short. • STVA motor malfunction.

Wiring Diagram



ECM coupler (Harness side)



Troubleshooting

NOTICE


When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

Step 1

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Check the STVA coupler (1) for loose or poor contacts.



IC11J1110034-01


- 3) Turn the ignition switch OFF.
- 4) Disconnect the STVA coupler and ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 5) Insert the needle pointed probes to the lead wire coupler.
- 6) Check the continuity between the W/B wire "A" and ECM terminal "45", B/Lg wire "B" and ECM terminal "35", G wire "C" and ECM terminal "36" and P/W wire "D" and ECM terminal "44".

Special tool

- (A): 09900-25008 (Multi circuit tester set)
- (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity (•)))



IC11J1110035-01


- 7) If the sound is heard from the tester, then check there is no continuity among the STVA coupler each terminal and ground.

Special tool

- (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•)))



I944H1110179-02

Are there continuity and no continuity?

- Yes Go to Step 2.
- No Open or short circuit in the W/B, B/Lg, G or P/W wire.

Step 2

- 1) Remove the throttle body assembly. Refer to "Throttle Body Removal and Installation" in Section 1D (Page 1D-9).
- 2) Check the continuity between each terminal and ground.

Special tool


- (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Resistance (Ω)

STVA continuity


$\infty \Omega$ (Infinity)
(Terminal - Ground)



IC11J1110036-01

- 3) If OK, then measure the STVA resistance (between the B/Lg wire "A" and P/W wire "B") and (between the G wire "C" and W/B wire "D").

Special tool

 (A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Resistance (Ω)

STVA resistance

Approx. 7 Ω

(Terminal "A" – Terminal "B", Terminal "C" – Terminal "D")




IC11J1110037-01

Is the resistance OK?

- Yes Go to Step 3.
- No Replace the throttle body assembly with a new one. Refer to "Throttle Body Removal and Installation" in Section 1D (Page 1D-9).

Step 3

- 1) Install the throttle body assembly. Refer to "Throttle Body Removal and Installation" in Section 1D (Page 1D-9).
- 2) Connect the STVA coupler and ECM coupler.
- 3) Start the engine to check the STV operation. (STVA operating order: Open → Approx. 38% open)




I705H1110063-01

Is the operation OK?

- Yes Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- No Replace the throttle body assembly with a new one. Refer to "Throttle Body Removal and Installation" in Section 1D (Page 1D-9).

Active Control Inspection

- 1) Set up the SDS tool. (Refer to the SDS operation manual for further details.)
- 2) Turn the ignition switch ON.
- 3) Click "Secondary throttle operating control" (1).




IC11J1110084-01


- 4) Click each button (2).

At this time, if an operation sound is heard from the STVA, the function is normal.

Item	Value	Unit
<input type="checkbox"/> Engine speed	0	rpm
<input type="checkbox"/> Throttle position	27.0	°
<input type="checkbox"/> Secondary throttle full opened	Except full opn	
<input type="checkbox"/> Secondary throttle full closed	Full closed	
<input type="checkbox"/> Intake air temperature	19.0	°C
<input type="checkbox"/> Battery voltage	0.0	V



Item	Value	Unit
<input type="checkbox"/> Engine speed	0	rpm
<input type="checkbox"/> Throttle position	27.0	°
<input type="checkbox"/> Secondary throttle full opened	Full opened	
<input type="checkbox"/> Secondary throttle full closed	Except full cls	
<input type="checkbox"/> Intake air temperature	19.0	°C
<input type="checkbox"/> Battery voltage	0.0	V



1944H1110141-01


DTC "C29" (P1654-H/L): Secondary Throttle Position Sensor (STPS) Circuit Malfunction

BENC11J11104018

Detected Condition and Possible Cause


Detected Condition		Possible Cause
C29	Output voltage is not within the following range. $0.1\text{ V} \leq \text{Sensor voltage} < 4.8\text{ V}$	<ul style="list-style-type: none"> • STP sensor maladjusted. • STP sensor circuit open or short. • STP sensor malfunction. • ECM malfunction.
P1654	H Sensor voltage is higher than specified value.	<ul style="list-style-type: none"> • STP sensor circuit shorted to VCC or ground circuit open.
	L Sensor voltage is lower than specified value.	<ul style="list-style-type: none"> • STP sensor circuit open or shorted to ground or VCC circuit open or shorted to ground.

Wiring Diagram



1944H1110187-01

ECM coupler (Harness side)



1944H1110061-01

Troubleshooting

NOTICE

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.


NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

C29 (Use of mode select switch)

Step 1

- 1) Turn the ignition switch OFF.
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 3) Check the STP sensor coupler (1) for loose or poor contacts.
If OK, then measure the STP sensor input voltage.



IC11J1110038-01

- 4) Disconnect the STP sensor coupler.
- 5) Turn the ignition switch ON.
- 6) Measure the input voltage between the R wire "A" and ground.
Also, measure the voltage between the R wire "A" and B/Br wire "B".

Special tool

(A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage ()

STP sensor input voltage

4.5 – 5.5 V

((+) terminal: R – (-) terminal: Ground, (+) terminal: R – (-) terminal: B/Br)



IB22H1110064-01

Is the voltage OK?

- Yes Go to Step 2.
No Open or short circuit in the R wire or B/Br wire.

Step 2


- 1) Turn the ignition switch OFF.
- 2) Disconnect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 3) Check there is no continuity between the R wire "A" and ground.
Also the R wire "A" and another wire.

Special tool

(A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity ()



IB44H1110142-01

Is there no continuity?

- Yes Go to Step 3.
No Short circuit in the R wire.

Step 3

- 1) Check the continuity between the Y wire "A" and terminal "4".


Special tool

- MOORE (A): 09900-25008 (Multi circuit tester set)
- MOORE (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity (•)))

ECM couplers (Harness side)




- 2) If the sound is heard from the tester, then check there is no continuity among the Y wire "A" and another wire.

Special tool

- MOORE (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•)))



Is the continuity OK?

- Yes Go to Step 4.
- No Open or short circuit in the Y wire.

Step 4

- 1) Turn the ignition switch OFF.
- 2) Connect the ECM coupler.
- 3) Connect the special tool between the STP sensor and its coupler.

Special tool

- MOORE (A): 09900-28630 (TP Sensor test lead)

- 4) Disconnect the STVA coupler. Refer to "DTC "C28" (P1655): Secondary Throttle Valve Actuator (STVA) Malfunction" (Page 1A-52).
- 5) Turn the ignition switch ON.
- 6) Measure the STP sensor output voltage at the coupler (between the R wire (+) and B wire (-)) by turning the secondary throttle valve (close and open) with your finger.

Special tool

- MOORE (B): 09900-25008 (Multi circuit tester set)

Tester knob indication



Voltage (---)

STP sensor output voltage

Secondary throttle valve is closed: Approx. 0.6 V

Secondary throttle valve is opened: Approx. 4.5 V

((+) terminal: R - (-) terminal: B)




Is the voltage OK?

- Yes Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- No Replace the STP sensor with a new one. Refer to "STP Sensor Removal and Installation" in Section 1C (Page 1C-6).

P1654-H (Use of SDS)

Step 1

- 1) Turn the ignition switch OFF.
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 3) Check the STP sensor coupler (1) for loose or poor contacts.
If OK, then check the STP sensor lead wire continuity.



1C11J1110038-01

- 4) Disconnect the STP sensor coupler.
- 5) Turn the ignition switch ON.
- 6) Measure the input voltage between the R wire "A" and ground.
Also, measure the voltage between the R wire "A" and B/Br wire "B".

Special tool

(A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage ()

STP sensor input voltage

4.5 – 5.5 V

((+) terminal: R – (-) terminal: Ground, (+) terminal: R – (-) terminal: B/Br)



1B22H1110064-01

Is the voltage OK?

- Yes Go to Step 2.
No Open circuit in the B/Br wire.

Step 2


- 1) Disconnect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 2) Check there is no continuity among the Y wire "A" and another wire.

Special tool

(A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity ()



1944H1110146-01

Is the continuity OK?

- Yes Go to Step 3.
No Open or short circuit in the Y wire.

Step 3

- 1) Turn the ignition switch OFF.
- 2) Connect the ECM coupler.
- 3) Connect the special tool between the STP sensor and its coupler.

Special tool

TOOL (A): 09900-28630 (TP Sensor test lead)

- 4) Disconnect the STVA coupler. Refer to "DTC "C28" (P1655): Secondary Throttle Valve Actuator (STVA) Malfunction" (Page 1A-52).
- 5) Turn the ignition switch ON.
- 6) Measure the STP sensor output voltage at the coupler (between the R wire (+) and B wire (-)) by turning the secondary throttle valve (close and open) with your finger.

Special tool

TOOL (B): 09900-25008 (Multi circuit tester set)

Tester knob indication



Voltage (V)

STP sensor output voltage

Secondary throttle valve is closed: Approx. 0.6 V

Secondary throttle valve is opened: Approx. 4.5 V

((+) terminal: R - (-) terminal: B)




Is the voltage OK?

- Yes** Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- No** Replace the STP sensor with a new one. Refer to "STP Sensor Removal and Installation" in Section 1C (Page 1C-6).

P1654-L (Use of SDS)

Step 1

- 1) Turn the ignition switch OFF.
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 3) Check the STP sensor coupler (1) for loose or poor contacts. If OK, then check the STP sensor lead wire continuity.



- 4) Disconnect the STP sensor coupler and ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 5) Check the continuity between the R wire "A" and terminal "5".

Special tool


TOOL (A): 09900-25008 (Multi circuit tester set)

TOOL (B): 09900-25009 (Needle-point probe set)

Tester knob indication


Continuity (•))

ECM coupler (Harness side)




- 6) If the sound is heard from the tester, then check there is no continuity between the R wire "A" and ground.
Also the R wire "A" and another wire.

Special tool

 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•)))



1944H1110143-01


Is there no continuity?


- Yes Go to Step 2.
No Open or short circuit in the R wire.

Step 2

- 1) Check the continuity between the Y wire "A" and terminal "4".

Special tool


 (A): 09900-25008 (Multi circuit tester set)

 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity (•)))


ECM couplers (Harness side)



1944H1110145-01


- 2) If the sound is heard from the tester, then check there is no continuity among the Y wire "A" and another wire.

Special tool

 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•)))



1944H1110146-01

Is the continuity OK?

- Yes Go to Step 3.
No Open or short circuit in the Y wire.

Step 3

- 1) Turn the ignition switch OFF.
- 2) Connect the ECM coupler.
- 3) Connect the special tool between the STP sensor and its coupler.

Special tool

(A): 09900-28630 (TP Sensor test lead)

- 4) Disconnect the STVA coupler. Refer to "DTC "C28" (P1655): Secondary Throttle Valve Actuator (STVA) Malfunction" (Page 1A-52).
- 5) Turn the ignition switch ON.
- 6) Measure the STP sensor output voltage at the coupler (between the R wire (+) and B wire (-)) by turning the secondary throttle valve (close and open) with your finger.

Special tool

(B): 09900-25008 (Multi circuit tester set)

Tester knob indication


Voltage (---)

STP sensor output voltage


Secondary throttle valve is closed: Approx. 0.6 V

Secondary throttle valve is opened: Approx. 4.5 V

((+) terminal: R - (-) terminal: B)




IC11J1110039-01



I705H1110071-01

Is the voltage OK?

- Yes** Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- No** Replace the STP sensor with a new one. Refer to "STP Sensor Removal and Installation" in Section 1C (Page 1C-6).



NOTE

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnostic Reset Procedures" (Page 1A-16).


DTC "C31" (P0705): GP Switch Circuit Malfunction

BENC11J11104019


Detected Condition and Possible Cause

Detected Condition	Possible Cause
Gear position signal voltage should be higher than the following. Gear position sensor voltage ≥ 0.2 V If lower than the above value for 3 seconds or more.	<ul style="list-style-type: none"> • GP switch circuit open or short. • GP switch malfunction. • ECM malfunction.

Wiring Diagram



ECM coupler (Harness side)



Troubleshooting

NOTICE


When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

Step 1

- 1) Turn the ignition switch OFF.
- 2) Check the GP switch coupler (1) for loose or poor contacts.
If OK, then measure the GP switch voltage.



IC11J1110041-02

- 3) Support the motorcycle with a jack.

CAUTION

Make sure that the motorcycle is supported securely.

NOTICE

Do not support the motorcycle with the exhaust pipes.

- 4) Fold the side-stand to up position.
- 5) Insert the needle pointed probe to the lead wire coupler.
- 6) Turn the ignition switch ON.

- 7) Measure the voltage between the P wire "A" and B/W wire "B" and P wire "A" and ground. When shifting the gearshift lever from 1st to Top.

Special tool

(A): 09900-25008 (Multi circuit tester set)

(B): 09900-25009 (Needle-point probe set)

Tester knob indication


Voltage (---)

GP switch voltage

0.6 V or more

((+) terminal: P – (-) terminal: B/W, (+) terminal:

P – (-) terminal: Ground)



IC11J1110085-01

Is the voltage OK?


Yes Go to Step 2.


No Open circuit in the P or B/W wire.

Step 2

- 1) Disconnect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 2) Insert the needle pointed probes to the lead wire coupler.
- 3) Check there is continuity between the P wire "A" and ECM terminal "1". Also the B/W wire "B" and ECM terminal "13".


Special tool

 (A): 09900-25008 (Multi circuit tester set)

 (B): 09900-25009 (Needle-point probe set)

Tester knob indication


Continuity (•)))



1944H1110181-01


- 4) If the sound is heard from the tester, then check there is no continuity among the P wire "A" and ground, B/W wire "B" and ground, P wire "A" and another wire, B/W wire and another wire.

Special tool

 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•)))



1944H1110182-02

Is continuity OK?


Yes Go to Step 3.

No Open or short circuit in the P wire or B/W wire.

Step 3

- 1) Connect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 2) Turn the ignition switch ON.
- 3) Measure the voltage between the BI wire "A" and ground.


Special tool

 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Voltage (---)

((+) terminal: BI - (-) terminal: Ground)



IC11J1110042-0

Is the battery voltage?

Yes Go to Step 4.

No Open or short circuit in the BI wire.

Step 4

- 1) Check the GP switch. Refer to "Side-stand / Ignition Interlock System Parts Inspection" in Section 1I (Page 1I-8).

Is it in good condition?

Yes Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).

No Replace the GP switch with a new one. Refer to "GP Switch Removal and Installation" in Section 1C (Page 1C-8).


DTC "C32" (P0201), "C33" (P0202): Fuel Injector Circuit Malfunction

BENC11J11104020

Detected Condition and Possible Cause


Detected Condition	Possible Cause
CKP signal is produced but fuel injector signal is interrupted by 8 times or more continuity.	<ul style="list-style-type: none"> • Injector circuit open or short. • Injector malfunction. • ECM malfunction.

Wiring Diagram



1944H1110072-02

ECM coupler (Harness side)



1944H1110073-01

Troubleshooting

NOTICE


When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

Step 1


- 1) Turn the ignition switch OFF.
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 3) Check the injector coupler (#1 (1) or #2 (2)) for loose or poor contacts.
If OK, then measure the injector resistance.



IC11J1110043-01

- 4) Disconnect the injector coupler and measure the resistance between terminals.

Special tool


 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Resistance (Ω)

Injector resistance


11.5 – 12.5 Ω at 20 °C (68 °F)
(Terminal – Terminal)



IC11J1110044-01


- 5) If OK, then check the continuity between each terminal and ground.

Special tool

 (A): 09900-25008 (Multi circuit tester set)

Injector continuity

$\infty \Omega$ (Infinity)



IC11J1110045-01

Are the resistance and continuity OK?

Yes Go to Step 2.

No Replace the injector with a new one. Refer to "Throttle Body Disassembly and Assembly" in Section 1D (Page 1D-11).


Step 2

- 1) Turn the ignition switch ON.
- 2) Measure the injector voltage between the Y/R wire and ground.

NOTE

Injector voltage can be detected only for 3 seconds after ignition switch is turned ON.

Special tool

 (A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage (---)

Injector voltage

Battery voltage

(+) terminal: Y/R – (-) terminal: Ground



IC11J1110046-01

Is the voltage OK?

Yes Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).

No Open or short circuit in the Y/R wire.

DTC "C40" (P0505): ISC Valve Circuit Malfunction

BENC11J11104021

Detected Condition and Possible Cause

Detected Condition	Possible Cause
ISC valve circuit malfunction.	<ul style="list-style-type: none"> • Secondary throttle valve is fixed in opening position or closing position. • ECM malfunction.

Troubleshooting

NOTICE

- Be careful not to disconnect the STVA coupler at least 5 seconds after ignition switch is turned to OFF. If the ECM coupler is disconnected within 5 seconds after ignition switch is turned to OFF, there is a possibility of an unusual valve being written in the ECM and causing an error of ISC valve operation.
- When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

Step 1

- 1) Start the engine.
- 2) Check the engine idling speed.

NOTE

Make sure there is no crack or disconnection in the IAP sensor hoses and intake pipe.

Is engine idling speed normal?

- Yes Go to Step 3.
- No Go to Step 2.

Step 2

- 1) Stop the engine.
- 2) Replace the ECM with a known good one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 3) Start the engine.
- 4) Check the engine idling speed again.

Is engine idling speed normal?

- Yes Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- No Go to Step 3.

Step 3

- 1) Stop the engine.
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 3) Confirm the throttle valve closed position.
- 4) Turn the ignition switch ON.
- 5) Check the secondary throttle valve operation.


Is the operation OK?

- Yes Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- No Replace the throttle body assembly with a new one. Refer to "Throttle Body Removal and Installation" in Section 1D (Page 1D-9).

Active Control Inspection (ISC RPM Control)


Check 1

- 1) Set up the SDS tool. (Refer to the SDS operation manual for further details.)
- 2) Check that the engine is running.
- 3) Click the "Active control".
- 4) Click the "ISC rpm control" (1).



1944H1110166-02

- 5) Check that the "Spec" (2) is idle speed $1\ 300 \pm 100$ rpm.
- 6) Check that the "Desired idle speed" (3) is within the specified idle rpm.




1837H1110141-01

Item	Value	Unit
<input type="checkbox"/> Engine speed	1318	rpm
<input type="checkbox"/> Desired idle speed	3 → 1305	rpm
<input type="checkbox"/> Secondary throttle actuator position sensor	23.1	%
<input type="checkbox"/> Manifold absolute pressure 1	55.0	kPa

1944H1110167-01

Check 2

- 1) Click the button (4) and decrease the "Spec" (2) to 1 200 rpm slowly.
- 2) Check that the "Desired idle speed" (3) is nearly equal to the "Spec" (2). At the same time, check that the number of percent (5) in the secondary throttle actuator position sensor decreases.
- 3) Click the button (6) and increase the "Spec" (2) slowly.
- 4) Check that the "Desired idle speed" (3) is nearly equal to the "Spec" (2). Also, check that the number of percent (5) in the secondary throttle actuator position sensor increases.




1944H1110168-01

Item	Value	Unit
<input type="checkbox"/> Engine speed	1192	rpm
<input type="checkbox"/> Desired idle speed	3 → 1205	rpm
<input type="checkbox"/> Secondary throttle actuator position sensor	5 → 20.4	%
<input type="checkbox"/> Manifold absolute pressure 1	68.4	kPa

1944H1110169-01

Check 3

- 1) Click the button (6) and increase the "Spec" (2) to 1 800 rpm slowly.
- 2) Check that the "Desired idle speed" (3) is nearly equal to the "Spec" (2). Also, check that the number of percent (5) in the secondary throttle actuator position sensor increases.



1944H1110170-01

Item	Value	Unit
<input type="checkbox"/> Engine speed	1820	rpm
<input type="checkbox"/> Desired idle speed	3 → 1807	rpm
<input type="checkbox"/> Secondary throttle actuator position sensor	5 → 38.8	%
<input type="checkbox"/> Manifold absolute pressure 1	47.1	kPa

1944H1110171-01

NOTE

Be careful not to increase the "Spec" to 2 000 rpm, or the "Engine speed" may reach the upper limit.

If the secondary throttle valve actuator does not function properly, inspect the ISC or replace the throttle body assembly. Refer to "Troubleshooting" (Page 1A-68) under "DTC "C40" (P0505): ISC Valve Circuit Malfunction" or "Throttle Body Removal and Installation" in Section 1D (Page 1D-9).


DTC "C41" (P0230): FP Relay Circuit Malfunction

BENC11J11104022


Detected Condition and Possible Cause

Detected Condition	Possible Cause
No voltage is applied to the fuel pump, although fuel pump relay is turned ON, or voltage is applied to fuel pump although fuel pump relay is turned OFF.	Fuel pump relay, lead wire/coupler connection, power source to fuel pump relay and fuel injectors.

Wiring Diagram



ECM coupler (Harness side)



I944H1110079-01

Troubleshooting

NOTICE

When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

C41 (Use of mode select switch)

Step 1

- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Check the fuel pump relay coupler (1) for loose or poor contacts.
If OK, then check the fuel pump relay. Refer to "Fuel Pump Relay Inspection" in Section 1G (Page 1G-5).



IC11J1110048-02

Is the FP relay OK?

- Yes Go to Step 2.
No Replace the fuel pump relay with a new one.

Step 2


- 1) Disconnect the ECM coupler and fuel pump relay coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1) and "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 2) Insert the needle pointed probes to the lead wire coupler.
- 3) Check there is continuity between the Y/B wire "A" and ECM terminal "46".
Also the Y/R wire "B" and ECM terminal "9".

Special tool

- (A): 09900-25008 (Multi circuit tester set)
 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity (•)))



IC11J1110049-01


- 4) If the sound is heard from the tester, then check there is no continuity between the Y/B wire "A" and ground, Y/R wire "B" and ground, Y/B wire "A" and Y/R wire "B".

Special tool


- (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•)))



IC11J1110050-01



IC11J1110051-01


Is the continuity OK?

- Yes Go to Step 3.
No Open or short circuit in the Y/B or Y/R wire.

Step 3

- 1) Measure the fuel pump relay switch side voltage between the R/W wire "C" and ground.

Special tool

 (A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage (---)

Fuel pump relay switch side voltage

Battery voltage

((+) terminal: R/W – (-) terminal: Ground)



IC11J1110052-01

- 2) If OK, then support the motorcycle with a jack.

CAUTION


Make sure that the motorcycle is supported securely.

NOTICE

Do not support the motorcycle with the exhaust pipes.

- 3) Fold the side-stand to up position.
- 4) Turn the ignition switch ON.
- 5) Check the voltage between fuel pump relay coil side voltage between the O/W wire "D" and ground.

Special tool

 (A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage (---)

Fuel pump relay coil side voltage

Battery voltage

((+) terminal: O/W – (-) terminal: Ground)



IC11J1110053-01

Is the voltage OK?

- | | |
|-----|--|
| Yes | Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1). |
| No | Open or short circuit in the R/W wire or O/W wire. |

DTC "C42" (P1650): IG Switch Circuit Malfunction

BENC11J11104023

Detected Condition and Possible Cause

Detected Condition	Possible Cause
Ignition switch signal is not input to the ECM.	<ul style="list-style-type: none"> Ignition system circuit open or short. ECM malfunction.
When the ID agreement is not verified. ECM does not receive communication signal from the immobilizer antenna. (For E-21, 24)	<ul style="list-style-type: none"> Immobilizer system malfunction. (For E-21, 24)

Troubleshooting

NOTE

- Refer to "Ignition Switch Inspection" in Section 1H (Page 1H-11) for details.
- After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).


DTC "C44" (P0130 / P0135): HO2 Sensor (HO2S) Circuit Malfunction

BENC11J11104024


Detected Condition and Possible Cause

Detected Condition	Possible Cause
<p>C44/P0130</p> <p>After engine is started few minutes. (Sensor voltage ≥ 2.5 V) Engine is cold and stopped. (Sensor output voltage < 0.1 V) In other than the above value, C44 (P0130) is indicated.</p>	<ul style="list-style-type: none"> HO2 sensor circuit open or shorted to ground. Fuel system malfunction. ECM malfunction.
<p>C44/P0135</p> <p>The heater can not operate so that heater operation voltage is not supply to the oxygen heater circuit.</p>	<ul style="list-style-type: none"> Low battery voltage supply to the HO2 sensor.

Wiring Diagram



ECM coupler (Harness side)



I944H1110084-01

Troubleshooting (When Indicating C44 / P0130:)

NOTICE


When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

Step 1

- 1) Turn the ignition switch OFF.
- 2) Remove the seat and right frame side cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Check the HO2 sensor coupler (1) for loose or poor contacts.
If OK, then check the HO2 sensor lead wire continuity.




IC11J1110055-06

- 4) Disconnect the HO2 sensor coupler.
- 5) Turn the ignition switch ON.

- 6) Check the voltage between the W/G wire "A" and ground.
Also, check the voltage between W/G wire "A" and B/Br wire "B".

Special tool

 (A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage (---)

HO2 sensor input voltage

Approx. 5.0 V

((+) terminal: W/G - (-) terminal: Ground, (+) terminal: W/G - (-) terminal: B/Br)



IC11J1110056-03


Is the voltage OK?

- Yes Go to Step 2.
- No Open or short circuit in the W/G wire or B/Br wire.

Step 2


- 1) Disconnect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 2) Check there is no continuity between the W/G wire "A" and ground. Also the W/G wire "A" and another wire.

Special tool

 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•)))



IC11J1110057-05


Is the no continuity?


- Yes Go to Step 3.
- No Short circuit in the W/G wire.

Step 3

- 1) Connect the ECM coupler and HO2 sensor lead wire coupler.
- 2) Warm up the engine enough.
- 3) Insert the needle pointed probes to the lead wire coupler.
- 4) Measure the HO2 sensor output voltage between the B wire and Gr wire, in idling condition.

Special tool

 (A): 09900-25008 (Multi circuit tester set)

 (B): 09900-25009 (Needle-point probe set)


Tester knob indication

Voltage (---)

HO2 sensor output voltage at idle speed

0.45 V or less

((+) terminal: B – (-) terminal: Gr)



IC11J1110058-03

- 5) Measure the HO2 sensor output voltage while holding the engine speed at 6 000 r/min.

HO2 sensor output voltage at 6 000 r/min

0.6 V or more

((+) terminal: B – (-) terminal: Gr)

Is the voltage OK?

- Yes
 - W/G or B/Br wire open or shorted to the power source, or poor "6" or "12" connection.
 - Recheck each terminal and wire harness for open circuit and poor connection.
 - If wire and connection are OK, intermittent trouble or faulty ECM.
 - Replace the ECM with a known good one, and inspection it again. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- No Replace the HO2 sensor with a new one. Refer to "Heated Oxygen Sensor (HO2S) Removal and Installation" in Section 1B (Page 1B-6).


Troubleshooting (When Indicating C44 / P0135:)

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

Step 1

- 1) Turn the ignition switch OFF.
- 2) Remove the seat and right frame side cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Check the HO2 sensor coupler (1) for loose or poor contacts.
If OK, then measure the HO2 sensor resistance.



IC11J1110055-06

- 4) Disconnect the HO2 sensor coupler and measure the resistance between terminals.

NOTE

- Temperature of the sensor affects resistance value largely.
- Make sure that the sensor heater is in atmospheric temperature.

Special tool

(A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Resistance (Ω)

HO2 sensor heater resistance

Approx. 8 Ω at 23 °C (73 °F)

(W - W)



IC11J1110059-02

Is the resistance OK?

- Yes Go to Step 2.
- No Replace the HO2 sensor with a new one. Refer to "HO2 Sensor Removal and Installation" in Section 1C (Page 1C-8).

Step 2

- 1) Disconnect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 2) Insert the needle pointed probes to the lead wire coupler.
- 3) Check there is continuity between the W/B wire "A" and ECM terminal "37".

NOTE

Battery voltage can be detected only before starting the engine.


Special tool

(A): 09900-25008 (Multi circuit tester set)

(B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity (\bullet))



IC11J1110060-01

Is there continuity?

- Yes Go to Step 3.
- No Open circuit in the W/B wire.


Step 3


- 1) Connect the HO2 sensor coupler and ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 2) Insert the needle pointed probes to the lead wire coupler.
- 3) Turn the ignition switch ON and measure the heater voltage between the W/B wire and ground. If the tester voltage indicates the battery voltage, it is good condition.

NOTE

Battery voltage can be detected only before starting the engine.

Special tool

 (A): 09900-25008 (Multi circuit tester set)


 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Voltage (---)

Heater voltage

((+) terminal: W/B - (-) terminal: Ground)



IC11J1110061-02

Is the voltage OK?

- | | |
|-----|--|
| Yes | Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1). |
| No | Open or short circuit in the O/W wire. |


DTC "C60" (P0480): Cooling Fan Relay Circuit Malfunction

BENC11J11104025


Detected Condition and Possible Cause

Detected Condition	Possible Cause
Cooling fan relay signal is not input to ECM.	<ul style="list-style-type: none"> Cooling fan relay circuit open or short. ECM malfunction.

Wiring Diagram



ECM coupler (Harness side)



1944H1110093-01

Troubleshooting

NOTICE


When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

Step 1

- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Check the cooling fan relay (1) coupler for loose or poor contacts.
If OK, then inspection the cooling fan relay. Refer to "Cooling Fan Relay Inspection" in Section 1F (Page 1F-10).



IC11J1110063-01

Is the cooling fan relay OK?

- Yes Go to Step 2.
No Replace the cooling fan relay with a new one.

Step 2

- 1) Turn the ignition switch ON.
- 2) Measure the cooling fan relay switch side voltage between the O/R wire "A" and ground.

Special tool

(A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage (---)

Cooling fan relay switch side voltage

Battery voltage

((+) terminal: O/R – (-) terminal: Ground)



IC11J1110064-01

- 3) If OK, then measure the cooling fan relay coil side voltage between the O/W wire "B" and ground.

Special tool

(A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage (---)

Cooling fan relay coil side voltage

Battery voltage

((+) terminal: O/W – (-) terminal: Ground)



IC11J1110065-01

Is the voltage OK?

- Yes Go to Step 3.
No Open or short circuit in the O/R wire or O/W wire.


Step 3

- 1) Disconnect the cooling fan motor coupler (1).



IC11J1110066-01

- 2) Apply 12 V to the terminals and check the operation of cooling fan motor.
((+) terminal: B – (–) terminal: B/W)



IC11J1110067-01

Is the operation OK?

- Yes Go to Step 4.
- No Replace the cooling fan motor with a new one. Refer to "Radiator / Cooling Fan Motor Removal and Installation" in Section 1F (Page 1F-6).

Step 4


- 1) Disconnect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 2) Insert the needle pointed probes to the lead wire coupler.
- 3) Check there is continuity between the G/R wire "A" and ECM terminal "24".
Also the B wire "B" and cooling fan motor B wire "C".

Special tool


- (A): 09900-25008 (Multi circuit tester set)
- (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity (•)))



IC11J1110068-01




IC11J1110076-01

Is there continuity?

- Yes Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- No Open circuit in the G/R wire or B wire.

Active Control Inspection

- 1) Set up the SDS tool. (Refer to SDS operation manual for further details.)
- 2) Start the engine and run it in idling condition.
- 3) Click "Cooling fan relay control" (1).




I944H1110157-02

- 4) Click the "Operate" (2).
At this time, if an operation sound is heard from the cooling fan relay and cooling fan motors are operated, the function is normal.

NOTE

Cooling fan relay and cooling fan motor operation can be checked until the engine coolant temperature is less than 100 °C (212 °F) after starting the engine.

<input type="checkbox"/> Engine coolant / oil temperature	84.0	°C	
<input type="checkbox"/> Secondary throttle actuator position sensor	25.5	%	
<input type="checkbox"/> Cooling fan relay	On		
<input type="checkbox"/> Manifold absolute pressure 2	97.1	kPa	



I944H1110158-01

- 5) Click the "Stop" (3) to check the operation properly.

<input type="checkbox"/> Engine coolant / oil temperature	84.0	°C	
<input type="checkbox"/> Secondary throttle actuator position sensor	27.1	%	
<input type="checkbox"/> Cooling fan relay	Off		
<input type="checkbox"/> Manifold absolute pressure 2	72.3	kPa	



I944H1110159-01


DTC "C62" (P0443): EVAP System Purge Control Solenoid Valve Circuit Malfunction (E-33 only)

BENC11J111004026

Detected Condition and Possible Cause


Detected Condition	Possible Cause
EVAP system purge control valve voltage is not input to ECM.	<ul style="list-style-type: none"> • EVAP system purge control valve circuit open or short. • EVAP system purge control valve malfunction. • ECM malfunction.

Wiring Diagram



IC11J1110069-02

ECM coupler (Harness side)



I944H2110013-01

Troubleshooting

NOTICE


When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

Step 1


- 1) Turn the ignition switch OFF.
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 3) Check the EVAP system purge control valve coupler (1) for loose or poor contacts. If OK, then measure the EVAP system purge control valve resistance.



IC11J1110070-01

Tester knob indication
Resistance (Ω)

EVAP system purge control valve resistance
Approx. 32 Ω at 20 °C (68 °F)
(Terminal – Terminal)



I718H2120005-02

Is the resistance OK?

- Yes Go to Step 2.
- No Replace the EVAP system purge control with a new one. Refer to "Evaporative Emission Control System Removal and Installation (Only for E-33)" in Section 1B (Page 1B-7).

Step 2

- 1) Turn the ignition switch ON.
- 2) Measure the voltage between the O/W wire and ground.

Special tool

(A): 09900-25008 (Multi circuit tester set)


Tester knob indication

Voltage (---)

EVAP system purge control valve voltage

Battery voltage

(+) terminal: O/W – (-) terminal: Ground



I718H2110003-01


Is the voltage OK?


- Yes Go to Step 3.
- No Open or short circuit in the O/W wire.

Step 3

- 1) Turn the ignition switch OFF.
- 2) Disconnect the ECM coupler. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- 3) Insert the needle pointed probes to the lead wire coupler.
- 4) Check there is continuity between the Dbr wire "A" and ECM terminal "39".


Special tool

 (A): 09900-25008 (Multi circuit tester set)

 (B): 09900-25009 (Needle-point probe set)


Tester knob indication

Continuity (•)))




- 5) If the sound is heard from the tester, then check there is no continuity between the Dbr wire "A" and ground.

Special tool

 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•)))




Is the continuity OK?

- | | |
|-----|--|
| Yes | Replace the ECM with a new one. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1). |
| No | Open or short circuit in the Dbr wire. |

Active Control Inspection


- 1) Set up the SDS tool. (Refer to SDS operation manual for further details.)
- 2) Turn the ignition switch ON.
- 3) Click "EVAP purge valve operating control" (1).



I944H2110017-01

- 4) Click each button (2). At this time, if an operating sound is heard from the EVAP system purge control valve, the function is normal.

<input type="checkbox"/> Secondary throttle actuator position sensor	30.6	%	
<input type="checkbox"/> Manifold absolute pressure 1	1021	kPa	
<input type="checkbox"/> EVAP purge valve	On		
<input type="checkbox"/> Throttle position	27.0	°	
<input type="checkbox"/> Engine coolant / oil temperature	93.0	°C	



I944H2110018-01

DTC "C65" (P0506 / P0507): Idle Speed Malfunction

BENC11J11104027

Detected Condition and Possible Cause

Detected Condition		Possible Cause
C65	Idle speed rose higher than or dropped lower than desired idle speed by more than specified range.	<ul style="list-style-type: none"> • Air passage clogged. • STVA is fixed. • Idle speed malfunction. • Air leakage • ECM malfunction.
P0506	Idle speed dropped lower than desired idle speed by more than specified range.	
P0507	Idle speed rose higher than desired idle speed by more than specified range.	

Troubleshooting

NOTICE


- Be careful not to disconnect the STVA coupler at least 5 seconds after ignition switch is turned to OFF. If the ECM coupler is disconnected within 5 seconds after ignition switch is turned to OFF, there is a possibility of an unusual value being written in the ECM and causing an error of ISC valve operation.
- When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent terminal damage.

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "Use of SDS Diagnosis Reset Procedures" (Page 1A-15).

Step 1

- 1) Run the engine at idle speed.
- 2) By spraying water to exhaust pipes from #1 and #2, check evaporation from each of them to make sure for equal combustion among cylinders.



IC11J1110072-01

Is check result OK?

- Yes Go to Step 2.
- No Repair or replace defective parts.

Step 2

- 1) Check STV actuator. Refer to "STV Actuator Inspection" in Section 1C (Page 1C-7).

Is check result OK?


- Yes Go to Step 3.
- No Replace the throttle body. Refer to "Throttle Body Disassembly and Assembly" in Section 1D (Page 1D-11).

Step 3

- 1) Check air intake system for clogging and leakage.



IC11J1110073-01



IC11J1110074-01

Is check result OK?

- Yes Go to Step 4.
- No Repair or replace defective parts.

Step 4

- 1) Check the following points related to engine mechanical system.
 - Engine compression. Refer to "Compression Pressure Check" in Section 1D (Page 1D-3).
 - Fuel pressure. Refer to "Fuel Pressure Inspection" in Section 1G (Page 1G-4).

Is check result OK?

- Yes Replace the ECM with a known good one, and inspect it again. Refer to "ECM Removal and Installation" in Section 1C (Page 1C-1).
- No Repair or replace defective parts.

Specifications

Service Data

BENC11J11107001

Injector

Item	Specification	Note
Injector resistance	11.5 – 12.5 Ω at 20 °C (68 °F)	
Fuel pump discharge amount	167 ml (5.6/5.9 US/lmp oz) or more/10 sec.	
Fuel pressure regulator operating set pressure	Approx. 300 kPa (3.0 kgf/cm ² , 43 psi)	

FI Sensors

Item	Specification	Note
CKP sensor resistance	130 – 240 Ω	
CKP sensor peak voltage	3.7 V or more	When cranking
IAP sensor (#1) input voltage	4.5 – 5.5 V	
IAP sensor (#1) output voltage	Approx. 2.5 V at idle speed	
IAP sensor (#2) input voltage	4.5 – 5.5 V	
IAP sensor (#2) output voltage	Approx. 2.5 V at idle speed	
TP sensor input voltage	4.5 – 5.5 V	
TP sensor output voltage	Closed	Approx. 1.1 V
	Opened	Approx. 4.3 V
ECT sensor input voltage	4.5 – 5.5 V	
ECT sensor resistance	Approx. 2.45 k Ω at 20 °C (68 °F)	
IAT sensor input voltage	4.5 – 5.5 V	
IAT sensor resistance	Approx. 2.6 k Ω at 20 °C (68 °F)	
TO sensor resistance	16.5 – 22.3 k Ω	
TO sensor voltage	Normal	0.4 – 1.4 V
	Leaning	3.7 – 4.4 V
GP switch voltage	0.6 V or more	When leaning 65° From 1st to Top
Injector voltage	Battery voltage	
Ignition coil primary peak voltage	150 V or more	When cranking
STP sensor input voltage	4.5 – 5.5 V	
STP sensor output voltage	Closed	Approx. 0.6 V
	Opened	Approx. 4.5 V
STV actuator resistance	Approx. 7 Ω	
HO2 sensor heater resistance	Approx. 8 Ω at 23 °C (73 °F)	
HO2 sensor output voltage	Approx. 0.45 V or less at idle speed	
	0.6 V or more at 6 000 r/min.	
EVAP system purge control solenoid valve resistance	Approx. 32 Ω at 20 °C (68 °F)	E-33 only

Special Tools and Equipment

BENC11J11108001

Special Tool

09900-25008

Multi circuit tester set



- ☞(Page 1A-28) /
- ☞(Page 1A-29) /
- ☞(Page 1A-29) /
- ☞(Page 1A-29) /
- ☞(Page 1A-31) /
- ☞(Page 1A-31) /
- ☞(Page 1A-31) /
- ☞(Page 1A-32) /
- ☞(Page 1A-32) /
- ☞(Page 1A-34) /
- ☞(Page 1A-34) /
- ☞(Page 1A-34) /
- ☞(Page 1A-35) /
- ☞(Page 1A-35) /
- ☞(Page 1A-36) /
- ☞(Page 1A-36) /
- ☞(Page 1A-37) /
- ☞(Page 1A-37) /
- ☞(Page 1A-37) /
- ☞(Page 1A-38) /
- ☞(Page 1A-38) /
- ☞(Page 1A-38) /
- ☞(Page 1A-38) /
- ☞(Page 1A-40) /
- ☞(Page 1A-40) /
- ☞(Page 1A-41) /
- ☞(Page 1A-41) /
- ☞(Page 1A-42) /
- ☞(Page 1A-44) /
- ☞(Page 1A-44) /
- ☞(Page 1A-45) /
- ☞(Page 1A-46) /
- ☞(Page 1A-46) /
- ☞(Page 1A-48) /
- ☞(Page 1A-48) /
- ☞(Page 1A-48) /
- ☞(Page 1A-49) /
- ☞(Page 1A-49) /
- ☞(Page 1A-49) /
- ☞(Page 1A-50) /
- ☞(Page 1A-50) /
- ☞(Page 1A-50) /
- ☞(Page 1A-51) /
- ☞(Page 1A-53) /
- ☞(Page 1A-53) /
- ☞(Page 1A-53) /
- ☞(Page 1A-54) /
- ☞(Page 1A-57) /
- ☞(Page 1A-57) /
- ☞(Page 1A-58) /
- ☞(Page 1A-58) /
- ☞(Page 1A-58) /
- ☞(Page 1A-59) /
- ☞(Page 1A-59) /
- ☞(Page 1A-60) /

- ☞(Page 1A-60) /
- ☞(Page 1A-61) /
- ☞(Page 1A-61) /
- ☞(Page 1A-61) /
- ☞(Page 1A-62) /
- ☞(Page 1A-64) /
- ☞(Page 1A-65) /
- ☞(Page 1A-65) /
- ☞(Page 1A-65) /
- ☞(Page 1A-67) /
- ☞(Page 1A-67) /
- ☞(Page 1A-67) /
- ☞(Page 1A-71) /
- ☞(Page 1A-71) /
- ☞(Page 1A-72) /
- ☞(Page 1A-72) /
- ☞(Page 1A-74) /
- ☞(Page 1A-75) /
- ☞(Page 1A-75) /
- ☞(Page 1A-76) /
- ☞(Page 1A-76) /
- ☞(Page 1A-77) /
- ☞(Page 1A-79) /
- ☞(Page 1A-79) /
- ☞(Page 1A-80) /
- ☞(Page 1A-83) /
- ☞(Page 1A-84) /
- ☞(Page 1A-84) /

09900-25009

Needle-point probe set



- ☞(Page 1A-29) /
- ☞(Page 1A-31) /
- ☞(Page 1A-34) /
- ☞(Page 1A-37) /
- ☞(Page 1A-38) /
- ☞(Page 1A-49) /
- ☞(Page 1A-49) /
- ☞(Page 1A-50) /
- ☞(Page 1A-51) /
- ☞(Page 1A-53) /
- ☞(Page 1A-58) /
- ☞(Page 1A-60) /
- ☞(Page 1A-61) /
- ☞(Page 1A-64) /
- ☞(Page 1A-65) /
- ☞(Page 1A-71) /
- ☞(Page 1A-75) /
- ☞(Page 1A-76) /
- ☞(Page 1A-77) /
- ☞(Page 1A-80) /
- ☞(Page 1A-84) /

1A-89 Engine General Information and Diagnosis:

<p>09900-28630 TP Sensor test lead</p> <p>☞(Page 1A-35) / ☞(Page 1A-37) / ☞(Page 1A-38) / ☞(Page 1A-58) / ☞(Page 1A-60) / ☞(Page 1A-62)</p>	<p>09904-41010 SUZUKI Diagnostic system set</p> <p>☞(Page 1A-14) / ☞(Page 1A-18)</p>
<p>09917-47011 Vacuum pump gauge set</p> <p>☞(Page 1A-32)</p>	<p>09930-82720 Mode selection switch</p> <p>☞(Page 1A-4) / ☞(Page 1A-13) / ☞(Page 1A-13)</p>
<p>99565-01010-024 CD-ROM Ver.24</p> <p>☞(Page 1A-14) / ☞(Page 1A-18)</p>	



Emission Control Devices

Precautions

Precautions for Emission Control Devices

BENC11J11200001


Refer to "General Precautions" in Section 00 (Page 00-1).

General Description

Fuel Injection System Description

BENC11J11201001

DL650 motorcycles are equipped with a fuel injection system for emission level control. This fuel injection system is precision designed, manufactured and adjusted to comply with the applicable emission limits. With varying engine conditions, all of the fuel injection volumes are precisely controlled by the programmed injection maps in the ECM to reduce CO, NOX and HC. Adjusting, interfering with, improper replacement, or resetting of any of the fuel injection components may adversely affect injection performance and cause the motorcycle to exceed the exhaust emission level limits.




IC11J1120010-01

1. Fuel tank	4. Fuel delivery pipe	"B": Pressurized fuel
2. Fuel pump	5. Fuel injector	"C": Relieved fuel
3. Fuel feed hose	"A": Before-pressurized fuel	

Crankcase Emission Control System Description

BENC11J11201002

The engine is equipped with a PCV system to prevent discharging crankcase emissions into the atmosphere. Blow-by gas in the engine is constantly drawn into the crankcase, which is returned to the combustion chamber through the PCV (breather) hose, air cleaner and throttle body.



1. Air cleaner box	"A": Fresh air	"C": Blow-by gas
2. PCV (breather) hose	"B": Fuel/Air mixture	

Noise Emission Control System Description

BENC11J11201003

TAMPERING WITH THE NOISE CONTROL SYSTEM PROHIBITED: Federal law prohibits the following acts or the causing thereof:


- The removal or rendering inoperative by any person, other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or
- The use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among Those Acts Presumed to Constitute Tampering are the Acts Listed Below:

- Removing or puncturing the muffler, baffles, header pipes, screen type spark arrester (if equipped) or any other component which conducts exhaust gases.
- Removing or puncturing the air cleaner case, air cleaner cover, baffles or any other component which conducts intake air.
- Replacing the exhaust system or muffler with a system or muffler not marked with the same model specific code as the code listed on the Motorcycle Noise Emission Control Information label.

Evaporative Emission Control System Diagram (Only for E-33)

BENC11J11201004







1. Fuel tank	5. Surge hose	9. EVAP canister	"C": Fresh air
2. Fuel pump	6. Purge hose	10. Throttle body	"D": Vacuum
3. IAP sensor	7. Fuel shut-off valve	"A": Fuel	
4. Fuel feed hose	8. EVAP system purge control valve	"B": HC vapor	

IC11J1120011-01

Schematic and Routing Diagram

EVAP Canister Hose Routing Diagram (Only for E-33)

BENC11J11202001



IC11J1120012-02

1. EVAP canister	"A": From the EVAP canister	█ "G": Red marking
2. Fuel shut-off valve	"B": From the fuel tank	█ "H": Face the clamp end outside.
3. Purge hose	"C": To the EVAP canister purge valve	█ "I": Face the clamp end upward.
4. Surge hose	"D": To the fuel shut-off valve	Ⓞ : 7 N·m (0.7 kgf-m, 5.0 lbf-ft)
5. Fuel tank breather hose	"E": White marking	
6. EVAP system purge control solenoid valve	"F": Yellow marking	

Repair Instructions

Heated Oxygen Sensor (HO2S) Removal and Installation

BENC11J11206001

NOTICE


- Be careful not to expose the HO2 sensor to excessive shock.
- Do not use an impact wrench when removing or installing the HO2 sensor.
- Be careful not to twist or damage the sensor lead wires.

Removal

▲ WARNING


Do not remove the HO2 sensor while it is hot.

- 1) Remove the seat and right frame side cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Disconnect the HO2 sensor coupler (1).
- 3) Remove the clamp (2).



IC11J1120013-02

- 4) Remove the HO2 sensor (3).



IC11J1120001-03

Installation

Install the HO2 sensor in the reverse order of removal. Pay attention to the following points:

- Apply anti seize compound (Never-seez purenickel special) to the HO2 sensor.


NOTICE

Do not apply anti seize compound or other materials to the sensor air hole.

- Tighten the HO2 sensor (1) to the specified torque.

Tightening torque

HO2 sensor (a): 25 N·m (2.5 kgf-m, 18.0 lbf-ft)



IC11J1120002-03

- Route the HO2 sensor lead wire properly. Refer to "Wiring Harness Routing Diagram" in Section 9A (Page 9A-7).

Heated Oxygen Sensor (HO2S) Inspection


BENC11J11206002

Refer to "DTC "C44" (P0130 / P0135): HO2 Sensor (HO2S) Circuit Malfunction" in Section 1A (Page 1A-73).

Crankcase Breather (PCV) Hose Inspection

BENC11J11206003

Inspect the PCV hose (1) for wear and damage. If it is worn or damaged, replace the PCV hose with a new one. Refer to "Crankcase Breather (PCV) Hose Removal and Installation" (Page 1B-7).




IC11J1120003-01

Crankcase Breather (PCV) Hose Removal and Installation

BENC11J11206004

Removal

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Remove the crankcase breather (PCV) hose (1).



IC11J1120003-01

Installation

- 1) Install the crankcase breather (PCV) hose as shown in the intake system construction. Refer to "Throttle Body Construction" in Section 1D (Page 1D-8).
- 2) Reinstall the removed parts.

Evaporative Emission Control System Removal and Installation (Only for E-33)

BENC11J11206005

Hose

Removal


- 1) Remove the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 3) Remove the EVAP hose as shown in the EVAP canister hose routing diagram and intake system construction. Refer to "EVAP Canister Hose Routing Diagram (Only for E-33)" (Page 1B-5) and "Throttle Body Construction" in Section 1D (Page 1D-8).

Installation

- 1) Install the EVAP hose as shown in the EVAP canister hose routing diagram and intake system construction. Refer to "EVAP Canister Hose Routing Diagram (Only for E-33)" (Page 1B-5) and "Throttle Body Construction" in Section 1D (Page 1D-8).
- 2) Reinstall the removed parts.

EVAP Canister Removal

- 1) Remove the left frame cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Disconnect the surge hose (1) and purge hose (2).
- 3) Remove the EVAP canister (3).




IC11J1120004-01

Installation

- 1) Install the EVAP canister.
- 2) Connect the EVAP canister hoses as shown in the EVAP canister hose routing diagram. Refer to "EVAP Canister Hose Routing Diagram (Only for E-33)" (Page 1B-5).
- 3) Install the left frame cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).

Fuel Shut-off Valve Removal


- 1) Remove the right frame side cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Disconnect the surge hoses (1).
- 3) Remove the fuel shut-off valve (2) with bracket by removing the bolt (3).



IC11J1120005-02

1B-8 Emission Control Devices:

- 4) Remove the fuel shut-off valve (2) by removing the screws (4).




IC11J1120006-01

Installation

- 1) Install the fuel shut-off valve as shown in the EVAP canister hose routing diagram. Refer to "EVAP Canister Hose Routing Diagram (Only for E-33)" (Page 1B-5).
- 2) Reinstall the removed parts.

EVAP System Purge Control Solenoid Valve Removal

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Disconnect the coupler (1) and purge hoses (2).
- 3) Remove the EVAP system purge control valve (3).



IC11J1120007-01


Installation

Install the EVAP system purge control solenoid valve in the reverse order of removal. Pay attention on the following points:

- Tighten the EVAP system purge control valve mounting nut (1) to the specified torque.

Tightening torque

EVAP system purge control solenoid valve mounting nut (a): 7 N·m (0.7 kgf-m, 5.0 lbf-ft)



IC11J1120008-01

Evaporative Emission Control System Inspection (Only for E-33)

BENC11J11206006

Hose


Inspect the hoses for wear or damage. If it is worn or damaged, replace the hose with a new one.

NOTE

Make sure that the hoses are securely connected.

EVAP Canister

Inspect the EVAP canister body for damage to the body. If any defects is found, replace the EVAP canister with a new one.



IC11J1120009-01

EVAP System Purge Control Solenoid Valve

NOTE


EVAP system purge control solenoid valve can be checked without removing it from the motorcycle. Refer to "DTC "C62" (P0443): EVAP System Purge Control Solenoid Valve Circuit Malfunction (E-33 only)" in Section 1A (Page 1A-82).

- 1) Check that no air flows through both of the air inlet and outlet ports. If air flows out, replace the EVAP system purge control solenoid valve with a new one.



1718H2120003-03


- 2) Connect the 12 V battery to the terminals of the EVAP system purge control solenoid valve and check the air flow. If air flows out, the solenoid valve is in normal condition.



1718H2120004-01

- 3) Check the resistance between the terminals of the EVAP system purge control solenoid valve. If the resistance is not within the standard range, replace the EVAP system purge control solenoid valve with a new one.

Special tool


 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Resistance (Ω)

EVAP system purge control solenoid valve resistance

Approx. 32 Ω at 20 °C (68 °F)



1718H2120005-02


Fuel Shut-Off Valve

▲ WARNING

Gasoline and gasoline vapor is toxic. A small amount of fuel remains in the fuel shut-off valve when checking it.


Do not swallow the fuel when blowing the fuel shut-off valve.

- 1) When air is blown into the fuel shut-off valve with its side "A" positioned upward, the air can pass through to the canister side.



1823H1120037-01

- 2) When air is blown into the fuel shut-off valve with its side "A" positioned sideways, the air cannot pass through to the canister side. If the fuel shut-off valve operates otherwise, it must be replaced.



1823H1120038-02

Specifications

Service Data

BENC11J11207001

FI Sensors

Item	Specification	Note
HO2 sensor heater resistance	Approx. 8 Ω at 23 °C (73 °F)	
HO2 sensor output voltage	Approx. 0.45 V or less at idle speed 0.6 V or more at 6 000 r/min	
EVAP system purge control solenoid valve resistance	Approx. 32 Ω at 20 °C (68 °F)	E-33 only

Tightening Torque Specifications

BENC11J11207002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
HO2 sensor	25	2.5	18.0	☞ (Page 1B-6)
EVAP system purge control solenoid valve mounting nut	7	0.7	5.0	☞ (Page 1B-8)

NOTE

The tightening torque(s) also specified in:
 “EVAP Canister Hose Routing Diagram (Only for E-33)” (Page 1B-5)

Reference:

For the tightening torques of fasteners not specified in this section, refer to “Tightening Torque List” in Section 0C (Page 0C-7).

Special Tools and Equipment

Special Tool

BENC11J11208001

09900-25008 Multi circuit tester set ☞ (Page 1B-9)	
--	---

Engine Electrical Devices

Precautions

Precautions for Engine Electrical Device

BENC11J11300001

Refer to "General Precautions" in Section 00 (Page 00-1) and "Precautions for Electrical Circuit Service" in Section 00 (Page 00-2).

Component Location

Engine Electrical Components Location

BENC11J11303001

Refer to "Electrical Components Location" in Section 0A (Page 0A-9).

Diagnostic Information and Procedures

Engine Symptom Diagnosis

BENC11J11304001

Refer to "Engine Symptom Diagnosis" in Section 1A (Page 1A-9).


Repair Instructions

ECM Removal and Installation

BENC11J11306001

Removal

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Disconnect the battery (-) lead wire (1).
- 3) Remove the band (2).
- 4) Disconnect the ECM couplers (3) and remove the ECM (4).



IC11J1130001-02

Installation

Install the ECM in the reverse order of removal.

CKP Sensor Inspection

BENC11J11306002


Refer to "CKP Sensor Inspection" in Section 1H (Page 1H-9).

CKP Sensor Removal and Installation

BENC11J11306003

Removal

- 1) Remove the generator cover. Refer to "Generator Removal and Installation" in Section 1J (Page 1J-4).
- 2) Remove the CKP sensor (1) along with generator stator (2).



I944H1130003-02

Installation

Install the CKP sensor in the reverse order of removal. Refer to "Generator Removal and Installation" in Section 1J (Page 1J-4).

IAP Sensor Inspection

BENC11J11306004


Refer to "DTC "C13" (P1750) or "C17" (P0105): IAP Sensor Circuit Malfunction" in Section 1A (Page 1A-30).

IAP Sensor Removal and Installation


BENC11J11306005

Removal

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 2) Disconnect the IAP sensor (#1 and #2) couplers (1) and vacuum hoses (2).
- 3) Remove the IAP sensors (3) (#1 and #2).



IC11J1130002-01



IC11J1130003-01

Installation

Install the IAP sensors in the reverse order of removal.

TP Sensor Inspection

BENC11J11306006

Refer to "DTC "C14" (P0120-H/L): TP Sensor Circuit Malfunction" in Section 1A (Page 1A-33).

TP Sensor Removal and Installation

BENC11J11306007

Refer to "Throttle Body Disassembly and Assembly" in Section 1D (Page 1D-11).

TP Sensor Adjustment

BENC11J11306008


Inspect the TP sensor setting position and adjust it if necessary in the following procedures:

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Connect the special tool (Mode select switch) to the dealer mode coupler. Refer to "Self-Diagnostic Procedures" in Section 1A (Page 1A-13).

Special tool

: 09930-82720 (Mode selection switch)

- 3) Warm up the engine and keep it running in idling speed.
- 4) Turn the mode select switch ON.
- 5) Check the position of the bar in the left of C code displayed on the LCD panel.



1823H1130022-01

"A": Incorrect position

"B": Correct position

- 6) If the TP sensor adjustment is necessary, lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 7) Loosen the TP sensor mounting screw (1) using the special tool and turn the TP sensor to bring the bar to the correct position.

Special tool

: 09930-11950 (Torx® wrench (T25H))



IC11J1130004-01

- 8) Tighten the TP sensor mounting screw to the specified torque.

Tightening torque

TP sensor mounting screw: 3.5 N·m (0.35 kgf-m, 2.5 lbf-ft)

- 9) Turn off the engine and install the removed parts.

IAT Sensor Removal and Installation

BENC11J11306009


Removal

- 1) Remove the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 2) Disconnect the IAT sensor coupler (1).



IC11J1110025-01

- 3) Remove the IAT sensor (2).



IC11J1130005-01

Installation

Install the IAT sensor in the reverse order of removal. Pay attention to the following points:

- Tighten the IAT sensor screw to the specified torque.

Tightening torque

IAT sensor screw (a): 1.5 N·m (0.15 kgf·m, 1.0 lbf·ft)



IC11J1130006-01

IAT Sensor Inspection

BENC11J11306010

Refer to "DTC "C21" (P0110-H/L): IAT Sensor Circuit Malfunction" in Section 1A (Page 1A-43).

NOTICE

- The IAT sensor operative temperature range is $-30 - 120\text{ }^{\circ}\text{C}$ ($-22 - 248\text{ }^{\circ}\text{F}$).
- Do not heat the oil up to $120\text{ }^{\circ}\text{C}$ ($248\text{ }^{\circ}\text{F}$) or more for this inspection.

NOTE

IAT sensor resistance measurement method is the same way as that of the ECT sensor. Refer to "ECT Sensor Inspection" (Page 1C-4).

IAT sensor specification

Temperature	Standard resistance
0 °C (32 °F)	Approx. 6.00 kΩ
20 °C (68 °F)	Approx. 2.60 kΩ
80 °C (176 °F)	Approx. 0.34 kΩ

ECT Sensor Removal and Installation

BENC11J11306011

Removal

- 1) Drain engine coolant. Refer to "Cooling System Inspection" in Section 0B (Page 0B-12).
- 2) Remove the throttle body. Refer to "Throttle Body Removal and Installation" in Section 1D (Page 1D-9).
- 3) Disconnect the ECT sensor coupler (1).




IC11J1130007-01

4) Remove the ECT sensor (2).

NOTICE

Take special care when handling the ECT sensor. It may cause damage if it gets an excessive impact.



IC11J1130008-01


Installation

Install the ECT sensor in the reverse order of removal. Pay attention to the following points:

- Install the new gasket washer (1) and tighten the ECT sensor (2) to the specified torque.

Tightening torque

ECT sensor (a): 18 N·m (1.8 kgf-m, 13.0 lbf-ft)



IC11J1130009-02

ECT Sensor Inspection

BENC11J11306012

Refer to "DTC "C15" (P0115-H/L): ECT Sensor Circuit Malfunction" in Section 1A (Page 1A-39).

Inspect the ECT sensor in the following procedures:

- 1) Remove the ECT sensor. Refer to "ECT Sensor Removal and Installation" (Page 1C-3).
- 2) Connect the ECT sensor (1) to a circuit tester and place it in the oil (2) contained in a pan, which is placed on a stove.
- 3) Heat the oil to raise its temperature slowly and read the column thermometer (3) and the ohmmeter. If the ECT sensor ohmic value does not change in the proportion indicated, replace it with a new one.

NOTICE

- Take special care when handling the ECT sensor. It may cause damage if it gets an excessive sharp impact.
- Do not contact the ECT sensor and the column thermometer with a pan.

Special tool


(A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Resistance (Ω)

Temperature sensor specification

Temperature	Standard resistance
20 °C (68 °F)	Approx. 2.45 k Ω
50 °C (122 °F)	Approx. 0.811 k Ω
80 °C (176 °F)	Approx. 0.318 k Ω
110 °C (230 °F)	Approx. 0.142 k Ω



I718H1130014-01

- 4) Install the ECT sensor. Refer to "ECT Sensor Removal and Installation" (Page 1C-3).

TO Sensor Removal and Installation

BENC11J11306013

Removal

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Disconnect the coupler (1) and remove the TO sensor (2).



IC11J1130010-03

Installation

Install the TO sensor in the reverse order of removal. Pay attention to the following point:

- When installing the TO sensor, bring the "UP" letters and arrow mark "A" upward.



IC11J1130011-03

TO Sensor Inspection

BENC11J11306014

Refer to "DTC "C23" (P1651-H/L): TO Sensor Circuit Malfunction" in Section 1A (Page 1A-47).

STP Sensor Inspection

BENC11J11306015


Refer to "DTC "C29" (P1654-H/L): Secondary Throttle Position Sensor (STPS) Circuit Malfunction" in Section 1A (Page 1A-56).

STP Sensor Adjustment

BENC11J11306016

Adjust the STP sensor in the following procedures:


- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Disconnect the STVA coupler (1).




IC11J1110034-01

- 3) Insert the needle pointed probes to the STP sensor coupler (between Y and B/Br wires).
- 4) Turn the ignition switch ON.
- 5) Close the secondary throttle valve by finger and measure the STP sensor output voltage.

Special tool

 (A): 09900-25008 (Multi circuit tester set)


 (B): 09900-25009 (Needle-point probe set)

Tester knob indication


Voltage (---)

STP sensor output voltage

ST valve is fully closed: Approx. 0.6 V ((+): Y - (-): B/Br)



I718H1130017-01




IC11J1130012-01

1C-6 Engine Electrical Devices:


- Loosen the STP sensor mounting screw (2) adjust the STP sensor (3) until the output voltage comes within the specified value and tighten the STP sensor mounting screw.

Special tool

 : 09930-11950 (Torx® wrench (T25H))

Tightening torque

STP sensor mounting screw (a): 3.5 N·m (0.35 kgf-m, 2.5 lbf-ft)



IC11J1130013-01

- Reinstall the removed parts.

STP Sensor Removal and Installation

BENC11J11306017


Removal


- Turn the ignition switch OFF.
- Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- Disconnect the coupler (1) and remove the STP sensor (2) with the special tool.

NOTE

Prior to disassembly, mark each sensor's original position with a paint or scribe for accurate reinstallation.

Special tool


 : 09930-11950 (Torx® wrench (T25H))



IC11J1130014-01

Installation

- Disconnect the STVA coupler (1).



IC11J1110034-01

- Close the secondary throttle valve by finger.




1718H1130017-01


- With the STV fully closed, install the STP sensor (2) and tighten the STP sensor mounting screw to the specified torque.

NOTE

- Apply a thin coat of engine oil to the new O-ring (3).
- Align the secondary throttle shaft end "A" with the groove "B" of STP sensor.
- Apply grease to the secondary throttle shaft end "A", if necessary.


 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)

Special tool

 : 09930-11950 (Torx® wrench (T25H))

Tightening torque

STP sensor mounting screw: 3.5 N·m (0.35 kgf-m, 2.5 lbf-ft)



IC11J1130015-01

- Make sure the STP valve open or close smoothly.

- 5) Adjust the position of STP sensor. Refer to "STP Sensor Adjustment" (Page 1C-5).
- 6) Reinstall the removed parts.

STV Actuator Inspection

BENC11J11306018

Refer to "DTC "C28" (P1655): Secondary Throttle Valve Actuator (STVA) Malfunction" in Section 1A (Page 1A-52).

STV Actuator Removal and Installation

BENC11J11306019

Refer to "Throttle Body Disassembly and Assembly" in Section 1D (Page 1D-11).

NOTICE

- Never remove the STVA from the throttle body.
- The STVA and throttle body are available only as an assembly.

ISC Valve Inspection

BENC11J11306020


Refer to "DTC "C40" (P0505): ISC Valve Circuit Malfunction" in Section 1A (Page 1A-68).

ISC Learned Value Reset and Opening Initialization

BENC11J11306021



When removing or replacing the throttle body assembly, set the ISC valve to the following procedures:

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Set up the SDS tool. (Refer to the SDS operation manual for further details.)
- 3) Turn the ignition switch ON.
- 4) Click the "Active control".
- 5) Click the "ISC learned value reset" (1).



I944H1130021-01


- 6) Click the "Reset" button (2) to clear the ISC leaned valve.



I944H1130022-01

NOTE

The ISC leaned value of the ISC valve is set at preset position.



I822H1140335-02

- 7) Close the SDS tool and turn the ignition switch OFF.

NOTE

The ISC valve opening initialization is automatically started after the ignition switch is turned OFF position.

1C-8 Engine Electrical Devices:

HO2 Sensor Inspection

BENC11J11306022

Refer to "DTC "C44" (P0130 / P0135): HO2 Sensor (HO2S) Circuit Malfunction" in Section 1A (Page 1A-73).

HO2 Sensor Removal and Installation

BENC11J11306023

Refer to "Heated Oxygen Sensor (HO2S) Removal and Installation" in Section 1B (Page 1B-6).

GP Switch Inspection

BENC11J11306024

Refer to "Side-stand / Ignition Interlock System Parts Inspection" in Section 1I (Page 1I-8).

GP Switch Removal and Installation

BENC11J11306025

Refer to "Gear Position Switch Removal and Installation" in Section 5B (Page 5B-12).

Specifications

Service Data

BENC11J11307001

FI Sensors

Item	Standard/Specification		Note
CKP sensor resistance	130 – 240 Ω		
CKP sensor peak voltage	3.7 V or more		When cranking
IAP sensor (#1 & #2) input voltage	4.5 – 5.5 V		
IAP sensor (#1 & #2) output voltage	Approx. 2.5 V at idle speed		
TP sensor input voltage	4.5 – 5.5 V		
TP sensor output voltage	Closed	Approx. 1.1 V	
	Opened	Approx. 4.3 V	
ECT sensor input voltage	4.5 – 5.5 V		
ECT sensor resistance	Approx. 2.45 k Ω at 20 °C (68 °F)		
IAT sensor input voltage	4.5 – 5.5 V		
IAT sensor resistance	Approx. 2.6 k Ω at 20 °C (68 °F)		
TO sensor resistance	16.5 – 22.3 k Ω		
TO sensor voltage	Normal	0.4 – 1.4 V	
	Leaning	3.7 – 4.4 V	When leaning 65°
GP switch voltage	0.6 V or more		From 1st to Top
Injector voltage	Battery voltage		
Ignition coil primary peak voltage	150 V or more		When cranking
STP sensor input voltage	4.5 – 5.5 V		
STP sensor output voltage	Closed	Approx. 0.6 V	
	Opened	Approx. 4.5 V	
STV actuator resistance	Approx. 7 Ω		
HO2 sensor heater resistance	Approx. 8 Ω at 23 °C (73 °F)		
HO2 sensor output voltage	Approx. 0.45 V or less at idle speed		
	0.6 V or more at 6 000 r/min.		
EVAP system purge control solenoid valve resistance	Approx. 32 Ω at 20 °C (68 °F)		E-33 only

Tightening Torque Specifications

BENC11J11307002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
TP sensor mounting screw	3.5	0.35	2.5	☞(Page 1C-2)
IAT sensor screw	1.5	0.15	1.0	☞(Page 1C-3)
ECT sensor	18	1.8	13.0	☞(Page 1C-4)
STP sensor mounting screw	3.5	0.35	2.5	☞(Page 1C-6) / ☞(Page 1C-6)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment





Recommended Service Material

BENC11J11308001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE "A" or equivalent	P/No.: 99000-25010	☞(Page 1C-6)

Special Tool

BENC11J11308002

<p>09900-25008 Multi circuit tester set ☞(Page 1C-4) / ☞(Page 1C-5)</p> 	<p>09900-25009 Needle-point probe set ☞(Page 1C-5)</p> 
<p>09930-11950 Torx® wrench (T25H) ☞(Page 1C-2) / ☞(Page 1C-6) / ☞(Page 1C-6) / ☞(Page 1C-6)</p> 	<p>09930-82720 Mode selection switch ☞(Page 1C-2)</p> 

Engine Mechanical


General Description

ISC Valve System Description

BENC11J11401001

DL650 motorcycles are equipped with a ISC valve system of secondary throttle valve interlinked. In the throttle body is provided a bypass through which air volume is varied when the cutaway on the secondary throttle shaft is moved, causing the engine idle speed to be adjusted.


ISC Valve is Closed Position



I944H1140337-02


1. Secondary throttle valve	2. Throttle valve
-----------------------------	-------------------

ISC Valve is Opened Position



I944H1140338-02

1. Secondary throttle valve	2. Throttle valve
-----------------------------	-------------------



Fully closed

Opening at 20%


Opening at 80% or more

IC11J1140099-01

Schematic and Routing Diagram


Camshaft and Sprocket Assembly Diagram

BENC11J11402001



I944H1140350-01

Throttle Cable Routing Diagram



IC11J1140095-03

1. Throttle cable No.1	☑ "C": Pass the clutch cable above the wire harness.
2. Throttle cable No.2	☑ "D": Pass the clutch cable outside of the wire harness.
3. Clutch cable	☑ "E": Pass the throttle cables under the wire harness.
☑ 4. Clamp : Bind the clutch cable to frame bridge with the clamp. Set the locked part facing outside.	☑ "F": Pass the clutch cable left side of frame head pipe. Pass the throttle cables right side of frame head pipe.
5. Clutch cable stopper	☑ "G": Pass the clutch cable under the radiator inlet hose.
☑ "A": The adjustment of clutch cable play should be made on the adjuster on which the clutch cable cap is installed with 3-5 mm of threads left on the clutch lever adjuster.	"a": 0 – 1 mm (0 – 0.04 in)
☑ "B": Pass the throttle cables outside of left handlebar switch lead wire.	

Diagnostic Information and Procedures

Engine Mechanical Symptom Diagnosis

BENC11J11404001

Refer to "Engine Symptom Diagnosis" in Section 1A (Page 1A-9).

Compression Pressure Check

BENC11J11404002

The compression pressure reading of a cylinder is a good indicator of its internal condition.


The decision to overhaul the cylinder is often based on the results of a compression test. Periodic maintenance records kept at your dealership should include compression readings for each maintenance service.


NOTE


- Before checking the engine for compression pressure, make sure that the cylinder head nuts are tightened to the specified torque values and the valves are properly adjusted.
- Make sure that the battery is in fully-charged condition.

- 1) Warm up the engine.
- 2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 3) Disconnect all the spark plug caps and remove the outside spark plugs (Front side and rear side). Refer to "Spark Plug Cap and Spark Plug Removal and Installation" in Section 1H (Page 1H-6).
- 4) Install the compression gauge and adaptor in the spark plug hole. Make sure that the connection is tight.

Special tool

 (A): 09915-64512 (Compression gauge)

 (B): 09915-63311 (Compression gauge attachment)



IC11J1140001-01

- 5) Keep the throttle grip in the fully-opened position.



IC11J1140002-01

- 6) Press the starter button and crank the engine for a few seconds. Record the maximum gauge reading as the cylinder compression.
- 7) Repeat this procedure with the other cylinder.

Compression pressure specification

Standard	Limit	Difference
1 300 – 1 700 kPa (13 – 17 kgf/cm ² , 185 – 242 psi)	1 100 kPa (11 kgf/cm ² , 156 psi)	200 kPa (2.0 kgf/cm ² , 28 psi)

Low compression pressure can indicate any of the following conditions:

- Excessively worn cylinder walls
- Worn piston or piston rings
- Piston rings stuck in grooves
- Poor valve seating
- Ruptured or otherwise defective cylinder head gasket

Overhaul the engine in the following cases:

- Compression pressure in one of the cylinders is 1 100 kPa (11 kgf/cm², 156 psi) or less.
 - The difference in compression pressure between any two cylinders is 200 kPa (2.0 kgf/cm², 28 psi) or more.
 - All compression pressure readings are below 1 300 kPa (13 kgf/cm², 185 psi) even when they measure 1 100 kPa (11 kgf/cm², 156 psi) or more.
- 8) After checking the compression pressure, reinstall the removed parts.

Repair Instructions

Engine Components Removable with the Engine in Place

BENC11J11406001

Engine components which can be removed while the engine is installed on the frame are as follows. For the installing and removing procedures, refer to respective paragraphs describing each component.

Center of Engine

Item	Removal	Inspection	Installation
Air cleaner element	Refer to "Air Cleaner Element Removal and Installation" (Page 1D-6).	Refer to "Air Cleaner Element Inspection and Cleaning" in Section 0B (Page 0B-3).	Refer to "Air Cleaner Element Removal and Installation" (Page 1D-6).
Oil filter	Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).	—	Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).
Throttle body	Refer to "Throttle Body Removal and Installation" (Page 1D-9).	Refer to "Throttle Body Inspection and Cleaning" (Page 1D-15).	Refer to "Throttle Body Removal and Installation" (Page 1D-9).
Starter motor	Refer to "Starter Motor Removal and Installation" in Section 1I (Page 1I-4).	Refer to "Starter Motor Related Parts Inspection" in Section 1I (Page 1I-5).	Refer to "Starter Motor Removal and Installation" in Section 1I (Page 1I-4).
Oil pressure switch	Refer to "Oil Pressure Switch Removal and Installation" in Section 1E (Page 1E-8).	Refer to "Oil Pressure Indicator Inspection" in Section 9C (Page 9C-9).	Refer to "Oil Pressure Switch Removal and Installation" in Section 1E (Page 1E-8).
Thermostat	Refer to "Thermostat Removal and Installation" in Section 1F (Page 1F-11).	Refer to "Thermostat Inspection" in Section 1F (Page 1F-11).	Refer to "Thermostat Removal and Installation" in Section 1F (Page 1F-11).

Engine Right Side

Item	Removal	Inspection	Installation
Exhaust pipe/Muffler	Refer to "Exhaust Pipe / Muffler Removal and Installation" in Section 1K (Page 1K-3).	Refer to "Exhaust System Construction" in Section 1K (Page 1K-2).	Refer to "Exhaust Pipe / Muffler Removal and Installation" in Section 1K (Page 1K-3).
Clutch cover	Refer to "Clutch Installation" in Section 5C (Page 5C-9).	—	Refer to "Clutch Installation" in Section 5C (Page 5C-9).
Clutch plates	Refer to "Clutch Removal" in Section 5C (Page 5C-7).	Refer to "Clutch Parts Inspection" in Section 5C (Page 5C-13).	Refer to "Clutch Removal" in Section 5C (Page 5C-7).
Clutch sleeve hub	Refer to "Clutch Removal" in Section 5C (Page 5C-7).	Refer to "Clutch Parts Inspection" in Section 5C (Page 5C-13).	Refer to "Clutch Installation" in Section 5C (Page 5C-9).
Primary driven gear	Refer to "Clutch Removal" in Section 5C (Page 5C-7).	Refer to "Clutch Parts Inspection" in Section 5C (Page 5C-13).	Refer to "Clutch Installation" in Section 5C (Page 5C-9).
Oil pump drive gear	Refer to "Oil Pump Removal and Installation" in Section 1E (Page 1E-12).	—	Refer to "Oil Pump Removal and Installation" in Section 1E (Page 1E-12).
Oil pump	Refer to "Oil Pump Removal and Installation" in Section 1E (Page 1E-12).	Refer to "Oil Pump Inspection" in Section 1E (Page 1E-13).	Refer to "Oil Pump Removal and Installation" in Section 1E (Page 1E-12).
Water pump	Refer to "Water Pump Removal and Installation" in Section 1F (Page 1F-14).	Refer to "Water Pump Related Parts Inspection" in Section 1F (Page 1F-18).	Refer to "Water Pump Removal and Installation" in Section 1F (Page 1F-14).
Gearshift shaft	Refer to "Gearshift Shaft / Gearshift Cam Plate Removal and Installation" in Section 5B (Page 5B-15).	Refer to "Gearshift Linkage Inspection" in Section 5B (Page 5B-18).	Refer to "Gearshift Shaft / Gearshift Cam Plate Removal and Installation" in Section 5B (Page 5B-15).

Engine Left Side


Item	Removal	Inspection	Installation
Generator	Refer to "Generator Removal and Installation" in Section 1J (Page 1J-4).	Refer to "Generator Inspection" in Section 1J (Page 1J-4).	Refer to "Generator Removal and Installation" in Section 1J (Page 1J-4).
Engine sprocket	Refer to "Engine Sprocket Removal and Installation" in Section 3A (Page 3A-2).	Refer to "Drive Chain Related Parts Inspection" in Section 3A (Page 3A-5).	Refer to "Engine Sprocket Removal and Installation" in Section 3A (Page 3A-2).
Driven chain	Refer to "Drive Chain Replacement" in Section 3A (Page 3A-7).	Refer to "Drive Chain Inspection and Adjustment" in Section 0B (Page 0B-15).	Refer to "Drive Chain Replacement" in Section 3A (Page 3A-7).
Starter idle gear	Refer to "Starter Clutch Inspection" in Section 1I (Page 1I-12).	—	Refer to "Starter Clutch Inspection" in Section 1I (Page 1I-12).
Starter clutch	Refer to "Starter Clutch Removal and Installation" in Section 1I (Page 1I-10).	Refer to "Starter Clutch Inspection" in Section 1I (Page 1I-12).	Refer to "Starter Clutch Removal and Installation" in Section 1I (Page 1I-10).
CKP sensor	Refer to "Generator Removal and Installation" in Section 1J (Page 1J-4).	Refer to "CKP Sensor Inspection" in Section 1H (Page 1H-9).	Refer to "Generator Removal and Installation" in Section 1J (Page 1J-4).
Gear position switch	Refer to "Gear Position Switch Removal and Installation" in Section 5B (Page 5B-12).	Refer to "Gear Position Switch Inspection" in Section 5B (Page 5B-12).	Refer to "Gear Position Switch Removal and Installation" in Section 5B (Page 5B-12).

Air Cleaner Element Removal and Installation

BENC11J11406002


Removal

- 1) Remove the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 2) Remove the air cleaner box cap (1) by removing its screws (2).



IC11J1140003-01

- 3) Remove the air cleaner element (3).



IC11J1140004-01

Installation

Install the air cleaner element in the reverse order of removal.

Air Cleaner Element Inspection and Cleaning

BENC11J11406003

Refer to "Air Cleaner Element Inspection and Cleaning" in Section 0B (Page 0B-3).


Air Cleaner Box Removal and Installation

BENC11J11406004

Removal


- 1) Remove the side cowling refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Remove the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 3) Remove the IAP sensors. Refer to "IAP Sensor Removal and Installation" in Section 1C (Page 1C-2).
- 4) Remove the IAT sensor. Refer to "IAT Sensor Removal and Installation" in Section 1C (Page 1C-3).

- 5) Loosen the air cleaner outlet tube clamp screws (1).



IC11J1140005-01

- 6) Disconnect the crankcase breather hose (2).




IC11J1140006-01

- 7) Remove the air cleaner box.

Installation


Install the air cleaner box in the reverse order of removal. Pay attention to the following points:

- Fit the air cleaner outlet tube clamps properly. Refer to "Throttle Body Construction" (Page 1D-8).
- Route the hoses properly. Refer to "Throttle Body Construction" (Page 1D-8).
- Tighten the air cleaner outlet tube clamp screws (1).




IC11J1140007-01

Throttle Body Components






1. Fuel delivery pipe #1	8. TP sensor	15. EVAP system purge control valve bracket screw
2. Fuel delivery pipe #2	9. STP sensor mounting screw	(a) : 3.5 N·m (0.35 kgf-m, 2.5 lbf-ft)
3. Fuel delivery pipe mounting screw	10. TP sensor mounting screw	(b) : 7 N·m (0.7 kgf-m, 5.0 lbf-ft)
4. O-ring	11. Air screw	(c) : 5 N·m (0.5 kgf-m, 3.5 lbf-ft)
5. Fuel injector	12. EVAP system purge control solenoid valve	🛢️ : Apply engine oil.
6. Cushion seal	13. Purge hose	⊗ : Do not reuse.
7. STP sensor	14. EVAP system purge control solenoid valve mounting nut	

Throttle Body Construction



1. Fuel hose	<input checked="" type="checkbox"/> "C": Make sure the intake pipe clamp is not contacted to the STV/ISC actuator.	"b": 25 – 30°
2. Breather hose	<input checked="" type="checkbox"/> "D": Make sure the intake pipe clamp is not contacted to the throttle body.	"c": 20°
<input checked="" type="checkbox"/> 3. Reservoir tank overflow hose : Pass the reservoir tank overflow hose in rear of the fuel hose.	<input checked="" type="checkbox"/> "E": Two ribs	"d": 45°
"A": Blue mark	<input checked="" type="checkbox"/> "F": One rib	"e": 0 – 10°
<input checked="" type="checkbox"/> "B": Make sure the clamp is not contacted to the starter motor lead wire.	"a": Clearance	<input checked="" type="checkbox"/> (a) : 8.5 N·m (0.85 kgf·m, 5.7 lbf·ft)



IC11J1140097-02


1. HO2 sensor lead wire	"B": Clamp the HO2 sensor lead wire and rear brake hose and face the clamp end downward.	(a) : 25 N·m (2.5 kgf-m, 18.0 lbf-ft)
2. ECT sensor	"C": Pass the HO2 sensor lead wire between the seat frame and rear brake hose.	(b) : 18 N·m (1.8 kgf-m, 13.0 lbf-ft)
"A": Yellow marking	"D": Face the clamp end backward.	(c) : 10 N·m (1.0 kgf-m, 7.0 lbf-ft)

Throttle Body Removal and Installation

BENC11J11406007


Removal

- 1) Disconnect the battery (-) lead wire. Refer to "Battery Removal and Installation" in Section 1J (Page 1J-12).
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" (Page 1D-6).
- 3) Disconnect the STVA coupler (1), STP sensor coupler (2) and TP sensor coupler (3).



IC11J1140008-02

- 4) Disconnect the fuel injector couplers (4).



IC11J1140009-01

- 5) Loosen the throttle body clamp screws (5).




IC11J1140010-01

- 6) Disconnect the throttle cables (6) from the throttle body and move the throttle body assembly upward.


NOTICE

After disconnecting the throttle cables, do not snap the throttle valve from the open to full close. It may cause damage to the throttle valve and throttle body.



IC11J1140011-02

- 7) Disconnect the EVAP system purge control valve coupler (7) (for E-33) and purge hose (8) (for E-33).




IC11J1140012-01

- 8) Remove the throttle body assembly.

Installation

Install the throttle body in the reverse order of removal. Pay attention to the following points:


- Connect the throttle pulling cable (1) and throttle returning cable (2) to the throttle body.



IC11J1140013-02

- Tighten the throttle body clamp screws. Refer to "Throttle Body Construction" (Page 1D-8).
- Loosen each throttle cable lock-nut.

- Turn in each throttle cable adjuster fully and locate each outer cable so that the clearance "a" is 0 – 1 mm (0 – 0.04 in).



IS22H1140016-01

"a": 0 – 1 mm (0 – 0.04 in)

- Tighten the throttle cable lock-nuts to the specified torque.


Tightening torque

Throttle cable lock-nut: 4.5 N·m (0.45 kgf·m, 3.3 lbf·ft)

- Adjust the throttle cable play. Refer to "Throttle Cable Play Inspection and Adjustment" in Section 0B (Page 0B-12).
- Connect the fuel injector couplers.

NOTE

Make sure that each coupler is installed in the correct position.



IC11J1140014-01

Coupler	Wire color
Front injector "A"	Y/R and Gr/W
Rear injector "B"	Y/R and Gr/B

Throttle Body Disassembly and Assembly


BENC11J11406008

Disassembly

NOTE


Identify the position of each removed part. Organize the parts in their respective groups so that they can be reinstalled in their original positions.

- 1) Remove the fuel feed hose (1) and IAP sensor vacuum hoses (2).




IC11J1140015-01

- 2) Remove the EVAP system purge control valve (3) (for E-33) and purge hoses (4) (for E-33).



IC11J1140016-01

- 3) Remove the EVAP system purge control valve bracket (5) (for E-33).




IC11J1140017-01

- 4) Remove the throttle link rod (6) and secondary throttle link rod (7).
- 5) Remove the fuel delivery pipe assemblies (8).


NOTICE

Be careful not to twist the fuel delivery pipe, when disconnecting the fuel feed hose or removing the fuel delivery pipe.



IC11J1140018-01

- 6) Remove the fuel injectors (9) from the fuel delivery pipes (10).




IC11J1140019-01


- 7) Remove the TP sensor (11) and STP sensor (12) by removing each screw (13) and (14).

NOTE

Prior to disassembly, mark sensor's original position with a paint or scribe for accurate reinstallation.

Special tool


 : 09930-11950 (Torx® wrench (T25H))



IC11J1140020-01

NOTICE


Never remove the STVA (15) and link plates (16) from the throttle body.



IC11J1140021-01

NOTICE


Never remove the throttle valve (17) and secondary throttle valve (18).



IC11J1140022-01

NOTE

These adjusting screws (19), (20), (21) and (22) are factory-adjusted at the time of delivery and therefore avoid removing or turning it unless otherwise necessary.



IC11J1140023-01

Assembly

Assembly is the throttle body in the reverse order of removal. Pay attention to the following points:

- Apply thin coat of the engine oil to the new O-ring.
- With the STV fully closed, install the STP sensor (1) and tighten the STP sensor mounting screw to the specified torque.

NOTE

- Align the secondary throttle shaft end "A" with the groove "B" of the STP sensor.
- Apply grease to the secondary throttle shaft end "A", if necessary.


Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)

Special tool

: 09930-11950 (Torx® wrench (T25H))

Tightening torque


STP sensor mounting screw: 3.5 N·m (0.35 kgf-m, 2.5 lbf-ft)



I944H1140277-01

NOTE

Make sure the secondary throttle valve open or close smoothly. If the STP sensor adjustment is necessary, refer to "STP Sensor Adjustment" in Section 1C (Page 1C-5).



I944H1140278-01


1D-13 Engine Mechanical:

- Apply thin coat of the engine oil to the new O-ring.
- With the throttle valve fully closed, install the TP sensor (2) and tighten the TP sensor mounting screw to the specified torque.

NOTE


- Align the throttle shaft end "C" with the groove "D" of the TP sensor.
- Apply grease to the throttle shaft end "C", if necessary.

Special tool

 : 09930-11950 (Torx® wrench (T25H))

Tightening torque


TP sensor mounting screw: 3.5 N·m (0.35 kgf·m, 2.5 lbf·ft)



I944H1140279-01


NOTE

Make sure the throttle valve open or close smoothly. If the TP sensor adjustment is necessary, refer to "TP Sensor Adjustment" in Section 1C (Page 1C-2).



I944H1140280-01

- Apply a small quantity thin coat of the engine oil to the new cushion seal (3) and new O-ring (4).



I944H1140281-01


- Wipe off the mounting surface on the delivery pipe (5) where the fuel injector (6) will be seated with a clean rag.
- Install the fuel injector (6) by pushing it straight to the delivery pipe (5).

NOTICE

Never turn the injector while pushing it.

NOTE

Align the coupler "E" of the injector with boss "F" of the delivery pipe.




IC11J1140024-02

- Install the fuel delivery pipe assemblies (7) to the throttle body assembly.

NOTICE

- When installing the fuel delivery pipes to the throttle body, pay attention to the difference of the fuel delivery pipes.
- Never turn the fuel injectors while installing them.




IC11J1140025-01

"G": Front side	"H": Rear side
-----------------	----------------

- Install rubber washers (8).
- Tighten the fuel delivery pipe mounting screws (9) to the specified torque.

Tightening torque

Fuel delivery pipe mounting screw (a): 3.5 N·m (0.35 kgf-m, 2.5 lbf-ft)




IC11J1140026-02

- Install the throttle link rod (10) and secondary throttle link rod (11).

NOTE

The throttle link rod (10) is longer than the secondary throttle link rod (11).




IC11J1140027-01

- Tighten the EVAP system purge control valve bracket screws (12) (for E-33).

Tightening torque

EVAP system purge control valve bracket screw (b): 5 N·m (0.5 kgf-m, 3.5 lbf-ft)




IC11J1140028-02

- Tighten the EVAP system purge control valve nut (13) (for E-33).

Tightening torque

EVAP system purge control valve nut (c): 7 N·m (0.7 kgf-m, 5.0 lbf-ft)



IC11J1140029-02

Throttle Body Inspection and Cleaning

BENC11J11406009

Refer to "Throttle Body Disassembly and Assembly" (Page 1D-11).

Cleaning

Clean passageways with a spray-type carburetor cleaner and blow dry with compressed air.

NOTICE

- Never clean the main bore of throttle body to prevent come off molybdenum from the throttle valve.
- Do not use wire to clean passageways. Wire can damage passageways. Always follow the chemical manufacturer's instructions for proper use and cleaning of the throttle body components. Do not apply carburetor cleaning chemicals to the rubber and plastic materials.

Inspection

Check following items for any defects or clogging. Replace the throttle body, if necessary.

- O-ring
- Throttle valve
- Secondary throttle valve
- Vacuum hose
- STVA lead wire


Throttle Valve Synchronization

BENC11J11406010

Use of SDS Tool


Check and adjust the throttle valve synchronization between two cylinders.

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" (Page 1D-6).
- 2) Disconnect the IAP sensor vacuum hoses (1) at the throttle body side.



IC11J1140030-01

- 3) Connect the respective vacuum tester hoses (2) to the vacuum nipples.



IC11J1140031-01

- 4) Connect fuel feed hose. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 5) Set up the SDS tool. (Refer to the SDS operation manual for further details.)
- 6) Start the engine.
- 7) Click "Data monitor".
- 8) Warm up the engine (Water temp. more than 80 °C (176 °F) "A").

<input type="checkbox"/> Engine speed	1318	rpm
<input type="checkbox"/> Throttle position	27.0	°
<input type="checkbox"/> Engine coolant / oil temperature	"A" 89.0	°C
<input type="checkbox"/> Manifold absolute pressure 1	63.4	kPa
<input type="checkbox"/> Intake air temperature	33.0	°C

I944H1140344-02

- 9) Click "Active control".
- 10) Click "ISC air volume control" (3).




I944H1140345-02

11) Click "ON" button (4) to fix the ISC air volume between 2 cylinders.

NOTE

When making this synchronization, be sure that the water temperature is within 80 – 105 °C (176 – 221 °F) "A".

Item	Value	Unit
<input type="checkbox"/> Engine speed	"B" → 1318	rpm
<input type="checkbox"/> Engine coolant / oil temperature	"A" → 86.0	°C
<input type="checkbox"/> Secondary throttle actuator position sensor	"C" → 29.8	%
<input type="checkbox"/> Manifold absolute pressure 1	126.4	kPa
<input type="checkbox"/> Manifold absolute pressure 2	126.4	kPa
<input type="checkbox"/> Manifold absolute pressure 2	60.0	kPa



1944H1140346-02

"B": Engine speed: Approx. 1300 rpm "C": ISC valve position: Approx. 30%

12) Check for the synchronization of vacuum from #1 and #2 cylinders.




IC11J1140032-01

13) Equalize the vacuum of the cylinders by turning each air screw (5) and keep it turning at idling speed.

NOTE

Always set the engine rpm at idle rpm.



IC11J1140033-01

14) If the adjustment is not yet correct, remove each air screw and clean them with a spray-type carburetor cleaner and blow dry with a compressed air. Also, clean the air screw passageways.

NOTE

- Slowly turn the air screw in clockwise and count the number of turns until the screw is lightly seated.
- Make a note of how many turns were made so the screw can be reset correctly after cleaning.

15) Repeat the procedures of 5) to 13).

16) Close the SDS tool and turn the ignition switch to OFF position.

17) Disconnect the vacuum tester and reinstall the removed parts.


18) After completing the throttle valve synchronization, clear the DTC and reset the ISC learned value using SDS tool. Refer to "ISC Learned Value Reset and Opening Initialization" in Section 1C (Page 1C-7).

ISC Learned Value Reset

BENC11J11406011



When removing or replacing the throttle body assembly, reset the ISC valve learned value in the following procedures:

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Set up the SDS tools. (Refer to the SDS operation manual for further details.)
- 3) Turn the ignition switch ON position.
- 4) Click "Active control".
- 5) Click "ISC learned value reset" (1).



I944H1140347-01


- 6) Click "Reset" button (2) to clear the ISC learned value.



I944H1140348-01

NOTE

The ISC learned value is set at preset position.



I822H1140335-02

- 7) Close the SDS tool.
- 8) Turn the ignition switch OFF position.

NOTE

The ISC valve opening initialization is automatically started after the ignition switch is turned OFF.

Engine Assembly Removal

BENC11J11406012


Before taking the engine out of the frame, wash the engine using a stream cleaner. Engine removal is sequentially explained in the following steps:

- 1) Drain engine oil. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).
- 2) Drain engine coolant. Refer to "Cooling System Inspection" in Section 0B (Page 0B-12).
- 3) Disconnect the battery (-) lead wire (1). Refer to "Battery Removal and Installation" in Section 1J (Page 1J-12).




IC11J1140034-02

- 4) Remove the air cleaner box (2). Refer to "Air Cleaner Box Removal and Installation" (Page 1D-6).




IC11J1140035-01

- 5) Remove the throttle body assembly (3). Refer to "Throttle Body Removal and Installation" (Page 1D-9).




IC11J1140036-01

- 6) Remove the radiator assembly (4). Refer to "Radiator / Cooling Fan Motor Removal and Installation" in Section 1F (Page 1F-6).



IC11J1140037-01

- 7) Remove the clamp (5) and radiator inlet hose (6).




IC11J1140038-02

- 8) Remove the muffler (7) and front exhaust pipe (8). Refer to "Exhaust Pipe / Muffler Removal and Installation" in Section 1K (Page 1K-3).




IC11J1140039-01

- 9) Remove the front spark plug caps (9) and disconnect the clamp (10).




IC11J1140040-01

- 10) Remove the rear spark plug caps (11) and disconnect the clamp (12).



IC11J1140041-03


- 11) Disconnect the ECT sensor coupler (13).



IC11J1140042-03


1D-19 Engine Mechanical:

- 12) Disconnect the generator lead wire coupler (14) and CKP sensor lead wire coupler (15) and disconnect the clamp (16).




IC11J1140043-02

- 13) Disconnect the GP sensor lead wire coupler (17) and ignition coil #1 lead wire coupler (18).




IC11J1140044-02

- 14) Disconnect the speed sensor lead wire coupler (19).




IC11J1140045-02

- 15) Disconnect the reservoir tank overflow hose (20) and reservoir tank inlet hose (21).




IC11J1140046-02

- 16) Disconnect the starter motor lead wire (22) and oil pressure switch lead wire (23) and disconnect the clamp (24).




IC11J1140047-02

- 17) Disconnect engine ground cable coupler (25).



IC11J1140048-02

- 18) Remove the engine sprocket outer cover (26).




IC11J1140049-02

- 19) Remove the side-stand switch (27).
- 20) Disengage the gearshift link arm (28) by removing the bolt (29).


NOTE

Mark the gearshift shaft head at which the gearshift link arm slit is set for correct reinstallation.




IC11J1140098-01

- 21) Remove the speed sensor (30).
- 22) Remove the engine sprocket inner cover (31).




IC11J1140050-03

- 23) Remove the dowel pins (32).
- 24) Remove the speed sensor rotor (33) by removing its bolt (34) and disconnect the clamps (35).



IC11J1140051-03

- 25) Flatten the lock washer (36).
- 26) Remove the engine sprocket nut (37) while depressing the rear brake pedal.
- 27) Remove the lock washer (36).




IC11J1140052-02

- 28) Loosen the rear axle nut (38).
- 29) Support the motorcycle with a jock or wooden block.

▲ CAUTION


Make sure that the motorcycle is supported securely.

- 30) Loosen the chain adjuster bolts (39) to provide additional chain slack, left and right.



IC11J1140053-02

- 31) Remove the engine sprocket (40).




IC11J1140054-03

1D-21 Engine Mechanical:


32) Remove the clutch release arm (41) by removing the clutch release arm bolt (42). Refer to "Clutch Cable Removal and Installation" in Section 5C (Page 5C-2).

33) Remove the return spring (43) and washer (44).




34) Disconnect the clutch cable (45).


35) Disconnect the clamp (46).



36) Disconnect the reservoir tank overflow hose clamp (47).




37) Remove the rear brake light switch (48) and right footrest bracket (49).




38) Support the engine with a proper jack (50).

▲ CAUTION

Do not support at the oil filter (51).





39) Remove the engine mounting nut (52) and bolt (53).



- 40) Loosen the engine mounting thrust adjuster lock-nut (54) with the special tool.


Special tool

 (A): 09940-14990 (Engine mounting adjust wrench)



IC11J1140061-02

- 41) Loosen the engine mounting thrust adjuster (55).




IC11J1140062-02

- 42) Remove the left engine mounting bracket (56).



IC11J1140063-02


- 43) Remove the engine mounting nut (57) and bolt (58).




IC11J1140064-02

- 44) Loosen the engine mounting thrust adjuster lock-nut (59) with the special tool.

Special tool

 (A): 09940-14990 (Engine mounting adjust wrench)




IC11J1140065-02

- 45) Loosen the engine mounting thrust adjuster (60).



IC11J1140066-02


- 46) Loosen the pinch bolt (61).



IC11J1140067-02

1D-23 Engine Mechanical:

- 47) Remove engine mount bolt (62) and gradually lower the engine. Then, take off the drive chain from the drive shaft.



- 48) Remove the engine assembly.

▲ CAUTION


Be careful not to contact the rear exhaust pipe with the frame and swingarm.

Engine Assembly Installation

BENC11J11406013

Reinstall the engine in the reverse order of engine removal. Pay attention to the following points:
Install the engine in the reverse order of engine removal. Pay attention to the following points:

- Install the collar (1) on to the crankcase properly as shown.




- Install the left engine mounting bracket (2).

Tightening torque

Engine mounting bracket bolt (a): 35 N·m (3.5 kgf·m, 25.5 lbf·ft)


←1322 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER "1322" or equivalent)




- Gradually raise the engine assembly, and then put the drive chain (3) on the driveshaft (4).


NOTICE

Be careful not to catch the wiring harness between the frame and the engine.




- Install the front upper engine mounting bolt (5), rear upper engine mounting bolt (6), rear lower engine mounting bolt (7) and nuts (8) and (9), and tighten them temporarily.





IC11J1140073-01



IC11J1140074-01

- Tighten the engine mounting thrust adjusters (10) and (11) to the specified torque.

Tightening torque

Engine mounting thrust adjuster (b): 12 N·m (1.2 kgf-m, 8.5 lbf-ft)



IC11J1140075-01



IC11J1140076-01


- Tighten the engine mounting thrust adjuster lock-nuts (12) and (13) to the specified torque with the special tool.

Special tool


11000 (A): 09940-14990 (Engine mounting adjust wrench)

Tightening torque

Engine mounting thrust adjuster lock-nut (c): 45 N·m (4.5 kgf-m, 32.5 lbf-ft)



IC11J1140077-01



IC11J1140078-01

- Tighten the rear upper engine mounting bolt (6) to the specified torque.

Tightening torque

Engine mounting bolt (d): 55 N·m (5.5 kgf-m, 40.0 lbf-ft)




IC11J1140079-01

1D-25 Engine Mechanical:

- Tighten the pinch bolt (14) to the specified torque.

Tightening torque

Engine mounting pinch bolt (e): 25 N·m (2.5 kgf-m, 18.0 lbf-ft)




IC11J1140080-01

- Tighten the engine mounting nuts (8) and (9) to the specified torque.

Tightening torque

Engine mounting nut (f): 93 N·m (9.3 kgf-m, 67.5 lbf-ft)

Engine mounting nut (g): 55 N·m (5.5 kgf-m, 40.0 lbf-ft)




IC11J1140081-01

- When installing the clutch release arm, align the punch mark "A" of clutch release arm with slit "B" of camshaft.
- Tighten the clutch release arm bolt (15) to the specified torque.


Tightening torque


Clutch release arm bolt (h): 9 N·m (0.9 kgf-m, 6.5 lbf-ft)



IC11J1140082-01

- Apply thread lock super to the driveshaft.

 : Thread lock cement 99000-32030 (THREAD LOCK CEMENT SUPER 1303 or equivalent)




IC11J1140083-01

- Tighten the engine sprocket nut (16) to the specified torque.

Tightening torque

Engine sprocket nut (i): 145 N·m (14.5 kgf-m, 105.0 lbf-ft)

- Bend the lock washer (17).




IC11J1140084-01

- Tighten the speed sensor rotor bolt (18) to the specified torque.

Tightening torque

Speed sensor rotor bolt (j): 28 N·m (2.8 kgf-m, 20.5 lbf-ft)

- Install the dowel pins (19).




IC11J1140085-02

- Tighten the speed sensor mounting bolt (20) to the special torque.

Tightening torque

Speed sensor mounting bolt (k): 4.5 N·m (0.45 kgf-m, 3.3 lbf-ft)



IC11J1140086-02


- Install the engine sprocket cover and tighten the engine sprocket cover bolts (21) to the specified torque.

NOTE

Fit the clamp to the bolt (22).

Tightening torque

Engine sprocket cover bolt (l): 5.5 N·m (0.55 kgf-m, 4.0 lbf-ft)




IC11J1140087-01

- Install the gearshift lever to the gearshift shaft in the correct position.

Gearshift lever height "a"

Standard: 20 – 30 mm (0.8 – 1.2 in)



IC11J1140088-01

- Adjust the drive chain slack. Refer to "Drive Chain Inspection and Adjustment" in Section 0B (Page 0B-15).
- After remounting the engine, route the wiring harness properly. Refer to "Wiring Harness Routing Diagram" in Section 9A (Page 9A-7).
- Connect the clutch cable. Refer to "Clutch Cable Removal and Installation" in Section 5C (Page 5C-2).
- Install the throttle body. Refer to "Throttle Body Removal and Installation" (Page 1D-9).
- Install the front exhaust pipe and muffler. Refer to "Exhaust Pipe / Muffler Removal and Installation" in Section 1K (Page 1K-3).
- Install the radiator. Refer to "Radiator / Cooling Fan Motor Removal and Installation" in Section 1F (Page 1F-6).
- Install the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" (Page 1D-6).
- Pour engine coolant and engine oil. Refer to "Cooling System Inspection" in Section 0B (Page 0B-12) and "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).
- After finishing the engine installation, check the following items.
 - Throttle cable play
Refer to "Throttle Cable Play Inspection and Adjustment" in Section 0B (Page 0B-12).
 - Throttle valve synchronization
Refer to "Throttle Valve Synchronization" in Section 0B (Page 0B-12).
 - Engine oil and coolant leakage
Refer to "Cooling Circuit Inspection" in Section 1F (Page 1F-5).
 - Clutch cable play
Refer to "Clutch System Inspection" in Section 0B (Page 0B-14).

Engine Top Side Disassembly

BENC11J11406014

It is unnecessary to remove the engine assembly from the frame when servicing the engine top side.

NOTICE


Identify the position of each removed part. Organize the parts in their respective groups (e.g., intake, exhaust) so that they can be reinstalled in their original positions.

NOTE

Before servicing the engine top side with engine in place, remove the air cleaner box, throttle body, fuel tank, exhaust pipe, muffler and etc. Refer to "Engine Assembly Removal" (Page 1D-17).

Radiator Hose / Breather Hose


Remove the radiator hose (1), oil cooler hoses (2) and breather hose (3).



1944H1140134-01

Thermostat


Remove the thermostat assembly (1) and water hoses (2).



1944H1140135-01

Intake Pipe / Water Union


Remove the intake pipe (1) and water unions (2).



1944H1140136-01

Exhaust Pipe


Remove the rear exhaust pipe (1) and gasket (2).



1944H1140137-01

Front Cylinder Head Cover


- 1) Remove the front cylinder spark plugs. Refer to "Spark Plug Cap and Spark Plug Removal and Installation" in Section 1H (Page 1H-6).
- 2) Remove the front cylinder head cover (1) and its gasket.



1944H1140138-01

Front Camshaft

- 1) Remove the valve timing inspection plug (1) and generator cover plug (2).




I944H1140139-01


- 2) Turn the crankshaft to bring the "I F" line "A" on generator rotor to the index mark "B" of the valve inspection hole and also to bring the cams to the position as shown.

NOTE

At the above condition, the front cylinder is at TDC on compression stroke and also the engraved lines "C" on the camshafts are parallel with the mating surface of the cylinder head.




I944H1140140-01




I944H1140141-01

- 3) Remove the cam chain tension adjuster cap bolt (3), washer (4) and spring (5).
- 4) Remove the front cam chain tension adjuster (6) and gasket.




IC11J1140100-01

- 5) Remove the cam chain guide No. 2 (7).
- 6) Remove the camshaft journal holders (8).



I944H1140143-01


- 7) Remove the dowel pins (9).
- 8) Remove the intake camshaft (10) and exhaust camshaft (11).



I944H1140144-01

Front Cylinder Head

- 1) Remove the front cylinder head bolt (M6) (L40) (1).




I944H1140145-01

- 2) Remove the front cylinder head (2) by removing the cylinder head bolts (M6) (L70) (3) and (M10) (4).


NOTE

Loosen the cylinder head bolts little by little diagonally with the smaller sizes first.



I944H1140146-01

- 3) Remove the front cylinder head gasket (5) and dowel pins (6).
- 4) Remove the front cam chain guide No.1 (7).




I944H1140147-01

Front Cylinder

- 1) Remove the front cylinder (1) by removing the cylinder nuts (2).


NOTE

Firmly grip the cylinder at both ends, and lift it straight up. If the cylinder does not come off, lightly tap it with a plastic hammer.



I944H1140148-01

- 2) Remove the front cylinder gasket (3) and dowel pins (4).




I944H1140149-01

Front Piston

- 1) Place a clean rag over the cylinder base so as not to drop the piston pin circlips into the crankcase.
- 2) Remove the piston pin circlip (1).
- 3) Draw out the piston pin (2) and remove the piston (3).

NOTE


Scribe the cylinder number on the piston head.



I944H1140150-01

Rear Cylinder Head Cover

- 1) Remove the rear cylinder spark plugs. Refer to "Spark Plug Cap and Spark Plug Removal and Installation" in Section 1H (Page 1H-6).
- 2) Remove the rear cylinder head cover (1) and its gasket.




I944H1140151-01

Rear Camshaft


- 1) Rotate the crankshaft 360 degrees (1 turn) counterclockwise and align the "I F" line "A" on the generator rotor with the index mark "B" of the valve timing inspection hole.

NOTE

At the above condition, the rear cylinder is at ATDC 90° on expansion stroke and also the engraved lines "C" on the camshafts are parallel with the mating surface of the cylinder head.




I944H1140152-01



I944H1140153-01


- 2) Remove the cam chain tension adjuster cap bolt (1), washer (2) and spring (3).
- 3) Remove the rear cam chain tension adjuster (4) and gasket.



I944H1140154-01


1D-31 Engine Mechanical:

- 4) Remove the cam chain guide No. 2 (5).
- 5) Remove the camshaft journal holder (6).



1944H1140155-01

- 6) Remove the dowel pins (7).
- 7) Remove the intake camshaft (8) and exhaust camshaft (9).



1944H1140156-01

Rear Cylinder Head

- 1) Remove the rear cylinder head bolt (M6) (L40) (1).




1944H1140157-01

- 2) Remove the rear cylinder head (2) by the removing cylinder head bolts (M6) (L70) (3) and (M10) (4).


NOTE

Loosen the cylinder head bolts little by little diagonally with the smaller sizes first.



1944H1140158-01

- 3) Remove the rear cylinder gasket (1) and dowel pins (2).
- 4) Remove the rear cam chain guide (3).




1944H1140159-01

Rear Cylinder

- 1) Remove the cylinder nuts (1) and clamp (2).
- 2) Remove the rear cylinder (3).


NOTE

Firmly grip the cylinder at both ends, and lift it straight up. If the cylinder does not come off, lightly tap it with a plastic hammer.



1944H1140160-01

- 3) Remove the rear cylinder gasket (4) and dowel pins (5).



1944H1140161-01

Engine Top Side Reassembly

Assemble the engine top side in the reverse order of disassembly. Pay attention to the following points:

Piston

- When installing the piston pins, apply molybdenum oil solution onto each piston pins.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)

NOTE


When installing the pistons, the indent "A" on the piston head must be faced to each exhaust side.

Rear Piston

- Place a clean rag over the cylinder base so as not to drop the piston pin circlips into the crankcase.
- Remove the piston pin circlip (1).
- Draw out the piston pin (2) and remove the piston (3).

NOTE

Scribe the cylinder number on the piston head.




1944H1140163-01

- Place a clean rag over the cylinder base so as not to drop the piston pin circlips (1) into the crankcase.
- Install the new piston pin circlips (1).

NOTE


End gap of the circlip (1) should not be aligned with the cutaway "A" in the piston pin bore.



1944H1140164-02

- Apply molybdenum oil solution to the position rings.


M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)



1944H1140162-01

1D-33 Engine Mechanical:

- Position the gaps of the three rings and side rails as shown. Before inserting piston into the cylinder, check that the gaps are so located.




1837H1140282-02

"C": 1st ring and upper side rail	[A]: IN
"D": Spacer	[B]: EX
"E": 2nd ring and lower side rail	

Cylinder


- Thoroughly wipe off oil from the fitting surface of the crankcase.
- Coat bond lightly to the mating surfaces at the parting line between the right and left crankcases as shown.

1215 : Sealant 99000-31110 (SUZUKI BOND No.1215 or equivalent)



1944H1140165-01

- Install the dowel pins (1) and new gaskets (2), front and rear.



1944H1140166-01

- Apply molybdenum oil solution to the sliding surface of the pistons and cylinder walls.


M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)



1944H1140167-01


- Hold the piston rings in proper positions, and insert each of the pistons into the respective cylinders (1).
- Install the clamp (2) to the rear cylinder.
- Tighten the cylinder nuts (3) temporarily.

Front



1944H1140169-01


Rear



1944H1140170-01

NOTE

- The cylinders can be distinguished by the embossed-letters, "FRONT" and "REAR".
- When installing the cylinders, keep the cam chains taut.
- The cam chain must not be caught between cam drive sprocket and crankcase when turning the crankshaft.



I944H1140168-01

"A": FRONT "B": REAR

Cylinder Head

NOTE

Install the front and rear cylinder heads in same manner.


- Pull the cam chains out of the cylinders and install the cam chain guides (1).
- Fit the dowel pins (2) and a new cylinder head gaskets (3) to the cylinders.

NOTICE

- There is the guide holder for the bottom end of each cam chain guides (1) cast in the crankcase.
- Be sure that the cam chain guides (1) is installed properly.

NOTE

The front and rear cam chain guides are the same.




I944H1140171-01

- Place the cylinder heads on the cylinders.


NOTE

- The cylinder heads can be distinguished by the embossed-letters, "F" and "R".
- When installing the cylinder head, keep the cam chain taut.




I944H1140172-01

- Apply engine oil to the both side of the washers and thread portion of the bolts before installing the cylinder head bolts.



I944H1140173-01



I944H1140328-01

- Tighten the cylinder head bolts (M10) (4) to the specified two-step torque with a torque wrench sequentially and diagonally.

Tightening torque

Cylinder head bolt (M10) (Initial) (a): 25 N·m (2.5 kgf-m, 18.0 lbf-ft)


Cylinder head bolt (M10) (Final) (a): 42 N·m (4.2 kgf-m, 30.5 lbf-ft)

- Tighten the other bolts (M6) (L70) (5) and (L40) (6) to the specified torque.

Tightening torque

Cylinder head bolt (M6) (L70) (b): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)

Cylinder head bolt (M6) (L40) (c): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)



I944H1140174-01




I944H1140175-01

- Tighten the cylinder nuts (7) to the specified torque.

Tightening torque

Cylinder nut (M6) (d): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)




I944H1140176-01

Front Camshaft

- Turn the crankshaft clockwise and align "I F" line "A" on the generator rotor with the index mark "B" of the valve timing inspection hole while keeping the cam chains pulled upward.

NOTICE

- Pull the cam chain upward, or the chain will be caught between crankcase and cam drive sprocket.
- To adjust the camshaft timing correctly, be sure to align "I F" line "A" with the index mark "B" and hold this position when installing the camshafts.



I944H1140177-01

- The camshafts are identified by the embossed letters.


	letter mark
Intake	INF
Exhaust	EXF

- Before replacing the camshafts on cylinder head, apply molybdenum oil solution to their journals and cam faces.
- Apply molybdenum oil solution to the camshaft journal holders.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)


NOTE

Before installing the camshaft, check that the tappets are installed correctly.



I944H1140178-01

- Pull the cam chain lightly.
- The exhaust camshaft sprocket has an arrow mark "1F" "C". Install the exhaust camshaft so that the arrow "C" is aligned with the mating surface of the cylinder head.
- Engage the cam chain with the intake camshaft sprocket.




I944H1140179-01

- The other arrow marked "2" "D" should now be pointing straight up. Starting from the roller pin that is directly above the arrow marked "2" "D", count out 16th roller pins (from the exhaust camshaft side going towards the intake camshaft side).


- Engage the 16th roller pin "E" on the cam chain with the arrow marked "3" on the intake sprocket.

NOTE

The cam chain should now be on all three sprockets. Be careful not to move the crankshaft until the camshaft journal holders and cam chain tension adjuster are secured.



I944H1140180-01




I944H1140181-01

- Install the dowel pins (1).

- Apply molybdenum oil to the camshaft journal holders.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)

- Install the camshaft journal holders, intake and exhaust.




I944H1140182-01

NOTICE

Damage to head or camshaft journal holder thrust surfaces may result if the camshaft journal holders are not drawn down evenly.

NOTE

Align the flange "F" of the camshafts with the groove "G" of the camshaft journal holders. Each camshaft journal holder is identified with a cast-on letters (IN, EX).



1944H1140183-02

- Fasten the camshaft journal holders evenly by tightening the crankshaft journal holder bolts sequentially and diagonally.


NOTICE

The camshaft journal holder bolts are made of a special material and much superior in strength, compared with other types of high strength bolts. Take special care not to use other types of bolts.

- Tighten the camshaft journal holder bolts (2) to the specified torque.

Tightening torque

Camshaft journal holder bolt (a): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)




1944H1140184-02

- Recheck the front camshaft positions, intake and exhaust.

Front Cam Chain Tension Adjuster

- Retract the push rod (1) by pushing the stopper (2).




1944H1140185-01

- Install a new gasket (3).
- Install the cam chain tension adjuster (4) with "F-UP" mark "A" faced to the top of cylinder head.
- Tighten the cam chain tension adjuster bolts (5) to the specified torque.

Tightening torque

Cam chain tension adjuster bolt (a): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)




1C11J1140101-01

- Install the spring (6), new washer (7) and cam chain tension adjuster cap bolt (8).

NOTE

Click sound is heard when the cam chain tension adjuster cap bolt is installed.



1C11J1140102-01


- Tighten the cam chain tension adjuster cap bolt (8) to the specified torque.

Tightening torque

Cam chain tension adjuster cap bolt (b): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)


NOTICE

After installing the cam chain tension adjuster, check to be sure that the adjuster works properly by checking the slack of cam chain.




IC11J1140103-01

- Install the cam chain guide No.2 (9) by tightening its bolts (10).



I944H1140189-02




I944H1140190-02

Rear Camshaft

- From the position where the front camshafts have now been installed, rotate the crankshaft 360 degrees (1 turn) counterclockwise and align the "I F" line "A" on the generator rotor with the index mark "B" of the valve timing inspection hole.

NOTICE

- Pull the cam chains upward, or the chain will be caught between crankcase and cam drive sprocket.
- To adjust the camshaft timing correctly, be sure to align "F I T" line "A" with the index mark "B" and hold this position when installing the camshafts.



I944H1140140-01

- The camshafts are identified by the embossed letters.


	letter mark
Intake	INR
Exhaust	EXR

- Before replacing the camshafts on cylinder head, apply molybdenum oil solution to their journals and cam faces.
- Apply molybdenum oil solution to the camshaft journal holders.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)

NOTE

Before installing the camshaft, check that the tappets are installed correctly.




I944H1140191-01

- Pull the cam chain lightly.
- The No. 2 intake camshaft sprocket has an arrow mark "1R" "C". Install the intake camshaft so that the arrow "C" is aligned with the mating surface of the cylinder head.
- Engage the cam chain with the intake camshaft sprocket.

NOTE

Before installing the camshaft, check that the tappets are installed correctly.




I944H1140192-01


- The other arrow marked "2" "D" should now be pointing straight up. Starting from the roller pin that is directly above the arrow marked "2" "D", count out 16 roller pins (from the intake camshaft side going towards the exhaust camshaft side).
- Engage the 16th roller pin "E" on the cam chain with the marked "3" on the exhaust sprocket.

NOTE

The cam chain should now be on all three sprockets. Be careful not to move the crankshaft until the camshaft journal holders and cam chain tension adjuster are secured.



I944H1140193-01



1944H1140194-01

- Install the dowel pins (1).



1944H1140195-01

- Apply molybdenum oil to the camshaft journal holders.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)


- Install the camshaft journal holders, intake and exhaust.

NOTICE

Damage to head or camshaft journal holder thrust surfaces may result if the camshaft journal holders are not drawn down evenly.

NOTE

Align the flange "F" of the camshafts with the groove "G" of the camshaft journal holders. Each camshaft journal holder is identified with a cast-on letters (IN, EX).



1944H1140196-01

- Fasten the camshaft journal holders evenly by tightening the camshaft journal holder bolts sequentially and diagonally.


NOTICE

The camshaft journal holder bolts are made of a special material and much superior in strength, compared with other types of high strength bolts. Take special care not to use other types of bolts.

- Tighten the camshaft journal holder bolts (2) to the specified torque.

Tightening torque


Camshaft journal holder bolt (a): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)



1944H1140197-02

Rear Cam Chain Tension Adjuster

- The rear cam chain tension adjuster are identified by the embossed letters "R-UP".
- Retract the push rod (1) by pushing the stopper (2).




1944H1140198-01

- Install a new gasket (3).
- Install the cam chain tension adjuster (4) with "R-UP" mark "A" faced to the top of cylinder head.
- Tighten the cam chain tension adjuster bolts (5) to the specified torque.

Tightening torque

Cam chain tension adjuster bolt (a): 10 N·m (1.0 kgf·m, 7.0 lbf·ft)




1944H1140199-02

- Install the spring (6), new washer (7) and cam chain tension adjuster cap bolt (8).

NOTE

Click sound is heard when the cam chain tension adjuster cap bolt is installed.



1944H1140200-01

- Tighten the cam chain tension adjuster cap bolt (8) to the specified torque.

Tightening torque

Cam chain tension adjuster cap bolt (b): 23 N·m (2.3 kgf·m, 16.5 lbf·ft)


NOTICE

After installing the cam chain tension adjuster, check to be sure that the adjuster works properly by checking the slack of cam chain.




1944H1140201-01

- Install the cam chain guide No.2 (9).



1944H1140202-01

- After installing the cam chain tension adjuster, rotate the crankshaft (some turns), and recheck the positions of the camshafts.




1944H1140203-02

- Be sure to check and adjust the valve clearance. Refer to "Valve Clearance Inspection and Adjustment" in Section 0B (Page 0B-4).
- Apply engine oil to the new O-ring.
- Install the new gasket.
- Tighten the generator cover plug (10) and valve timing inspection plug (11) to the specified torque.

Tightening torque

Generator cover plug (c): 11 N·m (1.1 kgf-m, 8.0 lbf-ft)


Valve timing inspection plug (d): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



1944H1140336-02

Cylinder Head Cover


- Pour engine oil in each oil pocket in the cylinder heads.



1944H1140204-01

- Install the new gasket to the cylinder head covers.
- Apply bond to the cam end caps of the gaskets as shown in the figure.


[BOND] : Sealant 99000-31140 (SUZUKI BOND No.1207B or equivalent)



1944H1140205-01

Rear Cam Chain Tension Adjuster

- The rear cam chain tension adjuster are identified by the embossed letters "R-UP".
- Retract the push rod (1) by pushing the stopper (2).




I944H1140198-01

- Install a new gasket (3).
- Install the cam chain tension adjuster (4) with "R-UP" mark "A" faced to the top of cylinder head.
- Tighten the cam chain tension adjuster bolts (5) to the specified torque.

Tightening torque

Cam chain tension adjuster bolt (a): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)




I944H1140199-02

- Install the spring (6), new washer (7) and cam chain tension adjuster cap bolt (8).

NOTE

Click sound is heard when the cam chain tension adjuster cap bolt is installed.



I944H1140200-01

- Tighten the cam chain tension adjuster cap bolt (8) to the specified torque.

Tightening torque

Cam chain tension adjuster cap bolt (b): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)


NOTICE

After installing the cam chain tension adjuster, check to be sure that the adjuster works properly by checking the slack of cam chain.




I944H1140201-01

- Install the cam chain guide No.2 (9).



I944H1140202-01

- After installing the cam chain tension adjuster, rotate the crankshaft (some turns), and recheck the positions of the camshafts.




1944H1140203-02

- Be sure to check and adjust the valve clearance. Refer to "Valve Clearance Inspection and Adjustment" in Section 0B (Page 0B-4).
- Apply engine oil to the new O-ring.
- Install the new gasket.
- Tighten the generator cover plug (10) and valve timing inspection plug (11) to the specified torque.

Tightening torque

Generator cover plug (c): 11 N·m (1.1 kgf-m, 8.0 lbf-ft)


Valve timing inspection plug (d): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



1944H1140336-02

Cylinder Head Cover


- Pour engine oil in each oil pocket in the cylinder heads.



1944H1140204-01


- Install the new gasket to the cylinder head covers.
- Apply bond to the cam end caps of the gaskets as shown in the figure.

1207B : Sealant 99000-31140 (SUZUKI BOND No.1207B or equivalent)



1944H1140205-01

- The cylinder head covers can be distinguished by radiator mounting hole "A".



1944H1140206-01

"A": Front cylinder only

- Place the cylinder head covers on the cylinder heads.
- Fit new gaskets (1) and (2) to each head cover bolts.

NOTE

The metal side of the gasket (1) must face to the bolt flange.




1944H1140207-01

- Tighten the cylinder head cover bolts (3) in ascending order of numbers to the specified torque.

Tightening torque

Cylinder head cover bolt (a): 14 N·m (1.4 kgf-m, 10.0 lbf-ft)



1944H1140208-01

Spark Plug


Install the spark plugs. Refer to "Spark Plug Cap and Spark Plug Removal and Installation" in Section 1H (Page 1H-6).

Exhaust Pipe

- Install the new gasket (1) and rear exhaust pipe (2).
- Tighten the exhaust pipe bolts (3) to the specified torque.

Tightening torque


Exhaust pipe bolt (a): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



1011J1140104-01

Water Union


- Apply engine coolant to the new O-ring (1).



1944H1140210-01


Intake Pipe

- Apply grease to the new O-ring.

: Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)


NOTE

- Face the "UP" mark "A" on the intake pipe to upper.
- The intake pipe can be identified by the marks, "F" and "R".



1944H1140211-05

"F": Front cylinder head intake pipe
"R": Rear cylinder head intake pipe




1944H1140212-01

- Tighten the intake pipe screws to the specified torque.

Tightening torque


Intake pipe screw (a): 8.5 N·m (0.85 kgf-m, 6.0 lbf-ft)



IC11J1140089-01

Thermostat

Install the thermostat assembly (1) and water hoses (2). Refer to "Water Hose Routing Diagram" in Section 1F (Page 1F-3).




1944H1140135-01

Radiator Hose / Breather Hose

Install the radiator hose (1), oil cooler hoses (2) and breather hose (3).

Refer to "Water Hose Routing Diagram" in Section 1F (Page 1F-3) and "Throttle Body Construction" (Page 1D-8).



1944H1140134-01

Valve Clearance Inspection and Adjustment

BENC11J11406016

Refer to "Valve Clearance Inspection and Adjustment" in Section 0B (Page 0B-4).




Camshaft Inspection


BENC11J11406017

Camshaft Identification

The camshafts can be identified by the engraved letter "A" and cords "B" stamped on the camshaft ends.



I944H1140213-01




I944H1140214-01

	Letter "A"	Cord "B"
Front intake camshaft	INF	T
Front exhaust camshaft	EXF	B
Rear intake camshaft	INR	V
Rear exhaust camshaft	EXR	D

Cam Wear

Check the camshaft for wear or damage. Measure the cam height "a" with a micrometer. Replace a camshaft if the cams are worn to the service limit.


Special tool

 : 09900-20202 (Micrometer (1/100 mm, 25 – 50 mm))

Cam height "a"

Service limit: (IN.) 35.18 mm (1.385 in)

Service limit: (EX.) 33.18 mm (1.306 in)




I649G1140199-02


Camshaft Journal Wear


Inspect the camshaft journal wear in the following procedures:

- 1) Determine whether or not each journal is worn down to the limit by measuring the oil clearance with the camshaft installed in place.
- 2) Use the plastigauge to read the clearance at the widest portion, which is specified as follows:

Special tool

 (A): 09900-22301 (Plastigauge (0.025 – 0.076 mm))

 (B): 09900-22302 (Plastigauge (0.051 – 0.152 mm))



I944H1140216-01


- 3) Install camshaft journal holder and tighten the camshaft journal holder bolts in ascending order of numbers to the specified torque. Refer to "Engine Top Side Reassembly" (Page 1D-32).

NOTE

Do not rotate the camshafts with the plastigauge in place.

Tightening torque

Camshaft journal holder bolt: 10 N·m (1.0 kgf·m, 7.0 lbf·ft)




I944H1140217-01

- 4) Remove the camshaft journal holder and measure the width of the compressed plastigauge using the envelope scale.

- 5) This measurement should be taken at the widest part of the compressed plastigauge.

Camshaft journal oil clearance (IN. & EX.)

Service limit: 0.150 mm (0.0059 in)



1944H1140218-01

- 6) If the camshaft journal oil clearance exceeds the limit, measure the inside diameter of the camshaft journal holder and the outside diameter of the camshaft journal. Replace the camshaft or the cylinder head depending upon which one exceeds the specification.

Special tool

TOOL (C): 09900-20602 (Dial gauge (1/1000 mm, 1 mm))

TOOL (D): 09900-22403 (Small bore gauge (18 - 35 mm))

Camshaft journal holder I.D. (IN. & EX.)


Standard: 22.007 - 22.028 mm (0.8664 - 0.8672 in)

Special tool


TOOL (E): 09900-20205 (Micrometer (0 - 25 mm))

Camshaft journal O.D. (IN. & EX.)

Standard: 21.959 - 21.980 mm (0.8645 - 0.8654 in)



1944H1140219-01



1944H1140220-01

Camshaft Runout

Measure the runout using the dial gauge. Replace the camshaft if the runout exceeds the limit.

Special tool


TOOL (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

TOOL (B): 09900-20701 (Magnetic stand)

TOOL (C): 09900-21304 (V-block (100 mm))

Camshaft runout (IN. & EX.)

Service limit: 0.10 mm (0.004 in)




1944H1140221-02

Cam Chain Tension Adjuster Inspection

BENC11J11406018

The cam chain tension adjusters are maintained at the proper cam chain tension automatically.

- 1) Remove the cam chain tension adjusters, front and rear adjuster. Refer to "Engine Top Side Disassembly" (Page 1D-27).
- 2) Unlock the ratchet (1), and move the push rod in place to see if it slides smoothly. If any stickiness is noted or ratchet mechanism is faulty, replace the cam chain tension adjuster assembly with a new one.



I944H1140222-01

"A": Front cam chain tension adjuster
"B": Rear cam chain tension adjuster


- 3) Install the cam chain tension adjusters. Refer to "Engine Top Side Reassembly" (Page 1D-32).

Cam Chain Guide Inspection

BENC11J11406019

Inspect the cam chain guides in the following procedures:

- 1) Remove the cam chain guides No. 1 and No. 2. Refer to "Engine Top Side Disassembly" (Page 1D-27).
- 2) Check the contacting surface of the cam chain guides. If it is worn or damaged, replace it with a new one.



I944H1140223-01


- 3) Install the cam chain guides No. 1 and No. 2. Refer to "Engine Bottom Side Reassembly" (Page 1D-66) and "Engine Top Side Reassembly" (Page 1D-32).

Cam Chain Tensioner Inspection

BENC11J11406020

Inspect the cam chain tensioner in the following procedures:

- 1) Remove the cam chain tensioner No. 1, front and rear. Refer to "Engine Bottom Side Disassembly" (Page 1D-59).
- 2) Check the contacting surface of the cam chain tensioner. If it is worn or damaged, replace it with a new one.



I944H1140224-01

- 3) Install the cam chain tensioner, front and rear. Refer to "Engine Bottom Side Reassembly" (Page 1D-66).

Cylinder Head Disassembly and Assembly

BENC11J11406021


NOTICE

Identify the position of each removed part. Organize the parts in their respective groups (i.e., intake, exhaust, No. 1 or No. 2) so that they can be installed in their original locations.

Disassembly

Oil gallery plug (Cylinder head)


Remove the oil gallery plugs (1) (for front and rear cylinder).



I944H1140225-01

Valve / Valve spring

- 1) Remove the tappet (1) and shim (2) by fingers or magnetic hand.




I944H1140226-01

- 2) When compressing the valve spring use a sleeve protector. Cut the sleeve protector as shown in the illustration.

Special tool

TOOL (A): 09919-28620 (Sleeve protector)



I944H1140227-01

- 3) Install the sleeve protector between the valve spring and cylinder head.

NOTICE

To prevent damage of the tappet sliding surface with the valve lifter attachment, use a protector.

- 4) Using the special tools, compress the valve spring and remove the two cotter halves (3) from the valve stem.


Special tool

TOOL (A): 09919-28620 (Sleeve protector)

TOOL (B): 09916-14510 (Valve spring compressor)


TOOL (C): 09916-14522 (Valve spring compressor attachment)

TOOL : 09916-84511 (Tweezers)




I944H1140228-01

- 5) Remove the valve spring retainer (4) and valve spring (5).
- 6) Pull out the valve (6) from the combustion chamber side.



I944H1140229-01

- 7) Remove the oil seal (7) and spring seat (8).



I944H1140230-01


Assembly

Assembly is in the reverse order of disassembly. Pay attention to the following points:

Valve / Valve spring

- Install the valve spring seat (1).
- Apply molybdenum oil solution to the new oil seal (2), and press-fit it into position.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)




1944H1140231-01

- Insert the valve, with its stem coated with molybdenum oil solution all around and along the full stem length without any break.

NOTICE


When inserting the valve, take care not to damage the lip of the oil seal.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)



1705H1140165-01

- Install the valve spring with the small-pitch portion "A" facing cylinder head.



1822H1140347-01

"A": Small-pitch portion	"C": Upward
"B": Large-pitch portion	"D": Paint


- Put on the valve spring retainer (3), and using the special tools, press down the spring, fit the cotter halves to the stem end, and release the lifter to allow the cotter (4) halves to wedge in between retainer and stem.

NOTICE

- Be sure to restore each spring and valve to their original positions.
- Be careful not to damage the valve and valve stem when handling it.
- To prevent damage of the tappet sliding surface with the valve lifter attachment, use a protector.


Special tool

- TOOL (A):** 09919-28620 (Sleeve protector)
- TOOL (B):** 09916-14510 (Valve spring compressor)
- TOOL (C):** 09916-14522 (Valve spring compressor attachment)
- TOOL :** 09916-84511 (Tweezers)



1944H1140232-01

- Be sure that the rounded lip "E" of the cotter fits snugly into the groove "F" in the stem end.



1944H1140233-01


3. Valve spring retainer	4. Cotter
--------------------------	-----------

- Install the tappet shims and the tappets to their original positions.

NOTE

- Apply engine oil to the stem.
- Apply molybdenum oil solution to the tappet.
- When seating the tappet shim, be sure the figure printed surface faces the tappet.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)




I944H1140234-01

Oil gallery plug (Cylinder head)

- Install the new gasket.
- Tighten the oil gallery plugs (1) to the specified torque.

Tightening torque

Oil gallery plug (Cylinder head) (M6) (a): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)



I944H1140235-01

Cylinder Head Related Parts Inspection

BENC11J11406022

Cylinder Head Distortion


- 1) Decarbonize the combustion chambers.
- 2) Check the gasketed surface of the cylinder head for distortion with a straightedge and thickness gauge, taking a clearance reading at several places as indicated. If the largest reading at any position of the straightedge exceeds the limit, replace the cylinder head.

Special tool

: 09900-20804 (Thickness gauge)

Cylinder head distortion

Service limit: 0.05 mm (0.002 in)



I944H1140236-01

Valve Stem Runout

Support the valve using V-blocks, and check its runout using the dial gauge as shown in the figure. If the runout exceeds the service limit, replace the valve.

Special tool


(A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

(B): 09900-20701 (Magnetic stand)

(C): 09900-21304 (V-block (100 mm))

Valve stem runout (IN. & EX.)

Service limit: 0.05 mm (0.002 in)




I849G1140231-03


Valve Head Radial Runout

Place the dial gauge at a right angle to the valve head face and measure the valve head radial runout. If it measures more than the service limit, replace the valve.

Special tool


 (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

 (B): 09900-20701 (Magnetic stand)

 (C): 09900-21304 (V-block (100 mm))

Valve head radial runout (IN. & EX.)

Service limit: 0.03 mm (0.001 in)




1649G1140232-03

Valve Face Wear


Visually inspect each valve face for wear. Replace any valve with an abnormally worn face. The thickness of the valve face decreases as the face wears. Measure the valve head "a". If it is out of specification replace the valve with a new one.

Special tool

 : 09900-20102 (Vernier calipers (1/20 mm, 200 mm))

Valve head thickness "a" (IN. & EX.)

Service limit: 0.5 mm (0.02 in)




1649G1140233-02

Valve Stem Deflection

Lift the valve about 10 mm (0.39 in) from the valve seat. Measure the valve stem deflection in two directions, "X" and "Y", perpendicular to each other, positioning the dial gauge as shown in the figure. If the deflection measured exceeds the service limit, then determine whether the valve or the guide should be replaced with a new one.


Special tool

 (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

 (B): 09900-20701 (Magnetic stand)

Valve stem deflection (IN. & EX.)

Service limit: 0.35 mm (0.014 in)




1944H1140237-01

Valve Stem Wear

Measure the valve stem O.D. using the micrometer.
 If the valve stem is worn down to the limit, as measured with a micrometer, replace the valve.
 If the stem is within the limit, then replace the guide.
 After replacing valve or guide, be sure to recheck the deflection.

Special tool


 (A): 09900-20205 (Micrometer (0 - 25 mm))

Valve stem O.D.

Standard (IN.): 4.475 - 4.490 mm (0.1762 - 0.1768 in)
 Standard (EX.): 4.455 - 4.470 mm (0.1754 - 0.1760 in)

NOTE

If valve guides have to be removed for replacement after inspecting related parts, carry out the steps shown in valve guide replacement. Refer to "Valve Guide Replacement" (Page 1D-53).




I718H1140122-01

Valve Seat Width

- 1) Visually check for valve seat width on each valve face. If the valve face has worn abnormally, replace the valve.
- 2) Coat the valve seat with a red lead (Prussian Blue) and set the valve in place.
- 3) Rotate the valve with light pressure.

Special tool

 (A): 09916-10911 (Valve lapper set)




I944H1140238-01

- 4) Check that the transferred red lead (Blue) on the valve face is uniform all around and in center of the valve face.
 If the seat width "a" measured exceeds the standard value, or seat width is not uniform reface the seat using the seat cutter. Refer to "Valve Seat Repair" (Page 1D-54).

Valve seat width "a" (IN. & EX.)

Standard: 0.9 - 1.1 mm (0.035 - 0.043 in)




I649G1140246-02

Valve Seat Sealing Condition

- 1) Clean and assemble the cylinder head and valve components.
- 2) Fill the intake and exhaust ports with gasoline to check for leaks. If any leaks occur, inspect the valve seat and face for burrs or other things that could prevent the valve from sealing. Refer to "Valve Seat Repair" (Page 1D-54).

▲ WARNING

Always use extreme caution when handling gasoline.



I944H1140239-02

NOTE


After servicing the valve seats, be sure to check the valve clearance after the cylinder head has been reinstalled. Refer to "Valve Clearance Inspection and Adjustment" in Section 0B (Page 0B-4).

Valve Guide Replacement

BENC11J11406023


- 1) Remove the cylinder head. Refer to "Engine Top Side Disassembly" (Page 1D-27).
- 2) Remove the valves and springs. Refer to "Cylinder Head Disassembly and Assembly" (Page 1D-47).
- 3) Using the valve guide remover, drive the valve guide out toward the intake or exhaust camshaft side.

Special tool

 (A): 09916-43211 (Valve guide remover/installer)

NOTE

- Discard the removed valve guide sub assemblies.
- Only oversized valve guides are available as replacement parts. (Part No. 11115-18D72)




I944H1140240-01

- 4) Refinish the valve guide holes in the cylinder head using the reamer and handle.


NOTICE

When refinishing or removing the reamer from the valve guide hole, always turn it clockwise.

Special tool

 (B): 09916-34580 (Valve guide reamer (10.8 mm))

 (C): 09916-34542 (Reamer handle)



I944H1140241-01

- 5) Cool down the new valve guides in a freezer for about one hour and heat the cylinder head to 100 – 150 °C (212 – 302 °F) with a hot plate.

NOTICE

Do not use a burner to heat the valve guide hole to prevent cylinder head distortion.

- 6) Apply engine oil to each valve guide and valve guide hole.
- 7) Drive the guide into the guide hole using the valve guide installer and attachment.

NOTE

Install the valve guide until the attachment contacts the cylinder head.


NOTICE

Failure to oil the valve guide hole before driving the new guide into place may result in a damaged guide or head.

Special tool


 (A): 09916-43211 (Valve guide remover/installer)

 (D): 09916-53330 (Attachment)



I717H1140113-01



1. Cylinder head	"a": 13.5 mm (0.53 in)
2. Valve guide	



I944H1140242-01


- 8) After installing the valve guides, refinish their guiding bores using the reamer. Be sure to clean and oil the guides after reaming.

Special tool

-  (C): 09916-34542 (Reamer handle)
-  (E): 09916-33210 (Valve guide reamer (4.5 mm))

NOTE

- Be sure to cool down the cylinder head to ambient air temperature.
- Insert the reamer from the combustion chamber and always turn the reamer handle clockwise.




- 9) Install the valves and springs. Refer to "Cylinder Head Disassembly and Assembly" (Page 1D-47).
- 10) Install the cylinder head. Refer to "Engine Top Side Reassembly" (Page 1D-32).

Valve Seat Repair

BENC11J11406024

The valve seats (1) for both the intake and exhaust valves are machined to three different angles. The seat contact surface is cut at 45°.



IB31G1140170-02

	Intake	Exhaust
Seat angle	30°/45°/60°	15°/45°/60°
Seat width	0.9 – 1.1 mm (0.035 – 0.043 in)	←
Valve diameter	31.0 mm (1.22 in)	25.5 mm (1.00 in)
Valve guide I.D.	4.500 – 4.512 mm (0.1772 – 0.1776 in)	←

NOTICE

- The valve seat contact area must be inspected after each cut.
- Do not use lapping compound after the final cut is made. The finished valve seat should have a velvety smooth finish but not a highly polished or shiny finish. This will provide a soft surface for the final seating of the valve which will occur during the first few seconds of engine operation.

NOTE


After servicing the valve seats, be sure to check the valve clearance after the cylinder head has been reinstalled. Refer to "Valve Clearance Inspection and Adjustment" in Section 0B (Page 0B-4).

Valve Spring

The force of the coil spring keeps the valve seat tight. Weakened spring results in reduced engine power output and often accounts for the chattering noise coming from the valve mechanism.

Check the valve springs for proper strength by measuring their free length and also by the force required to compress them. If the spring length is less than the service limit or if the force required to compress the spring does not fall within the specified range, replace the valve spring.

Special tool


 (A): 09900-20102 (Vernier calipers (1/20 mm, 200 mm))

Valve spring free length (IN. & EX.)


Service limit: 37.1 mm (1.46 in)

Valve spring tension (IN. & EX.)

Standard: 127 – 147 N (12.7 – 14.7 kgf, 28.5 – 33.0 lbs)/33.4 mm (1.31 in)



1649G1140237-03



1649G1140238-03

Tension "a"	Length "b"
127 – 147 N (12.7 – 14.7 kgf, 28.5 – 33.0 lbs)	33.4 mm (1.31 in)


Cylinder Inspection

BENC11J11406025

Cylinder Distortion


Check the gasketed surface of the cylinder for distortion with a straightedge and thickness gauge, taking a clearance reading at several places as indicated. If the largest reading at any position of the straightedge exceeds the limit, replace the cylinder.

Special tool

 : 09900-20804 (Thickness gauge)

Cylinder distortion

Service limit: 0.05 mm (0.002 in)




1944H1140244-01

Cylinder Bore


Inspect the cylinder wall for any scratches, nicks or other damage. Measure the cylinder bore diameter at six places.

Special tool


 (A): 09900-20530 (Cylinder gauge set)

Cylinder bore

Standard: 81.000 – 81.015 mm (3.1890 – 3.1896 in)



1944H1140245-01



1944H1140245-01

Piston Ring Removal and Installation


BENC11J11406026

Removal

- 1) Draw out the piston pin and remove the piston. Refer to "Engine Top Side Disassembly" (Page 1D-27).
- 2) Carefully spread the ring opening with your thumbs and then push up the opposite side of the 1st ring to remove it.

NOTE

Do not expand the piston ring excessively since it is apt to be broken down.



I944H1140247-01


- 3) Remove the 2nd ring and oil ring in the same procedure.

Installation

NOTE

- When installing the piston ring, be careful not to damage the piston.
- Do not expand the piston ring excessively since it is apt to be broken down.


- 1) Install the piston rings in the order of the oil ring, 2nd ring and 1st ring.
 - a) The first member to go into the of the oil ring groove is a spacer (1). After placing the spacer, fit the two side rails (2).



I718H1140143-02

NOTICE

When installing the spacer, be careful not to allow its two ends to overlap in the groove.



I705H1140170-02

"A": INCORRECT

"B": CORRECT

- b) Install the 2nd ring (3) and 1st ring (4) to piston.

NOTE


1st ring (4) and 2nd ring (3) differ in shape.



I823H1140147-01


NOTE

- 2nd ring has letters "2T" marked on the side. Be sure to bring the marked side to the top when fitting it to the piston.
- Be sure to bring the concave side of 1st ring to the top when fitting it to the piston.



I944H1140248-01

- 2) Position the gaps of the three rings and side rails as shown. Before inserting piston into the cylinder, check that the gaps are so located.



I837H1140282-02

"C": 1st ring and upper side rail	[A]: IN
"D": Spacer	[B]: EX
"E": 2nd ring and lower side rail	

- 3) Install the piston and piston pin. Refer to "Engine Top Side Reassembly" (Page 1D-32).

Piston and Piston Ring Inspection

BENC11J11406027

Piston Diameter


Measure the piston diameter using the micrometer at 20 mm (0.8 in) "a" from the skirt end. If the piston diameter is less than the service limit, replace the piston.

Special tool


(A): 09900-20204 (Micrometer (75 – 100 mm))

Piston diameter

Service limit: 80.880 mm (3.1842 in)



I944H1140249-01



I944H1140250-01

Piston-to-cylinder Clearance

Subtract the piston diameter from the cylinder bore diameter. If the piston-to-cylinder clearance exceeds the service limit, replace both the cylinder and the piston.

Piston-to-cylinder clearance

Service limit: 0.120 mm (0.0047 in)

Piston Ring-to-groove Clearance

Measure the side clearances of the 1st and 2nd piston rings using the thickness gauge. If any of the clearances exceed the limit, replace both the piston and piston rings.

Special tool

(A): 09900-20804 (Thickness gauge)

(B): 09900-20205 (Micrometer (0 – 25 mm))

Piston ring-to-groove clearance

Service limit: (1st): 0.180 mm (0.0071 in)

Service limit: (2nd): 0.150 mm (0.0059 in)

Piston ring groove width

"a": Standard: (1st): 0.83 – 0.85 mm (0.0327 – 0.0335 in)

"b": Standard: (1st): 1.30 – 1.32 mm (0.0512 – 0.0520 in)

"c": Standard: (2nd): 1.01 – 1.03 mm (0.0398 – 0.0406 in)


"d": Standard: (Oil): 2.01 – 2.03 mm (0.0791 – 0.0799 in)

Piston ring thickness


Standard: (1st): 0.76 – 0.81 mm (0.0299 – 0.0319 in)

Standard: (1st): 1.08 – 1.10 mm (0.0425 – 0.0433 in)


Standard: (2nd): 0.97 – 0.99 mm (0.0382 – 0.0390 in)



I849G1140263-02



I944H1140349-01



1649G1140264-03

Piston Pin / Pin Bore

Measure the piston pin bore inside diameter using the small bore gauge. If measurement is out of specification, replace the piston.


Special tool

(A): 09900-20602 (Dial gauge (1/1000 mm, 1 mm))

(B): 09900-22403 (Small bore gauge (18 – 35 mm))

Piston pin bore I.D.

Service limit: 20.030 mm (0.7886 in)



1649G1140267-03


Measure the piston pin outside diameter at three positions using the micrometer. If any of the measurements are out of specification, replace the piston pin.

Special tool

(C): 09900-20205 (Micrometer (0 – 25 mm))

Piston pin O.D.

Service limit: 19.980 mm (0.7866 in)



1649G1140268-03

Piston Ring Free End Gap and Piston Ring End Gap

Measure the piston ring free end gap using vernier calipers. Next, fit the piston ring squarely into the cylinder and measure the piston ring end gap using the thickness gauge. If any of the measurements exceed the service limit, replace the piston ring with a new one.

Special tool

(A): 09900-20101 (Vernier calipers (1/15 mm, 150 mm))

Piston ring free end gap

Service limit: (1st): 5.2 mm (0.20 in)

Service limit: (2nd): 7.2 mm (0.28 in)

Special tool

(B): 09900-20804 (Thickness gauge)


Piston ring end gap

Service limit: (1st): 0.50 mm (0.020 in)

Service limit: (2nd): 0.50 mm (0.020 in)



1649G1140265-03



1944H1140251-01

Engine Bottom Side Disassembly

BENC11J11406028

NOTICE

Identify the position of each removed part. Organize the parts in their respective groups (e.g., intake, exhaust) so that they can be reinstalled in their original positions.


NOTE

The crankcase must be separated to service the crankshaft, oil pump.

- 1) Remove the engine assembly. Refer to "Engine Assembly Removal" (Page 1D-17).
- 2) Remove the cylinder head, cylinder and piston. Refer to "Engine Top Side Disassembly" (Page 1D-27).

Starter Motor


Remove the starter motor (1).



IC11J1140105-01


Generator Cover

- 1) Remove the generator cover (1) and clutch cable stopper (2) by removing the generator cover bolts (3).



IC11J1140106-01


- 2) Remove the gasket (4), dowel pins (5) and clutch push rod (6).



1944H1140004-02

Starter Idle Gear

Remove the idle gear shaft (7) and starter idle gear (8).



1944H1140004-02

Clutch

Remove the clutch component parts (1). Refer to "Clutch Removal" in Section 5C (Page 5C-7).



IC11J1140107-01


Oil Pump

- 1) Remove the snap ring (1).


NOTE

Do not drop the snap ring (1) into the crankcase.

Special tool

 : 09900-06107 (Snap ring pliers)

- 2) Remove the oil pump driven gear (2).




I944H1140008-01

- 3) Remove the pin (3) and washer (4).

NOTE

Do not drop the pin (3) and washer (4) into the crankcase.


- 4) Remove the oil pump (5) by removing the its bolts (6).



I944H1140007-02


Oil Pipe

- 1) Remove the oil pipe stopper (1) by removing the its screw (2).



I944H1140008-02

- 2) Remove the oil pipe (3).



I944H1140009-02

Gearshift System

NOTE


Do not drop the each parts into the crankcase.

- 1) Remove the snap ring (1) and washer (2) from the gearshift shaft.

Special tool


Tool : 09900-06107 (Snap ring pliers)

- 2) Remove the gearshift shaft assembly (3) and washer (4).



I944H1140010-01

- 3) Remove the gearshift cam plate bolt (5) and gearshift cam plate (6).
 4) Remove the gearshift cam stopper bolt (7) and gearshift arm stopper (8).




I944H1140011-02

Oil Filter

Remove the oil filter (1) with the special tool.

Special tool


 (A): 09915-40620 (Oil filter wrench)



1944H1140012-01

Oil Cooler


Remove the oil cooler (1).



1944H1140013-01

Oil Pressure Switch

Remove the oil pressure switch (1).





1944H1140014-01

Primary Drive Gear

1) Hold the generator rotor with the special tool.

Special tool

 (A): 09930-44530 (Rotor holder)




1944H1140015-01

2) Remove the primary drive gear bolt (1).


NOTICE

This bolt has left-hand thread. Turning it counterclockwise may cause damage.



1944H1140016-01

3) Remove the water pump drive gear (2) and primary drive gear (3).




1944H1140017-01

Rear Cam Chain

- 1) Remove the cam chain tensioner (1).


NOTE

Do not drop the washer (2) into the crankcase.



IS44H1140018-01


- 2) Remove the rear cam chain (3) and cam chain drive sprocket (4).



IS44H1140019-01

Generator Rotor


Remove the generator rotor (1). Refer to "Generator Removal and Installation" in Section 1J (Page 1J-4).



IS44H1140020-01

Starter Driven Gear

Remove the key (1) and starter driven gear (2).




IS44H1140021-01

Front Cam Chain

- 1) Remove the cam chain tensioner (1).


NOTE

Do not drop the washer (2) into the crankcase.



IS44H1140022-02


- 2) Remove the front cam chain (3).



IS44H1140023-01


Gear Position Switch

- 1) Remove the driveshaft oil seal retainer (1) by removing its bolts (2).



1944H1140024-02


- 2) Remove the gear position switch (3) by removing its bolts (4).
- 3) Remove the O-ring (5).



1944H1140025-02

Crankcase

- 1) Remove the oil plate (1) by removing its bolts (2).




1944H1140026-02


- 2) Remove the crankcase bolts (M6) (3).
- 3) Remove the crankcase bolts (M8) (4).

NOTE

Loosen the crankcase bolts diagonally and smaller sizes first.



1944H1140027-02




1944H1140028-02

- 4) Separate the crankcase into two parts, right and left with the special tool.

NOTE

- Fit the crankcase separating tool, so that the tool arms are in parallel with the side of crankcase.
- The crankshaft and transmission components should remain in the left crankcase half.


Special tool

 (A): 09920-13120 (Crankcase separating tool)



1944H1140029-02


- 5) Remove the O-rings (5) and dowel pins (6).



I944H1140030-02

Oil Strainer


- 1) Remove the oil strainer plate (1).
- 2) Remove the oil strainer (2).



I944H1140031-02

Oil Pressure Regulator


Remove the oil pressure regulator (1).



I944H1140032-01

Crankshaft


Remove the crankshaft (1).



I944H1140033-01

Transmission / Gearshift

- 1) Remove the transmission component. Refer to "Transmission Removal and Installation" in Section 5B (Page 5B-3).
- 2) Remove the engine sprocket spacer (1) and O-ring (2).




I944H1140035-01

Oil Jet

Piston cooling oil jet


- 1) Remove the plates (1) by removing the its bolts (2).
- 2) Remove the piston cooling oil jets (3) from left and right crankcase halves.



I944H1140036-02

Oil gallery jet (for cylinder)


Remove the oil gallery jets (1) (for cylinder) from left and right crankcase halves.



1944H1140037-02


Oil Gallery Jet (for Transmission)

- 1) Remove the clutch push rod oil seal (1).
- 2) Remove the oil gallery plug (M8) (2).
- 3) Remove the oil gallery plug (M6) (3) if necessary.



1944H1140038-01

- 4) Remove the oil gallery jet (for transmission) (4) with a suitable bar (5).



1944H1140039-02

NOTE

Loc


Crankshaft Journal Bearing


- 1) Set the special tool as shown to remove the crankshaft journal bearings (1) with the special tool.

NOTE

Remove the crankshaft journal bearings in only one direction, from inside to outside of each crankcase half.

Special tool

 (A): 09913-60221 (Journal bearing installer and holder)




1944H1140040-01

- 2) Gradually press out the journal bearings with the special tool by using the hydraulic-press.



1944H1140041-01




1944H1140042-01


1. Journal bearing	3. hydraulic press
2. Crankcase	

Oil Gallery Plug

- 1) Remove the oil gallery plugs (M6) (1), (M8) (2) and (M12) (3) from the left crankcase.




I944H1140043-01



I944H1140044-01


- 2) Remove the oil gallery plugs (M8) (4) and (M16) (5) from the right crankcase.




I944H1140045-01

Transmission Oil Seal / Bearing

Remove the transmission oil seals (1) and bearings (2) if necessary. Refer to "Transmission Removal and Installation" in Section 5B (Page 5B-3) and "Gearshift Shaft Oil Seal Removal and Installation" in Section 5B (Page 5B-18).



I944H1140046-02



I944H1140047-02

Engine Bottom Side Reassembly

BENC11J11406029

Assembly the engine bottom side in the reverse order of disassembly. Pay attention to the following points:

NOTE

Apply engine oil to each running and sliding part before reassembling.

Transmission Oil Seal / Bearing

- Install the transmission oil seals and bearings. Refer to "Transmission Oil Seal / Bearing Removal and Installation" in Section 5B (Page 5B-10) and "Gearshift Shaft Oil Seal Removal and Installation" in Section 5B (Page 5B-18).

Oil Gallery Plug

- Install the new gaskets.
- Tighten each plug to the specified torque.


Tightening torque

Oil gallery plug (M6) (a): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)


Oil gallery plug (M8) (b): 18 N·m (1.8 kgf-m, 13.0 lbf-ft)

Oil gallery plug (M12) (c): 21 N·m (2.1 kgf-m, 15.0 lbf-ft)


Oil gallery plug (M16) (d): 35 N·m (3.5 kgf-m, 25.5 lbf-ft)



1944H1140048-01



1944H1140049-01



1944H1140050-01

Crankcase Journal Bearing

- Set the specified crankshaft journal bearings (1) to the special tool.


NOTICE

Before setting the bearing, apply molybdenum oil solution to the special tool and bearings.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)

Special tool

TOOL (A): 09913-60221 (Journal bearing installer and holder)




1944H1140051-01

- When setting the bearing, align the bearing side with the engraved line "A" and also the bearing end with the mating surface of the special tool.

NOTE

The upper and lower bearings are same.



1944H1140052-01


- Tighten the special tool bolts to the specified torque.

Special tool

Tool (A): 09913-60221 (Journal bearing installer & holder)

Tightening torque

Special tool bolt (a): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



I944H1140053-01

- Set the bearings installed in the special tool to the crankcase half as shown.

NOTICE


- Before installing the bearings, lightly shave off the sharp edge part "B" of the crankcase chamfer by using an oilstone and wash the crankcase bore with enough molybdenum oil solution.
- Be sure the bearing protruded side "C" faces the crankcase bore.
- Align the bearing/special tool mating surface with the line "D" on the crankcase.

NOTE


Install the bearing from inside to outside of each crankcase halves.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)

- The color code of the bearing must face crankshaft side.



I944H1140054-01




I944H1140055-01

- Apply enough molybdenum oil solution to the special tool and the bearings and then set the special tool carefully.


M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)

1D-69 Engine Mechanical:



- Gradually press in the bearing into the main journal bore by using the hydraulic press until the special tool (1) contacts the special tool (2).



1944H1140056-01



1944H1140057-01




1944H1140058-02

1. Journal bearing 2. hydraulic press

- After installing the bearings (1), check the bearing surface for any scratch or damage.

Left side

Right side





1944H1140059-02

Oil Jet

- Fit the new O-rings to each oil jets.
- Apply grease to new O-ring.

⚠️ : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)

- Install the oil gallery jet (for transmission) (1) with a suitable bar.




1944H1140060-01

- Install the new gaskets.
- Tighten the oil gallery plug (M8) (2) and (M6) (3) to the specified torque.

Tightening torque

Oil gallery plug (M8) (a): 18 N·m (1.8 kgf-m, 13.0 lbf-ft)


Oil gallery plug (M6) (b): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)




1944H1140065-01


- Install the new clutch push rod oil seal (4) with the special tool.

Special tool

 (A): 09913-70210 (Bearing installer set)


- Apply grease to the lip of oil seal.

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)




1944H1140062-01

- Apply grease to new O-rings.


 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)

- Install the oil gallery jets (5) (for cylinder) to the left and right crankcase halves.




1944H1140063-02

- Apply grease to new O-rings.


 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)

- Install the piston cooling oil jets (6) to the left and right crankcase halves.




1944H1140064-02

- Apply a small quantity of thread lock to the bolts (7) and tighten them to the specified torque.

 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER "1322" or equivalent)

Tightening torque

Piston cooling oil jet bolt (c): 10 N·m (1.0 kgf·m, 7.0 lbf·ft)



1944H1140065-02


Transmission / Gearshift

Install the transmission component. Refer to "Transmission Removal and Installation" in Section 5B (Page 5B-3).

Crankshaft

- Coat lightly molybdenum oil solution to the crankshaft journal bearings.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)



1944H1140066-01


- Install the crankshaft assembly into the left crankcase.

NOTICE

Never strike the crankshaft with a plastic hammer when inserting it into the crankcase.

NOTE

- Be sure to set the crankshaft in the proper direction.
- Of the two conrods, the one with the embossed letter marked should be brought to the rear cylinder.




IC11J1140108-01

Oil Pressure Regulator

- Tighten the oil pressure regulator (1) to the specified torque.

Tightening torque

Oil pressure regulator (a): 27 N·m (2.7 kgf-m, 19.5 lbf-ft)




1944H1140067-01

Oil Strainer


- Install the oil strainer (1).

NOTICE

- The lip "A" of the oil strainer should be positioned downward.
- The shorter side "B" of the oil strainer should be positioned inside.




1944H1140068-01



1944H1140069-02

"A": Lip	"C": Shorter side
"B": Lower side	

- Install the oil strainer plate (2).




1944H1140070-02

Crankcase

- Clean the mating surface of the left and right crankcase halves.
- Apply grease to the new O-rings (1).

Ex: Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)

- Install the O-rings (1) and dowel pins (2).




1944H1140072-02

- Apply bond to the mating surface of the right crankcase.

NOTE

- Make surfaces free from moisture, oil, dust and other foreign materials.
- Spread on surfaces thinly to form an even layer, and assemble the crankcases within few minutes.
- Take extreme care not to apply any bond to the oil hole, oil groove and bearing.
- Apply to distorted surfaces as it forms a comparatively thick film.

Ex: Sealant 99000-31110 (SUZUKI BOND No.1215 or equivalent)



1944H1140073-02

- Tighten the crankcase bolts a little at a time to equalize the pressure.

NOTICE

Do not drop the O-ring into the crankcase when assembling the right and left crankcase halves.

NOTE


Fit the clamp (3) to the bolt as shown.

Tightening torque

Crankcase bolt (M8) (a): 26 N·m (2.6 kgf-m, 19.0 lbf-ft)


Crankcase bolt (M6) (b): 11 N·m (1.1 kgf-m, 8.0 lbf-ft)

- After the crankcase bolts have been tightened, check if the crankshaft, the driveshaft and the countershaft rotate smoothly.



1944H1140074-02

"A": Crankcase bolt (M8) (L80)





1944H1140075-02

"B": Crankcase bolt (M8) (L55)

1D-73 Engine Mechanical:

- Apply grease to the new oil seal lip and new O-ring (4).

 Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)




1944H1140076-01

- Install the engine sprocket spacer (5).

NOTE

The grooved "A" side of the engine sprocket spacer (5) must face crankcase side.




1944H1140077-01

- Install the oil plate (6).
- Tighten the oil plate bolts (7) to the specified torque.

Tightening torque

Oil plate bolt (c): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)



1944H1140078-02


Gear Position Switch

- Apply grease to the new O-ring.

NOTE


Align the gear position switch pin "A" with the gearshift cam hole "B".

 Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)




1944H1140079-01

- Tighten the gear position switch bolts (1) to the specified torque.

 Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER "1322" or equivalent)

Tightening torque

Gear position switch bolt (a): 6.5 N·m (0.65 kgf-m, 4.7 lbf-ft)




IC11J1140090-02

- Install the drive shaft oil seal retainer (2).

NOTE


Pass the gear position switch lead wire under the driveshaft oil seal retainer.



1944H1140081-02

Front Cam Chain

- Install the front cam chain (1).




1944H1140082-01

- Install the cam chain tensioner (2), washer (3) and cam chain tensioner bolt (4).
- Tighten the cam chain tensioner bolt (4) to the specified torque.

Tightening torque


Cam chain tensioner bolt (a): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)



1944H1140083-01

Starter Driven Gear


- Apply engine oil to the bushing of the starter driven gear.



1944H1140084-02

Generator Rotor

- Install the generator rotor (1). Refer to "Generator Removal and Installation" in Section 1J (Page 1J-4).




1944H1140085-01

Rear Cam Chain

- Install the cam chain drive sprocket (1).

NOTE

Align the punched mark "A" on the cam chain drive sprocket with the punched mark "B" on the crankshaft.



1944H1140086-02

- Install the rear cam chain (2).



IS44H1140087-01

- Install the cam chain tensioner (3), washer (4) and cam chain tensioner bolt (5).
- Tighten the cam chain tensioner bolt (5) to the specified torque.

Tightening torque


Cam chain tensioner bolt (a): 10 N·m (1.0 kgf·m, 7.0 lbf·ft)



IS44H1140088-01

Primary Drive Gear

- Install the primary drive gear (1) and water pump drive gear (2).



IS44H1140089-01

- Hold the generator rotor with the special tool.


Special tool

(A): 09930-44530 (Rotor holder)

- Tighten the primary drive gear bolt (3) to the specified torque.

Tightening torque

Primary drive gear bolt (a): 70 N·m (7.0 kgf·m, 50.5 lbf·ft)



IS44H1140090-01

Oil Pressure Switch

- Apply bond to the thread part of the oil pressure switch (1) and tighten the oil pressure switch (1) to the specified torque.


NOTE

Be careful not to apply bond to the hole of thread end.

Sealant : Sealant 99000-31140 (SUZUKI BOND No.1207B or equivalent)

Tightening torque

Oil pressure switch (a): 14 N·m (1.4 kgf·m, 10.0 lbf·ft)



IS44H1140091-01


Oil Cooler

- Apply grease to the new O-ring.

NOTE

When install the oil cooler, fit the convex part "A" of the left crankcase onto the concave part "B" of the oil cooler.

 Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)




1944H1140092-01

- Tighten the union bolt (1) to the specified torque.

Tightening torque

Oil cooler union bolt (a): 70 N·m (7.0 kgf-m, 50.5 lbf-ft)





1944H1140093-01

Oil Filter

- Install the oil filter with the special tool. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).

Special tool


 (A): 09915-40620 (Oil filter wrench)



1944H1140094-01

Gearshift System

- Install the gearshift cam stopper (1), bolt (2), washer (3) and return spring (4).



1944H1140095-01


- Tighten the gearshift cam stopper bolt (2) to the specified torque.

NOTE

Hook the return spring end "A" to the stopper (1).

Tightening torque

Gearshift cam stopper bolt (a): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)




1944H1140096-01

- Check the gearshift cam stopper moves smoothly.
- Locate the gearshift cam in the neutral position.
- Install the gearshift cam stopper plate (5).

NOTE


Align the gearshift cam pins "B" with the gearshift cam stopper plate holes "C".



1944H1140097-01

1D-77 Engine Mechanical:

- Degrease thread portion of the gearshift cam stopper plate bolt (6) and gearshift cam.
- Apply thread lock to the gearshift cam stopper plate bolt (6) and tighten it to the specified torque.

 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER "1322" or equivalent)


Tightening torque

Gearshift cam stopper plate bolt (b): 13 N·m (1.3 kgf-m, 9.5 lbf-ft)




1944H1140098-02

- Apply thread lock to the gearshift arm stopper (7) and tighten it to the specified torque.

 : Thread lock cement 99000-32030 (THREAD LOCK CEMENT SUPER 1303 or equivalent)

Tightening torque

Gearshift arm stopper (c): 19 N·m (1.9 kgf-m, 13.5 lbf-ft)




1944H1140100-01


- Install the gearshift shaft assembly (8) and washers (9) as shown in the figure.

NOTE

Pinch the gearshift arm stopper (7) with return spring ends "D".




1944H1140101-01




1944H1140102-02

- Install the washer (10) and new snap ring (11).

Special tool


 : 09900-06107 (Snap ring pliers (Open type))



1944H1140103-01

Oil Pipe

- Install the oil pipe (1).



1944H1140104-01


- Tighten the oil pipe stopper screw (2) to the specified torque.

NOTE

Align the projection "A" of the oil pipe with the groove "B" of its stopper.

Tightening torque

Oil pipe stopper screw (a): 8 N·m (0.8 kgf-m, 5.7 lbf-ft)



1944H1140105-01

Oil Pump

- Tighten the oil pump mounting bolts (1) to the specified torque.

Tightening torque


Oil pump mounting bolt (a): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)



- Install the washer (2) and pin (3).

NOTE


Be careful not to drop the washer (2) and pin (3) into the crankcase.




IC11J1140092-01

- Install the oil pump driven gear (4) and new snap ring (5).

Special tool


 : 09900-06107 (Snap ring pliers)



1944H1140107-02

Clutch

Install the clutch component parts (1). Refer to "Clutch Installation" in Section 5C (Page 5C-9).




IC11J1140107-01

Starter Idle Gear

- Apply molybdenum oil solution to both ends of the shaft (1).

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)

- Install the starter idle gear (2) and shaft (1).




IC11J1140109-01

Generator Cover

- Install the dowel pins (1), new gasket (2) and clutch push rod (3).
- Apply a small quantity of grease to the push rod (3).

⚠: Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)




1944H1140110-01

- Install the generator cover (4), clutch cable stopper (5) and clamp (6).
- Fit the new gasket washer to the generator cover mounting bolts "A" correctly as shown.
- Tighten the generator cover mounting bolts to the specified torque.

Tightening torque

Generator cover mounting bolt: 10 N·m (1.0 kgf-m, 7.0 lbf-ft)



1944H1140111-02

Starter Motor

- Apply grease to the new O-ring.

⚠: Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



1944H3190003-01

- Tighten the starter motor mounting bolts (1) to the specified torque.

Tightening torque

Starter motor mounting bolt (a): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)



IC11J1140093-02

Engine Top Side

Assembly the engine top side. Refer to "Engine Top Side Reassembly" (Page 1D-32).

Conrod Removal and Installation

BENC11J11406030

Removal

- 1) Remove the crankshaft assembly from the crankcase. Refer to "Engine Bottom Side Disassembly" (Page 1D-59).
- 2) Loosen the conrod cap bolts, and tap the conrod cap bolts lightly with plastic hammer to remove the conrod cap.
- 3) Remove the conrods and mark them to identify their respective cylinders.



I944H1140114-01


- 4) Remove the bearings (1).

NOTICE

When removing the bearings, be careful not to scratch the conrods and the bearings.

NOTE

- Do not remove the bearings (1) unless absolutely necessary.
- Make a note of where the bearings are removed from so that they can be reinstalled in their original positions.




I718H1140269-01

Installation

- 1) When installing the bearings into the conrod cap and conrod, be sure to fix the stopper part "A" first, and then press in the opposite side of the bearing.

NOTE

Inspect and select the conrod crank pin bearing if necessary. Refer to "Conrod Crank Pin Bearing Inspection and Selection" (Page 1D-82).




I717H1140221-02

- 2) Apply molybdenum oil solution to the crank pin and bearing surface.

NOTICE

Be sure to clean the conrod big end.


M/O: Molybdenum oil (Molybdenum oil solution)




I718H1140273-01

1D-81 Engine Mechanical:

- 3) When fitting the conrod cap, make sure that I.D. code "B" on each conrod faces intake side and that embossed lettering "C" on each conrod faces outside.




1944H1140115-01



1944H1140116-01

- 4) Apply engine oil to the conrod cap bolts.




1944H1140117-02


- 5) Tighten the conrod cap bolts as following two steps.

Tightening torque

Conrod cap bolt: 21 N·m (2.1 kgf·m, 15.0 lbf·ft)
then turn in 90° turn



1944H1140118-01



1944H1140119-01

"a": 90°

- 6) Apply molybdenum oil solution to the conrod big end side surfaces.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)

- 7) Check that the conrod moves smoothly.
8) Install the crankshaft assembly to the crankcase.
Refer to "Engine Bottom Side Reassembly" (Page 1D-66).



Conrod / Crankshaft Inspection


BENC11J11406031


Conrod Small End I.D.

Measure the conrod small end inside diameter using the small bore gauge.

If the conrod small end inside diameter exceeds the service limit, replace the conrod.


Special tool

 (A): 09900-20602 (Dial gauge (1/1000 mm, 1 mm))

 (B): 09900-22403 (Small bore gauge (18 – 35 mm))

Conrod small end I.D.

Service limit: 20.040 mm (0.7890 in)




I944H1140099-01

Conrod Big End Side Clearance


- 1) Check the conrod big end side clearance using the thickness gauge.

Special tool

 (A): 09900-20804 (Thickness gauge)

Conrod big end side clearance

Service limit: 0.50 mm (0.020 in)




I944H1140120-01

- 2) If the clearance exceeds the limit, remove the conrod and measure the conrod big end width and crank pin width. Refer to "Conrod Removal and Installation" (Page 1D-80). If the width exceed the limit, replace the conrod or crankshaft.

Special tool

 (B): 09900-20205 (Micrometer (0 – 25 mm))


 : 09900-20101 (Vernier calipers (1/15 mm, 150 mm))

Conrod big end width

Standard: 20.95 – 21.00 mm (0.825 – 0.827 in)

Crank pin width "a"

Standard: 42.17 – 42.22 mm (1.660 – 1.662 in)



I944H1140121-01


Conrod Crank Pin Bearing Inspection and Selection

BENC11J11406032

Refer to "Conrod Removal and Installation" (Page 1D-80).

Inspection

- 1) Inspect the bearing surfaces for any signs of fusion, pitting, burn or flaws. If any, replace them with a specified set of bearings.




I716H1140285-01

1D-83 Engine Mechanical:

- Place the plastigauge axially along the crank pin, avoiding the oil hole, as shown.

Special tool

(A): 09900-22301 (Plastigauge (0.025 – 0.076 mm))



1944H1140122-01


- Tighten the conrod cap bolts to the specified torque, in two stages. Refer to "Conrod Removal and Installation" (Page 1D-80).

NOTE

- When installing the conrod cap to the crank pin, make sure that I.D code "A" on the conrod faces towards the intake side.
- Never rotate the crankshaft or conrod when a piece of plastigauge is installed.

Tightening torque

Conrod cap bolt: 21 N·m (2.1 kgf·m, 15.0 lbf·ft)
then turn in 90° turn



1944H1140123-01


- Remove the conrod caps and measure the width of the compressed plastigauge using the envelope scale. This measurement should be taken at the widest part of the compressed plastigauge. If the oil clearance exceeds the service limit, select the specified bearings from the bearing selection table.

Conrod big end oil clearance

Standard: 0.032 – 0.056 mm (0.0013 – 0.0022 in)

Conrod big end oil clearance


Service limit: 0.080 mm (0.0031 in)



1944H1140124-02

Selection

- Check the corresponding conrod I.D. code numbers ([1] or [2]) "A".




1822H1140296-01

Conrod I.D. specification

Code "A"	I.D. specification
1	41.000 – 41.008 mm (1.6142 – 1.6145 in)
2	41.008 – 41.016 mm (1.6145 – 1.6148 in)

- 2) Check the corresponding crank pin O.D. code numbers ([1], [2] or [3]) "B".



1944H1140125-02

- 3) Measure the conrod crank pin O.D. with the special tool. If any of the measurements are out of specification, replace the crankshaft.

NOTE


The crank pin O.D. measurement should be taken at 10.5 mm and 31.5 mm positions from the crank pin end.

Crank pin O.D. specification

Code "B"	O.D. specification
1	37.992 – 38.000 mm (1.4957 – 1.4961 in)
2	37.984 – 37.992 mm (1.4954 – 1.4957 in)
3	37.976 – 37.984 mm (1.4951 – 1.4954 in)

Special tool

(A): 09900-20202 (Micrometer (1/100 mm, 25 – 50 mm))



1944H1140126-01

"a": 10.5 mm (0.413 in)	"b": 31.5 mm (1.240 in)
-------------------------	-------------------------

- 4) Select the specified bearings from the bearing selection table.

NOTICE

The bearings should be replaced as a set.


Bearing selection table

Conrod I.D. "A"	Code	Crank pin O.D. "B"		
		1	2	3
	1	Green	Black	Brown
	2	Black	Brown	Yellow

1718H1140293-01

Bearing thickness specification

Color "C" (Part No.)	Thickness
Green (12164-46E01-0A0)	1.480 – 1.484 mm (0.0583 – 0.0584 in)
Black (12164-46E01-0B0)	1.484 – 1.488 mm (0.0584 – 0.0586 in)
Brown (12164-46G01-0C0)	1.488 – 1.492 mm (0.0586 – 0.0587 in)
Yellow (12164-46E01-0D0)	1.492 – 1.496 mm (0.0587 – 0.0589 in)



1649G1140336-02


"C": Color code

Crankshaft Journal Bearing Inspection and Selection

BENC11J11406033

Inspection


- 1) Inspect each upper and lower crankcase bearings (1) for any damage.



1944H1140127-01

1D-85 Engine Mechanical:


- 2) Inspect the crankshaft journal for any damage.



I944H1140128-01


- 3) Measure the crankshaft O.D. with the special tool. If any of the measurements are out of specification, replace the crankshaft.

Special tool


 (A): 09900-20202 (Micrometer (1/100 mm, 25 – 50 mm))

Crankshaft journal O.D.

Standard: 41.985 – 42.000 mm (1.6529 – 1.6535 in)



I944H1140129-01



I944H1140132-01

Crankcase journal I.D. specification

Code "A"	I.D. specification	Bearing color
A	46.000 – 46.006 mm (1.8110 – 1.8113 in)	Green
B	46.006 – 46.012 mm (1.8113 – 1.8115 in)	Black
C	46.012 – 46.018 mm (1.8115 – 1.8117 in)	Brown

Bearing thickness specification

Color "B" (Part No.)	Thickness
Green (12229-44H00-0A0)	1.999 – 2.002 mm (0.0787 – 0.0788 in)
Black (12229-44H00-0B0)	2.002 – 2.005 mm (0.0788 – 0.0789 in)
Brown (12229-44H00-0C0)	2.005 – 2.008 mm (0.0789 – 0.0791 in)




I944H1140133-01

Selection

- 1) Select the specified bearings from the crankcase journal I.D. codes. The crankcase journal I.D. codes ((A), (B) or (C)) "A", is stamped on the inside of each crankcase half.

▲ CAUTION

The bearings should be replaced as a set.



I944H1140131-01

Specifications

Service Data

BENC11J11407001

Valve + Guide

Unit: mm (in)

Item	Standard		Limit
Valve diam.	IN.	31.0 (1.22)	—
	EX.	25.5 (1.00)	—
Valve clearance (when cold)	IN.	0.10 – 0.20 (0.004 – 0.008)	—
	EX.	0.20 – 0.30 (0.008 – 0.012)	—
Valve guide to valve stem clearance	IN.	0.010 – 0.037 (0.0004 – 0.0015)	—
	EX.	0.030 – 0.057 (0.0012 – 0.0022)	—
Valve guide I.D.	IN. & EX.	4.500 – 4.512 (0.1772 – 0.1776)	—
Valve stem O.D.	IN.	4.475 – 4.490 (0.1762 – 0.1768)	—
	EX.	4.455 – 4.470 (0.1754 – 0.1760)	—
Valve stem deflection	IN. & EX.	—	0.35 (0.014)
Valve stem runout	IN. & EX.	—	0.05 (0.002)
Valve head thickness	IN. & EX.	—	0.5 (0.02)
Valve seat width	IN. & EX.	0.9 – 1.1 (0.035 – 0.043)	—
Valve head radial runout	IN. & EX.	—	0.03 (0.001)
Valve spring free length	IN. & EX.	—	37.1 (1.46)
Valve spring tension	IN. & EX.	127 – 147 N (12.7 – 14.7 kgf, 28.5 – 33.0 lbs) at length 33.4 mm (1.31 in)	—

Camshaft + Cylinder Head

Unit: mm (in)

Item	Standard		Limit
Cam height	IN.	35.48 – 35.55 (1.397 – 1.400)	35.18 (1.385)
	EX.	33.48 – 33.55 (1.318 – 1.321)	33.18 (1.306)
Camshaft journal oil clearance	IN. & EX.	0.027 – 0.069 (0.0011 – 0.0027)	0.150 (0.0059)
Camshaft journal holder I.D.	IN. & EX.	22.007 – 22.028 (0.8664 – 0.8672)	—
Camshaft journal O.D.	IN. & EX.	21.959 – 21.980 (0.8645 – 0.8654)	—
Camshaft runout	IN. & EX.	—	0.10 (0.004)
Cam chain pin (at arrow "3")	16th pin		—
Cylinder head distortion	—		0.05 (0.002)

Cylinder + Piston + Piston Ring

Unit: mm (in)

Item	Standard		Limit
Compression pressure	1 300 – 1 700 kPa (13 – 17 kgf/cm ² , 185 – 242 psi)		1 100 kPa (11 kgf/cm ² , 156 psi)
Compression pressure difference	—		200 kPa (2.0 kgf/cm ² , 28 psi)
Piston-to-cylinder clearance	0.025 – 0.035 (0.0010 – 0.0014)		0.120 (0.0047)
Cylinder bore	81.000 – 81.015 (3.1890 – 3.1896)		No nicks or Scratches
Piston diam.	80.970 – 80.985 (3.1878 – 3.1884) Measure 20 mm (0.8 in) from the skirt end.		80.880 (3.1842)
Cylinder distortion	—		0.05 (0.002)
Piston ring free end gap	1st	—	Approx. 6.5 (0.26)
	2nd	2T	Approx. 9.0 (0.35)
Piston ring end gap	1st	—	0.06 – 0.18 (0.002 – 0.007)
	2nd	2T	0.06 – 0.18 (0.002 – 0.007)
Piston ring-to-groove clearance	1st	—	0.180 (0.0071)
	2nd	—	0.150 (0.0059)
Piston ring groove width	1st	0.83 – 0.85 (0.0327 – 0.0335)	—
	2nd	1.30 – 1.32 (0.0512 – 0.0520)	—
	Oil	2.01 – 2.03 (0.0791 – 0.0799)	—

1D-87 Engine Mechanical:

Item	Standard		Limit
	Piston ring thickness	1st	
2nd		0.97 – 0.99 (0.0382 – 0.0390)	—
Piston pin bore I.D.	20.002 – 20.008 (0.7875 – 0.7877)		20.030 (0.7886)
Piston pin O.D.	19.992 – 20.000 (0.7871 – 0.7874)		19.980 (0.7866)

Conrod + Crankshaft

Unit: mm (in)

Item	Standard	Limit
Conrod small end I.D.	20.010 – 20.018 (0.7878 – 0.7881)	20.040 (0.7890)
Conrod big end side clearance	0.170 – 0.320 (0.0067 – 0.0126)	0.5 (0.020)
Conrod big end width	20.95 – 21.00 (0.825 – 0.827)	—
Crank pin width	42.17 – 42.22 (1.660 – 1.662)	—
Conrod big end oil clearance	0.032 – 0.056 (0.0013 – 0.0022)	0.080 (0.0031)
Crank pin O.D.	37.976 – 38.000 (1.4951 – 1.4961)	—
Crankshaft journal O.D.	41.985 – 42.000 (1.6529 – 1.6535)	—
Crankshaft runout	—	0.05 (0.002)

Tightening Torque Specifications

BENC11J11407002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Throttle cable lock-nut	4.5	0.45	3.3	☞(Page 1D-10)
STP sensor mounting screw	3.5	0.35	2.5	☞(Page 1D-12)
TP sensor mounting screw	3.5	0.35	2.5	☞(Page 1D-13)
Fuel delivery pipe mounting screw	3.5	0.35	2.5	☞(Page 1D-14)
EVAP system purge control valve bracket screw	5	0.5	3.5	☞(Page 1D-14)
EVAP system purge control valve nut	7	0.7	5.0	☞(Page 1D-14)
Engine mounting bracket bolt	35	3.5	25.5	☞(Page 1D-23)
Engine mounting thrust adjuster	12	1.2	8.5	☞(Page 1D-24)
Engine mounting thrust adjuster lock-nut	45	4.5	32.5	☞(Page 1D-24)
Engine mounting bolt	55	5.5	40.0	☞(Page 1D-24)
Engine mounting pinch bolt	25	2.5	18.0	☞(Page 1D-25)
Engine mounting nut	93	9.3	67.5	☞(Page 1D-25)
Engine mounting nut	55	5.5	40.0	☞(Page 1D-25)
Clutch release arm bolt	9	0.9	6.5	☞(Page 1D-25)
Engine sprocket nut	145	14.5	105.0	☞(Page 1D-25)
Speed sensor rotor bolt	28	2.8	20.5	☞(Page 1D-25)
Speed sensor mounting bolt	4.5	0.45	3.3	☞(Page 1D-26)
Engine sprocket cover bolt	5.5	0.55	4.0	☞(Page 1D-26)
Cylinder head bolt (M10) (Initial)	25	2.5	18.0	☞(Page 1D-34)
Cylinder head bolt (M10) (Final)	42	4.2	30.5	☞(Page 1D-34)
Cylinder head bolt (M6) (L70)	10	1.0	7.0	☞(Page 1D-35)
Cylinder head bolt (M6) (L40)	10	1.0	7.0	☞(Page 1D-35)
Cylinder nut (M6)	10	1.0	7.0	☞(Page 1D-35)
Camshaft journal holder bolt	10	1.0	7.0	☞(Page 1D-37) / ☞(Page 1D-40) / ☞(Page 1D-45)
Cam chain tension adjuster bolt	10	1.0	7.0	☞(Page 1D-37) / ☞(Page 1D-41)
Cam chain tension adjuster cap bolt	23	2.3	16.5	☞(Page 1D-38) / ☞(Page 1D-41)
Generator cover plug	11	1.1	8.0	☞(Page 1D-42)
Valve timing inspection plug	23	2.3	16.5	☞(Page 1D-42)
Cylinder head cover bolt	14	1.4	10.0	☞(Page 1D-43)
Exhaust pipe bolt	23	2.3	16.5	☞(Page 1D-43)
Intake pipe screw	8.5	0.85	6.0	☞(Page 1D-44)
Oil gallery plug (Cylinder head) (M6)	10	1.0	7.0	☞(Page 1D-50)

Fastening part	Tightening torque			Note
	N-m	kgf-m	lbf-ft	
Oil gallery plug (M6)	10	1.0	7.0	☞(Page 1D-67) / ☞(Page 1D-69)
Oil gallery plug (M8)	18	1.8	13.0	☞(Page 1D-67) / ☞(Page 1D-69)
Oil gallery plug (M12)	21	2.1	15.0	☞(Page 1D-67)
Oil gallery plug (M16)	35	3.5	25.5	☞(Page 1D-67)
Special tool bolt	23	2.3	16.5	☞(Page 1D-68)
Piston cooling oil jet bolt	10	1.0	7.0	☞(Page 1D-70)
Oil pressure regulator	27	2.7	19.5	☞(Page 1D-71)
Crankcase bolt (M8)	26	2.6	19.0	☞(Page 1D-72)
Crankcase bolt (M6)	11	1.1	8.0	☞(Page 1D-72)
Oil plate bolt	10	1.0	7.0	☞(Page 1D-73)
Gear position switch bolt	6.5	0.65	4.7	☞(Page 1D-73)
Cam chain tensioner bolt	10	1.0	7.0	☞(Page 1D-74) / ☞(Page 1D-75)
Primary drive gear bolt	70	7.0	50.5	☞(Page 1D-75)
Oil pressure switch	14	1.4	10.0	☞(Page 1D-75)
Oil cooler union bolt	70	7.0	50.5	☞(Page 1D-76)
Gearshift cam stopper bolt	10	1.0	7.0	☞(Page 1D-76)
Gearshift cam stopper plate bolt	13	1.3	9.5	☞(Page 1D-77)
Gearshift arm stopper	19	1.9	13.5	☞(Page 1D-77)
Oil pipe stopper screw	8	0.8	5.7	☞(Page 1D-78)
Oil pump mounting bolt	10	1.0	7.0	☞(Page 1D-78)
Generator cover mounting bolt	10	1.0	7.0	☞(Page 1D-79)
Starter motor mounting bolt	10	1.0	7.0	☞(Page 1D-79)
Conrod cap bolt	21 N-m (2.1 kgf-m, 15.0 lbf-ft) then turn in 90° turn			☞(Page 1D-81) / ☞(Page 1D-83)

NOTE

The tightening torque(s) also specified in:
 “Throttle Body Components” (Page 1D-7)
 “Throttle Body Construction” (Page 1D-8)

Reference:

For the tightening torques of fasteners not specified in this section, refer to “Tightening Torque List” in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J11408001





Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE "A" or equivalent	P/No.: 99000-25010	☞(Page 1D-12) / ☞(Page 1D-44) / ☞(Page 1D-69) / ☞(Page 1D-70) / ☞(Page 1D-70) / ☞(Page 1D-70) / ☞(Page 1D-72) / ☞(Page 1D-73) / ☞(Page 1D-73) / ☞(Page 1D-76) / ☞(Page 1D-79) / ☞(Page 1D-79)
Molybdenum oil	MOLYBDENUM OIL SOLUTION	—	☞(Page 1D-32) / ☞(Page 1D-32) / ☞(Page 1D-33) / ☞(Page 1D-35) / ☞(Page 1D-36) / ☞(Page 1D-39) / ☞(Page 1D-40) / ☞(Page 1D-49) / ☞(Page 1D-49) / ☞(Page 1D-50) / ☞(Page 1D-67) / ☞(Page 1D-68) / ☞(Page 1D-68) / ☞(Page 1D-70) / ☞(Page 1D-79) / ☞(Page 1D-80) / ☞(Page 1D-81)
Sealant	SUZUKI BOND No.1215 or equivalent	P/No.: 99000-31110	☞(Page 1D-33) / ☞(Page 1D-72)
	SUZUKI BOND No.1207B or equivalent	P/No.: 99000-31140	☞(Page 1D-42) / ☞(Page 1D-75)
Thread lock cement	THREAD LOCK CEMENT SUPER 1303 or equivalent	P/No.: 99000-32030	☞(Page 1D-25) / ☞(Page 1D-77)
	THREAD LOCK CEMENT SUPER "1322" or equivalent	P/No.: 99000-32110	☞(Page 1D-23) / ☞(Page 1D-70) / ☞(Page 1D-73) / ☞(Page 1D-77)

















NOTE

Required service material(s) also described in:
 "Throttle Body Components" (Page 1D-7)















Special Tool

BENC11J11408002

09900-06107 Snap ring pliers (Open type) ☞(Page 1D-59) / ☞(Page 1D-60) / ☞(Page 1D-77) / ☞(Page 1D-78)		09900-20101 Vernier calipers (150 mm) ☞(Page 1D-58) / ☞(Page 1D-82)	
09900-20102 Vernier calipers (200 mm) ☞(Page 1D-51) / ☞(Page 1D-55)		09900-20202 Micrometer (25 – 50 mm) ☞(Page 1D-45) / ☞(Page 1D-84) / ☞(Page 1D-85)	

<p>09900-20204 Micrometer (75 – 100 mm) ☞(Page 1D-57)</p>		<p>09900-20205 Micrometer (0 – 25 mm) ☞(Page 1D-46) / ☞(Page 1D-52) / ☞(Page 1D-57) / ☞(Page 1D-58) / ☞(Page 1D-82)</p>	
<p>09900-20530 Cylinder gauge set ☞(Page 1D-55)</p>		<p>09900-20602 Dial gauge ☞(Page 1D-46) / ☞(Page 1D-58) / ☞(Page 1D-82)</p>	
<p>09900-20607 Dial gauge ☞(Page 1D-46) / ☞(Page 1D-50) / ☞(Page 1D-51) / ☞(Page 1D-51)</p>		<p>09900-20701 Dial gauge chuck ☞(Page 1D-46) / ☞(Page 1D-50) / ☞(Page 1D-51) / ☞(Page 1D-51)</p>	
<p>09900-20804 Thickness gauge ☞(Page 1D-50) / ☞(Page 1D-55) / ☞(Page 1D-57) / ☞(Page 1D-58) / ☞(Page 1D-82)</p>		<p>09900-21304 V blocks ☞(Page 1D-46) / ☞(Page 1D-50) / ☞(Page 1D-51)</p>	
<p>09900-22301 Plastigage (0.025 – 0.076 mm) ☞(Page 1D-45) / ☞(Page 1D-83)</p>		<p>09900-22302 Plastigage (0.051 – 0.152 mm) ☞(Page 1D-45)</p>	
<p>09900-22403 Small bore gauge (18 – 35 mm) ☞(Page 1D-46) / ☞(Page 1D-58) / ☞(Page 1D-82)</p>		<p>09913-60221 Journal bearing installer & holder ☞(Page 1D-65) / ☞(Page 1D-67) / ☞(Page 1D-68)</p>	
<p>09913-70210 Bearing installing set (10 – 75 Φ) ☞(Page 1D-70)</p>		<p>09915-40620 Oil filter wrench ☞(Page 1D-61) / ☞(Page 1D-76)</p>	
<p>09915-63311 Compression gauge attachment ☞(Page 1D-3)</p>		<p>09915-64512 Compression gauge ☞(Page 1D-3)</p>	

1D-91 Engine Mechanical:

<p>09916-10911 Valve lapper set ☞(Page 1D-52)</p> 	<p>09916-14510 Valve lifter ☞(Page 1D-48) / ☞(Page 1D-49)</p> 
<p>09916-14522 Valve lifter attachment ☞(Page 1D-48) / ☞(Page 1D-49)</p> 	<p>09916-33210 Valve guide reamer (4.5 mm) ☞(Page 1D-54)</p> 
<p>09916-34542 Reamer handle ☞(Page 1D-53) / ☞(Page 1D-54)</p> 	<p>09916-34580 Valve guide reamer (10.8 mm) ☞(Page 1D-53)</p> 
<p>09916-43211 Valve guide installer & remover ☞(Page 1D-53) / ☞(Page 1D-53)</p> 	<p>09916-53330 Valve guide installer attachment ☞(Page 1D-53)</p> 
<p>09916-84511 Tweezer ☞(Page 1D-48) / ☞(Page 1D-49)</p> 	<p>09919-28620 Sleeve protector ☞(Page 1D-48) / ☞(Page 1D-48) / ☞(Page 1D-49)</p> 
<p>09920-13120 Crankshaft remover ☞(Page 1D-63)</p> 	<p>09930-11950 Torx® wrench (T25H) ☞(Page 1D-11) / ☞(Page 1D-12) / ☞(Page 1D-13)</p> 
<p>09930-44530 Rotor holder ☞(Page 1D-61) / ☞(Page 1D-75)</p> 	<p>09940-14990 Engine mounting adjust wrench ☞(Page 1D-22) / ☞(Page 1D-22) / ☞(Page 1D-24)</p> 

Torx® is the registered trademark of Camcar Division of Textron inc. U.S.A.


Engine Lubrication System

Precautions

Precautions for Engine Oil

Refer to "Fuel and Oil Recommendation" in Section 0A (Page 0A-5).


BENC11J11500001



Schematic and Routing Diagram

Engine Lubrication System Chart Diagram


BENC11J11502001



Engine Lubrication Circuit Diagram

Front Cylinder

1944H1150042-03
BENC11J11502002



Condition
Engine overheat
Exhaust smoke is dirty or thick
Engine lacks power

Oil Pressure Check
Check the engine oil pressure with a good indicator of the


- NOTE
- Before checking the oil pressure, the following:
 - Oil level (Refer to the Repair Manual)
 - Oil leaks
 - Oil quality (Refer to the Repair Manual)
 - 1) Start the engine and run for 5 minutes. Check the oil pressure. If the oil pressure is OK, check the oil level.
 - 2) Run the engine for 5 minutes. Check the oil pressure. If the oil pressure is OK, check the oil level.

Oil pressure specification
200 – 400 MPa (2.0 – 4.0 kgf/cm²), 20 – 30 MPa (2.0 – 3.0 kgf/cm²) at 1000 rpm, Oil temp. at 60 °C (140 °F)

High oil pressure	Low oil pressure
• Engine oil viscosity is low	• Clogged oil filter
• Clogged oil passage	• Oil leakage from O-ring passage
• Contamination of the oil pan	• Damaged O-ring
	• Defective oil pump
	• Loose head of the oil pump

1E-4 Engine Lubrication System:

Rear Cylinder



Diagnostic Information and Procedures

Engine Lubrication Symptom Diagnosis

BENC11J11504001

Condition	Possible cause	Correction / Reference Item
Engine overheats	Insufficient amount of engine oil.	Check level and add.
	Defective oil pump.	Replace.
	Clogged oil circuit.	Clean.
	Clogged oil cooler	Clean or replace.
	Incorrect engine oil.	Change.
Exhaust smoke is dirty or thick	Excessive amount of engine oil.	Check level and drain.
Engine lacks power	Excessive amount of engine oil.	Check level and drain.

Oil Pressure Check

BENC11J11504002


Check the engine oil pressure periodically. This will give a good indication of the condition of the moving parts.

NOTE

Before checking the oil pressure, check the following:

- Oil level (Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10))
- Oil leaks (If leak is found, repair it.)
- Oil quality (If oil is discolored or deteriorated, replace it.)

- 1) Start the engine and check if the oil pressure indicator light is turned on. If the light stays on, check the oil pressure indicator light circuit. If the circuit is OK, check the oil pressure in the following manner.
- 2) Remove the main oil gallery plug (1).




IC11J1150001-01

- 3) Install the oil pressure gauge and adaptor into the main oil gallery.

Special tool

- TOOL (A): 09915-74521 (Oil pressure gauge hose)
- TOOL (B): 09915-70610 (Oil pressure gauge attachment)
- TOOL (C): 09915-77331 (Meter (for high pressure))



IC11J1150002-01

- 4) Warm up the engine as follows:
Summer: 10 min. at 2 000 r/min.
Winter: 20 min. at 2 000 r/min.
- 5) After warm up, increase the engine speed to 3 000 r/min (Observe the tachometer), and read the oil pressure gauge.
If the oil pressure is lower or higher than the specification, the following causes may be considered.

Oil pressure specification

200 – 600 kPa (2.0 – 6.0 kgf/cm², 28 – 85 psi) at 3 000 r/min, Oil temp. at 60 °C (140 °F)


High oil pressure	Low oil pressure
<ul style="list-style-type: none"> • Engine oil viscosity is too high • Clogged oil passage • Combination of the above items 	<ul style="list-style-type: none"> • Clogged oil filter • Oil leakage from the oil passage • Damaged O-ring • Defective oil pump • Combination of the above items

1E-6 Engine Lubrication System:

- 6) Stop the engine and remove the oil pressure gauge and attachment.
- 7) Reinstall the new gasket and main oil gallery plug (1) and tighten it to the specified torque.

Tightening torque

Main Oil gallery plug (M12) (a): 21 N·m (2.1 kgf-m, 15.0 lbf-ft)



IC11J1150003-01

- 8) Check the engine oil level. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).

Repair Instructions

Engine Oil and Filter Replacement

BENC11J11506001

Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).

Engine Oil Level Inspection

BENC11J11506002


Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).

Oil Strainer / Oil Pressure Regulator Removal and Installation

BENC11J11506003


Removal

- 1) Remove the engine assembly from the frame. Refer to "Engine Assembly Removal" in Section 1D (Page 1D-17).
- 2) Disassemble the engine top side. Refer to "Engine Top Side Disassembly" in Section 1D (Page 1D-27).
- 3) Separate the left and right crankcase. Refer to "Engine Bottom Side Disassembly" in Section 1D (Page 1D-59).
- 4) Remove the oil pressure regulator (1).



I944H1150004-01

- 5) Remove the oil strainer plate (2).
- 6) Remove the oil strainer (3).



I944H1150005-01




Installation

Installation is in the reverse order of removal. Pay attention to the following points:


- Install the oil strainer (1).

NOTICE

- The lip "A" of the oil strainer should be positioned downward.
- The shorter side "B" of the oil strainer should be positioned inside.



I944H1140068-01




I944H1150007-01

"A" Lip	"C" Lower side
"B" Shorter side	

- Tighten the oil pressure regulator (2) to the specified torque.

Tightening torque

Oil pressure regulator (a): 27 N·m (2.7 kgf-m, 19.5 lbf-ft)



I944H1150008-02

- Assemble the engine. Refer to "Engine Bottom Side Reassembly" in Section 1D (Page 1D-66) and "Engine Top Side Reassembly" in Section 1D (Page 1D-32).
- Remount the engine assembly. Refer to "Engine Assembly Installation" in Section 1D (Page 1D-23).

Oil Strainer Inspection and Cleaning

BENC11J11506004

Inspect the oil strainer in the following procedures:

- 1) Remove the oil strainer. Refer to "Oil Strainer / Oil Pressure Regulator Removal and Installation" (Page 1E-6).
- 2) If the oil strainer is clogged with sediment or rust, clean the oil strainer using compressed air.

NOTE

When the strainer is dirtied excessively, replace the oil strainer with a new one.



I944H1150009-01

- 3) Install the oil strainer. Refer to "Oil Strainer / Oil Pressure Regulator Removal and Installation" (Page 1E-6).

Oil Pressure Regulator Inspection

BENC11J11506005

- 1) Remove the oil pressure regulator. Refer to "Oil Strainer / Oil Pressure Regulator Removal and Installation" (Page 1E-6).
- 2) Inspect the operation of the oil pressure regulator by pushing on the piston with a proper bar.
- 3) If the piston does not operate, replace the oil pressure regulator with a new one.



I944H1150010-01

1E-8 Engine Lubrication System:


- 4) Install the oil pressure regulator. Refer to "Oil Strainer / Oil Pressure Regulator Removal and Installation" (Page 1E-6).

Oil Cooler Removal and Installation

BENC11J11506006

Removal

- 1) Drain engine oil and engine coolant. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10) and "Cooling System Inspection" in Section 0B (Page 0B-12).
- 2) Remove the Oil filter. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).
- 3) Disconnect the oil cooler hoses (1).
- 4) Remove the washer (2) and oil cooler (3) by removing the union bolt (4).



IC11J1150004-02

Installation


Install the oil cooler in the reverse order of removal. Pay attention to the following points:

- Apply grease to the new O-ring.

NOTE

When installing the oil cooler, fit the concave part "A" of the oil cooler onto the convex part "B" of the crankcase.

 Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)




IC11J1150005-01

- Tighten the union bolt (1) to the specified torque.

Tightening torque

Oil cooler union bolt (a): 70 N·m (7.0 kgf-m, 50.5 lbf-ft)



IC11J1150006-01

Oil Pressure Switch Removal and Installation

BENC11J11506007


Removal

- 1) Turn the ignition switch OFF.
- 2) Drain engine oil. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).
- 3) Disconnect the oil pressure switch lead wire.



IC11J1150007-01


- 4) Remove the oil pressure switch (1).



IC11J1150008-01


Installation

- 1) Install the oil pressure switch (1), apply the bond to its thread part and tighten it to the specified torque.

 : Sealant 99000-31140 (SUZUKI BOND No.1207B or equivalent)

Tightening torque

Oil pressure switch (a): 14 N·m (1.4 kgf-m, 10.0 lbf-ft)




IC11J1150009-01

- 2) Connect the oil pressure switch lead wire securely. Refer to "Wiring Harness Routing Diagram" in Section 9A (Page 9A-7).

Tightening torque

Oil pressure switch lead wire bolt (b): 1.5 N·m (0.15 kgf-m, 1.0 lbf-ft)



IC11J1150010-01

- 3) Pour engine oil. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).

Oil Pressure Switch Inspection

BENC11J11506008

Refer to "Oil Pressure Indicator Inspection" in Section 9C (Page 9C-9).

Oil Jet Removal and Installation


BENC11J11506009

Oil Jet (For Cam Chain Tension Adjuster)

Removal

- 1) Remove the each cam chain tension adjuster. Refer to "Engine Top Side Disassembly" in Section 1D (Page 1D-27).

- 2) Remove the oil jets (1).





1944H1150047-01

Installation

Installation is in the reverse order of removal. Pay attention to the following point:

- Apply grease to the new O-ring.

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)




1944H1150019-01

Oil Jet (For Cylinder Head and Piston Cooling) Removal

NOTE

Do not drop the each parts into the crankcase.


- 1) Remove the cylinder. Refer to "Engine Top Side Disassembly" in Section 1D (Page 1D-27).
- 2) Remove the oil gallery jets (1) (for cylinder).



1944H1150048-01

1E-10 Engine Lubrication System:

- 3) Remove the plates (2).
- 4) Remove the piston cooling oil jets (3).





1944H1150049-01

Installation

Installation is in the reverse order of removal. Pay attention to the following points:


- Fit new O-rings to piston cooling oil jets (1) and oil gallery jets (2) (for cylinder) as shown.
- Apply grease to O-rings.

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)




1944H1150022-02

- Apply a small quantity of thread lock to the bolts (3) and tighten them to the specified torque.

 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER "1322" or equivalent)

Tightening torque

Piston cooling oil jet bolt (a): 10 N·m (1.0 kgf·m, 7.0 lbf·ft)




1944H1150050-01

Oil Jet (For Transmission)


Removal

- 1) Drain engine oil. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).
- 2) Remove the generator cover. Refer to "Generator Removal and Installation" in Section 1J (Page 1J-4).
- 3) Remove the engine sprocket. Refer to "Engine Sprocket Removal and Installation" in Section 3A (Page 3A-2).
- 4) Remove the oil seal retainer mounting bolts (1).




IC11J1150011-01

- 5) Remove the clutch push rod oil seal (2).




IC11J1150012-01

- 6) Remove the oil gallery plug (M8) (3).
- 7) Remove the oil gallery plug (M6) (4) if necessary.



IC11J1150013-01

- 8) Remove the oil gallery jet (for transmission) (5) with a suitable bar (6).



IC11J1150014-01


Installation

Installation is in the reverse order of removal. Pay attention to the following points:

- Apply grease to the new O-ring.

⚠️ : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)

- Install the oil gallery jet (for transmission) (1) with a suitable bar.




IC11J1150015-02

- Install the new gaskets.
- Tighten the oil gallery plug (M8) (2) and (M6) (3) to the specified torque.

Tightening torque

Oil gallery plug (M8) (a): 18 N·m (1.8 kgf-m, 13.0 lbf-ft)

Oil gallery plug (M6) (b): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)



I944H1150028-01


- Install the new clutch push rod oil seal (4) with the special tool.

Special tool

⚠️ (A): 09913-70210 (Bearing installer set)

- Apply grease to lip of clutch push rod oil seal.

⚠️ : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



I944H1150029-02


- Reinstall the engine sprocket. Refer to "Engine Sprocket Removal and Installation" in Section 3A (Page 3A-2).
- Reinstall the generator cover. Refer to "Generator Removal and Installation" in Section 1J (Page 1J-4).

Oil Jet / Oil Gallery Jet Inspection

BENC11J11506010

Oil Jet

Make sure that the oil jets are not clogged. If they are clogged, clean their oil passage using a wire of the proper size and compressed air.



I944H1150030-01

1. Piston cooling oil jet	3. Oil gallery jet (for transmission)
2. Oil gallery jet (for cylinder)	4. Oil jet (for tensioner adjuster)

Oil Pump Removal and Installation

BENC11J11506011


NOTICE


Do not drop the each parts into the crankcase.

Removal

- 1) Drain engine oil. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).
- 2) Remove the clutch. Refer to "Clutch Removal" in Section 5C (Page 5C-7).
- 3) Remove the snap ring (1) and oil pump driven gear (2).


Special tool

 : 09900-06107 (Snap ring pliers)




1944H1150031-01

- 4) Remove the pin (3) and washer (4).



1944H1150032-02

- 5) Remove the oil pump (5) by removing the oil pump mounting bolts (6).



1944H1150033-02

Installation

Installation is in the reverse order of removal. Pay attention to the following points:

- Tighten the oil pump mounting bolts (1).


Tightening torque

Oil pump mounting bolt (a): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)

- Install the washer (2) and pin (3).

NOTE


Be careful not to drop the washer (2) and pin (3) into the crankcase.




IC11J1150016-01

- Install the oil pump driven gear (4) and new snap ring (5).

Special tool

 : 09900-06107 (Snap ring pliers)



1944H1150035-02

- Reinstall the clutch. Refer to "Clutch Installation" in Section 5C (Page 5C-9).

Oil Pump Inspection


BENC11J11506012

Inspect the oil pump in the following procedures:

- 1) Remove the oil pump. Refer to "Oil Pump Removal and Installation" (Page 1E-12).
- 2) Rotate the oil pump by hand and check that it moves smoothly. If it does not move smoothly, replace the oil pump assembly.

NOTICE

Do not attempt to disassemble the oil pump assembly.
The oil pump is available only as an assembly.



I944H1150036-01


- 3) Install the oil pump. Refer to "Oil Pump Removal and Installation" (Page 1E-12).

Oil Pipe Removal and Installation

BENC11J11506013


Removal

- 1) Drain engine oil. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).
- 2) Remove the clutch. Refer to "Clutch Removal" in Section 5C (Page 5C-7).
- 3) Remove the oil pipe stopper (1) by removing its screw (2).



I944H1150037-02

- 4) Remove the oil pipe (3).




I944H1150038-02

Installation

Installation is in reverse order of removal. Pay attention to the following points:

- Install the oil pipe (1).



I944H1150039-01


- Tighten the oil pipe stopper screw (2) to the specified torque.

NOTE

Align the projection "A" of the oil pipe with the groove "B" of its stopper.

Tightening torque

Oil pipe stopper screw (a): 8 N·m (0.8 kgf-m, 6.0 lbf-ft)



I944H1150040-01

- Reinstall the clutch. Refer to "Clutch Installation" in Section 5C (Page 5C-9).

1E-14 Engine Lubrication System:

Oil Pipe Inspection

BENC11J11506014

Inspect the oil pipe the following procedures:

- 1) Remove the oil pipe. Refer to "Oil Pipe Removal and Installation" (Page 1E-13).
- 2) Inspect the oil pipe for clogging. Clean the oil pipe if necessary.



IC11J1150017-01

- 3) Install the oil pipe. Refer to "Oil Pipe Removal and Installation" (Page 1E-13).

Specifications

Service Data

Oil Pump

BENC11J11507001

Item	Standard	Limit
Oil pressure (at 60 °C, 140 °F)	200 – 600 kPa (2.0 – 6.0 kgf/cm ² , 28 – 85 psi) at 3 000 r/min	—

Oil

Item	Specification	Note
Engine oil type	SAE 10W-40, API SF/SG or SH/SJ with JASO MA	
Engine oil capacity	Change	2 400 ml (2.5/2.1 US/Imp qt)
	Filter change	2 750 ml (2.9/2.4 US/Imp qt)
	Overhaul	3 000 ml (3.2/2.6 US/Imp qt)

Tightening Torque Specifications

BENC11J11507002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Main Oil gallery plug (M12)	21	2.1	15.0	☞(Page 1E-6)
Oil pressure regulator	27	2.7	19.5	☞(Page 1E-7)
Oil cooler union bolt	70	7.0	50.5	☞(Page 1E-8)
Oil pressure switch	14	1.4	10.0	☞(Page 1E-9)
Oil pressure switch lead wire bolt	1.5	0.15	1.0	☞(Page 1E-9)
Piston cooling oil jet bolt	10	1.0	7.0	☞(Page 1E-10)
Oil gallery plug (M8)	18	1.8	13.0	☞(Page 1E-11)
Oil gallery plug (M6)	10	1.0	7.0	☞(Page 1E-11)
Oil pump mounting bolt	10	1.0	7.0	☞(Page 1E-12)
Oil pipe stopper screw	8	0.8	6.0	☞(Page 1E-13)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment






Recommended Service Material

BENC11J11508001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE "A" or equivalent	P/No.: 99000-25010	☞ (Page 1E-8) / ☞ (Page 1E-9) / ☞ (Page 1E-10) / ☞ (Page 1E-11) / ☞ (Page 1E-11)
Sealant	SUZUKI BOND No.1207B or equivalent	P/No.: 99000-31140	☞ (Page 1E-9)
Thread lock cement	THREAD LOCK CEMENT SUPER "1322" or equivalent	P/No.: 99000-32110	☞ (Page 1E-10)

Special Tool

BENC11J11508002

09900-06107 Snap ring pliers (Open type) ☞ (Page 1E-12) / ☞ (Page 1E-12)		09913-70210 Bearing installing set (10 – 75 Φ) ☞ (Page 1E-11)	
09915-70610 Oil pressure gauge attachment ☞ (Page 1E-5)		09915-74521 Adapter hose ☞ (Page 1E-5)	
09915-77331 Oil pressure gauge (1000 kPa) ☞ (Page 1E-5)			

Engine Cooling System

Precautions

Precautions for Engine Cooling System

BENC11J11600001

▲ WARNING

- You can be injured by boiling fluid or steam if you open the radiator cap when the engine is hot. After the engine cools, wrap a thick cloth around cap and carefully remove the cap by turning it a quarter turn to allow pressure to escape and then turn the cap all the way off.
- The engine must be cool before servicing the cooling system.
- Coolant is harmful:
 - If it comes in contact with skin or eyes, flush with water.
 - If swallowed accidentally, induce vomiting and call physician immediately.
 - Keep it away from children.

Precautions for Engine Coolant

BENC11J11600002

Refer to "Engine Coolant Recommendation" in Section 0A (Page 0A-6).

General Description

Engine Coolant Description

BENC11J11601001

For SUZUKI Super Long Life Coolant

NOTICE

- Ethanol or methanol base coolant or water alone should not be used in cooling system at any time as damage to cooling system could occur.
- Do not mix the distilled water, SUZUKI long life coolant (coolant color: Green) or equivalent.

SUZUKI super long life coolant will provide the optimum corrosion protection and excellent heat protection, and will protect the cooling system from freezing at temperatures above -36°C (-33°F).

Anti-freeze concentration table

Anti-freeze density	Freezing point
50%	-36°C (-33°F)

For SUZUKI Long Life Coolant

NOTICE

- Use a high quality ethylene glycol base anti-freeze, mixed with distilled water. Do not mix an alcohol base anti-freeze and different brands of anti-freeze.
- Do not put in more than 60% anti-freeze or less than 50%. (Refer to Fig. 1 and 2.)


The 50:50 mixture of distilled water and ethylene glycol anti-freeze will provide the optimum corrosion protection and excellent heat protection, and will protect the cooling system from freezing at temperatures above -31°C (-24°F).

If the vehicle is to be exposed to temperatures below -31°C (-24°F), this mixing ratio should be increased up to 55% or 60% according to the figure.

Anti-freeze Proportioning Chart


Anti-freeze density	Freezing point
50%	-31°C (-24°F)
55%	-40°C (-40°F)
60%	-55°C (-67°F)

Fig.1: Engine coolant density-freezing point curve



I310G1160001-01

Fig.2: Engine coolant density-boiling point curve




I310G1160002-01

Schematic and Routing Diagram


Cooling Circuit Diagram

BENC11J11602001



IC11J1160001-02

Water Hose Routing Diagram



1. Thermostat	☑ "H": Face the screw head right side.
2. Jiggle valve	☑ "I": Face the screw head forward.
3. Radiator outlet hose	☑ "J": Face the clamp end upward.
4. Radiator inlet hose	☑ "K": Pass the reservoir tank inlet hose left side of the high-tension cord.
5. Reservoir tank overflow hose	☑ "L": Clamp the drain hose and oil pressure switch lead wire.
6. Reservoir tank inlet hose	☑ "M": Face the screw head downward.
7. Oil cooler outlet hose	☑ "N": Face the clamp end left side.
8. Oil cooler inlet hose	☑ "O": Face the screw head backward.
"A": Marking	☑ "P": Face the clamp end backward.
"B": Yellow marking	☑ "Q": Pass the reservoir tank inlet hose into the concave part of the radiator heat shield.
"C": White marking	☑ "R": Pass the reservoir tank inlet hose in front of the wire harness and fuel feed hose.
"D": Red marking	"a": 2 – 8 mm (0.08 – 0.30 in)
☑ "E": Face the clamp end downward.	"b": Clearance
☑ "F": Face the screw head left side.	"c": 90°
☑ "G": Face the clamp end forward.	"d": 45 – 90°

Diagnostic Information and Procedures

Engine Cooling Symptom Diagnosis

BENC11J11604001

Condition	Possible cause	Correction / Reference Item
Engine overheats	Not enough engine coolant.	<i>Add engine coolant.</i>
	Radiator core clogged with dirt or scale.	<i>Clean.</i>
	Faulty cooling fan.	<i>Repair or replace.</i>
	Defective cooling fan relay, or open-or-short circuited.	<i>Repair or replace.</i>
	Clogged engine coolant passage.	<i>Clean.</i>
	Air trapped in the cooling circuit.	<i>Bleed air.</i>
	Defective water pump.	<i>Replace.</i>
	Use of incorrect engine coolant.	<i>Replace.</i>
	Defective thermostat.	<i>Replace.</i>
	Defective ECT sensor.	<i>Replace.</i>
Engine over cools	Defective ECM.	<i>Replace.</i>
	Defective cooling fan relay, or open-or-short circuited.	<i>Repair or replace.</i>
	Extremely cold weather.	<i>Put on radiator cover.</i>
	Defective thermostat.	<i>Replace.</i>
	Defective ECT sensor.	<i>Replace.</i>
Defective ECM.	<i>Replace.</i>	

Repair Instructions

Cooling Circuit Inspection

BENC11J11606001

▲ WARNING


- Do not open the radiator cap when the engine is hot, as you may be injured by escaping hot liquid or vapor.
- When removing the radiator cap tester, put a rag on the filler to prevent the engine coolant from spraying out.

Inspect the cooling circuit in the following procedures:


- 1) Remove the body cowling assembly. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Remove the radiator cap (1) and connect the radiator tester (2) to the filler.
- 3) Pressurize the cooling system with 120 kPa (1.2 kgf/cm, 17 psi) of pressure, and then check if it holds the pressure for 10 seconds.

NOTICE

Do not exceed the radiator cap release pressure, or the radiator cap and subsequently the radiator, can be damaged.



IC11J1160002-01



I933H1160003-02


- 4) After finishing the cooling circuit inspection, reinstall the removed parts.

Radiator Cap Inspection

BENC11J11606002

Inspect the radiator cap in the following procedures:

- 1) Remove the radiator cap. Refer to "Cooling Circuit Inspection" (Page 1F-5).
- 2) Attach the radiator cap (1) to the radiator tester (2) as shown in the figure.



I718H1160033-01

- 3) Slowly apply pressure to the radiator cap. If the radiator cap does not hold the pressure for at least 10 seconds, replace it with a new one.

Radiator cap release pressure

93 – 123 kPa (0.93 – 1.23 kgf/cm², 13.2 – 17.5 psi)

- 4) After finishing the radiator cap inspection, reinstall the removed parts.

Radiator Inspection and Cleaning

BENC11J11606003

Radiator Hose

Refer to "Cooling System Inspection" in Section 0B (Page 0B-12).

Radiator

Inspect the radiator for engine coolant leaks. If any defects are found, replace the radiator with a new one. If the fins are bent or dented, repair them by carefully straightening them with the blade of a small screwdriver.



IC11J1160003-01

Radiator Cleaning

Blow out any foreign matter that is stuck in the radiator fins using compressed air.

NOTICE

- Make sure not to bend the fins when using compressed air.
- Always apply compressed air from the engine side. If compressed air is applied from the front side, dirt will be forced into the pores of radiator.




IC11J1160004-01

Radiator / Cooling Fan Motor Removal and Installation


BENC11J11606004

Removal

- 1) Drain engine coolant. Refer to "Cooling System Inspection" in Section 0B (Page 0B-12).
- 2) Remove the body cowling assembly. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Disconnect the radiator inlet hose (1), radiator outlet hose (2), reservoir tank inlet hose (3), cooling fan motor lead wire coupler (4) and horn coupler (5).
- 4) Remove the radiator assembly (6) by removing the bolts (7).




IC11J1160005-01




IC11J1160006-02

- 5) Remove the right handle switch coupler (8), ignition switch lead wire coupler (9) immobilizer coupler (10) (for E-21, 24) and left handle switch couplers (11).




IC11J1160018-02

- 6) Remove the radiator heat shield (12).




IC11J1160019-01

- 7) Remove the horn (13).




IC11J1160020-01

Remove the cooling fan assembly (14).




IC11J1160021-01

Remove the cooling fan (15).




IC11J1160022-01

Disconnect the coupler (16) and remove the cooling fan motor (17).



IC11J1160023-01

Remove the radiator under rubber (18) and bracket (19).



IC11J1160024-01


Installation

Install the radiator/cooling fan motor in the reverse order of removal. Pay attention to the following points:

- Tighten the cooling fan assembly mounting bolts (1) to the specified torque.

Tightening torque

Cooling fan assembly mounting bolt (a): 5 N·m (0.5 kgf·m, 3.5 lbf·ft)



IC11J1160007-01

- Connect the radiator hoses securely. Refer to "Water Hose Routing Diagram" (Page 1F-3).
- Pour engine coolant. Refer to "Cooling System Inspection" in Section 0B (Page 0B-12).
- Bleed air from the cooling circuit. Refer to "Cooling System Inspection" in Section 0B (Page 0B-12).

Water Hose Inspection


BENC11J11606005

Inspect the water hose in the following procedures:


- 1) Remove the body cowling assembly. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Check the water hoses for crack, damage or engine coolant leakage. If any defect is found, replace the radiator hose with a new one.




- 3) Any leakage from the connecting section should be corrected by proper tightening. Refer to "Water Hose Routing Diagram" (Page 1F-3).




IC11J1160008-01



IC11J1160009-01



IC11J1160010-01



IC11J1160011-01

- 4) After finishing the water hose inspection, reinstall the removed parts.

Water Hose Removal and Installation

BENC11J11606006

Removal

- 1) Drain engine coolant. Refer to "Cooling System Inspection" in Section 0B (Page 0B-12).
- 2) Remove the body cowling assembly. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Remove the water hose as shown in the water hose routing diagram. Refer to "Water Hose Routing Diagram" (Page 1F-3).

Installation

- 1) Install the water hose as shown in the water hose routing diagram. Refer to "Water Hose Routing Diagram" (Page 1F-3).
- 2) Pour engine coolant and bleed air from the cooling circuit. Refer to "Cooling System Inspection" in Section 0B (Page 0B-12).
- 3) Reinstall the removed parts.

Radiator Reservoir Tank Inspection

BENC11J11606007

Inspect the radiator reservoir tank in the following procedures:

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 2) Inspect the radiator reservoir tank coolant leaks. If any defects are found, replace the radiator reservoir tank with a new one.



IC11J1160012-01

- 3) Reinstall the removed parts.


1F-9 Engine Cooling System:

Radiator Reservoir Tank Removal and Installation

BENC11J11606008


Removal

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 2) Disconnect the reservoir tank inlet hose (1) and drain the engine coolant.
- 3) Disconnect the overflow hose (2).
- 4) Remove the reservoir tank mounting (3) by removing the reservoir tank mounting bolts (4).
- 5) Remove the reservoir tank (5) by removing the reservoir tank bolt (6).



IC11J1160013-02

- 3) Fill the reservoir tank to the upper level "A".



IC11J1160014-03

- 4) Reinstall the removed parts.

Cooling Fan Inspection

BENC11J11606009

Cooling fan operating temperature Standard

(ON→OFF): Approx. 99 °C (210 °F)

(OFF→ON): Approx. 105 °C (221 °F)

Inspect the cooling fan in the following procedures:


- 1) Disconnect the cooling fan motor coupler (1).




IC11J1110066-01

Installation

- 1) Apply thread lock to the reservoir tank bolt (1).

 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER "1322" or equivalent)

- 2) Install the reservoir tank (2) as shown in the water hose routing diagram. Refer to "Water Hose Routing Diagram" (Page 1F-3).




IC11J1160026-03

- 2) Test the cooling fan motor for load current with an ammeter connected as shown in the figure. If the fan motor does not turn, replace the cooling fan motor with a new one. Refer to "Radiator / Cooling Fan Motor Removal and Installation" (Page 1F-6).

NOTE

- When making this test, it is not necessary to remove the cooling fan.
- The voltmeter is for making sure that the battery applies 12 V to the motor. With the fan motor with electric motor fan running at full speed, the ammeter should be indicating not more than 5 A.



I718H1160048-01

2. Fan motor	3. Ammeter	4. Battery
--------------	------------	------------

- 3) Connect the cooling fan motor coupler.
- 4) Reinstall the removed parts.

Cooling Fan Relay Inspection

BENC11J11606010

Inspect the fan relay in the following procedures:

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Disconnect the cooling fan relay coupler and remove the cooling fan relay (1).



IC11J1110063-01


- 3) First check the insulation between "A" and "B" terminals with tester. Then apply 12 V volts to "C" and "D" terminals, (+) to "C" and (-) to "D", and check the continuity between "A" and "B". If there is no continuity, replace it with a new one.

Special tool

: 09900-25008 (Multi circuit tester set)

Tester knob indication set

Continuity test (•)))



I718H1160006-03

- 4) Reinstall the removed parts.

ECT Sensor Removal and Installation

BENC11J11606011

Refer to "ECT Sensor Removal and Installation" in Section 1C (Page 1C-3).

ECT Sensor Inspection

BENC11J11606012

Refer to "ECT Sensor Inspection" in Section 1C (Page 1C-4).

Engine Coolant Temperature Indicator Inspection

BENC11J11606013


Refer to "Engine Coolant Temperature Indicator Light Inspection" in Section 9C (Page 9C-4).

Thermostat Removal and Installation

BENC11J11606014


Removal

- 1) Drain a small amount of engine coolant. Refer to "Cooling System Inspection" in Section 0B (Page 0B-12).
- 2) Place a clean rag under the thermostat case (1).
- 3) Remove the thermostat case (1).



IC11J1160015-01

- 4) Remove the thermostat (2).



IC11J1160016-01


Installation

Install the thermostat in the reverse order of removal, pay attention to the following points:

- Apply engine coolant to the rubber seal on the thermostat (1).
- Install the thermostat (1).

NOTE

The jiggle valve "A" of the thermostat faces upside.



IC11J1160017-01

- Pour engine coolant and bleed air from the cooling circuit. Refer to "Cooling System Inspection" in Section 0B (Page 0B-12).

Thermostat Inspection

BENC11J11606015

Inspect the thermostat in the following procedures:

- 1) Remove the thermostat. Refer to "Thermostat Removal and Installation" (Page 1F-11).
- 2) Inspect the thermostat pellet for signs of cracking.




1944H1160021-01

- 3) Test the thermostat at the bench for control action.

CAUTION

- Do not contact the thermostat (1) and the column thermometer (2) with a pan.
- As the thermostat operating response to water temperature change is gradual, do not raise water temperature too quickly.
- The thermostat with its valve open even slightly under normal temperature must be replaced.

- 4) Immerse the thermostat (1) in the water contained in a beaker and note that the immersed thermostat is in suspension.
- 5) Heat the water by placing the beaker on a stove and observe the rising temperature on a thermometer (2).



1705H1160030-01

"A": String	"B": Water
-------------	------------

- 6) Read the thermometer just when opening the thermostat. If this reading, which is the temperature level at which the thermostat valve begins to open, is out of the standard value, replace the thermostat with a new one.


Thermostat valve opening temperature

Standard: Approx. 82 °C (180 °F)

- 7) Keep on heating the water to raise its temperature.
8) Just when the water temperature reaches specified value, the thermostat valve should have been lifted by at least 8.0 mm (0.31 in). A thermostat failing to satisfy either of the two requirements (start-to-open temperature and valve lift) must be replaced.

Thermostat valve lift "a"

Standard: 8.0 mm (0.31 in) and over at 95 °C (203 °F)




RM44H1160022-01

- 9) Install the thermostat. Refer to "Thermostat Removal and Installation" (Page 1F-11).

Water Pump Components

BENC11J11605DPS



1944H1160056-01

1. Snap ring	6. Bearing	11. Water pump cover screw	LLC : Apply engine coolant.
2. Water pump driven gear	7. O-ring	12. Water drain bolt	AO : Apply engine oil.
3. Pin	8. Oil seal	(a) : 4.5 N·m (0.45 kgf-m, 3.3 lbf-ft)	X : Do not reuse.
4. Washer	9. Mechanical seal	(b) : 13 N·m (1.3 kgf-m, 9.5 lbf-ft)	
5. E-ring	10. Impeller	AG : Apply grease.	

Water Pump Removal and Installation

BENC11J11606017

Removal


NOTE

Before draining engine oil and engine coolant, inspect engine oil and coolant leakage between the water pump and crankcase. If engine oil is leaking, visually inspect the oil seal and O-ring. If engine coolant is leaking, visually inspect the mechanical seal and seal ring. Refer to "Water Pump Related Parts Inspection" (Page 1F-18).

- 1) Drain engine oil and coolant. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10) and "Cooling System Inspection" in Section 0B (Page 0B-12).
- 2) Remove the clutch cover. Refer to "Clutch Removal" in Section 5C (Page 5C-7).
- 3) Remove the snap ring (1), water pump driven gear (2), pin (3) and washer (4).


Special tool

 : 09900-06107 (Snap ring pliers)



1944H1160024-01


- 4) Remove the water pump assembly (5) from the clutch cover.




1944H1160025-01

Installation

- 1) Apply grease to the new O-rings.

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)


- 2) Install the water pump assembly to the clutch cover.




1944H1160026-01

- 3) Install the washer (1), pin (2), water pump driven gear (3) and new snap ring (4).

Special tool

 : 09900-06107 (Snap ring pliers)



1944H1160027-01


- 4) Install the clutch cover. Refer to "Clutch Installation" in Section 5C (Page 5C-9).
- 5) After installing the removed parts, pour engine oil and engine coolant. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10) and "Cooling System Inspection" in Section 0B (Page 0B-12).

Water Pump Disassembly and Assembly

BENC11J11606018


Disassembly

- 1) Remove the O-rings (1).




I944H1160028-01

- 2) Remove the water pump body (2) by removing the screws (3).




I944H1160029-02

- 3) Remove the O-ring (4).




I944H1160030-02

- 4) Remove the E-ring (5) and impeller (6).



I944H1160031-02

- 5) Remove the mechanical seal ring (7) and rubber seal (8) from the impeller.




I944H1160032-02


- 6) Remove the mechanical seal with the special tool.

NOTE

If there is no abnormal condition, the mechanical seal removal is not necessary.

Special tool

 (A): 09921-20240 (Bearing remover set)




I944H1160033-01

- 7) Remove the oil seal (9).

NOTE

If there is no abnormal condition, the oil seal removal is not necessary.




I944H1160034-02


8) Remove the bearings with the special tool.

NOTE

If there is no abnormal noise, bearings removal is necessary.

Special tool

 (A): 09921-20240 (Bearing remover set)




1944H1160035-01


2) Install the new oil seal with the special tool.

NOTE

The stamped mark on the oil seal should face mechanical seal side.


Special tool


 (A): 09913-70210 (Bearing installer set)



1944H1160037-01

3) Apply a small quantity of the grease to the oil seal lip.

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)




1944H1160038-01

4) Install a new mechanical seal using a suitable size socket wrench.

NOTE

On the new mechanical seal, the sealer "A" has been applied.



1944H1160039-01


Assembly


1) Apply engine oil to the new bearings and install the bearings with the special tool.

NOTE

The stamped mark on the bearings face to the crankcase side.

Special tool

 (A): 09913-70210 (Bearing installer set)




1944H1160036-01

1F-17 Engine Cooling System:

- 5) Install the rubber seal (1) into the impeller.
- 6) After wiping off the oily or greasy matter from the mechanical seal ring (2), install it into the impeller.

NOTE

The paint marked side "B" of mechanical seal ring faces the impeller.



1944H1160040-02

- 7) Apply grease to the impeller shaft.

 Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)

- 8) Install the impeller to the water pump body.




1944H1160041-01

- 9) Fix the impeller shaft with the new E-ring (3).



1944H1160042-01

- 10) Install a new O-ring (4) and apply engine coolant to it.




1944H1160043-02

- 11) Fit the water pump cover and tighten the water pump cover screws (5) to the specified torque.

Tightening torque

Water pump cover screw (a): 4.5 N·m (0.45 kgf·m, 3.3 lbf·ft)

- 12) Install the new O-rings (6).




1944H1160044-01

Water Pump Related Parts Inspection

BENC11J11606019

Mechanical Seal


Visually inspect the mechanical seal for damage, with particular attention given to the sealing face. Replace the mechanical seal that shows indications of leakage. Also replace the seal ring if necessary.



1944H1160045-01

Oil Seal


Visually inspect the oil seal for damage, with particular attention given to the lip. Replace the oil seal that shows indications of leakage.



1944H1160046-01

Impeller


Visually inspect the impeller and its shaft for damage. Replace the impeller if necessary.



1944H1160047-01

Bearing


Inspect the play of the bearings by hand while it is in the water pump case. Rotate the inner race by hand to inspect for abnormal noise and smooth rotation. Replace the bearings if there is anything unusual.



1944H1160048-01

Bearing case

Visually inspect the bearing case for damage or scratch. Replace the water pump body if necessary.



1944H1160049-01

Specifications

Service Data

BENC11J11607001

Thermostat + Radiator + Fan + Coolant

Item	Standard		Note
Thermostat valve opening temperature	Approx. 82 °C (180 °F)		—
Thermostat valve lift	8 mm (0.31 in) and over at 95 °C (203 °F)		—
ECT sensor resistance	20 °C (68 °F)	Approx. 2.45 kΩ	—
	50 °C (122 °F)	Approx. 0.811 kΩ	—
	80 °C (176 °F)	Approx. 0.318 kΩ	—
	110 °C (230 °F)	Approx. 0.142 kΩ	—
Radiator cap valve opening pressure	93 – 123 kPa (0.93 – 1.23 kgf/cm ² , 13.2 – 17.5 psi)		—
Cooling fan operating temperature	OFF → ON	Approx. 105 °C (221 °F)	—
	ON → OFF	Approx. 99 °C (210 °F)	—
Engine coolant type	Use an antifreeze/coolant compatible with aluminum radiator.		—
Engine coolant	Reservoir tank side	Approx. 250 ml (0.3/0.2 US/Imp qt)	—
	Engine side	Approx. 1 700 ml (1.8/1.5 US/Imp qt)	—

Tightening Torque Specifications

BENC11J11607002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Cooling fan assembly mounting bolt	5	0.5	3.5	④ (Page 1F-7)
Water pump cover screw	4.5	0.45	3.3	④ (Page 1F-17)

NOTE

The tightening torque(s) also specified in:
 "Water Pump Components" (Page 1F-13)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J11608001





Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE "A" or equivalent	P/No.: 99000-25010	☞(Page 1F-14) / ☞(Page 1F-16) / ☞(Page 1F-17)
Thread lock cement	THREAD LOCK CEMENT SUPER "1322" or equivalent	P/No.: 99000-32110	☞(Page 1F-9)

NOTE

Required service material(s) also described in:
 "Water Pump Components" (Page 1F-13)

Special Tool

BENC11J11608002

09900-06107 Snap ring pliers (Open type) ☞(Page 1F-14) / ☞(Page 1F-14)		09900-25008 Multi circuit tester set ☞(Page 1F-10)	
09913-70210 Bearing installing set (10 – 75 Φ) ☞(Page 1F-16) / ☞(Page 1F-16)		09921-20240 Bearing remover set ☞(Page 1F-15) / ☞(Page 1F-16)	

Fuel System

Precautions

Precautions for Fuel System

BENC11J11700001

▲ WARNING

- Keep away from fire or spark.
 - During disassembling, use care to minimize spillage of gasoline.
 - Spilled gasoline should be wiped off immediately.
 - Work in a well-ventilated area.
-

▲ CAUTION

- To prevent the fuel system (fuel tank, fuel hose, etc.) from contamination with foreign particles, blind all openings.
 - After removing the throttle body, tape the cylinder intake section to prevent foreign particles from entering.
-

General Description


Fuel System Description

BENC11J11701001

Fuel System

The fuel delivery system consists of the fuel tank (1), fuel pump (2), fuel mesh filter (3), fuel feed hose (4), fuel delivery pipe (5), fuel injectors (8) and fuel pressure regulator (6). There is no fuel return hose. The fuel in the fuel tank (1) is pumped up by the fuel pump (2) and pressurized fuel flows into the injector (8) installed in the fuel delivery pipe (5). Fuel pressure is regulated by the fuel pressure regulator (6). As the fuel pressure applied to the fuel injector (8) (the fuel pressure in the fuel delivery pipe) is always kept at absolute fuel pressure of 300 kPa (3.0 kgf/cm², 43 psi), the fuel is injected into the throttle body in conic dispersion when the injector (8) opens according to the injection signal from the ECM.

The fuel relieved by the fuel pressure regulator (6) flows back to the fuel tank (1).



IC11J1170024-01

1. Fuel tank	5. Fuel delivery pipe	"A": Before-pressurized fuel
2. Fuel pump	6. Fuel pressure regulator	"B": Pressurized fuel
3. Fuel mesh filter	7. Fuel filter (For high pressure)	"C": Relieved fuel
4. Fuel feed hose	8. Fuel injector	

Diagnostic Information and Procedures

Fuel System Diagnosis

BENC11J11704001

Condition	Possible cause	Correction / Reference Item
Engine will not start or is hard to start (No fuel reaching the intake manifold)	Clogged fuel filter or fuel hose.	<i>Clean or replace.</i>
	Defective fuel pump.	<i>Replace.</i>
	Defective fuel pressure regulator.	<i>Replace.</i>
	Defective fuel injectors.	<i>Replace.</i>
	Defective fuel pump relay.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Open-circuited wiring connections.	<i>Check and repair.</i>
Engine will not start or is hard to start (Incorrect fuel/air mixture)	TP sensor out of adjustment.	<i>Adjust.</i>
	Defective fuel pump.	<i>Replace.</i>
	Defective fuel pressure regulator.	<i>Replace.</i>
	Defective TP sensor.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective IAP sensor.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Defective ECT sensor.	<i>Replace.</i>
	Defective IAT sensor.	<i>Replace.</i>
	Dirty throttle body.	<i>Clean.</i>
Defective ISC valve.	<i>Replace the STVA.</i>	
Engine stalls often (Incorrect fuel/air mixture)	Defective IAP sensors or circuit.	<i>Repair or replace.</i>
	Clogged fuel filter.	<i>Clean or replace.</i>
	Defective fuel pump.	<i>Replace.</i>
	Defective fuel pressure regulator.	<i>Replace.</i>
	Damaged or cracked vacuum hose.	<i>Replace.</i>
	Defective ECT sensor.	<i>Replace.</i>
	Defective thermostat.	<i>Replace.</i>
	Defective IAT sensor.	<i>Replace.</i>
Defective ISC valve.	<i>Replace the STVA.</i>	
Engine stalls often (Fuel injector improperly operating)	Defective fuel injectors.	<i>Replace.</i>
	No injection signal from ECM.	<i>Repair or replace.</i>
	Open or short circuited wiring connection.	<i>Repair or replace.</i>
	Defective battery or low battery voltage.	<i>Replace or recharge.</i>
Engine runs poorly in high speed range (Defective control circuit or sensor)	Low fuel pressure.	<i>Repair or replace.</i>
	Defective TP sensor.	<i>Replace.</i>
	Defective IAT sensor.	<i>Replace.</i>
	Defective IAP sensors.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Defective STP sensor or STVA.	<i>Replace.</i>
	Defective GP switch.	<i>Replace.</i>
Engine lacks power (Defective control circuit or sensor)	Low fuel pressure.	<i>Repair or replace.</i>
	Defective TP sensor.	<i>Replace.</i>
	Defective IAT sensor.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective GP switch.	<i>Replace.</i>
	Defective IAP sensors.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Defective STP sensor or STVA.	<i>Replace.</i>
	Imbalanced throttle valve synchronization.	<i>Adjust.</i>
TP sensor out of adjustment.	<i>Adjust.</i>	

Repair Instructions

Fuel Pressure Inspection


BENC11J11706001

▲ WARNING

- Keep away from fire or spark.
- Spilled gasoline should be wiped off immediately.
- Work in a well-ventilated area.

Inspect the fuel pressure in the following procedures:

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation" (Page 1G-6).
- 2) Place a clean rag under the fuel feed hose (1) and disconnect fuel feed hose (1) from the fuel pump.




IC11J1170001-01


- 3) Install the special tools between the fuel pump and fuel feed hose.

Special tool

- 🔧 (A): 09940-40211 (Fuel pressure gauge adapter)
- 🔧 (B): 09940-40220 (Fuel pressure gauge hose attachment)
- 🔧 (C): 09915-77331 (Meter (for high pressure))
- 🔧 (D): 09915-74521 (Oil pressure gauge hose)



IC11J1170002-01



I944H1170003-01

"A": To fuel feed hose

"B": To fuel pump

- 4) Turn the ignition ON and check for fuel pressure.

Fuel pressure

Approx. 300 kPa (3.0 kgf/cm², 43 psi)

If the fuel pressure is lower than the specification, check for the followings:

- Fuel hose leakage
- Clogged fuel filter
- Pressure regulator
- Fuel pump

If the fuel pressure is higher than the specification, check for the following:

- Pressure regulator

- 5) Remove the special tools.

▲ WARNING

Before removing the special tools, turn the ignition switch OFF position and release the fuel pressure slowly.

NOTE

Connect the fuel feed hose to the fuel pump until it locks securely (a click is heard).

- 6) Reinstall the fuel tank. Refer to "Fuel Tank Removal and Installation" (Page 1G-6).

Fuel Pump Inspection

BENC11J11706002

Turn the ignition switch ON and check that the fuel pump operates for a few seconds.

If the fuel pump motor does not make operating sound, inspect the fuel pump circuit connections or inspect the fuel pump relay and TO sensor. Refer to "Fuel Pump Relay Inspection" (Page 1G-5) and "TO Sensor Inspection" in Section 1C (Page 1C-5).

If the fuel pump relay, TO sensor and fuel pump circuit connections are OK, the fuel pump may be faulty, replace the fuel pump with a new one. Refer to "Fuel Pump Assembly Removal and Installation" (Page 1G-9).

Fuel Discharge Amount Inspection


BENC11J11706003

▲ WARNING

- Keep away from fire or spark.
- Spilled gasoline should be wiped off immediately.
- Work in a well-ventilated area.


Inspect the fuel discharge amount in the following procedures:

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation" (Page 1G-6).
- 2) Place a clean rag under the fuel feed hose (1) and disconnect the fuel feed hose (1) from the fuel pump.



IC11J1170001-01

- 3) Connect a proper fuel hose (2) to the fuel pump.
- 4) Place the measuring cylinder and insert the fuel hose end into the measuring cylinder.



IC11J1170003-01

- 5) Connect a proper lead wire into the fuel pump lead wire coupler (fuel pump side) and apply 12 V to the fuel pump (between (+) Y/R wire and (-) B/W wire) for 10 seconds and measure the amount of fuel discharged.

If the discharge amount is out of the specification, the probable cause may be failure of the fuel pump or clogged fuel filter.

NOTE

The battery must be in fully charged condition.

Fuel discharge amount

167 ml (5.6/5.9 US/Imp oz) or more/10 seconds



IC11J1170004-02

- 6) After finishing the fuel discharge inspection, reinstall the fuel tank. Refer to "Fuel Tank Removal and Installation" (Page 1G-6).

Fuel Pump Relay Inspection

BENC11J11706004

Inspect the fuel pump relay in the following procedures:

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Disconnect the fuel pump relay coupler and remove the fuel pump relay (1).



IC11J1110045-02


- 3) First, check for insulation with the tester between terminals "A" and "B". Next, check for continuity between "A" and "B" with 12 V voltage applied, positive (+) to terminal "C" and negative (-) to terminal "D". If continuity does not exist, replace the relay with a new one.

Special tool

TOOL : 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity test (•))



1718H1170013-01

- 4) Reinstall the removed parts.

Fuel Hose Inspection

BENC11J11706005

Refer to "Fuel Line Inspection" in Section 0B (Page 0B-10).

Fuel Hose Removal and Installation

BENC11J11706006

▲ WARNING

- Keep away from fire or spark.
- Spilled gasoline should be wiped off immediately.
- Work in a well-ventilated area.

Removal

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Place a clean rag under the fuel feed hoses (1).
- 3) Disconnect the fuel feed hoses (1) from the fuel delivery pipe.



IC11J1170005-01

- 4) Remove the fuel hose.

Installation

- 1) Install the fuel hose as shown in the throttle body construction. Refer to "Throttle Body Construction" in Section 1D (Page 1D-8).

NOTE

Connect the fuel feed hoses to the fuel delivery pipe until its locks securely (a click is heard).

- 2) Install the fuel tank. Refer to "Fuel Tank Removal and Installation" (Page 1G-6).

Fuel Tank Removal and Installation


BENC11J11706008

Removal

▲ WARNING

- Keep away from fire or spark.
- Spilled gasoline should be wiped off immediately.
- Work in a well-ventilated area.

- 1) Remove the seat, frame side covers, frame covers, fuel tank side covers and fuel tank front cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Remove the fuel tank front mounting bolts (1).



IC11J1170017-01


- 3) Remove the side cowling bolts (2).



IC11J1170022-01

1G-7 Fuel System:

- Remove the fuel tank rear mounting bolt (3), fuel tank mount stay (4) upper cushion (5) and lower cushion (6).




IC11J1170018-04

- Lift and support the fuel tank with the fuel tank mounting stay (4).

▲ CAUTION


Lifting up the fuel tank by force can damage the hoses and wiring harness.

- Disconnect the fuel pump lead wire coupler (7).



IC11J1170019-03

- Place a clean rag under the fuel feed hose (8) and disconnect the fuel feed hose (8).
- Disconnect the fuel tank breather hose (9) and fuel tank drain hose (10).



IC11J1170021-02

- Remove the fuel tank.

Installation

Install the fuel tank in the reverse order of removal. Pay attention to the following point:


NOTICE

Be sure not to bend or twist the hoses when installing.

- Connect the fuel tank drain hose (1) and breather hose (2) as shown in the fuel tank drain hose and breather hose routing diagram and EVAP canister hose routing diagram (for E-33). Refer to "EVAP Canister Hose Routing Diagram (Only for E-33)" in Section 1B (Page 1B-5).

NOTE


Connect the fuel feed hose (3) to the fuel pump until it locks securely (a click is heard).



IC11J1170006-02

Fuel Pump Components

BENC11J11706009



IC11J1170023-01

1. Fuel level gauge	5. Fuel pump	: 10 N·m (1.0 kgf-m, 7.0 lbf-ft)
2. Fuel pressure regulator assembly	6. Fuel mesh filter	: Apply engine oil.
3. O-ring	7. Fuel feed hose	: Apply grease.
4. Joint	8. Fuel pump mounting bolt	: Do not reuse.

Fuel Pump Assembly Removal and Installation


BENC11J11706010

Removal

▲ WARNING

- Spilled gasoline should be wiped off immediately.
- Keep away from fire or spark.
- Work in a well-ventilated area.

- 1) Remove the fuel tank. Refer to "Fuel Tank Removal and Installation" (Page 1G-6).
- 2) Remove the fuel pump assembly (1) by removing its mounting bolts (2) diagonally.




IC11J1170007-01

Installation

- 1) Install the new O-ring (1) and apply grease to it.

⚠ Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)




IC11J1170008-01

- 2) When installing the fuel pump assembly, first tighten all the fuel pump mounting bolts lightly in the ascending order and then tighten them to the specified torque in the figure.

Tightening torque

Fuel pump mounting bolt: 10 N·m (1.0 kgf-m, 7.0 lbf-ft)



IC11J1170009-01

- 3) Reinstall the fuel tank. Refer to "Fuel Tank Removal and Installation" (Page 1G-6).

Fuel Level Gauge Inspection

BENC11J11706011


Refer to "Fuel Level Gauge Inspection" in Section 9C (Page 9C-6).

Fuel Pump Disassembly and Assembly

BENC11J11706012


Disassembly

- 1) Disconnect the fuel level gauge (+) lead wire (1).




1944H1170020-01

- 2) Remove the fuel level gauge (2) by removing the screws (3).



IC11J1170010-01


3) Remove the fuel pressure regulator assembly (4).



1944H1170022-02


4) Disconnect the fuel pump (+) lead wire (5).

5) Remove the fuel pump assembly (6).



1944H1170023-02


6) Remove the fuel mesh filter (7).



1944H1170024-02

7) Remove the fuel pump (8).

8) Disconnect the lead wires (9).




1944H1170025-02

9) Remove the joint (10).

NOTICE

Never remove the fuel pressure regulator (11) from the holder.



1944H1170026-02

Assembly

Assemble the fuel tank pump in the reverse order of the disassembly. Pay attention to the following points:

NOTICE


The removed fuel pump lead wire and fuel level gauge lead wire must be replaced with the new ones.

NOTE


Connect all lead wires securely so as not to cause contact failure.

1G-11 Fuel System:

- Apply engine oil to the new O-rings.



1944H1170027-01



1944H1170028-01

1. Fuel pump (+) lead wire (Bl)
2. Fuel pump (-) lead wire (B)
3. Fuel level gauge (+) lead wire (R)
4. Fuel level gauge (-) lead wire (B)

Fuel Mesh Filter Inspection and Cleaning

BENC11J11706013

Inspect the fuel mesh filter in the following procedures:

- Remove the fuel mesh filter. Refer to "Fuel Pump Disassembly and Assembly" (Page 1G-9).
- If the fuel mesh filter is clogged with foreign particles, it hinders smooth gasoline flow resulting in loss of engine power. Such a filter should be cleaned by blowing with compressed air.

NOTE

When the fuel mesh filter is dirtied excessively, replace the fuel filter cartridge with a new one.



1944H1170029-02

- After finishing the fuel mesh filter inspection, reinstall the fuel mesh filter. Refer to "Fuel Pump Disassembly and Assembly" (Page 1G-9).

Fuel Injector / Fuel Delivery Pipe Removal and Installation

BENC11J11706014


Removal

- Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- Place a rug under the fuel feed hoses (1) and disconnect the fuel feed hoses (1) from the fuel delivery pipes.
- Disconnect the fuel injector couplers (2).
- Remove the fuel delivery pipes (3) along with the fuel injectors.



IC11J1170011-01

- Remove the fuel injectors (4) from the fuel delivery pipe.



IC11J1170012-01

Installation


Install the fuel injector / fuel delivery pipe in the reverse order of removal.

Pay attention to the following points:

NOTE

Wipe off the mounting surface on the delivery pipe and throttle body where the fuel injector will be seated with a clean rag.

- Apply a thin coat of engine oil to the new cushion seal (1) and O-ring (2).



1944H1170033-01


- Install the fuel injector (3) by pushing it straight to the delivery pipe (4).

NOTICE

Never turn the injector while pushing it.

NOTE

Align the coupler "A" of injector with boss "B" of the delivery pipe.




IC11J1170013-01

- Install the fuel delivery pipes along with the fuel injectors to the throttle body assembly.

NOTICE

- When installing the fuel delivery pipes to the throttle body, pay attention to the difference of the fuel delivery pipes.
- Never turn the fuel injectors while installing it.



IC11J1170014-01

"C": Front side	"D": Rear side
-----------------	----------------

- Install rubber washers (5).




IC11J1170015-01

- Tighten the fuel delivery pipe mounting screws (6) to the specified torque.

Tightening torque

Fuel delivery pipe mounting screw (a): 3.5 N·m (0.35 kgf-m, 2.5 lbf-ft)

- Connect the fuel injector couplers to the fuel injectors. Make sure that each coupler is installed in the correct position. the color on each lead wire refers to the appropriate fuel injector.



IC11J1170016-01

Coupler	Wire color
Front injector "E"	Y/R and Gr/W
Rear injector "F"	Y/R and Gr/B

NOTE

Connect the fuel feed hoses to the fuel delivery pipes until its locks securely (a click is heard).

Fuel Injector Inspection and Cleaning

BENC11J11706015

Inspect the fuel injector in the following procedures:

- 1) Remove the fuel injector. Refer to "Fuel Injector / Fuel Delivery Pipe Removal and Installation" (Page 1G-11).

- 2) Check the fuel injector filter for evidence of dirt and contamination. If present, clean and check for presence of dirt in the fuel lines and fuel tank.



1944H1170036-01

- 3) Install the fuel injector. Refer to "Fuel Injector / Fuel Delivery Pipe Removal and Installation" (Page 1G-11).

Specifications

Service Data

Injector + Fuel Pump + Fuel Pressure Regulator

BENC11J117070001

Item	Specification	Note
Injector resistance	11.5 – 12.5 Ω at 20 °C (68 °F)	—
Fuel pump discharge amount	167 ml (5.6/5.9 US/Imp oz) or more for 10 seconds, at 300 kPa (3.0 kgf/cm ² , 43 psi)	—
Fuel pressure regulator operating set pressure	Approx. 300 kPa (3.0 kgf/cm ² , 43 psi)	—

Fuel

Item	Specification	Note
Fuel type	Use unleaded gasoline with a minimum pump octane rating of 87 ((R+M)/2 method). Gasoline containing MTBE (Methyl Tertiary Butyl Ether), less than 10% ethanol, or less than 5% methanol with appropriate cosolvents and corrosion inhibitor is permissible.	E-03, 28, 33
	Use unleaded gasoline with an octane rating of 91 or higher (Research method).	E-21, 24
Fuel tank capacity	20.0 L (5.3/4.5 US/Imp gal)	—

Tightening Torque Specifications

BENC11J117070002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Fuel pump mounting bolt	10	1.0	7.0	(Page 1G-9)
Fuel delivery pipe mounting screw	3.5	0.35	2.5	(Page 1G-12)

NOTE

The tightening torque(s) also specified in: "Fuel Pump Components" (Page 1G-8)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J11708001






Material	SUZUKI recommended product or Specification	Note
Grease	SUZUKI SUPER GREASE "A" or equivalent	P/No.: 99000-25010 ☞ (Page 1G-9)

NOTE

Required service material(s) also described in:
 "Fuel Pump Components" (Page 1G-8)

Special Tool

BENC11J11708002

09900-25008 Multi circuit tester set ☞ (Page 1G-6) 	09915-74521 Adapter hose ☞ (Page 1G-4) 
09915-77331 Oil pressure gauge (1000 kPa) ☞ (Page 1G-4) 	09940-40211 Fuel pressure gauge adapter ☞ (Page 1G-4) 
09940-40220 Fuel pressure gauge attachment ☞ (Page 1G-4) 	

Ignition System


General Description

Immobilizer Description (For E-21, 24)

BENC11J11801001


The immobilizer, an anti-theft system, is installed as a standard equipment.

The immobilizer verifies that the key ID agrees with ECM ID by means of radio communication through the immobilizer antenna. When the ID agreement is verified, the system makes the engine ready to start.



IC11J1180001-03

- | | |
|------------------------|--------------------|
| 1. Immobilizer antenna | 2. Indicator light |
|------------------------|--------------------|



I815H1180002-02


- | | |
|------------------------|----------------|
| 1. Immobilizer antenna | 3. Transponder |
| 2. Indicator light | 4. ID |

Operation

When the ignition switch is turned ON with the engine stop switch in ON, the immobilizer antenna and ECM are powered ON.

The ECM transmits a signal to the transponder through the immobilizer antenna in order to make comparison between the key ID and ECM ID.

With the signal received, the transponder transmits the key ID signal to ECM so that ECM can make comparison with its own ID, and if it matches, the engine is made ready to start.




I815H1180003-01

- | | |
|------------------------|--------------------|
| 1. Immobilizer antenna | 3. Ignition switch |
| 2. Transponder | 4. ECM |

Also, when the ignition switch is turned ON, the indicator light flashes as many as the number of IDs registered in ECM. Thereafter, if the IDs are in agreement, the indicator light turns on for two seconds to notify of completion in successful communication.

If the indicator light (LED) flashes fast, it notifies of communication error or disagreement of ID.




I705H1180006-01

▲ CAUTION

When the battery performance is lowered in winter (low temperature), the system may at times makes a re-judgment at the time of beginning the starter motor operation. In this case, the indicator light operation starts immediately after the starter operation.

NOTE

If the indicator light flashes fast, turn the ignition switch OFF then ON to make judgment again as there is possible misjudgment due to environmental radio interference.



IC11J1180021-01


5. Indicator light

Schematic and Routing Diagram

Ignition System Diagram

Refer to "Wire Color Symbols" in Section 0A (Page 0A-7).

BENC11J11802001



I944H1180001-05

Component Location

Ignition System Components Location

BENC11J11803001

Refer to "Electrical Components Location" in Section 0A (Page 0A-9).

Diagnostic Information and Procedures

Ignition System Symptom Diagnosis

BENC11J11804001

Condition	Possible cause	Correction / Reference Item
Spark plug not sparking	Damaged spark plugs.	<i>Replace.</i>
	Fouled spark plugs.	<i>Clean or replace.</i>
	Wet spark plugs.	<i>Clean and dry or replace.</i>
	Defective ignition coils or spark plug caps.	<i>Replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Open-circuited wiring connections.	<i>Repair or replace.</i>
	Open or short in high-tension cord.	<i>Replace.</i>
Engine stalls easily (No spark)	Defective ignition coils.	<i>Replace.</i>
	Fouled spark plugs.	<i>Clean or replace.</i>
	Defective CKP sensor.	<i>Replace.</i>
	Defective ECM.	<i>Replace.</i>
	Open-circuited wiring connections.	<i>Repair or replace.</i>
Spark plug is wet or quickly becomes fouled with carbon	Excessively rich air/fuel mixture.	<i>Inspect FI system.</i>
	Excessively high idling speed.	<i>Inspect FI system.</i>
	Incorrect gasoline.	<i>Change.</i>
	Dirty air cleaner element.	<i>Clean or replace.</i>
	Incorrect spark plugs. (Cold type)	<i>Change to hot type spark plug.</i>
Spark plug quickly becomes fouled with oil or carbon	Worn piston rings.	<i>Replace.</i>
	Worn pistons or cylinders.	<i>Replace.</i>
	Worn cylinder.	<i>Replace.</i>
	Excessive valve-stem to valve-guide clearance.	<i>Replace.</i>
	Worn valve stem oil seals.	<i>Replace.</i>
Spark plug electrodes overheat or burn	Incorrect spark plugs. (Hot type)	<i>Change to cold type spark plug.</i>
	Overheated engine.	<i>Tune-up.</i>
	Loose spark plugs.	<i>Tighten.</i>
	Excessively lean air/fuel mixture.	<i>Inspect FI system.</i>

No Spark or Poor Spark

BENC11J11804002

Troubleshooting**NOTE**

Check that the transmission is in neutral and the engine stop switch is in the "RUN" position. Grasp the clutch lever. Check that the fuse is not blown and the battery is fully-charged before diagnosing.

Step 1

Check the ignition system couplers for poor connections.

Is there connection in the ignition system couplers?

- Yes Go to Step 2.
No Poor connection of couplers.

Step 2

Measure the battery voltage between input lead wires (E-21, 24: O/G and B/W, E-03, 28, 33: O/W and B/W) at the ECM with the ignition switch in the "ON" position.

Is the voltage OK?

- Yes Go to Step 3.
No • Faulty ignition switch.
 • Faulty turn signal / side-stand relay.
 • Faulty engine stop switch.
 • Broken wire harness or poor connection of related circuit couplers.

Step 3

Measure the ignition coil primary peak voltage. Refer to "Ignition Coil and Plug Cap Inspection" (Page 1H-7).

NOTE

This inspection method is applicable only with the multi-circuit tester and the peak volt adaptor.

Is the peak voltage OK?

- Yes Go to Step 4.
No Go to Step 5.

Step 4

Inspect the spark plugs. Refer to "Spark Plug Inspection and Cleaning" in Section 0B (Page 0B-9).

Is the spark plug OK?

- Yes Go to Step 5.
No Faulty spark plugs.

Step 5

Inspect the ignition coils. Refer to "Ignition Coil and Plug Cap Inspection" (Page 1H-7).

Is the ignition coil OK?

- Yes Go to Step 6.
No Faulty ignition coil.

Step 6

Measure the CKP sensor peak voltage and its resistance. Refer to "CKP Sensor Inspection" (Page 1H-9).

NOTICE

The CKP sensor peak voltage inspection is applicable only with the multi-circuit tester and peak volt adaptor.


Are the peak voltage and resistance OK?

- Yes • Faulty ECM.
 • Open or short circuit in wire harness.
 • Poor connection of ignition wire harness.
No • Faulty CKP sensor.
 • Metal particles or foreign material being stuck on the CKP sensor and rotor tip.

Repair Instructions

Ignition Coil Construction

BENC11J11806001



IC11J1180020-02

1. Ignition coil #1	5. High-tension cord #1	9. Clutch cable
2. Ignition coil #2	6. High-tension cord #2	▲ "A": Pass the high-tension cord #2 under the wire harness.
3. FC mark	7. Radiator inlet hose	▲ "B": Press firmly on the spark plug cap to fit it securely with mark "▲" on the plug cap facing exhaust side.
4. RC mark	▲ 8. Clamp : Clamp the high-tension cord #2.	

Spark Plug Cap and Spark Plug Removal and Installation

BENC11J11806002


▲ WARNING

The hot engine can burn you.
Wait until the engine is cool enough to touch.

Removal

#1 (Front):

- 1) Turn the ignition switch OFF position.
- 2) Remove the body cowling assembly. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Move the radiator assembly (1) by removing the bolt (2).



IC11J1180004-01


- 4) Disconnect the spark plug caps (3).



IC11J1180005-01

- 5) Remove the spark plugs (4) with a spark plug wrench.

Special tool


 (A): 09930-10121 (Spark plug wrench set)



IC11J1180006-01

#2 (Rear):


- 1) Turn the ignition switch OFF position.
- 2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 3) Disconnect the spark plug caps (1).




IC11J1180007-02

- 4) Remove the spark plugs (2) with a spark plug wrench.

Special tool

 (A): 09930-10121 (Spark plug wrench set)



IC11J1180008-02

Installation

Install the spark plug caps and spark plugs in the reverse order of removal. Pay attention to the following points:

- Screw the spark plugs into the cylinder head with fingers, and then tighten them to the specified torque.

NOTICE

Do not cross thread or over tighten the spark plug, or such an operation will damage the aluminum threads of the cylinder head.

Special tool

 : 09930-10121 (Spark plug wrench set)

Tightening torque

Spark plug: 11 N·m (1.1 kgf-m, 8.0 lbf-ft)

1H-7 Ignition System:

- Connect the spark plug caps. Refer to "Ignition Coil Construction" (Page 1H-5).

NOTE


Fit the spark plug caps into the spark plug holes positively so that is no space.

Ignition Coil Removal and Installation

BENC11J11806003

Removal

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Disconnect the spark plug caps. Refer to "Spark Plug Cap and Spark Plug Removal and Installation" (Page 1H-6).
- 3) Disconnect the ignition coil lead wire couplers (1).



IC11J1180009-03

- 4) Remove the ignition coils as shown in the ignition coil construction. Refer to "Ignition Coil Construction" (Page 1H-5).

Installation

Install the ignition coils in the reverse order of removal. Pay attention to the following points:

- Install the ignition coils as shown in the ignition coil construction. Refer to "Ignition Coil Construction" (Page 1H-5).

Spark Plug Inspection and Cleaning

BENC11J11806004

Refer to "Spark Plug Inspection and Cleaning" in Section 0B (Page 0B-9).

Ignition Coil and Plug Cap Inspection


BENC11J11806005

Ignition Coil Primary Peak Voltage

- 1) Disconnect the all spark plug caps. Refer to "Spark Plug Cap and Spark Plug Removal and Installation" (Page 1H-6).
- 2) Connect the new spark plugs to each spark plug caps and ground them to the cylinder heads.

NOTE

Be sure that all the spark plugs are connected properly and the battery used is in fully-charged condition.



IC11J1180010-01

- 3) Insert the needle pointed probe to the lead wire coupler.

NOTE

Use the special tool, to prevent the rubber of the water proof coupler from damage.

4) Connect the multi-circuit tester with the peak voltage adaptor as follows:

NOTE


- Before using the multi-circuit tester and peak voltage adaptor, refer to the appropriate instruction manual.
- Do not disconnect the ignition coil lead wire coupler.

Special tool


- 🔧 (A): 09900-25008 (Multi circuit tester set)
- 🔧 (B): 09900-25009 (Needle-point probe set)

Tester knob indication: Voltage (---)


	((+) Probe)	((-) Probe)
Ignition coil #1	O/W lead wire	W/BI lead wire
Ignition coil #2	B/O lead wire	B lead wire



IC11J1180011-02



IC11J1180012-02



1944H1180012-02

1. ECM	"A": (-) probe
2. Peak voltage adaptor	"B": (+) probe
3. New spark plug	"C": For engine stop switch
4. Ignition coil	

5) Measure the ignition coils primary peak voltage in the following procedures:

⚠ WARNING

Do not touch the tester probes and spark plug to prevent an electric shock while testing.


- Shift the transmission to the neutral, turn the ignition switch ON and grasp the clutch lever.
 - Press the starter button and allow the engine to crank for a few seconds, and then measure the ignition coil primary peak voltage.
- 6) Repeat the b) procedure few times and measure the highest peak voltage.
If the voltage is lower than standard range, inspect the ignition coil and the CKP sensor.

**Ignition coil primary peak voltage
150 V or more**

7) After measuring the ignition coil primary peak voltage, reinstall the removed parts.

Ignition Coil Resistance

- Disconnect the spark plug caps. Refer to "Spark Plug Cap and Spark Plug Removal and Installation" (Page 1H-6).
- Disconnect the ignition coil lead wire couplers (1).



IC11J1180009-03

3) Measure the ignition coil resistance in both the primary and secondary windings. If the resistance is not within the standard range, replace the ignition coil with a new one.

Special tool

- 🔧 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Resistance (Ω)

Ignition coil resistance

Primary: 1 – 5 Ω ((+) Br – (-) B/W)

Secondary: 25 – 45 kΩ (Spark plug cap – spark plug cap)

4) After measuring the ignition coil resistance, reinstall the removed parts.

CKP Sensor Inspection

BENC11J11806006

CKP Sensor Peak Voltage

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Disconnect the CKP sensor lead wire coupler (1).

NOTE

Be sure that all of the couplers are connected properly and the battery is fully-charged.



IC11J1110012-04

- 3) Connect the multi-circuit tester with the peak volt adaptor as follows:

NOTICE


Before using the multi-circuit tester and peak voltage adaptor, refer to the appropriate instruction manual.

Special tool

1000 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication: Voltage (---)

CKP sensor	(+) Probe W	(-) Probe G
------------	----------------	----------------



IC11J1180013-01

2. CKP sensor lead wire coupler	4. Peak voltage adaptor
3. CKP sensor	

- 4) Measure the CKP sensor peak voltage in the following procedures:
 - a) Shift the transmission to the neutral, turn the ignition switch ON and grasp the clutch lever.
 - b) Press the starter button and allow the engine to crank for a few seconds, and then measure the CKP sensor peak voltage.
- 5) Repeat the b) procedure a few times and measure the highest CKP sensor peak voltage.

CKP sensor peak voltage
3.7 V or more (W - G)

- 6) If the peak voltage is within the specification, check the continuity between the CKP sensor lead wire coupler and ECM coupler.


NOTICE

Normally, use the needle pointed probe to the backside of the lead wire coupler to prevent the terminal bend and terminal alignment.

- 7) After measuring the CKP sensor peak voltage, reinstall the removed parts.

CKP Sensor Resistance

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Disconnect the CKP sensor lead wire coupler (1).




IC11J1110012-04

- 3) Measure the resistance between the lead wires and ground. If the resistance is not within the standard range, replace the CKP sensor with a new one. Refer to "CKP Sensor Removal and Installation" (Page 1H-10).

Tester knob indication
Resistance (Ω)

CKP sensor resistance
130 – 240 Ω (W – G)
∞ Ω (B/R – Ground)



I718H1180008-02

2. CKP sensor lead wire coupler	3. CKP sensor
---------------------------------	---------------

- 4) After measuring the CKP sensor resistance, connect the CKP sensor lead wire coupler.

CKP Sensor Removal and Installation

BENC11J11806007

Refer to "Generator Removal and Installation" in Section 1J (Page 1J-4).


Engine Stop Switch Inspection

BENC11J11806008

Inspect the engine stop switch in the following procedures:

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).

- 2) Disconnect the right handlebar switch lead wire coupler (1).



IC11J1180023-01

- 3) Inspect the engine stop switch for continuity with a tester.
If any abnormality is found, replace the right handlebar switch assembly with a new one. Refer to "Handlebars Removal and Installation" in Section 6B (Page 6B-3).

Special tool

TOOL : 09900-25008 (Multi circuit tester set)

Tester knob indication
Continuity (••)

Color Position	B/BI	B/R
RUN (⊙)	○	○
OFF (⊗)		

I044H1180018-01


- 4) After finishing the engine stop switch inspection, reinstall the removed parts.

Immobilizer Antenna Removal and Installation
(for E-21, 24)

BENC11J11806011

Removal


- 1) Turn the ignition switch OFF.
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 3) Disconnect the immobilizer antenna lead wire coupler (1).



IC11J1180024-01

1H-11 Ignition System:

- 4) Remove the immobilizer antenna (2).



IC11J1180015-02

Installation

Install the immobilizer antenna in the reverse order of removal.

Ignition Switch Inspection

BENC11J11806009


Refer to "Ignition Switch Inspection" in Section 9C (Page 9C-9).

Ignition Switch Removal and Installation (for E-21)

BENC11J11806012

Removal

- 1) Remove the steering stem upper bracket. Refer to "Steering Removal and Installation" in Section 6B (Page 6B-5).
- 2) Using a chisel, remove the ignition switch mounting bolts.
- 3) Remove the ignition switch (1) from the steering stem upper bracket.



IC11J1180025-01


Installation

Install the ignition switch in the reverse order of removal. Pay attention to the following points:

- Install the ignition switch and new bolts.
- Tighten each bolt until its head is broken off.

NOTE

The spare ignition switch comes equipped with the special bolts, however, the bolts are also individually available as spare parts.




IC11J1180022-01

Ignition Switch Removal and Installation (for E-03, 24, 28, 33)

BENC11J11806010

Removal



- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Disconnect the ignition switch lead wire coupler (1).




IC11J1180026-01

3) Remove the ignition switch mounting bolts (2) with the special tools and remove the ignition switch (3).

Special tool

-  (A): 09930-11920 (Torx® bit (JT40H))
-  (B): 09930-11940 (Torx® bit holder (3/8 sq.))



IC11J1180017-02

Installation




Install the ignition switch in the reverse order of removal. Pay attention to the following point:


- Apply thread lock to the ignition switch mounting bolts (1).

▲ CAUTION

When reusing the ignition switch mounting bolts, clean threaded part and apply the thread lock to them.

Special tool

-  (A): 09930-11920 (Torx® bit (JT40H))
-  (B): 09930-11940 (Torx® bit holder (3/8 sq.))
-  : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER "1322" or equivalent)



IC11J1180018-02

Specifications

Service Data

BENC11J11807001

Electrical

Unit: mm (in)

Item	Specification		Note
Spark plug	Type	NGK: CR8EIA-9 DENSO: IU24D	
	Gap	0.8 – 0.9 (0.031 – 0.035)	
Spark performance	Over 8 (0.3) at 1 atm.		
CKP sensor resistance	130 – 240 Ω		
CKP sensor peak voltage	3.7 V or more		When cranking
Ignition coil resistance	Primary	1 – 5 Ω	Terminal – Terminal
	Secondary	25 – 45 Ω	Plug cap – Plug cap
Ignition coil primary peak voltage	150 V or more		When cranking

Tightening Torque Specifications

BENC11J11807002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Spark plug	11	1.1	8.0	☞(Page 1H-6)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment






Recommended Service Material

BENC11J11808001

Material	SUZUKI recommended product or Specification		Note
Thread lock cement	THREAD LOCK CEMENT SUPER "1322" or equivalent	P/No.: 99000-32110	☞ (Page 1H-12)

Special Tool

BENC11J11808002

09900-25008 Multi circuit tester set ☞ (Page 1H-8) / ☞ (Page 1H-8) / ☞ (Page 1H-9) / ☞ (Page 1H-10)		09900-25009 Needle-point probe set ☞ (Page 1H-8)	
09930-10121 Spark plug wrench set ☞ (Page 1H-6) / ☞ (Page 1H-6) / ☞ (Page 1H-6)		09930-11920 Torx® bit (JT40H) ☞ (Page 1H-12) / ☞ (Page 1H-12)	
09930-11940 Torx® bit holder (3/8 sq.) ☞ (Page 1H-12) / ☞ (Page 1H-12)			

Torx® is the registered trademark of Camcar Division of Textron inc. U.S.A.


Starting System

Schematic and Routing Diagram

Starting System Diagram

BENC11J11902001

Refer to "Wire Color Symbols" in Section 0A (Page 0A-7).



1944H1190001-02

Component Location

Starting System Components Location

BENC11J11903001

Refer to "Electrical Components Location" in Section 0A (Page 0A-9).

Diagnostic Information and Procedures

Starting System Symptom Diagnosis

BENC11J11904001

Condition	Possible cause	Correction / Reference Item
Engine does not turn though the starter motor runs	Faulty starter clutch.	<i>Replace.</i>
Starter button is not effective	Run down battery.	<i>Repair or replace.</i>
	Defective switch contacts.	<i>Replace.</i>
	Brushes not seating properly on starter motor commutator.	<i>Repair or replace.</i>
	Defective starter relay or starter interlock switch.	<i>Replace.</i>
	Defective main fuse.	<i>Replace.</i>

Starter Motor will not Run

BENC11J11904002

NOTE

Make sure the fuses are not blown and the battery is fully-charged before diagnosing.

Troubleshooting

Step 1

- 1) Shift the transmission into neutral.
- 2) Grasp the clutch lever, turn on the ignition switch with the engine stop switch in the "RUN" position and listen for a click from the starter relay when the starter button is pushed.

Is a click sound heard?

- Yes Go to Step 2.
No Go to Step 3.

Step 2

Check if the starter motor runs when its terminal is connected to the battery (+) terminal. (Do not use thin "wire" because a large amount of current flows.)

Does the starter motor run?

- Yes
- Faulty starter relay.
 - Loose or disconnected starter motor lead wire.
 - Loose or disconnected between starter relay and battery (+) terminal.
- No Faulty starter motor.

Step 3

Measure the starter relay voltage at the starter relay connectors (between Y/G (+) and B/Y (-)) when the starter button is pushed.

Is the voltage OK?

- Yes Go to Step 4.
No
- Faulty ignition switch.
 - Faulty engine stop switch.
 - Faulty clutch lever position switch.
 - Faulty gear position switch.
 - Faulty turn signal/side-stand relay.
 - Faulty starter button.
 - Faulty side-stand switch.
 - Poor contact of connector.
 - Open circuit in wire harness.

Step 4

Check the starter relay. Refer to "Starter Relay Inspection" (Page 11-7).

Is the starter relay OK?

- Yes Poor contact of the starter relay.
No Faulty starter relay.

Starter Motor Runs but Does not Crank the Engine

BENC11J11904003

The starter motor runs when the transmission is in neutral with the side-stand up or down, but does not run when the transmission is in any position other than neutral, with the side-stand up.

Step 1

Check the side-stand switch. Refer to "Side-stand / Ignition Interlock System Parts Inspection" (Page 11-8).

Is the side-stand switch OK?

- Yes Go to Step 2.
No Faulty side-stand switch.

Step 2

Check the starter clutch. Refer to "Starter Clutch Inspection" (Page 11-12).


Is the starter clutch OK?

- Yes
- Open circuit in wire harness.
 - Poor contact of connector.
- No Faulty starter clutch.

Repair Instructions

Starter Motor Components

BENC11J11906001



IA44H1190001-01


1. O-ring	6. Brush	⊕(c) : 5 N·m (0.5 kgf-m, 3.7 lbf-ft)
2. Housing end (Inside)	7. Housing end (Outside)	⊕(d) : 10 N·m (1.0 kgf-m, 7.0 lbf-ft)
3. O-ring	8. O-ring	⊗ : Do not reuse.
4. Starter motor case	⊕(a) : 6 N·m (0.6 kgf-m, 4.3 lbf-ft)	⊕M : Apply molybdenum grease to sliding surface.
5. Armature	⊕(b) : 11 N·m (1.1 kgf-m, 8.0 lbf-ft)	

Starter Motor Removal and Installation

BENC11J11906002


Removal

- 1) Turn the ignition switch OFF and disconnect the battery (-) lead wire. Refer to "Battery Removal and Installation" in Section 1J (Page 1J-12).
- 2) Remove the starter motor lead wire (1) by removing the nut (2).



IC11J1190001-01


- 3) Remove the starter motor (3) by removing the mounting bolts (4).



IC11J1190002-01

Installation

- 1) Apply grease to the new starter motor O-ring.
⚠ : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



IS44H3190003-01

- 2) Install the starter motor.
- 3) Tighten the starter motor mounting bolts (1) to the specified torque.

Tightening torque

Starter motor mounting bolt (a): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)




IC11J1190003-01

- 4) Tighten the starter motor lead wire mounting nut (2) to the specified torque. Refer to "Wiring Harness Routing Diagram" in Section 9A (Page 9A-7).

Tightening torque

Starter motor lead wire mounting nut (b): 6 N·m (0.6 kgf-m, 4.3 lbf-ft)



IC11J1190004-01

Starter Motor Disassembly and Assembly

BENC11J11906003

Refer to "Starter Motor Removal and Installation" (Page 11-4).


Disassembly

Disassemble the starter motor as shown in the starter motor components diagram. Refer to "Starter Motor Components" (Page 11-3).

Assembly

Reassemble the starter motor in the reverse order of removal. Pay attention to the following points:


- Apply grease to the new oil seal lip.

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



I944H3190006-01

- Apply a small quantity of moly paste to the armature shaft.

 : Moly paste 99000-25140 (SUZUKI MOLY PASTE or equivalent)



I944H3190007-01

- Align the match mark on the starter motor case with the match mark on the housing end.


NOTE

The groove side "A" of starter motor case should face housing end (outside).

- Tighten the starter motor housing bolts (1) to the specified torque.

Tightening torque

Starter motor housing bolt (a): 5 N·m (0.5 kgf·m, 3.7 lbf·ft)



I944H3190008-01

Starter Motor Related Parts Inspection

BENC11J11906004

Carbon Brush

Inspect the carbon brushes for abnormal wear, cracks or smoothness in the brush holder.


If either carbon brush is defective, replace the brush holder set with a new one.


Measure the length "a" of the carbon brushes using a vernier calipers. If the measurement is less than the service limit, replace the housing end assembly (outside) with a new one.

Brush length "a"

Service limit: 6.5 mm (0.26 in)

Special tool

 : 09900-20102 (Vernier calipers (200 mm))



I718H1190013-01


Commutator

Inspect the commutator for discoloration, abnormal wear or undercut "A".

If the commutator is abnormally worn, replace the armature.

If the commutator surface is discolored, polish it with #400 sandpaper and wipe it using a clean, dry cloth.

If there is no undercut, scrape out the insulator (1) with a saw blade.



I944H3190009-01

Armature Coil

Measure for continuity between each segment. Measure for continuity between each segment and the armature shaft.


If there is no continuity between the segments or there is continuity between the segments and shaft, replace the armature with a new one.

Special tool

(A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity test (•••)



I649G1190017-03

Oil Seal

Check the oil seal lip for damage. If any damage is found, replace the housing end (inside).



I944H3190010-01

Bearing

Check the bearing of housing end for damage.

If any damage is found, replace the housing end (inside).




I944H3190011-01

Starter Relay Removal and Installation

BENC11J11906005

Removal

- 1) Turn the ignition switch OFF position.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Disconnect the battery (-) lead wire from the battery.
- 4) Disconnect the starter relay coupler (1) and remove the starter relay cover (2).




IC11J1190005-02

- 5) Disconnect the starter motor lead wire (3) and battery (+) lead wire (4).

NOTE

Be sure to disconnect the starter motor lead wire (3) first, then disconnect the battery (+) lead wire (4).

- 6) Remove the starter relay (5).



IC11J1190006-01

Installation

Install the starter relay in the reverse order of removal.

Starter Relay Inspection

BENC11J11906006

Inspect the starter relay in the following procedures:

- 1) Remove the starter relay. Refer to "Starter Relay Removal and Installation" (Page 11-6).
- 2) Apply 12 V to "A" and "B" terminals and check for continuity between the positive and negative terminals using the multi-circuit tester. If the starter relay clicks and continuity is found, the relay is ok.

NOTICE


Do not apply battery voltage to the starter relay for five seconds or more, since the relay coil may overheat and get damaged.

Special tool


(A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity test (•)))



I822H1190019-02



I823H1190040-02

- 3) Measure the relay coil resistance between the terminals "A" to "B" using the multi-circuit tester. If the resistance is not within the specified value, replace the starter relay with a new one.

Special tool


(A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Resistance (Ω)

Starter relay resistance

3 - 6 Ω



IC11J1190007-01

- 4) Install the starter relay. Refer to "Starter Relay Removal and Installation" (Page 11-6).

11-8 Starting System:

Turn Signal / Side-stand Relay Removal and Installation

BENC11J11906007

Refer to "Electrical Components Location" in Section 0A (Page 0A-9).

Removal

- 1) Turn the ignition switch OFF position.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Remove the turn signal/side-stand relay (1).



IC11J1190008-02

Installation

Install the turn signal/side-stand relay in the reverse order of removal.


Side-stand / Ignition Interlock System Parts Inspection

BENC11J11906008

Check the interlock system for proper operation. If the interlock system does not operate properly, check each component for damage or abnormalities. If any abnormality is found, replace the component with a new one.

Side-stand Switch

- 1) Turn the ignition switch OFF position.
- 2) Remove the left frame side cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Disconnect the side-stand switch lead wire coupler (1).




IC11J1190009-02

- 4) Measure the voltage between Green and Black/White lead wires.

Special tool

 : 09900-25008 (Multi circuit tester set)


Tester knob indication

Diode test ()

	G (+ probe)	B/W (- probe)
ON (Side-stand up)	0.4 - 0.6 V	
OFF (Side-stand down)	1.4 V or more (Tester's battery voltage)	

NOTE

If the tester reads 1.4 V and below when the tester probes are not connected, replace tester battery.




IC11J1190010-01

- 5) Connect the side-stand switch lead wire coupler.
- 6) Reinstall the removed parts.

Turn Signal / Side-stand Relay

The turn signal/side-stand relay is composed of the turn signal relay, side-stand relay and diode.




1649G1190027-02

Side-stand relay



- 1) Remove the turn signal/side-stand relay. Refer to "Turn Signal / Side-stand Relay Removal and Installation" (Page 11-8).
- 2) Check the insulation between "D" and "E" terminals using the multi-circuit tester.
- 3) Apply 12 V to terminals "D" and "C" ((+) to "D" and (-) to "C") and check the continuity between "D" and "E". If there is no continuity, replace the turn signal/side-stand relay with a new one. Refer to "Turn Signal / Side-stand Relay Removal and Installation" (Page 11-8).

Special tool

 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity test (•)))



1649G1190028-02

- 4) Install the turn signal/side-stand relay. Refer to "Turn Signal / Side-stand Relay Removal and Installation" (Page 11-8).

Diode inspection

- 1) Remove the turn signal/side-stand relay. Refer to "Turn Signal / Side-stand Relay Removal and Installation" (Page 11-8).


- 2) Measure the voltage between the "A", "B" and "C" terminals using the multi-circuit tester.

Special tool

 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Diode test (->)



1649G1190029-02

		⊕ Probe of tester to:	
		"B", "C"	"A"
⊖ Probe of tester to:	"B", "C"	—	1.4 V or more (Tester's battery voltage)
	"A"	0.4 - 0.6 V	—

IC11J1190014-01

NOTE

If the multi circuit tester reads 1.4 V and below when the tester probes are not connected, replace tester battery.

- 3) Install the turn signal/side-stand relay. Refer to "Turn Signal / Side-stand Relay Removal and Installation" (Page 11-8).

Gear Position Switch

- 1) Disconnect the gear position switch lead wire coupler (1).

NOTICE

When disconnecting and connecting the gear position switch lead wire coupler, make sure to turn off the ignition switch, or electronic parts may get damaged.




IC11J1190011-02

11-10 Starting System:



- 2) Check the continuity between Blue and Black/White lead wires with the transmission in "NEUTRAL".

Special tool

 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity test (•))

	Bl	B/W
ON (Neutral)		
OFF (Except neutral)		


1649G1190045-03


- 3) Connect the gear position switch lead wire coupler to the wiring harness.
- 4) Insert the needle pointed probes to the lead wire coupler.
- 5) Support the motorcycle with a jack or wooden block.

▲ CAUTION

- Do not support the motorcycle with the exhaust pipes.
 - Make sure that the motorcycle is supported securely.
- 6) Turn the ignition switch ON and side-stand to upright position.
 - 7) Measure the voltage between Pink and Black/White lead wires using the multi-circuit tester when shifting the gearshift lever from low to top.

Special tool

 (A): 09900-25008 (Multi circuit tester set)


 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Voltage (---)

Gear position switch voltage (Except neutral position)

0.6 V or more ((+) P - (-) B/W)




- 8) Turn the ignition switch OFF.

Starter Clutch Removal and Installation


BENC11J11906009

Removal

- 1) Drain engine oil. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).
- 2) Remove the generator rotor (1). Refer to "Generator Removal and Installation" in Section 1J (Page 1J-4).





- 3) Remove the key (2) and starter driven gear (3).
- 4) Remove the starter idle gear (4) and its shaft (5).




- 5) Hold the generator rotor with the special tool and remove the starter clutch bolts (6).

Special tool

 (A): 09930-44530 (Rotor holder)



- 6) Remove the one way clutch (7) from the guide (8).



I944H1190027-02


Installation

Install the starter clutch in the reverse order of removal. Pay attention to the following points:


- Apply engine oil to the one way clutch (1).
- When inserting the one way clutch (1) into the guide (2), fit the flange "A" in the step of the guide (2).

NOTE

Be sure to seat the flange "A" of the one way clutch (1) to the guide (2).




I944H1190028-01




I944H1190029-01

- Install the guide (3) to the generator rotor with the arrow mark "B" faced upward.



I944H1190030-03

- Apply thread lock to the bolts (4), and then tighten them to the specified torque with the special tool.


 : Thread lock cement 99000-32030 (THREAD LOCK CEMENT SUPER 1303 or equivalent)

Special tool

 (A): 09930-44530 (Rotor holder)

Tightening torque

Starter clutch bolt (a): 25 N·m (2.5 kgf-m, 18.0 lbf-ft)



I944H1190031-03


- Apply engine oil solution to the starter idle gear shaft hole.



I944H1190032-02


1I-12 Starting System:

- Apply engine oil to the bushing of the starter driven gear.



I944H1190033-02

- Fit the key (5) in the key slot on the crankshaft.



I944H1190034-03


- Install the generator rotor onto crankshaft. Refer to "Generator Removal and Installation" in Section 1J (Page 1J-4).

Starter Clutch Inspection

BENC11J11906010

Starter Clutch

- 1) Install the starter driven gear onto the starter clutch.
- 2) Turn the starter driven gear by hand to inspect the starter clutch for a smooth movement. The gear turns in one direction only. If a large resistance is felt for rotation, inspect the starter clutch or the starter clutch contacting surface on the starter driven gear for wear or damage. If they are found to be damaged, replace them with new ones.




I944H1190035-01

Starter Driven Gear Bushing

Inspect the starter driven gear bushing for wear or damage.


If necessary, replace it with a new one.



I944H1190036-01

Starter Idle Gear

Inspect the starter idle gear for wear or damage. If any damage is found, replace it with a new one.




I944H1190037-01

Starter Button Inspection

BENC11J119060

Inspect the starter button in the following procedures:

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Disconnect the right handlebar switch lead wire coupler (1).



IC11J1180023-01

- 3) Inspect the starter button for continuity with a tester. If any abnormality is found, replace the right handle switch assembly with a new one. Refer to "Handlebars Removal and Installation" in Section 6B (Page 6B-3).

Special tool

 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•)))

Color Position	O/W	Y/G	O/R	Y/W
•			○ — ○	
PUSH	○ — ○			

1815H1190019-01

- 4) After finishing the starter button inspection, reinstall the removed parts.

Specifications

Service Data

BENC11J11907001

Electrical

Unit: mm (in)

Item	Specification		Note
	Standard	Limit	
Starter motor brush length		12.0 (0.47)	
		6.5 (0.26)	
Starter relay resistance	3 – 6 Ω		

Tightening Torque Specifications

BENC11J11907002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Starter motor mounting bolt	10	1.0	7.0	☞(Page 11-4)
Starter motor lead wire mounting nut	6	0.6	4.3	☞(Page 11-4)
Starter motor housing bolt	5	0.5	3.7	☞(Page 11-5)
Starter clutch bolt	25	2.5	18.0	☞(Page 11-11)

NOTE

The tightening torque(s) also specified in:
"Starter Motor Components" (Page 11-3)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J11908001





Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE "A" or equivalent	P/No.: 99000-25010	☞(Page 11-4) / ☞(Page 11-5)
Moly paste	SUZUKI MOLY PASTE or equivalent	P/No.: 99000-25140	☞(Page 11-5)
Thread lock cement	THREAD LOCK CEMENT SUPER 1303 or equivalent	P/No.: 99000-32030	☞(Page 11-11)

NOTE

Required service material(s) also described in:
 "Starter Motor Components" (Page 11-3)

Special Tool

BENC11J11908002


09900-20102 Vernier calipers (200 mm) ☞(Page 11-5)		09900-25008 Multi circuit tester set ☞(Page 11-6) / ☞(Page 11-7) / ☞(Page 11-7) / ☞(Page 11-8) / ☞(Page 11-9) / ☞(Page 11-9) / ☞(Page 11-10) / ☞(Page 11-10) / ☞(Page 11-13)	
09900-25009 Needle-point probe set ☞(Page 11-10)		09930-44530 Rotor holder ☞(Page 11-10) / ☞(Page 11-11)	

Charging System

Schematic and Routing Diagram

Charging System Diagram

BENC11J11A02001



I944H11A0001-01

Component Location

Charging System Components Location

BENC11J11A03001

Refer to "Electrical Components Location" in Section 0A (Page 0A-9).

Diagnostic Information and Procedures

Charging System Symptom Diagnosis

BENC11J11A04001

Condition	Possible cause	Correction / Reference Item
Generator does not charge	Open- or short-circuited lead wires, or loose lead connections.	<i>Repair, replace or connect properly.</i>
	Short-circuited, grounded or open generator coil.	<i>Replace.</i>
	Short-circuited or punctured regulator/rectifier.	<i>Replace.</i>
Generator does charge, but charging rate is below the specification	Lead wires tend to get short- or open-circuited or loosely connected at terminals.	<i>Repair or retighten.</i>
	Grounded or open-circuited generator coil.	<i>Replace.</i>
	Defective regulator/rectifier.	<i>Replace.</i>
	Defective cell plates in the battery.	<i>Replace the battery.</i>
Generator overcharges	Internal short-circuit in the battery.	<i>Replace the battery.</i>
	Damaged or defective resistor element in the regulator/rectifier.	<i>Replace.</i>
	Poorly grounded regulator/rectifier.	<i>Clean and tighten ground connection.</i>
Unstable charging	Lead wire insulation frayed due to vibration, resulting in intermittent short-circuiting.	<i>Repair or replace.</i>
	Internally short-circuited generator.	<i>Replace.</i>
	Defective regulator/rectifier.	<i>Replace.</i>

1J-2 Charging System:

Condition	Possible cause	Correction / Reference Item
Battery overcharges	Faulty regulator/rectifier.	<i>Replace.</i>
	Faulty battery.	<i>Replace.</i>
	Poor contact of generator lead wire coupler.	<i>Repair.</i>
"Sulfation", acidic white powdery substance or spots on surface of cell plates	Cracked battery case.	<i>Replace the battery.</i>
	Battery has been left in a run-down condition for a long time.	<i>Replace the battery.</i>
Battery runs down quickly	Trouble in charging system.	<i>Check the generator, regulator/rectifier and circuit connections and make necessary adjustments to obtain specified charging operation.</i>
	Cell plates have lost much of their active materials a result of overcharging.	<i>Replace the battery and correct the charging system.</i>
	Internal short-circuit in the battery.	<i>Replace the battery.</i>
	Too low battery voltage.	<i>Recharge the battery fully.</i>
	Too old battery.	<i>Replace the battery.</i>
Battery "sulfation"	Incorrect charging rate. (When not in use battery should be checked at least once a month to avoid sulfation.)	<i>Replace the battery.</i>
	The battery was left unused in a cold climate for too long.	<i>Replace the battery if badly sulfated.</i>

Battery Runs Down Quickly

BENC11J11A04002

Troubleshooting

Step 1

Check accessories which use excessive amounts of electricity.

Are accessories being installed?

- Yes Remove accessories.
No Go to Step 2.

Step 2

Check the battery for current leakage. Refer to "Battery Current Leakage Inspection" (Page 1J-3).

Is the battery for current leakage OK?

- Yes Go to Step 3.
No • Short circuit of wire harness.
• Faulty electrical equipment.

Step 3

Measure the regulated voltage between the battery terminals. Refer to "Regulated Voltage Inspection" (Page 1J-3).

Is the regulated voltage OK?

- Yes • Faulty battery.
• Abnormal driving condition.
No Go to Step 4.

Step 4

Measure the resistance of the generator coil. Refer to "Generator Inspection" (Page 1J-4).

Is the resistance of generator coil OK?

- Yes Go to Step 5.
No • Faulty generator coil.
• Disconnected lead wires.

Step 5

Measure the generator no-load performance. Refer to "Generator Inspection" (Page 1J-4).

Is the generator no-load performance OK?

- Yes Go to Step 6.
No Faulty generator.

Step 6

Inspect the regulator/rectifier. Refer to "Regulator / Rectifier Inspection" (Page 1J-8).

Is the regulator/rectifier OK?

- Yes Go to Step 7.
No Faulty regulator/rectifier.

Step 7

Inspect wiring harness.

Is the wiring harness OK?

- Yes Faulty battery.
No • Short circuit of wire harness.
• Poor contact of couplers.

Repair Instructions

Battery Current Leakage Inspection

BENC11J11A06001


Inspect the battery current leakage in the following procedures:

- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Disconnect the battery (-) lead wire.
- 4) Measure the current between (-) battery terminal and the (-) battery lead wire using the multi-circuit tester. If the reading exceeds the specified value, leakage is evident.

NOTICE

- In case of a large current leak, turn the tester to high range first to avoid tester damage.
- Do not turn the ignition switch ON when measuring current.

Special tool


 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Current (---, 20 mA)

Battery current (Leak)

Under 2 mA



I837H11A0025-01

- 5) Connect the (-) battery terminal and install the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).

Regulated Voltage Inspection

BENC11J11A06002


Inspect the regulated voltage in the following procedures:

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Start the engine and keep it running at 5 000 r/min with the dimmer switch turned HI position.
- 3) Measure the DC voltage between the (+) and (-) battery terminals using the multi-circuit tester. If the voltage is not within the specified value, inspect the generator and regulator/rectifier. Refer to "Generator Inspection" (Page 1J-4) and "Regulator / Rectifier Inspection" (Page 1J-8).

NOTE

When making this test, be sure that the battery is in fully charged condition.

Special tool


 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Voltage (---)

Regulated voltage (Charging output)

Standard: 14.0 – 15.5 V at 5 000 r/min



I837H11A0026-01

- 4) Install the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).


1J-4 Charging System:

Generator Inspection

BENC11J11A06003

Generator Coil Resistance

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Disconnect the generator lead wire coupler (1).




IC11J11A0001-02

- 3) Measure the resistance between the three lead wires.
If the resistance is out of specified value, replace the stator with a new one. Also, check that the generator core is insulated properly.

NOTE

When making this test, be sure that the battery is in fully charged condition.

Special tool

 : 09900-25008 (Multi circuit tester set)


Tester knob indication

Resistance (Ω)

Generator coil resistance

0.2 – 0.7 Ω (Y – Y)

∞ Ω (Y – Ground)




IB31G11A0002-01

- 4) Connect the generator lead wire coupler.
- 5) Reinstall the removed parts.

No-load Performance

- 1) Disconnect the generator lead wire coupler (1).



IC11J11A0001-02

- 2) Start the engine and keep it running at 5 000 r/min.
- 3) Using the multi-circuit tester, measure the voltage between three lead wires.
If the tester reads under the specified value, replace the generator with a new one.

Special tool


 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Voltage (V)

Generator no-load performance (When engine is cold)

60 V (AC) or more at 5 000 r/min




IB31G11A0003-01

Generator Removal and Installation

BENC11J11A06004


Removal

- 1) Drain engine oil. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).
- 2) Remove the engine sprocket cover (1). Refer to "Engine Sprocket Removal and Installation" in Section 3A (Page 3A-2).




IC11J11A0002-02

- 3) Remove the clutch release arm (2), spring (3) and washer (4).




IC11J11A0003-01

- 4) Disconnect the CKP sensor lead wire coupler (5) and generator lead wire coupler (6).



IC11J11A0004-03




IC11J11A0019-01

- 5) Remove the speed sensor (7) and disconnect the clamps.




IC11J11A0005-03

- 6) Remove the generator cover (8).



IC11J11A0006-01

- 7) Remove the gasket (9) and dowel pins (10).




IC11J11A0007-01

- 8) Hold the generator rotor with the special tool and remove the generator rotor bolt.

Special tool

10004 (A): 09930-44530 (Rotor holder)



I944H11A0009-01

NOTE

Be sure to install the grommet (3) to the generator cover.

Tightening torque

Generator rotor nut bolt (a): 11 Nm (7.7 kgf-m)

8.0 lbf-ft

CKP sensor mounting bolt (b): 6.5 Nm (0.62 kgf-m)

11.2 lbf-ft



1J-6 Charging System:


- 9) Remove the generator rotor (11) with the special tool.

NOTE

Remove the starter clutch if necessary. Refer to "Starter Clutch Removal and Installation" in Section 1I (Page 1I-10).


Special tool

-  (A): 09930-44530 (Rotor holder)
 (B): 09930-30450 (Rotor remover bolt)



IC11J11A0008-01

- 10) Remove the generator stator (12) along with the CKP sensor (13).



IC11J11A0009-01

Installation

Install the generator in the reverse order of removal. Pay attention to the following points:


- Tighten the generator stator set bolts (1) and CKP sensor mounting bolts (2) to the specified torque.

NOTE

Be sure to install the grommet (3) to the generator cover.


Tightening torque

- Generator stator set bolt (a): 11 N·m (1.1 kgf-m, 8.0 lbf-ft)
CKP sensor mounting bolt (b): 6.5 N·m (0.65 kgf-m, 4.7 lbf-ft)



IG44H11A0012-02


- Degrease the tapered portion "A" of generator rotor and also the crankshaft "B". Use nonflammable cleaning solvent to wipe off oily or greasy matter and make these surfaces completely dry.
- When installing the generator rotor onto crankshaft, align the key "C" and slot "D".



IG44H11A0013-03


- While holding the generator rotor with the special tool, tighten generator rotor bolt (4) to the specified torque.

Special tool

-  (A): 09930-44530 (Rotor holder)

Tightening torque


- Generator rotor bolt (c): 140 N·m (14.0 kgf-m, 101.5 lbf-ft)



IG44H11A0014-03


- Apply molybdenum oil solution to the starter idle gear shaft hole.

M/O: Molybdenum oil (MOLYBDENUM OIL SOLUTION)



1944H11A0015-01


- Install the dowel pins (5) and new gasket (6).



IC11J11A0010-01

- Apply a small quantity of grease to the clutch push rod cap and clutch push rod.

⚠: Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



1944H11A0017-01

- Fit the new gasket washer to the bolts (7).
- Install the generator cover and tighten the generator cover bolts to specified torque.

▲ WARNING


Be careful not to pinch the finger between the generator cover and the crankcase.

NOTE

- Fit the clamp to the bolt (8).
- Fit the clutch cable stopper (9) to the bolts.

Tightening torque

Generator cover bolt (d): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)




IC11J11A0011-02

- Tighten the speed sensor mounting bolt (10) to the specified torque.

Tightening torque

Speed sensor mounting bolt (e): 4.5 N·m (0.45 kgf-m, 3.3 lbf-ft)



IC11J11A0012-03


- Route the wiring harness. Refer to "Wiring Harness Routing Diagram" in Section 9A (Page 9A-7).
- When installing the clutch release arm, align the punch mark "E" of clutch release arm with slit "F" of camshaft.

1J-8 Charging System:

- Tighten the clutch release arm bolt (11) to the specified torque.

Tightening torque

Clutch release arm bolt (f): 9 N·m (0.9 kgf-m, 6.5 lbf-ft)




IC11J11A0013-03

- Check the clutch cable play. Refer to "Clutch System Inspection" in Section 0B (Page 0B-14).
- Install the engine sprocket cover and tighten the engine sprocket cover bolts (12) to the specified torque.

Tightening torque

Engine sprocket cover bolt (g): 5.5 N·m (0.55 kgf-m, 4.0 lbf-ft)




IC11J11A0014-02

- After installing the removed parts, pour engine oil. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).

Regulator / Rectifier Construction

BENC11J11A06005



IC11J11A0015-01


1. Regulator/rectifier

Regulator / Rectifier Inspection

BENC11J11A06006

Inspect the regulator/rectifier in the following procedures:

- 1) Turn the ignition switch OFF.
- 2) Disconnect the regulator/rectifier lead wire couplers (1) and clamp (2).



IC11J11A0016-03

SHIMADzu

3) Measure the voltage between the terminals using the multi-circuit tester as indicated in the following table. If the voltage is not within the specified value, replace the regulator/rectifier with a new one.


NOTE


If the tester reads 1.4 V and below when the tester probes are not connected, replace its battery.

Special tool

 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Diode test ()



I944H11A0022-02

Unit: V

		(+) probe of tester to:						
		B/R ₁	B/R ₂	B ₁	B ₂	B ₃	B/W ₁	B/W ₂
(-) probe of tester to:	B/R ₁	—	0	0.4 - 0.7	0.4 - 0.7	0.4 - 0.7	0.5 - 1.2	0.5 - 1.2
	B/R ₂	0	—	0.4 - 0.7	0.4 - 0.7	0.4 - 0.7	0.5 - 1.2	0.5 - 1.2
	B ₁	*	*	—	*	*	0.4 - 0.7	0.4 - 0.7
	B ₂	*	*	*	—	*	0.4 - 0.7	0.4 - 0.7
	B ₃	*	*	*	*	—	0.4 - 0.7	0.4 - 0.7
	B/W ₁	*	*	*	*	*	—	0
	B/W ₂	*	*	*	*	*	0	—

*1.4 V or more (tester's battery voltage)


4) Connect the regulator/rectifier couplers (1).

Regulator / Rectifier Removal and Installation

BENC11J11A06007


Removal

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Disconnect the regulator/rectifier lead wire couplers (1) and clamp (2).



IC11J11A0016-03

- 3) Remove the regulator/rectifier (3) by removing the regulator/rectifier bolt (4).




IC11J11A0017-01

Installation

- 1) Install the regulator/rectifier as shown in the regulator/rectifier construction. Refer to "Regulator / Rectifier Construction" (Page 1J-8).
- 2) Install the removed parts.

Battery Components

BENC11J11A06008



I649G11A0046-03

1. Anode plates	5. Stopper
2. Separator (Fiberglass plate)	6. Filter
3. Cathode plates	7. Terminal
4. Upper cover breather	8. Safety valve

Battery Charging

BENC11J11A06009


Initial Charging

Filling electrolyte

NOTE

When filling electrolyte, the battery must be removed from the vehicle and must be put on the level ground.

- 1) Remove the aluminum tape (1) which seals the battery filler holes "A".




I649G11A0039-03

- 2) Remove the caps (2) from the electrolyte container.

NOTE

- Do not remove or pierce the sealed areas "B" of the electrolyte container.
- After filling the electrolyte completely, use the removed cap (2) as sealing caps of battery-filler holes.




I649G11A0040-03

- 3) Insert the nozzles of the electrolyte container (3) into the electrolyte filler holes of the battery.
- 4) Hold the electrolyte container firmly so that it does not fall.


NOTE

Do not allow any of the electrolyte to spill.



I649G11A0041-03


- 5) Make sure that air bubbles (4) rise to the top of each electrolyte container, and leave in this position for about more than 20 minutes.



I649G11A0042-03

NOTE

If no air bubbles are coming up from a filler port, tap the bottom of the electrolyte container two or three times. Never remove the container from the battery.




I310G11A0024-01

- 6) After confirming that the electrolyte has entered the battery completely, remove the electrolyte containers from the battery.
- 7) Wait for about 20 minutes.
- 8) Insert the caps (2) into the filler holes, pressing in firmly so that the top of the caps do not protrude above the upper surface of the battery's top cover.


NOTICE

- Once install the caps to the battery, do not remove the caps.
- Do not tap the caps with a hammer when installing them.




I718H11A0027-01

Correct



Incorrect



I649G11A0047-02

Charging

For initial charging, use the charger specially designed for MF battery.

NOTICE

- For charging the battery, make sure to use the charger specially designed for MF battery. Otherwise, the battery may be overcharged resulting in shortened service life.
- Do not remove the cap during charging.
- Position the battery with the cap facing upward during charging.

Battery Recharging**NOTICE**

Do not remove the caps on the battery top while recharging.

NOTE

When the motorcycle is not used for a long period, check the battery every 1 month to prevent the battery discharge.

- 1) Remove the battery from the motorcycle. Refer to "Battery Removal and Installation" (Page 1J-12).

1J-12 Charging System:

- 2) Measure the battery voltage using the multi-circuit tester.
If the voltage reading is less than the 12 V (DC), recharge the battery with a battery charger.


Recharging time

1.2 A for 5 to 10 hours or 5 A for 1 hour

NOTICE

Be careful not to permit the charging current to exceed 5 A at any time.

- 3) After recharging, wait at least 30 minutes and then measure the battery voltage using the multi-circuit tester.
If the battery voltage is less than 12.5 V, recharge the battery again.
If the battery voltage is still less than 12.5 V after recharging, replace the battery with a new one.




1649G11A0045-02

"A": Charging period

"B": Stop charging

- 4) Install the battery to the motorcycle. Refer to "Battery Removal and Installation" (Page 1J-12).



1944H11A0029-01

Battery Removal and Installation

BENC11J11A0601B


Removal

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Disconnect the battery (-) lead wire (1).
- 3) Disconnect the battery (+) lead wire (2).

NOTE

Be sure to disconnect the battery (-) lead wire (1) first, then disconnect the battery (+) lead wire (2).

- 4) Remove the band (3) battery (4) from the motorcycle.



IC11J11A0015-02

Installation

Install the battery in the reverse order of removal. Pay attention to following points:

NOTICE

Never use anything except the specified battery.

- Tighten the battery lead wire mounting bolts securely.

Battery Visual Inspection

BENC11J11A0601B

Inspect the battery in the following procedures:

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Visually inspect the surface of the battery container. If any signs of cracking or electrolyte leakage from the sides of the battery have occurred, replace the battery with a new one.
If the battery terminals are found to be coated with rust or an acidic white powdery substance, clean the battery terminals with sandpaper.
- 3) Install the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).

Specifications

Service Data

BENC11J11A07001

Electrical

Unit: mm (in)

Item	Specification	Note
Generator coil resistance	0.2 – 0.7 Ω	
Generator maximum output	375 W at 5 000 r/min.	
Generator no-load voltage (When engine is cold)	60 V (AC) or more at 5 000 r/min.	
Regulated voltage	14.0 – 15.5 V at 5 000 r/min.	
Battery	Type designation	FTX12-BS
	Capacity	12 V 36.0 kC (10 Ah)/10 HR
	Standard electrolyte S.G.	1.320 at 20 °C (68 °F)

▲ CAUTION

Never use anything except the specified battery.

Tightening Torque Specifications

BENC11J11A07002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Generator stator set bolt	11	1.1	8.0	☞(Page 1J-6)
CKP sensor mounting bolt	6.5	0.65	4.7	☞(Page 1J-6)
Generator rotor bolt	140	14.0	101.5	☞(Page 1J-6)
Generator cover bolt	10	1.0	7.0	☞(Page 1J-7)
Speed sensor mounting bolt	4.5	0.45	3.3	☞(Page 1J-7)
Clutch release arm bolt	9	0.9	6.5	☞(Page 1J-8)
Engine sprocket cover bolt	5.5	0.55	4.0	☞(Page 1J-8)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J11A08001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE "A" or equivalent	P/No.: 99000-25010	☞ (Page 1J-7)
Molybdenum oil	MOLYBDENUM OIL SOLUTION	—	☞ (Page 1J-7)

Special Tool

BENC11J11A08002

09900-25008 Multi circuit tester set ☞ (Page 1J-3) / ☞ (Page 1J-3) / ☞ (Page 1J-4) / ☞ (Page 1J-4) / ☞ (Page 1J-9)	09930-30450 Rotor remover bolt ☞ (Page 1J-6)
09930-44530 Rotor holder ☞ (Page 1J-5) / ☞ (Page 1J-6) / ☞ (Page 1J-6)	



Exhaust System

Precautions

Precautions for Exhaust System

BENC11J11B00001

▲ WARNING

To avoid the danger of being burned, do not touch the exhaust system when the system is hot. Any service on the exhaust system should be performed when the system is cool.

▲ CAUTION

Make sure that the exhaust pipe and muffler have enough clearance from the rubber parts and plastic parts to avoid melting.

Diagnostic Information and Procedures

Engine Symptom Diagnosis


BENC11J11B04001

Refer to "Engine Symptom Diagnosis" in Section 1A (Page 1A-9).

Repair Instructions

Exhaust System Construction

BENC11J11B06001



IC11J11B0001-03


1. Front exhaust pipe	5. Gasket	(c) : 10 N·m (1.0 kgf-m, 7.0 lbf-ft)
2. Rear exhaust pipe	6. HO2 sensor	(d) : 18 N·m (1.8 kgf-m, 13.0 lbf-ft)
3. Muffer	(a) : 23 N·m (2.3 kgf-m, 16.5 lbf-ft)	SEAL : Apply muffer seal.
4. Connector	(b) : 25 N·m (2.5 kgf-m, 18.0 lbf-ft)	X : Do not reuse.

Exhaust Pipe / Muffler Removal and Installation

BENC11J11B06002


Removal

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Disconnect the HO2 sensor lead wire coupler and remove the clamp. Refer to "Heated Oxygen Sensor (HO2S) Removal and Installation" in Section 1B (Page 1B-6).
- 3) Loosen the exhaust pipe connecting bolts (1), front and rear.



IC11J11B0002-01

- 4) Remove the muffler cover (2) by removing the bolts (3).




IC11J11B0003-01


- 5) Remove the front exhaust pipe (4) with the muffler (5) by removing the bolts (6).

NOTE

Support the front exhaust pipe (4) with the muffler (5) to prevent it from falling.




IC11J11B0004-01




IC11J11B0005-01

- 6) Remove the gasket (7).




IC11J11B0006-01

- 7) Remove the front exhaust pipe (4).



IC11J11B0007-01

- 8) Remove the exhaust cover (8) by removing the bolts (9).




IC11J11B0008-01

1K-4 Exhaust System:

9) Remove the HO2 sensor (10).

NOTICE

- Be careful not to expose the HO2 sensor to an excessive shock.
- Be careful not to twist or damage the HO2 sensor lead wire.




IC11J11B0009-01

10) Remove the rear shock absorber. Refer to "Rear Shock Absorber Removal and Installation" in Section 2C (Page 2C-3).

11) Remove the rear exhaust pipe (11) by removing the bolts (12).

12) Remove the gasket (13).



IC11J11B0010-01

Installation

Installation is in the reverse order of removal. Pay attention to the following points:


- Tighten the HO2 sensor (1) to the specified torque.

Tightening torque

HO2 sensor (a): 25 N·m (2.5 kgf-m, 18.0 lbf-ft)

NOTICE

- Apply anti seize compound to the HO2 sensor.
- Be careful not to expose the HO2 sensor to an excessive shock.
- Do not use an impact wrench when installing the HO2 sensor.
- Be careful not to twist or damage the HO2 sensor lead wire.




IC11J11B0011-01

- Tighten the exhaust cover bolts (2) to the specified torque.

Tightening torque

Exhaust cover bolt (b): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)




IC11J11B0012-01

- Install the new exhaust connectors (3).

NOTE

Apply the exhaust gas sealer to both the inside and outside of the new exhaust connector.

SEAL : Muffler seal (MUFFLER SEAL LOCTITE 5920 (commercially available) or equivalent)




IC11J11B0013-01

- Install the new gasket (4).
- Tighten the rear exhaust pipe bolts (5) to the specified torque.


Tightening torque

Exhaust pipe bolt (c): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



IC11J11B0014-01

- Install the new gasket (6).




IC11J11B0015-01

- Tighten the muffler mounting bolts and nuts (7) and front exhaust pipe bolts (8) to the specified torque.


Tightening torque

Muffler mounting bolt and nut (d): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)

Exhaust pipe bolt (e): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



IC11J11B0016-01



IC11J11B0017-01


1K-6 Exhaust System:

- Tighten the muffler cover bolts (9) and exhaust pipe connecting bolts (10) to the specified torque.


Tightening torque

Muffler cover bolt (f): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)

Exhaust pipe connecting bolt (g): 18 N·m (1.8 kgf-m, 13.0 lbf-ft)



IC11J11B0018-01



IC11J11B0019-02

- Route the HO2 sensor lead wire properly. Refer to "Wiring Harness Routing Diagram" in Section 9A (Page 9A-7).

Exhaust System Inspection

BENC11J11B06003

Inspect the exhaust pipe connection and muffler connection for exhaust gas leakage and mounting condition. If any defect is found, replace the exhaust pipe assembly or muffler with a new one.

Check the exhaust pipe bolts, connecting bolts and muffler mounting bolts are tightened to their specified torque. Refer to "Exhaust Pipe Bolts and Muffler Bolts Inspection" in Section 0B (Page 0B-4).

Tightening torque

Exhaust pipe bolt: 23 N·m (2.3 kgf-m, 16.5 lbf-ft)

Exhaust pipe connecting bolt: 18 N·m (1.8 kgf-m, 13.0 lbf-ft)

Muffler mounting bolt and nut: 23 N·m (2.3 kgf-m, 16.5 lbf-ft)

Specifications

Tightening Torque Specifications

BENC11J11B07001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lbf-ft	
HO2 sensor	25	2.5	18.0	☞ (Page 1K-4)
Exhaust cover bolt	10	1.0	7.0	☞ (Page 1K-4)
Exhaust pipe bolt	23	2.3	16.5	☞ (Page 1K-5) / ☞ (Page 1K-5) / ☞ (Page 1K-6)
Muffler mounting bolt and nut	23	2.3	16.5	☞ (Page 1K-5) / ☞ (Page 1K-6)
Muffler cover bolt	10	1.0	7.0	☞ (Page 1K-6)
Exhaust pipe connecting bolt	18	1.8	13.0	☞ (Page 1K-6) / ☞ (Page 1K-6)

NOTE

The tightening torque(s) also specified in:
"Exhaust System Construction" (Page 1K-2)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J11B08001

Material	SUZUKI recommended product or Specification	Note
Muffler seal	MUFFLER SEAL LOCTITE 5920 (commercially available) or equivalent	☞ (Page 1K-5)

NOTE

Required service material(s) also described in:
"Exhaust System Construction" (Page 1K-2)

Section 2

Suspension

CONTENTS

Precautions	2-1	Swingarm Related Parts Inspection	2C-10
Precautions	2-1	Swingarm Bearing Removal and Installation	2C-11
Precautions for Suspension	2-1	Specifications	2C-13
Suspension General Diagnosis	2A-1	Service Data.....	2C-13
Diagnostic Information and Procedures	2A-1	Tightening Torque Specifications.....	2C-13
Suspension and Wheel Symptom Diagnosis	2A-1	Special Tools and Equipment	2C-14
Front Suspension	2B-1	Recommended Service Material	2C-14
Repair Instructions	2B-1	Special Tool	2C-14
Front Fork Components	2B-1	Wheels and Tires	2D-1
Front Fork Removal and Installation	2B-2	Precautions	2D-1
Front Fork Inspection	2B-3	Precautions for Wheel and Tire.....	2D-1
Front Fork Adjustment	2B-4	Repair Instructions	2D-2
Front Fork Disassembly and Assembly.....	2B-4	Front Wheel Components	2D-2
Front Fork Parts Inspection.....	2B-9	Front Wheel Assembly Construction	2D-3
Specifications	2B-9	Front Wheel Assembly Removal and	
Service Data	2B-9	Installation	2D-4
Tightening Torque Specifications.....	2B-10	Front Wheel Related Parts Inspection	2D-6
Special Tools and Equipment	2B-10	Front Wheel Dust Seal / Bearing Removal	
Recommended Service Material.....	2B-10	and Installation	2D-7
Special Tool	2B-10	Rear Wheel Components	2D-9
Rear Suspension	2C-1	Rear Wheel Assembly Construction	2D-10
Repair Instructions	2C-1	Rear Wheel Assembly Removal and	
Rear Suspension Components	2C-1	Installation	2D-11
Rear Suspension Assembly Construction.....	2C-2	Rear Wheel Related Parts Inspection	2D-12
Rear Shock Absorber Removal and		Rear Wheel Dust Seal / Bearing Removal and	
Installation.....	2C-3	Installation	2D-13
Rear Suspension Inspection	2C-4	Tire Removal and Installation.....	2D-15
Rear Shock Absorber Inspection	2C-4	Wheel / Tire / Air Valve Inspection and	
Rear Suspension Adjustment	2C-4	Cleaning	2D-16
Rear Shock Absorber Disposal.....	2C-5	Air Valve Removal and Installation	2D-17
Cushion Lever / Cushion Rod Removal and		Wheel Balance Check and Adjustment.....	2D-18
Installation.....	2C-6	Specifications	2D-19
Cushion Lever Inspection	2C-7	Service Data.....	2D-19
Cushion Lever Bearing Removal and		Tightening Torque Specifications.....	2D-19
Installation.....	2C-7	Special Tools and Equipment	2D-20
Swingarm Removal and Installation.....	2C-8	Recommended Service Material	2D-20
		Special Tool	2D-20

Precautions

Precautions

Precautions for Suspension

BENC11J1200000

Refer to "General Precautions" in Section 00 (Page 00-1).

▲ WARNING

All suspensions, bolts and nuts are an important part in that it could affect the performance of vital parts. They must be tightened to the specified torque periodically and if the suspension effect is lost, replace it with a new one.

▲ CAUTION

Never attempt to heat, quench or straighten any suspension part. Replace it with a new one, or damage to the part may result.

Suspension General Diagnosis

Diagnostic Information and Procedures

Suspension and Wheel Symptom Diagnosis

BENC11J12104001


Condition	Possible cause	Correction / Reference Item
Wobbly front wheel	Distorted wheel rim.	<i>Replace.</i>
	Worn front wheel bearings.	<i>Replace.</i>
	Defective or incorrect tire.	<i>Replace.</i>
	Loose front axle or axle pinch bolt.	<i>Tighten.</i>
	Incorrect fork oil level.	<i>Adjust.</i>
	Incorrect front wheel weight balance.	<i>Adjust.</i>
Front suspension too soft	Weak spring.	<i>Replace.</i>
	Insufficient fork oil.	<i>Check level and add.</i>
	wrong weight fork oil.	<i>Replace.</i>
Front suspension too stiff	Excessively viscous fork oil.	<i>Replace.</i>
	Excessive fork oil.	<i>Check level and drain.</i>
	Bent front axle.	<i>Replace.</i>
Front suspension too noisy	Insufficient fork oil.	<i>Check level and add.</i>
	Loose front suspension fastener.	<i>Tighten.</i>
Wobbly rear wheel	Distorted wheel rim.	<i>Replace.</i>
	Worn rear wheel bearing.	<i>Replace.</i>
	Defective or incorrect tire.	<i>Replace.</i>
	Worn swingarm bearing.	<i>Replace.</i>
	Worn rear suspension bushing.	<i>Replace.</i>
	Loose rear suspension fastener.	<i>Tighten.</i>
Rear suspension too soft	Weak rear shock absorber spring.	<i>Replace.</i>
	Rear shock absorber leaks oil.	<i>Replace.</i>
	Improperly suspension setting.	<i>Adjust.</i>
Rear suspension too stiff	Improper suspension setting.	<i>Adjust.</i>
	Bent rear shock absorber shaft.	<i>Replace.</i>
	Bent swingarm.	<i>Replace.</i>
	Worn swingarm and rear suspension related bearings.	<i>Replace.</i>
Rear suspension too noisy	Loose rear suspension fastener.	<i>Tighten.</i>
	Worn rear suspension bushing.	<i>Replace.</i>
	Worn swingarm bearing.	<i>Replace.</i>

Front Suspension

Repair Instructions

Front Fork Components

BENC11J12206001



1. Dust seal	8. Outer tube (left)	15. Spring adjuster	22. Outer tube (right)
2. Oil seal stopper ring	9. Gasket	16. O-ring	: 20 N·m (2.0 kgf-m, 14.5 lbf-ft)
3. Oil seal	10. Cylinder bolt	17. Front fork cap bolt	: 23 N·m (2.3 kgf-m, 16.5 lbf-ft)
4. Oil seal retainer	11. Ring	18. Washer	: Apply thread lock to thread part.
5. Outer tube slide metal	12. Rebound spring	19. Spacer	: Apply fork oil.
6. Inner tube slide metal	13. Cylinder	20. Spring	: Do not reuse.
7. Oil lock piece	14. Inner tube	21. Front axle pinch bolt	

IC11J1220028-01

Front Fork Removal and Installation

BENC11J12206002

NOTE

The right and left front forks are installed symmetrically and therefore the removal procedure for one side is the same as that for the other side.

Removal

- 1) Remove the front wheel assembly. Refer to "Front Wheel Assembly Removal and Installation" in Section 2D (Page 2D-4).

NOTICE

- Make sure that the motorcycle is supported securely.
- Do not operate the front brake lever with the front wheel removed.

- 2) Disconnect the brake hose clamp (1) from the front fender.
- 3) Remove the front wheel speed sensor lead wire clamp (2).
- 4) Remove the reflex reflectors (3) (for E-03, 24, 28, 33) and reflex reflector bolts (4) (for E-03, 24, 28, 33).
- 5) Remove the front fender (5) by removing the bolts (6).




IC11J1220001-01

- 6) Loose the front fork upper clamp bolt (7).

NOTE

Slightly loosen the front fork cap bolt (8) to facilitate later disassembly.




IC11J1220002-01

- 7) Loosen the front fork lower clamp bolts (9) and remove the front fork.

NOTE


Hold the front fork by the hand to prevent sliding out of the steering stem.



IC11J1220003-01

Installation

- 1) Set the front fork to the front fork lower bracket temporarily by tightening the lower clamp bolts (1).



IC11J1220004-01

2B-3 Front Suspension:

- 2) Tighten the front fork cap bolt (2) to the specified torque.

Tightening torque


Front fork cap bolt (a): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)

- 3) Loosen the front fork lower clamp bolts.

NOTE

Hold the front fork by hand to prevent it sliding out of the steering stem.

- 4) Set the top end of outer tube "A" to the upper surface of the upper bracket "B".




IC11J1220005-01

- 5) Tighten the front fork lower clamp bolts (1).

Tightening torque

Front fork lower clamp bolt (b): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



IC11J1220006-02

- 6) Tighten the front fork upper clamp bolt (3).

Tightening torque

Front fork upper clamp bolt (c): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



IC11J1220007-01

- 7) Install the front fender (4).

- 8) Tighten the reflex reflector bolts (5) and reflex reflectors (6) to the specified torque.


Tightening torque

Reflex reflector bolt (d): 4.5 N·m (0.45 kgf-m, 3.3 lbf-ft)

Reflex reflector (e): 2 N·m (0.2 kgf-m, 1.5 lbf-ft)

- 9) Install the front wheel speed sensor lead wire clamp (7).

- 10) Connect the brake hose clamp (8).



IC11J1220027-01

- 11) Install the front wheel assembly. Refer to "Front Wheel Assembly Removal and Installation" in Section 2D (Page 2D-4).

▲ WARNING

After remounting the brake caliper, pump the brake lever until the pistons push the pads correctly.

NOTE

Before tightening the front axle and front axle pinch bolt, move the front fork up and down four or five times.



IC11J1220008-01

Front Fork Inspection

BENC11J12206003

Refer to "Front Fork Inspection" in Section 0B (Page 0B-20).

Front Fork Adjustment

BENC11J12206004

Turn the adjustment (1) to the desired position.

NOTICE


Adjust the left and right front forks to the same setting.

STD position

2nd groove from top



IC11J122009-01



IC11J1220010-02

[A]: Position 0 (maximum)	[C]: Position 4 (minimum)
[B]: Position 2 (STD)	

Front Fork Disassembly and Assembly

BENC11J12206005

Disassembly

1) Remove the front fork cap bolt (1).


CAUTION

Hold the front fork cap bolt when removing it, or it will jump out due to the spring pressure.



IC11J1220011-01


2) Remove the spacer (2), washer (3) and spring (4).



IC11J1220012-01


3) Invert the fork and stroke it several times to drain out fork oil.

4) Hold the fork inverted for a few minutes to drain oil.




M49G1220012-02

5) Remove the dust seal (5).



IC11J1220013-01


6) Remove the oil seal stopper ring (6).



IC11J1220014-01

2B-5 Front Suspension:


7) Remove the front axle pinch bolt (7).





IC11J1220015-01

8) Remove the cylinder bolt using the special tools.

Special tool


 (A): 09940-34520 (T handle)

 (B): 09940-34531 (Attachment A)



IC11J1220016-01

9) Remove the cylinder (8), rebound spring (9) and ring (10).




IC11J1220017-01

10) Remove the oil seal by slowly pulling out the inner tube.

NOTE


Be careful not to damage the inner tube.



IF17H1220017-01

11) Remove the following parts.

- Oil lock piece (11)
- Oil seal (12)
- Oil seal retainer (13)
- Outer tube slide metal (14)
- Inner tube slide metal (15)



IC11J1220018-01

Assembly

Assemble the front fork in the reverse order of disassembly. Pay attention to the following points:

NOTICE

- Thoroughly wash all the component parts being assembled. Insufficient washing can result in oil leakage or premature wear of the parts.
- Use the specified fork oil for the front fork.
- Use care not to cause damage to the slide metal surfaces since the surfaces are teflon coated.

Inner tube


- Hold the inner tube vertically, clean the metal groove and install the inner tube slide metal by hand.

NOTICE

Do not damage the Teflon coated surface of the inner tube's slide metal when mounting it.

- Apply fork oil to the inner tube slide metal.

FOK : Fork Oil 99000-99001-SS8 (SUZUKI FORK OIL SS-8 or equivalent)



I649G1220021-02


- Install the following parts onto the inner tube.
 - New outer tube slide metal (1)
 - New oil seal retainer (2)
 - New oil seal (3)
 - New inner tube slide metal (4).

NOTICE

When installing the oil seal to inner tube, be careful not to damage the oil seal lip.


- Apply fork oil to the outer slide metal and oil seal lip.

FOK : Fork Oil 99000-99001-SS8 (SUZUKI FORK OIL SS-8 or equivalent)



IC11J1220019-01

- Install the oil lock piece (5) into the inner tube.



IC11J1220020-01

- Install the inner tube into the outer tube with care not to drop the oil lock piece out.


NOTE

After installing the inner tube into the outer tube, keep the oil lock piece into the inner tube by compressing the front fork fully.

- Install the oil seal (3) into the outer tube using the special tool.

Special tool

FOK (A): 09940-52861 (Front fork oil seal installer)



I717H1220024-01


2B-7 Front Suspension:

- Install the oil seal stopper ring (6).

NOTICE

Make sure that the oil seal stopper ring is fitted securely.


- Install the new dust seal (7).



IC11J1220029-01

Cylinder bolt

- Install the ring (1) to the cylinder.




1944H1220018-01

- Install the rebound spring (2) to the cylinder (3).
- Apply fork oil to the cylinder ring.

FORK : Fork Oil 99000-99001-SS8 (SUZUKI FORK OIL SS-8 or equivalent)

- Insert the cylinder (3) into the inner tube.



1944H1220019-01

- Install the new cylinder bolt gasket (5).
- Apply thread lock to the cylinder bolt (4) and tighten it to the specified torque with a 6-mm hexagon wrench and special tools.

NOTE

Check the front fork for smoothness by stroking it after installing the cylinder.

Special tool


TOOL (A): 09940-34520 (T handle)

TOOL (B): 09940-34531 (Attachment A)


1322 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER "1322" or equivalent)

Tightening torque

Front fork cylinder bolt (a): 20 N·m (2.0 kgf·m, 14.5 lbf·ft)



IC11J1220022-01



IC11J1220023-01


Fork oil

- Place the front fork vertically without spring.
- Compress it fully.
- Pour specified front fork oil up to the top level of the inner tube.

TOOL : Fork Oil 99000-99001-SS8 (SUZUKI FORK OIL SS-8 or equivalent)

Capacity (Each leg)

530 ml (17.9/18.7 US/Imp oz)



1649G1220026-02

- Move the inner tube up and down several strokes until bubbles do not come out from the oil.
- Keep the front fork vertically and wait 5 – 6 minutes.

NOTE

Take extreme attention to pump out air completely.



1717H1220029-01

- Hold the front fork vertically and adjust fork oil level with the special tool.

NOTE


When adjusting the fork oil level, remove the fork spring and compress the inner tube fully.

Special tool

TOOL (A): 09943-74111 (Fork oil level gauge)

Fork oil level "a"

139 mm (5.47 in)




1705H1220021-01

Fork spring

- Install the fork spring as shown.

NOTE

The smaller pitch "a" should face to the bottom side of the front fork.



1C11J1220024-01

- Install the washer (1) and spacer (2).



1C11J1220025-01

2B-9 Front Suspension:

Front fork cap bolt

- Apply fork oil lightly to the new O-ring (1).
- FORK** : Fork Oil 99000-99001-SS8 (SUZUKI FORK OIL SS-8 or equivalent)
- Install the front fork cap bolt to the inner tube temporarily.




1944H1220024-02

Front Fork Parts Inspection

BENC11J12206006

Inner and Outer Tubes

Inspect the inner tube sliding surface and outer tube sliding surface for scuffing.




1649G1220035-03

Fork Spring

Measure the fork spring free length. If it is shorter than the service limit, replace it with a new one.

Front fork spring free length


Service limit: 442 mm (17.4 in)



1C11J1220026-01

Cylinder / Cylinder Ring

Inspect the cylinder (1) and cylinder ring (2) for wear or damage. If any defects are found, replace the cylinder or cylinder ring with a new one.



1944H1220027-01

Specifications

Service Data

BENC11J12207001

Front Fork

Unit: mm (in)

Item	Standard	Limit
Front fork stroke	150 (5.9)	—
Front fork inner tube O.D.	43 (1.69)	—
Front fork spring free length	451.1 (17.76)	442 (17.4)
Front fork oil level (without spring, inner tube fully compressed)	139 (5.47)	—
Front fork spring adjuster	2nd groove from top	—

Oil

Item	Specification	Note
Front fork oil type	SUZUKI FORK OIL SS-8 or equivalent	
Front fork oil capacity (Each leg)	530 ml (17.9/18.7 US/Imp oz)	

Tightening Torque Specifications

BENC11J12207002

Fastening part	Tightening torque			Note
	N-m	kgf-m	lbf-ft	
Front fork cap bolt	23	2.3	16.5	☞(Page 2B-3)
Front fork lower clamp bolt	23	2.3	16.5	☞(Page 2B-3)
Front fork upper clamp bolt	23	2.3	16.5	☞(Page 2B-3)
Reflex reflector bolt	4.5	0.45	3.3	☞(Page 2B-3)
Reflex reflector	2	0.2	1.5	☞(Page 2B-3)
Front fork cylinder bolt	20	2.0	14.5	☞(Page 2B-7)

NOTE

The tightening torque(s) also specified in:
 "Front Fork Components" (Page 2B-1)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J12208001





Material	SUZUKI recommended product or Specification		Note
Fork Oil	SUZUKI FORK OIL SS-8 or equivalent	P/No.: 99000-99001-SS8	☞(Page 2B-6) / ☞(Page 2B-6) / ☞(Page 2B-7) / ☞(Page 2B-8) / ☞(Page 2B-9)
Thread lock cement	THREAD LOCK CEMENT SUPER "1322" or equivalent	P/No.: 99000-32110	☞(Page 2B-7)

NOTE

Required service material(s) also described in:
 "Front Fork Components" (Page 2B-1)

Special Tool

BENC11J12208002


09940-34520 T type handle ☞(Page 2B-5) / ☞(Page 2B-7)		09940-34531 Front fork assembling attachment (A) ☞(Page 2B-5) / ☞(Page 2B-7)	
09940-52861 Front fork oil seal installer set ☞(Page 2B-6)		09943-74111 Front fork oil level gauge ☞(Page 2B-8)	

Rear Suspension

Repair Instructions

Rear Suspension Components

BENC11J1230600




IC11J1230001-01

1. Rear shock absorber	8. Spacer	: 50 N·m (5.0 kgf-m, 36.0 lbf-ft)
2. Rear shock absorber upper mounting nut	9. Chain case	: 78 N·m (7.8 kgf-m, 56.5 lbf-ft)
3. Rear shock absorber lower mounting nut	10. Swingarm	: 100 N·m (10.0 kgf-m, 72.5 lbf-ft)
4. Cushion rod	11. Chain buffer	: 15 N·m (1.5 kgf-m, 11.0 lbf-ft)
5. Cushion lever	12. Swingarm pivot nut	: 90 N·m (9.0 kgf-m, 65.0 lbf-ft)
6. Cushion lever mounting nut	13. Swingarm pivot shaft	: Apply grease to the bearing.
7. Cushion rod mounting nut	14. Swingarm pivot shaft lock-nut	: Do not reuse.

Rear Suspension Assembly Construction

BENC11J12306002



IC11J1230002-01

1. Rear shock absorber upper mounting nut	6. Swingarm pivot nut	: 100 N·m (10.0 kgf·m 72.5 lbf-ft)
2. Cushion lever mounting nut	7. Swingarm pivot shaft	: 15 N·m (1.5 kgf·m 11.0 lbf-ft)
3. Cushion rod lower mounting nut	8. Swingarm pivot shaft lock-nut	: 90 N·m (9.0 kgf·m 65.0 lbf-ft)
4. Rear shock absorber lower mounting nut	: 50 N·m (5.0 kgf·m 36.0 lbf-ft)	: Apply grease to the bearing.
5. Cushion rod upper mounting nut	: 78 N·m (7.8 kgf·m 56.5 lbf-ft)	

Rear Shock Absorber Removal and Installation

BENC11J12306003

Removal

- 1) Support the motorcycle with a jack to be no load for the rear shock absorber.


▲ CAUTION

Make sure that the motorcycle is supported securely.

NOTICE


Do not support the motorcycle with the exhaust pipes.

- 2) Remove the pre-load adjuster (1).
- 3) Remove the rear brake pipe by removing the bolt (2).




IC11J1230003-01

- 4) Remove the cushion lever rod upper bolt and nut (3).



IC11J1230004-01

- 5) Disconnect the pre-load adjuster hose from the clamp (4).
- 6) Remove the rear shock absorber upper mounting bolt and nut (5).




IC11J1230005-01

- 7) Remove the rear shock absorber lower mounting bolt and nut (6).



IC11J1230006-01

- 8) Remove the rear shock absorber (7).



IC11J1230007-02

Installation

Install the rear shock absorber in the reverse order of removal. Pay attention to the following points:

- Temporary install the rear shock absorber and cushion rod.
- Tighten the rear shock absorber upper mounting nut (1) to the specified torque.

Tightening torque

Rear shock absorber upper mounting nut (a): 50 N·m (5.0 kgf·m, 36.0 lbf·ft)

- Clamp the pre-load adjuster hose (2).




IC11J1230008-01

- Tighten the rear shock absorber lower mounting nut (3) and cushion rod upper mounting nut (4) to the specified torque.

Tightening torque

Rear shock absorber lower mounting nut (b): 50 N·m (5.0 kgf·m, 36.0 lbf·ft)

Cushion rod upper mounting nut (c): 78 N·m (7.8 kgf·m, 56.5 lbf·ft)



IC11J1230009-01

Rear Suspension Inspection

BENC11J12306004

Refer to "Rear Suspension Inspection" in Section 0B (Page 0B-20).

Rear Shock Absorber Inspection


BENC11J12306005

Inspect the rear shock absorber in the following procedures:

- Remove the rear shock absorber. Refer to "Rear Shock Absorber Removal and Installation" (Page 2C-3).
- Inspect the rear shock absorber for damage and oil leakage, and absorber bushing for wear and damage. If any defect is found, replace the rear shock absorber with a new one.

NOTICE

Do not attempt to disassemble the rear shock absorber. It is unserviceable.



IC11J1230010-01

- Install the rear shock absorber. Refer to "Rear Shock Absorber Removal and Installation" (Page 2C-3).

Rear Suspension Adjustment

BENC11J12306006

After installing the rear suspension, adjust the spring pre-load and damping force as follows.

Spring Pre-load Adjustment

The pre-load is adjusted by turning the pre-load adjuster knob without tool.

Position "0" provides the softest spring pre-load.


Position "5" provides the stiffest spring pre-load.

NOTE


Position 0 provides the softest spring tension and position 5 provides the stiffest.

STD position

2nd position



IC11J1230011-01



IC11J1230012-01

2C-5 Rear Suspension:

Damping Force Adjustment

NOTE

- Turn the adjuster clockwise to stiffen the damping force and turn it counterclockwise to soften the damping force.
- Fine-tune the adjusters by turning it slightly until two punch marks align.

The rebound damping force is adjusted by turning the adjuster.

Fully turn the damping force adjuster (1) clockwise. From that position (stiffest), turn it out to standard setting position.

STD position

2 turn back from stiffest position



IC11J1230013-02

Rear Shock Absorber Disposal

BENC11J12306007

The rear shock absorber unit contains high-pressure nitrogen gas.

▲ WARNING

- Mishandling can cause explosion.
- Keep away from fire and heat. High gas pressure caused by heat can cause an explosion.
- Release gas pressure before disposing.


Gas Pressure Release

Make sure to observe the following precautions.

▲ WARNING

- Never apply heat or disassemble the damper unit since it can explode or oil can splash hazardously.
- When discarding the rear cushion unit, be sure to release gas pressure from the unit following the procedures.

- 1) Mark the drill center at the location "A" using a center punch.



IC11J1230014-01

"a": 7 mm (0.28 in)

"A": Mark the drill hole

- 2) Wrap rear shock absorber (1) with a vinyl bag (2) and fix it on a vise as shown.
- 3) Drill a 2 – 3 mm (0.08 – 0.12 in) hole at the marked drill center using a drilling machine and let out gas while taking care not to get the vinyl bag entangled with the drill bit.

▲ WARNING

- Be sure to wear protective glasses since drilling chips and oil may fly off with blowing gas when the drill bit has penetrated through the body.
- Make sure to drill at the specified position. Otherwise, pressurized oil may spout out forcefully.



I649G1230009-03

Cushion Lever / Cushion Rod Removal and Installation

BENC11J12306008

Removal

- 1) Support the motorcycle with a jack to be no load for the cushion lever.


▲ CAUTION

Make sure that the motorcycle is supported securely.

NOTICE

Do not support the motorcycle with the exhaust pipes.

- 2) Remove the cushion lever (1) and cushion rods (2) by removing the cushion rod upper mounting bolt (3), shock absorber lower mounting bolt (4) and cushion lever mounting bolt (5).



IC11J1230015-01

- 3) Remove the cushion rods (6).



IC11J1230016-01


Installation

Install the cushion lever in the reverse order of removal. Pay attention to the following point:

- Temporarily the cushion rod mounting nut.


NOTE

The stamped marks "A" on the cushion rod should be face out side.



IC11J1230017-01

- Install the washers (1).



IC11J1230018-01

NOTICE

Insert the cushion lever mounting bolts from the left side.


- Tighten the cushion lever mounting nut (2), shock absorber lower mounting nut (3), cushion rod mounting nuts (4) to the specified torque.

Tightening torque

Cushion lever mounting nut (a): 78 N·m (7.8 kgf-m, 56.5 lbf-ft)

Rear shock absorber lower mounting nut (b): 50 N·m (5.0 kgf-m, 36.0 lbf-ft)

Cushion rod mounting nut (c): 78 N·m (7.8 kgf-m, 56.5 lbf-ft)



IC11J1230019-02


2C-7 Rear Suspension:

Cushion Lever Inspection

BENC11J12306009

Spacer

- 1) Remove the spacers from the cushion lever.
- 2) Inspect the spacers for any flaws or other damage. If any defects are found, replace the spacers with new ones.



IC11J1230020-01

Cushion Lever Bearing

- 1) Insert the spacers into bearings.
- 2) Check the play by moving the spacers up and down. If excessive play is noted, replace the bearing with a new one. Refer to "Cushion Lever Bearing Removal and Installation" (Page 2C-7).



IC11J1230021-01

Cushion Lever


Inspect the cushion lever for damage. If any defect is found, replace the cushion lever with a new one.



IC11J1230022-01

Cushion Rod

Inspect the cushion rods for damage and bend. If any defects are found, replace the cushion rods with new ones.



IC11J1230023-01


Cushion Lever Bearing Removal and Installation


BENC11J12306010

Removal

- 1) Remove the cushion lever. Refer to "Cushion Lever / Cushion Rod Removal and Installation" (Page 2C-6).
- 2) Remove the cushion lever bearings using the special tools.

Special tool

 (A): 09921-20240 (Bearing remover set)



IC11J1230024-01


Installation


- 1) Press the new bearings into the cushion lever with the special tool.

NOTE

When installing the bearing, stamped mark on the bearing must face outside.


Special tool


 (A): 09941-34513 (Steering race installer)



IC11J1230025-01

- 2) Apply grease to the bearings.

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



IC11J1230026-01

- 3) Install the cushion lever. Refer to "Cushion Lever / Cushion Rod Removal and Installation" (Page 2C-6).

Swingarm Removal and Installation

BENC11J12306011


Removal

- 1) Remove the muffler. Refer to "Exhaust Pipe / Muffler Removal and Installation" in Section 1K (Page 1K-3).
- 2) Support the motorcycle with a jack to be no load for the swingarm.

CAUTION


- Do not support the motorcycle with the exhaust pipes.
- Make sure that the motorcycle is supported securely.

- 3) Remove the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation" in Section 2D (Page 2D-11).
- 4) Disconnect the rear brake hose (1) and rear wheel speed sensor read wire (2).



IC11J1230027-01


- 5) Remove the cushion lever and cushion rods. Refer to "Cushion Lever / Cushion Rod Removal and Installation" (Page 2C-6).
- 6) Remove the rear shock absorber. Refer to "Rear Shock Absorber Removal and Installation" (Page 2C-3).
- 7) Remove the pivot covers (3).



IC11J1230028-02

- 8) Remove the swingarm pivot shaft lock-nut (4) using the special tool.

Special tool

 (A): 09940-14940 (Swingarm pivot thrust adjuster wrench)





IC11J1230029-02

2C-9 Rear Suspension:

- 9) Hold the swingarm pivot shaft (5) and remove the swingarm pivot nut (6).
- 10) Remove the swingarm pivot shaft with the special tool.


Special tool

 (B): 09944-28320 (Hexagon socket (19 mm))




IC11J1230030-02

- 11) Remove the chain cover (7).




IC11J1230031-01

- 12) Remove the chain adjusters (8).




IC11J1230032-01

- 13) Remove the chain buffer (9).



IC11J1230033-01

- 14) Remove the brake hose clamps (10).




IC11J1230034-02

Installation

Install the swingarm in the reverse order of removal. Pay attention to the following points:


- Insert the swingarm pivot shaft (1) and tighten it to the specified torque with the special tool.

Special tool

 (A): 09944-28320 (Hexagon socket (19 mm))

Tightening torque


Swingarm pivot shaft (a): 15 N·m (1.5 kgf-m, 11.0 lbf-ft)



IC11J1230035-01


- Hold the swingarm pivot shaft (1) with the special tool and tighten the swingarm pivot nut (2) to the specified torque.

Special tool

 (A): 09944-28320 (Hexagon socket (19 mm))

Tightening torque


Swingarm pivot nut (b): 100 N·m (10.0 kgf-m, 72.5 lbf-ft)



IC11J1230036-01


- Tighten the swingarm pivot lock-nut (3) to the specified torque with the special tool.

Special tool

 (B): 09940-14940 (Swingarm pivot thrust adjuster wrench)

Tightening torque

Swingarm pivot lock-nut (c): 90 N·m (9.0 kgf-m, 65.0 lbf-ft)




IC11J1230037-01

Swingarm Related Parts Inspection

BENC11J12306012

Spacers


- Remove the spacers (1) from the swingarm.
- Inspect the spacers for wear and damage. If any defects are found, replace the spacers with new ones.



IC11J1230038-01

Chain Buffer

Inspect the chain buffer for wear and damage. If any defect is found, replace the chain buffer with a new one.



IC11J1230039-01

Swingarm Bearing and Cushion Rod Bearing

- Insert the spacers into bearings.
- Check the play by moving the spacers up and down. If excessive play is noted, replace the bearing with a new one. Refer to "Swingarm Bearing Removal and Installation" (Page 2C-11).



IC11J1230040-01

2C-11 Rear Suspension:

Swingarm

Inspect the swingarm for damage. If any defect is found, replace the swingarm with a new one.




IC11J1230041-01


Swingarm Pivot Shaft

Measure the swingarm pivot shaft runout using the dial gauge. If the runout exceeds the service limit, replace the pivot shaft.

Special tool


 (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

 (B): 09900-20701 (Magnetic stand)

 (C): 09900-21304 (V-block (100 mm))

Swingarm pivot shaft runout

Service limit: 0.3 mm (0.01 in)



I649G1230034-03


Swingarm Bearing Removal and Installation


BENC11J12306013

Removal

- 1) Remove the swingarm. Refer to "Swingarm Removal and Installation" (Page 2C-8).
- 2) Draw out the swingarm pivot bearings (1) using the special tool.


Special tool

 (A): 09921-20240 (Bearing remover set)



IC11J1230042-01


- 3) Remove the center spacer (2).




IC11J1230043-01

- 4) Remove the swingarm cushion rod bearings (3) using the special tools.

Special tool

 (A): 09921-20240 (Bearing remover set)



IC11J1230044-01


Installation


- 1) Press the new bearings into the swingarm cushion rod with the special tool.

NOTE

When installing the bearing, stamped mark on the bearing must face outside.


Special tool

 (A): 09941-34513 (Steering race installer)



IC11J1230045-01

- 2) Install the center spacer (1).




IC11J1230046-01


- 3) Press the bearings into the swingarm pivot with the special tool.

NOTE

When installing the bearing, stamped mark on the bearing must face outside.


Special tool


 (A): 09941-34513 (Steering race installer)



IC11J1230047-01

- 4) Apply grease to the bearings.

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



IC11J1230048-01

- 5) Install the swingarm. Refer to "Swingarm Removal and Installation" (Page 2C-8).
- 6) Install the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation" in Section 2D (Page 2D-11).

NOTE

The tightening torque(s) also specified in "Rear Suspension Component" (Page 2C-1) and "Rear Suspension Assembly Construction" (Page C-2).

Reference:
For the tightening torque of fastener, refer to the "Fastener Tightening Torque" (Page D-2).

Specifications

Service Data

BENC11J123070

Suspension

Unit: mm (in)

Item	Standard	Limit
Rear shock absorber spring adjuster	2nd position	—
Rear shock absorber damping force adjuster	2 turn back from stiffest position	—
Rear wheel travel	159 (6.3)	—
Swingarm pivot shaft runout	—	0.3 (0.01)

Tightening Torque Specifications

BENC11J123070

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Rear shock absorber upper mounting nut	50	5.0	36.0	☞(Page 2C-3)
Rear shock absorber lower mounting nut	50	5.0	36.0	☞(Page 2C-4) / ☞(Page 2C-6)
Cushion rod upper mounting nut	78	7.8	56.5	☞(Page 2C-4)
Cushion lever mounting nut	78	7.8	56.5	☞(Page 2C-6)
Cushion rod mounting nut	78	7.8	56.5	☞(Page 2C-6)
Swingarm pivot shaft	15	1.5	11.0	☞(Page 2C-9)
Swingarm pivot nut	100	10.0	72.5	☞(Page 2C-10)
Swingarm pivot lock-nut	90	9.0	65.0	☞(Page 2C-10)

NOTE

The tightening torque(s) also specified in:

“Rear Suspension Components” (Page 2C-1)

“Rear Suspension Assembly Construction” (Page 2C-2)

Reference:

For the tightening torques of fasteners not specified in this section, refer to “Tightening Torque List” in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J12308001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE "A" or equivalent	P/No.: 99000-25010	☞(Page 2C-8) / ☞(Page 2C-12)

NOTE








Required service material(s) also described in:

"Rear Suspension Components" (Page 2C-1)

"Rear Suspension Assembly Construction" (Page 2C-2)

Special Tool

BENC11J12308002

09900-20607 Dial gauge ☞(Page 2C-11)		09900-20701 Dial gauge chuck ☞(Page 2C-11)	
09900-21304 V blocks ☞(Page 2C-11)		09921-20240 Bearing remover set ☞(Page 2C-7) / ☞(Page 2C-11) / ☞(Page 2C-11)	
09940-14940 Swingarm pivot thrust adjuster wrench ☞(Page 2C-8) / ☞(Page 2C-10)		09941-34513 Bearing installer ☞(Page 2C-8) / ☞(Page 2C-12) / ☞(Page 2C-12)	
09944-28320 Hexagon socket (19 mm) ☞(Page 2C-9) / ☞(Page 2C-9) / ☞(Page 2C-10)			

Wheels and Tires

Precautions

Precautions for Wheel and Tire

BENC11J1240001


▲ WARNING

- Proper tire pressure and proper tire loading are important factors. Over loading tire can lead to tire failure and loss of motorcycle control.
 - Under-inflated tires make smooth cornering difficult, and can result in rapid tire wear.
 - Over-inflated tires have a smaller amount of tire in contact with the load, which can contribute to skidding and loss of control.
 - Do not interchange tires between wheels on the same vehicle.
Do not use tires of sizes and types different from the originally installed tires.
Rotation of tires or use of such different tires may adversely affect handling of the vehicle and can result in loss of control.
 - Replace the wheel when wheel runout exceed the service limit or if find damage such as distortion, crack, nick or scratch.
 - When tire replacement is necessary, the original equipment type tire should be used.
 - Do not mix different types of tires on the same vehicle such as radial and bias-belted tires except in emergencies, because handling may be seriously affected and may result in loss of control.
 - Replacement wheel must be equivalent to the original equivalent wheel.
-

Repair Instructions

Front Wheel Components

BENC11J12406001




IC11J1240040-03

1. Front axle	8. Tire	: 23 N·m (2.3 kgf-m, 16.5 lbf-ft)
2. Brake disc bolt	9. Wheel balancer	: 6.5 N·m (0.65 kgf-m, 4.7 lbf-ft)
3. Brake disc	10. Air valve	: Apply grease.
4. Bearing	11. Front wheel	: Apply thread lock to thread part.
5. Spacer	12. Wheel speed sensor rotor	: Do not reuse.
6. Dust seal	13. Wheel speed sensor rotor bolt	
7. Collar	: 65 N·m (6.5 kgf-m, 47.0 lbf-ft)	

Front Wheel Assembly Construction

BENC11J12406002



IC11J1240001-03

1. Brake disc bolt	6. Sensor rotor bolt	(c) : 65 N·m (6.5 kgf-m, 47.0 lbf-ft)
2. Brake caliper mounting bolt	"a": Clearance	(d) : 6.5 N·m (0.65 kgf-m, 4.7 lbf-ft)
3. Front axle	"b": 0.26 – 1.67 mm (0.010 – 0.066 in)	(A) : Apply grease.
4. Front axle pinch bolt	(a) : 23 N·m (2.3 kgf-m, 16.5 lbf-ft)	(L) : Apply thread lock to thread part.
5. Front wheel speed sensor	(b) : 39 N·m (3.9 kgf-m, 28.0 lbf-ft)	

Front Wheel Assembly Removal and Installation

BENC11J12406003


NOTICE


Do not hit the front wheel speed sensor rotor when dismounting and remounting the front wheel.

Removal

- 1) Remove the brake calipers. Refer to "Front Brake Caliper Removal and Installation" in Section 4B (Page 4B-3).
- 2) Remove the front wheel speed sensor. Refer to "Front Wheel Speed Sensor Removal and Installation" in Section 4E (Page 4E-52).
- 3) Loosen the axle pinch bolt (1) on the right front fork leg.
- 4) Loosen the front axle (2) by using the special tool.

Special tool

 (A): 09900-18710 (Hexagon socket (12 mm))



IC11J1240002-01

- 5) Raise the front wheel off the ground and support the motorcycle with a jack or a wooden block.

CAUTION

Make sure that the motorcycle is supported securely.


NOTICE

Do not support the motorcycle with the exhaust pipes.

- 6) Draw out the front axle and remove the front wheel.

NOTE

After removing the front wheel, fit the calipers temporarily to the original positions.



IC11J1240003-01


- 7) Remove the collar (3).



IC11J1240004-02

Installation

- 1) Install the collars (1) into the left side and right side of the wheel.



IC11J1240005-01

2D-5 Wheels and Tires:

- 2) Install the front wheel with the front axle and tighten the front axle temporarily.

▲ WARNING

The directional arrow on the tire should point to the wheel rotation, when remounting the wheel.



IC11J1240006-01


- 3) Tighten the brake caliper mounting bolts (2) to the specified torque.

▲ WARNING

After remounting the brake calipers, pump the brake lever until the pistons push the pad correctly.

Tightening torque


Front brake caliper mounting bolt (a): 39 N·m (3.9 kgf-m, 28.0 lbf-ft)



IC11J1240007-01


- 4) Tighten the front axle (3) to the specified torque by using the special tool.

Special tool

 : 09900-18710 (Hexagon socket (12 mm))

Tightening torque

Front axle (b): 65 N·m (6.5 kgf-m, 47.0 lbf-ft)



IC11J1240008-01

- 5) Tighten axle pinch bolt (4) to the specified torque.

NOTE


Before toughening the front axle pinch bolt, move the front fork up and down four or five times.

Tightening torque

Front axle pinch bolt (c): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



IC11J1220008-01




IC11J1240009-01

- 6) Install the front wheel speed sensor. Refer to "Front Wheel Speed Sensor Removal and Installation" in Section 4E (Page 4E-52).
- 7) Check the clearance between the front wheel speed sensor and sensor rotor using the thickness gauge.

Special tool

- TOOL (A): 09900-20804 (Thickness gauge)**
TOOL (B): 09900-20806 (Thickness gauge)

Wheel speed sensor – Sensor rotor clearance
 0.26 – 1.67 mm (0.010 – 0.066 in)



IC11J1240010-02

Front Wheel Related Parts Inspection

BENC11J12406004

Tire

Refer to "Tire Inspection" in Section 0B (Page 0B-19).

Front Brake Disc

Refer to "Front Brake Disc Inspection" in Section 4B (Page 4B-7).

Dust Seal

Inspect the dust seal lips (1) for wear or damage. If any defects are found, replace the dust seal with the new ones. Refer to "Front Wheel Dust Seal / Bearing Removal and Installation" (Page 2D-7).



IC11J1240011-01

Wheel Axle


Using a dial gauge, check the wheel axle for runout. If the runout exceeds the limit, replace the axle shaft.

Special tool

- TOOL (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))**
TOOL (B): 09900-20701 (Magnetic stand)
TOOL (C): 09900-21304 (V-block (100 mm))

Wheel axle runout

Service limit: 0.25 mm (0.010 in)



1649G1240054-02


Wheel

Inspect the wheel in the following procedures:

- 1) Remove the brake pads. Refer to "Front Brake Pad Replacement" in Section 4B (Page 4B-2).
- 2) Make sure that the wheel rim runout checked as shown does not exceed the service limit. An excessive runout is usually due to worn or loosened wheel bearings and can be reduced by replacing the bearings. If bearing replacement fails to reduce the runout, replace the wheel.
- 3) Install the brake pads. Refer to "Front Brake Pad Replacement" in Section 4B (Page 4B-2).

Wheel rim runout

Service limit (Axial and Radial): 2.0 mm (0.08 in)




1649G1240014-02

2D-7 Wheels and Tires:

Wheel Bearing

Inspect the play of the wheel bearings by finger while they are in the wheel. Rotate the inner race by finger to inspect for abnormal noise and smooth rotation. Replace the bearing in the following procedure if there is anything unusual. Refer to "Front Wheel Dust Seal / Bearing Removal and Installation" (Page 2D-7).



I649G1240015-02


Front Wheel Dust Seal / Bearing Removal and Installation

BENC11J12406005

Removal

- 1) Remove the front wheel assembly. Refer to "Front Wheel Assembly Removal and Installation" (Page 2D-4).
- 2) Remove the front wheel speed sensor rotor. Refer to "Front Wheel Speed Sensor Rotor Removal and Installation" in Section 4E (Page 4E-54).
- 3) Remove the dust seal (1) on both sides using the special tool.

Special tool


 (A): 09913-50121 (Oil seal remover)




IC11J1240012-03

- 4) Remove the bearings (2) on both sides using the special tool.


Special tool

 (B): 09921-20240 (Bearing remover set)



IC11J1240013-02


- 5) Remove the spacer (3).



IC11J1240014-02

Installation

- 1) Apply grease to the new wheel bearings.



 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



IC11J1240039-01


- 2) First install the left wheel bearing, then install the spacer (1) and right wheel bearing with the special tool.

Special tool

-  (A): 09913-70210 (Bearing installer set)
 (B): 09941-34513 (Steering race installer)

NOTE


The sealed cover of the bearing must face outside.



IC11J1240015-02

- 3) Install the new dust seal with the special tool.


Special tool


-  (C): 09913-70210 (Bearing installer set)



IC11J1240017-02


- 4) Install the front wheel speed sensor rotor. Refer to "Front Wheel Speed Sensor Rotor Removal and Installation" in Section 4E (Page 4E-54).
 5) Apply grease to the lip of dust seal.

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



IC11J1240018-01

- 6) Install the front wheel assembly. Refer to "Front Wheel Assembly Removal and Installation" (Page 2D-4).




IC11J1240016-02

"a": Clearance

Rear Wheel Components

BENC11J12406006




IC11J1240020-02

1. Rear axle	10. Sprocket	19. Wheel speed sensor rotor
2. Brake disc	11. Collar	20. Wheel speed sensor rotor bolt
3. Spacer	12. Rear wheel	: 23 N·m (2.3 kgf-m, 16.5 lbf-ft)
4. Dust seal	13. Tire	: 60 N·m (6.0 kgf-m, 43.5 lbf-ft)
5. Bearing	14. Air valve	: 100 N·m (10.0 kgf-m, 72.5 lbf-ft)
6. Wheel damper	15. Wheel balancer	: 6.5 N·m (0.65 kgf-m, 4.7 lbf-ft)
7. Retainer	16. Rear sprocket nut	: Apply grease.
8. Sprocket mounting drum	17. Rear axle nut	: Apply thread lock to thread part.
9. Bearing	18. Brake disc bolt	: Do not reuse.

Rear Wheel Assembly Construction

BENC11J12406007



IC11J1240019-01

1. Rear sprocket nut	6. Sensor rotor bolt	(c) : 23 N·m (2.3 kgf·m, 16.5 lbf·ft)
2. Rear axle nut	"a": Clearance	(d) : 6.5 N·m (0.65 kgf·m, 4.7 lbf·ft)
3. Brake caliper mounting bolt	"b": 0.26 – 1.47 mm (0.010 – 0.058 in)	⊗ : Apply grease.
4. Brake disc bolt	(a) : 60 N·m (6.0 kgf·m, 43.5 lbf·ft)	⊗ : Apply thread lock to thread part.
5. Rear wheel speed sensor	(b) : 100 N·m (10.0 kgf·m, 72.5 lbf·ft)	

Rear Wheel Assembly Removal and Installation

BENC11J12406008

NOTICE

Do not hit the rear wheel speed sensor rotor when dismounting and remounting the rear wheel.

Removal

- 1) Remove the rear wheel speed sensor. Refer to "Rear Wheel Speed Sensor Removal and Installation" in Section 4E (Page 4E-53).
- 2) Loosen the rear axle nut (1).
- 3) Raise the rear wheel off the ground and support the motorcycle with a jack or wooden block.


CAUTION

Make sure that the motorcycle is supported securely.

NOTICE

Do not support the motorcycle with the exhaust pipes.

- 4) Remove the rear axle nut (1), washer (2) and draw out the rear axle.



IC11J1240021-01

- 5) Remove the rear axle and disengage the drive chain from the rear sprocket.
- 6) Remove the rear wheel assembly.


NOTICE

Do not operate the rear brake pedal with the rear wheel removed.



IC11J1240022-01


- 7) Remove the spacer (3) and collar (4).



IC11J1240023

Installation

- 1) Install the collar (1) and spacer (2).



IC11J1240024

- 2) Install the rear wheel with the rear axle and tighten the rear axle nut temporarily.
- 3) Adjust the drive chain slack after installing the rear wheel. Refer to "Drive Chain Inspection and Adjustment" in Section 0B (Page 0B-15).
- 4) Tighten the rear axle nut (3) to the specified torque.

Tightening torque

Rear axle nut (a): 100 N·m (10.0 kgf-m, 72.5 lbf-ft)

WARNING

After remounting the rear wheel, pump the brake pedal a few times to check for proper brake operation.




IC11J1240025-01

- 5) Install the rear wheel speed sensor. Refer to "Rear Wheel Speed Sensor Removal and Installation" in Section 4E (Page 4E-53).
- 6) Check the clearance between the rear wheel speed sensor and sensor rotor using the thickness gauge.

Special tool

-  (A): 09900-20804 (Thickness gauge)
-  (B): 09900-20806 (Thickness gauge)

Wheel speed sensor – Sensor rotor clearance
0.26 – 1.47 mm (0.010 – 0.058 in)



IC11J1240026-02

Rear Wheel Related Parts Inspection

BENC11J12406009


Tire
Refer to "Tire Inspection" in Section 0B (Page 0B-19).

Rear Brake Disc
Refer to "Rear Brake Disc Inspection" in Section 4C (Page 4C-7).

Wheel Damper
Refer to "Drive Chain Related Parts Inspection" in Section 3A (Page 3A-5).

Sprocket
Refer to "Drive Chain Related Parts Inspection" in Section 3A (Page 3A-5).

Dust Seal
Inspect the dust seal lip (1) for wear or damage. If any defects is found, replace the dust seal with a new one. Refer to "Rear Wheel Dust Seal / Bearing Removal and Installation" (Page 2D-13).



IC11J1240027-01




Wheel Axle


Using a dial gauge, check the wheel axle for runout. If the runout exceeds the limit, replace the axle shaft.

Wheel axle runout

Service limit: 0.25 mm (0.010 in)

Special tool

-  (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))
-  (B): 09900-20701 (Magnetic stand)
-  (C): 09900-21304 (V-block (100 mm))



I649G1230034-03


Wheel

Inspect the wheel in the following procedures:

- 1) Remove the brake pads. Refer to "Rear Brake Pad Replacement" in Section 4C (Page 4C-2).
- 2) Make sure that the wheel rim runout checked as shown does not exceed the service limit. An excessive runout is usually due to worn or loosened wheel bearings and can be reduced by replacing the bearings. If bearing replacement fails to reduce the runout, replace the wheel.
- 3) Install the brake pads. Refer to "Rear Brake Pad Replacement" in Section 4C (Page 4C-2).

Wheel rim runout

Service limit (Axial and Radial): 2.0 mm (0.08 in)




I649G1240014-02

2D-13 Wheels and Tires:

Bearing

Inspect the play of the wheel bearings by hand while they are in the wheel. Rotate the inner race by hand to inspect for abnormal noise and smooth rotation. Replace the bearing if there is anything unusual. Refer to "Rear Wheel Dust Seal / Bearing Removal and Installation" (Page 2D-13).




IC49G1240015-02

Rear Wheel Dust Seal / Bearing Removal and Installation

BENC11J12406010

Removal

- 1) Remove the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation" (Page 2D-11).
- 2) Remove the rear wheel speed sensor rotor. Refer to "Rear Wheel Speed Sensor Rotor Removal and Installation" in Section 4E (Page 4E-54).
- 3) Remove the rear sprocket mounting drum assembly (1) from the rear wheel.




IC11J1240028-01

- 4) Remove the dust seal (2).

Special tool


 (A): 09913-50121 (Oil seal remover)




IC11J1240029-02

- 5) Remove the bearings (3) on both sides using the special tool.


Special tool

 (B): 09921-20240 (Bearing remover set)



IC11J1240030-02


- 6) Remove the spacer (4).



IC11J1240031-02

Installation

- 1) Apply grease to the new wheel bearings.


 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)




IC11J1240039-01

- 2) First install the right wheel bearing, then install the spacer (1) and left wheel bearing with the special tools.


Special tool

 (A): 09941-34513 (Steering race installer)


 (B): 09913-70210 (Bearing installer set)

NOTE

The sealed cover of the bearing must face outside.




IC11J1240032-02




IC11J1240033-02

- 3) Install a new dust seal with the special tool.

Special tool


 (C): 09913-70210 (Bearing installer set)




IC11J1240034-03

- 4) Install the rear wheel speed sensor rotor. Refer to "Rear Wheel Speed Sensor Rotor Removal and Installation" in Section 4E (Page 4E-54).

- 5) Apply grease to the dust seal lip.

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



IC11J1240035-01

- 6) Install the rear sprocket mounting drum assembly (2).



IC11J1240036-01

- 7) Install the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation" (Page 2D-11).

Tire Removal and Installation

BENC11J12406011

NOTICE

When replacing the tire, make sure not to damage the sensor rotor.

Removal

The most critical factor of a tubeless tire is the seal between the wheel rim and the tire bead. For this reason, it is recommended to use a tire changer that can satisfy this sealing requirement and can make the operation efficient as well as functional.


- 1) Remove the wheel assembly. Refer to "Front Wheel Assembly Removal and Installation" (Page 2D-4) and "Rear Wheel Assembly Removal and Installation" (Page 2D-11).
- 2) Remove the mounting drum from the rear wheel. Refer to "Rear Wheel Dust Seal / Bearing Removal and Installation" (Page 2D-13).
- 3) Remove the valve core.
- 4) Remove the tire using the tire changer.

NOTICE

For operating procedures, refer to the instructions supplied by the tire changer manufacturer.

NOTE

When removing the tire in case of repair or inspection, mark the tire with a chalk to indicate the tire position relative to the valve position. Even though the tire is refitted to the original position after repairing puncture, the tire may have to be balanced again since such a repair can cause imbalance.



I649G1240037-02

Installation

- 1) Apply tire lubricant to the tire bead.

NOTICE

Never use oil, grease or gasoline on the tire bead in place of tire lubricant.



I649G1240038-02

- 2) Install the tire onto the wheel.

NOTICE

For installation procedure of tire onto the wheel, follow the instructions given by the tire changer manufacturer.

NOTE

- When installing the tire, the arrow on the side wall should point to the direction of wheel rotation.
- Align the chalk mark put on the tire at the time of removal with the valve position.




IC11J1240037-01

- 3) Bounce the tire several times while rotating. This makes the tire bead expand outward to contact the wheel, thereby facilitating air inflation.
- 4) Install the valve core and inflate the tire.

▲ WARNING

- Do not inflate the tire to more than 400 kPa (4.0 kgf/cm²). If inflated beyond this limit, the tire can burst and possibly cause injury. Do not stand directly over the tire while inflating.
- In the case of preset pressure air inflator, pay special care for the set pressure adjustment.

- 5) In this condition, check the "rim line" "B" cast on the tire side walls. The line must be equidistant from the wheel rim all around.
- 6) If the distance between the rim line and wheel rim varies, this indicates that the bead is not properly seated. If this is the case, deflate the tire completely and unseat the bead for both sides. Coat the bead with lubricant and fit the tire again.



I649G1240040-02

- 7) When the bead has been fitted properly, adjust the pressure to specification.
- 8) As necessary, adjust the tire balance. Refer to "Wheel Balance Check and Adjustment" (Page 2D-18).

Cold inflation tire pressure

	Front	Rear
Solo riding	225 kPa (2.25 kgf/cm ² , 33 psi)	250 kPa (2.50 kgf/cm ² , 36 psi)
Dual riding	225 kPa (2.25 kgf/cm ² , 33 psi)	280 kPa (2.80 kgf/cm ² , 41 psi)

- 9) Install the mounting drum to the rear wheel. (For rear wheel) Refer to "Rear Wheel Dust Seal / Bearing Removal and Installation" (Page 2D-13).
- 10) Install the wheel assembly. Refer to "Front Wheel Assembly Removal and Installation" (Page 2D-4) and "Rear Wheel Assembly Removal and Installation" (Page 2D-11).

Wheel / Tire / Air Valve Inspection and Cleaning

BENC11J12406012

Wheel

Wipe the wheel clean and check for the following points:

- Distortion and crack
- Any flaws and scratches at the bead seating area.
- Wheel rim runout. Refer to "Front Wheel Assembly Removal and Installation" (Page 2D-4) and "Rear Wheel Assembly Removal and Installation" (Page 2D-11).



I649G1240041-02


Tire

Tire must be checked for the following points:

- Nick and rupture on side wall
- Tire tread depth (Refer to "Tire Inspection" in Section 0B (Page 0B-19).)
- Tread separation
- Abnormal, uneven wear on tread
- Surface damage on bead
- Localized tread wear due to skidding (Flat spot)
- Abnormal condition of inner liner



I649G1240042-02




I649G1240043-02

2D-17 Wheels and Tires:


Air Valve

Inspect the air valve for peeling and damage. If any defect is found, replace the air valve with a new one. Refer to "Air Valve Removal and Installation" (Page 2D-17).



I649G1240044-02

Inspect the valve core seal (1) for wear and damage. If any defect is found, replace the valve core with a new one. Refer to "Air Valve Removal and Installation" (Page 2D-17).




I944H1240041-01

Air Valve Removal and Installation

BENC11J12406013

Removal

- 1) Remove the wheel assembly. Refer to "Front Wheel Assembly Removal and Installation" (Page 2D-4) and "Rear Wheel Assembly Removal and Installation" (Page 2D-11).
- 2) Remove the tire. Refer to "Tire Removal and Installation" (Page 2D-15).
- 3) Remove the air valve (1) from the wheel.




I649G1240046-02

Installation

Install the air valve in the reverse order of removal. Pay attention to the following points:

- Any dust or rust around the valve hole (1) must be cleaned off.



I718H1240054-01


- Install the new air valve (2) in the wheel (3).

NOTICE

Be careful not to damage the lip (4) of valve.

NOTE

To properly install the valve into the valve hole, apply a special tire lubricant or neutral soapy liquid to the valve.



I718H1240055-01

2. Valve	3. Wheel	4. Valve lip
----------	----------	--------------

Wheel Balance Check and Adjustment

BENC11J12406014


Check and adjust the wheel balance in the following procedures:

- 1) Removal the wheel assembly. Refer to "Front Wheel Assembly Removal and Installation" (Page 2D-4) and "Rear Wheel Assembly Removal and Installation" (Page 2D-11).
- 2) Remove the mounting drum from the rear wheel. Refer to "Rear Wheel Dust Seal / Bearing Removal and Installation" (Page 2D-13).
- 3) Check the wheel balance using the balancer and adjust the wheel balance if necessary.

NOTICE

For operating procedures, refer to the instructions supplied by the wheel balancer manufacturer.

- 4) When installing the balancer weight (1) to the wheel (2), set the balancer weight on center rib of the wheel.



IC11J1240038-01

- 5) Recheck the wheel balance.
- 6) Install the mounting drum to the rear wheel. (For rear wheel)
Refer to "Rear Wheel Dust Seal / Bearing Removal and Installation" (Page 2D-13).
- 7) Install the wheel assembly. Refer to "Front Wheel Assembly Removal and Installation" (Page 2D-4) and "Rear Wheel Assembly Removal and Installation" (Page 2D-11).

Specifications

Service Data

BENC11J12407001

Wheel

Unit: mm (in)

Item	Standard		Limit
Wheel rim runout	Axial	—	2.0 (0.08)
	Radial	—	2.0 (0.08)
Wheel axle runout	Front	—	0.25 (0.010)
	Rear	—	0.25 (0.010)
Wheel rim size	Front	19 M/C x MT2.50	—
	Rear	17 M/C x MT4.00	—

Tire

Item	Standard		Limit
Cold inflation tire pressure (Solo riding)	Front	225 kPa (2.25 kgf/cm ² , 33 psi)	—
	Rear	250 kPa (2.50 kgf/cm ² , 36 psi)	—
Cold inflation tire pressure (Dual riding)	Front	225 kPa (2.25 kgf/cm ² , 33 psi)	—
	Rear	280 kPa (2.80 kgf/cm ² , 41 psi)	—
Tire size	Front	110/80R19M/C 59H, tubeless	—
	Rear	150/70R19M/C 69H, tubeless	—
Tire type	Front	BRIDGESTONE: TW 101 RADIAL J	—
	Rear	BRIDGESTONE: TW 152 RADIAL F	—
Tire tread depth (Recommended depth)	Front	—	1.6 mm (0.06 in)
	Rear	—	2.0 mm (0.08 in)

Tightening Torque Specifications

BENC11J12407002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Front brake caliper mounting bolt	39	3.9	28.0	☞ (Page 2D-5)
Front axle	65	6.5	47.0	☞ (Page 2D-5)
Front axle pinch bolt	23	2.3	16.5	☞ (Page 2D-5)
Rear axle nut	100	10.0	72.5	☞ (Page 2D-11)

NOTE

The tightening torque(s) also specified in:

“Front Wheel Components” (Page 2D-2)

“Front Wheel Assembly Construction” (Page 2D-3)

“Rear Wheel Components” (Page 2D-9)

“Rear Wheel Assembly Construction” (Page 2D-10)

Reference:

For the tightening torques of fasteners not specified in this section, refer to “Tightening Torque List” in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J12408001

Material	SUZUKI recommended product or Specification	Note
Grease	SUZUKI SUPER GREASE "A" or equivalent	P/No.: 99000-25010 ☞ (Page 2D-7) / ☞ (Page 2D-8) / ☞ (Page 2D-13) / ☞ (Page 2D-14)

NOTE

Required service material(s) also described in:

"Front Wheel Components" (Page 2D-2)











"Front Wheel Assembly Construction" (Page 2D-3)

"Rear Wheel Components" (Page 2D-9)

"Rear Wheel Assembly Construction" (Page 2D-10)

Special Tool

BENC11J12408002

09900-18710 Hexagon socket (12 mm) ☞ (Page 2D-4) / ☞ (Page 2D-5)		09900-20607 Dial gauge ☞ (Page 2D-6) / ☞ (Page 2D-12)	
09900-20701 Dial gauge chuck ☞ (Page 2D-6) / ☞ (Page 2D-12)		09900-20804 Thickness gauge ☞ (Page 2D-6) / ☞ (Page 2D-12)	
09900-20806 Thickness gauge ☞ (Page 2D-6) / ☞ (Page 2D-12)		09900-21304 V blocks ☞ (Page 2D-6) / ☞ (Page 2D-12)	
09913-50121 Oil seal remover ☞ (Page 2D-7) / ☞ (Page 2D-13)		09913-70210 Bearing installing set (10 – 75 Φ) ☞ (Page 2D-8) / ☞ (Page 2D-8) / ☞ (Page 2D-14) / ☞ (Page 2D-14)	
09921-20240 Bearing remover set ☞ (Page 2D-7) / ☞ (Page 2D-13)		09941-34513 Bearing installer ☞ (Page 2D-8) / ☞ (Page 2D-14)	

Section 3

Driveline / Axle

CONTENTS

Precautions	3-1	Rear Sprocket / Rear Sprocket Mounting	
Precautions	3-1	Drum Removal and Installation	3A-4
Precautions for Driveline / Axle	3-1	Drive Chain Related Parts Inspection	3A-5
Drive Chain / Drive Train / Drive Shaft...	3A-1	Sprocket Mounting Drum Dust Seal / Bearing	
Diagnostic Information and Procedures	3A-1	Removal and Installation.....	3A-6
Drive Chain and Sprocket Symptom		Drive Chain Replacement	3A-7
Diagnosis	3A-1	Specifications	3A-10
Repair Instructions	3A-1	Service Data.....	3A-10
Drive Chain Related Components.....	3A-1	Tightening Torque Specifications	3A-10
Engine Sprocket Removal and Installation	3A-2	Special Tools and Equipment	3A-11
		Recommended Service Material	3A-11
		Special Tool	3A-11

Precautions

Precautions

Precautions for Driveline / Axle

BENC11J1300001

Refer to "General Precautions" in Section 00 (Page 00-1).

▲ WARNING

Never inspect or adjust the drive chain while the engine is running.

NOTICE

-
- Do not use trichloroethylene, gasoline or any similar solvent. These fluids will damage the O-rings of the drive chain.
 - Clean the drive chain with a spray-type chain cleaner and blow dry with compressed air. If the drive chain cannot be cleaned with a spray cleaner, it may be necessary to use a kerosine. Always follow the chemical manufacturer's instructions on proper use, handling and storage.
 - Lubricate the drive chain with a heavy weight motor oil. Wipe off any excess oil or chain lubricant. Do not use any oil sold commercially as "drive chain oil". Such oil can damage the O-rings.
-

NOTE

The standard drive chain is RK 525SMOZ8. Suzuki recommends to use this standard drive chain as a replacement.

Drive Chain / Drive Train / Drive Shaft

Diagnostic Information and Procedures

Drive Chain and Sprocket Symptom Diagnosis


BENC11J13104001

Condition	Possible cause	Correction / Reference Item
Noisy Drive Chain	Worn sprocket.	Replace.
	Worn drive chain.	Replace.
	Stretched drive chain.	Replace.
	Too large drive chain slack.	Adjust.
	Drive chain out of adjustment.	Adjust.

Repair Instructions

Drive Chain Related Components

BENC11J13106001



IC11J1310001-02


1. Engine sprocket	7. Rear sprocket nut	(b) : 60 N·m (6.0 kgf·m, 43.5 lbf·ft)
2. Drive chain	8. Rear sprocket	AH : Apply grease.
3. Lock washer	9. Sprocket mounting drum	K00 : Apply thread lock to thread part.
4. Engine sprocket nut	10. Wheel damper	X : Do not reuse.
5. Dust seal	11. Retainer	
6. Bearing		(a) : 145 N·m (14.5 kgf·m, 105.0 lbf·ft)

Engine Sprocket Removal and Installation

BENC11J13106002


Removal

- 1) Remove the engine sprocket outer cover (1) by removing the screws (2).




IC11J1310002-02

- 2) Remove the speed sensor (3).
- 3) Remove the engine sprocket inner cover (4) by removing the bolts (5).




IC11J1310003-03

- 4) Remove the dowel pins (6).
- 5) Remove the speed sensor rotor (7) by removing the bolt (8) while depressing the rear brake pedal.



IC11J1310004-02

- 6) Flatten the lock washer (9).
- 7) Remove the engine sprocket nut (10) while depressing the rear brake pedal.
- 8) Remove the lock washer (9).



IC11J1310005-01

- 9) Loosen the rear axle nut (11).
- 10) Support the motorcycle with a jack or wooden block.


CAUTION

Make sure that the motorcycle is supported securely.

NOTICE


Do not support the motorcycle with the exhaust pipes.

- 11) Loosen the chain adjuster bolts (12) to provide additional chain slack, left and right.



IC11J1310006-01

- 12) Remove the engine sprocket (13).





IC11J1310007-01

Installation

Install the engine sprocket in the reverse order of removal. Pay attention to the following points:

- Put the drive chain on the engine sprocket.
- Install the engine sprocket (1).
- Install the new lock washer (2).
- Apply thread lock to the driveshaft.

 : Thread lock cement 99000-32030 (Thread Lock Cement Super 1303 or equivalent)




IC11J1310008-01

- Tighten the engine sprocket nut (3) to the specified torque.

Tightening torque

Engine sprocket nut (a): 145 N·m (14.5 kgf-m, 105.0 lbf-ft)

Bend the lock washer (2).



IC11J1310009-01


- Tighten the speed sensor rotor bolt (4) to the specified torque.

Tightening torque

Speed sensor rotor bolt (b): 28 N·m (2.8 kgf-m, 20.5 lbf-ft)



- Install the dowel pins (5).




IC11J1310010-02

- Install the engine sprocket inner cover (6).
- Tighten the speed sensor mounting bolt (7) to the special torque.

Tightening torque

Speed sensor mounting bolt (c): 4.5 N·m (0.45 kgf-m, 3.3 lbf-ft)




IC11J1310011-03

- Install the engine sprocket cover and tighten the engine sprocket cover bolts (8) to the specified torque.

Tightening torque

Engine sprocket cover bolt (d): 5.5 N·m (0.55 kgf-m, 4.0 lbf-ft)



IC11J1310012-02


- Adjust the drive chain slack. Refer to "Drive Chain Inspection and Adjustment" in Section 0B (Page 0B-15).

Rear Sprocket / Rear Sprocket Mounting Drum Removal and Installation

BENC11J13106003


Removal

- 1) Remove the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation" in Section 2D (Page 2D-11).
- 2) Remove the rear sprocket nuts (1) and separate the rear sprocket (2) from its mounting drum (3).
- 3) Draw out the mounting drum (3) from the wheel hub.



IC11J1310013-02

- 4) Remove the retainer (4).



IC11J1310014-01

- 5) Remove the wheel dampers (5).





IC11J1310015-01

Installation

Install the rear sprocket and rear sprocket mounting drum in the reverse order of removal. Pay attention to the following points:

- Apply grease to the retainer (1).

: Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)




IC11J1310016-01

- Temporarily tighten the rear sprocket nuts (2).

NOTE

The stamped mark "A" on the sprocket should face outside.




IC11J1310017-02

- Apply grease to the contacting surface between the rear wheel hub and the mounting drum.

NOTICE

Never use oil, grease or gasoline on the wheel damper in place of the tire lubricant.

: Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)




IC11J1310018-01

Tighten the rear sprocket nuts (2) to the specified torque.

Tightening torque

Rear sprocket nut (a): 60 N·m (6.0 kgf·m, 43.5 lbf·ft)



IC11J1310019-01


Install the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation" in Section 2D (Page 2D-11).

Drive Chain Related Parts Inspection

BENC11J13106004

Dust Seal


Inspect the sprocket mounting drum dust seal (1) for wear or damage. If any damage is found, replace the dust seal with a new one.



IC11J1310020-01

Bearing


Inspect the play of the sprocket mounting drum bearings by hand while they are in the wheel and drum. Rotate the inner race by hand to inspect for abnormal noise and smooth rotation. Replace the bearing if there is anything unusual.



I649G1310015-02

Engine Sprocket and Rear Sprocket

Inspect the sprocket teeth for wear. If they are worn as shown, replace the engine sprocket, rear sprocket and drive chain as a set.




I649G1310016-02

"A": Normal wear "B": Excessive wear

Wheel Damper

Inspect the dampers for wear and damage. Replace the damper if there is anything unusual.



IC11J1310021-01

Drive Chain

Refer to "Drive Chain Inspection and Adjustment" in Section 0B (Page 0B-15).

Sprocket Mounting Drum Dust Seal / Bearing Removal and Installation

BENC11J13106005

Removal


- 1) Remove the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation" in Section 2D (Page 2D-11).
- 2) Remove the rear sprocket mounting drum assembly from the rear wheel. Refer to "Rear Wheel Dust Seal / Bearing Removal and Installation" in Section 2D (Page 2D-13).
- 3) Remove the retainer (1).




IC11J1310022-01

- 4) Remove the sprocket mounting drum dust seal (2) using the special tool.

Special tool


 (A): 09913-50121 (Oil seal remover)




IC11J1310023-01

- 5) Remove the sprocket mounting drum bearing using the special tool.

Special tool


 (B): 09921-20240 (Bearing remover set)



IC11J1310024-01

Installation

- 1) Apply grease to the new bearing before installing.


 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)




I649G1310020-01

- 2) Install the bearing (1) and new dust seal (2) to the sprocket mounting drum using the special tool.


Special tool

 (A): 09913-70210 (Bearing installer set)



IC11J1310025-01


- 3) Apply grease to the dust seal lip.

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



IC11J1310026-01

- Apply grease to the retainer (3) before installing the rear sprocket mounting drum.

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



IC11J1310027-02

- Install the rear sprocket mounting drum assembly to rear wheel. Refer to "Front Wheel Dust Seal / Bearing Removal and Installation" in Section 2D (Page 2D-7).
- Install the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation" in Section 2D (Page 2D-11).

Drive Chain Replacement


BENC11J13106006


Use the special tool in the following procedures, to cut and rejoin the drive chain.

NOTE

When using the special tool, apply a small quantity of grease to the threaded parts of the special tool.

Special tool


 : 09922-22711 (Drive chain cutting and joining tool)



1649G1310023-02

Drive Chain Cutting

- Set up the special tool as shown in the illustration.




1649G1310024-02

1.	Tool body
2.	Grip handle
3.	Pressure bolt [A]
4.	Pressure bolt [B]
5.	Bar
6.	Adjuster bolt (With through hole)
7.	Pin remover
8.	Chain holder (Engraved mark 500) with reamer bolt M5 x 10

NOTE

The tip of pin remover (7) should be positioned inside "a" approximately 5 mm (0.2 in) from the end face of pressure bolt [A] (3) as shown in the illustration.




"a": 5 mm (0.2 in)

1644H1310026-01

3A-8 Drive Chain / Drive Train / Drive Shaft:

- 2) Place the drive chain link being disjoined on the holder part (8) of the tool.
- 3) Turn in both the adjuster bolt (6) and pressure bolt [A] (3) so that each of their end hole fits over the chain joint pin properly.
- 4) Tighten the pressure bolt [A] (3) with the bar.




I718H1310032-01

- 5) Turn in the pressure bolt [B] (4) with the bar (5) and force out the drive chain joint pin (9).


NOTE

- Continue turning in the pressure bolt [B] (4) until the joint pin has been completely pushed out of the chain.
- After the joint pin (9) is removed, loosen the pressure bolt [B] (4) and then pressure bolt [A] (3).

- 6) Remove the joint pin (9) of the other side of joint plate.



I649G1310027-02



I649G1310028-02


Drive Chain Connecting

▲ WARNING

Do not use joint clip type of drive chain. The joint clip may have a chance to drop which may cause severe damage to motorcycle and severe injury.

Joint plate installation

- 1) Set up the special tool as shown in the illustration.




I944H1310027-02

1.	Tool body
2.	Grip handle
3.	Joint plate holder (Engraved mark "F520")
4.	Wedge holder and wedge pin
5.	Adjuster bolt (Without hole)
6.	Pressure bolt [A]
7.	Bar

- 2) Apply grease to the joint pins (8), new O-rings (9) and new plates (10).
- 3) Connect both ends of the drive chain with the joint pin (8) inserted from the wheel side "A" as installed on the motorcycle.

Joint set part number

RK: 27620 - 06G40




I649G1310030-02

- 4) Apply grease on the recessed portion of the joint plate holder (3) and set the joint plate (10).

NOTE


When positioning the joint plate (10) on the tool, its stamp mark must face the joint plate holder (3) side.

- 5) Set the drive chain on the tool as illustrated and turn in the adjuster bolt (5) to secure the wedge holder and wedge pin (4).



I649G1310031-02

- 6) Turn in the pressure bolt [A] (6) and align two joint pins (11) properly with the respective holes of the joint plate (10).
- 7) Turn in the pressure bolt [A] (6) further using the bar (7) to press the joint plate over the joint pins.




I649G1310032-02

- 8) Continue pressing the joint plate until the distance between the two joint plates come to the specification.

Joint plate distance specification "a"
18.6 – 18.9 mm (0.73 – 0.74 in)

NOTICE


Should pressing of the joint plate be made excessively beyond the specified dimension, the work should be redone using the new joint parts.



I649G1310033-03

Joint pin staking

- 1) Set up the special tool as shown in the illustration.



I649G1310034-02

1.	Tool body
2.	Grip handle
3.	Pressure bolt [A]
4.	Adjuster bolt (Without hole)
5.	Staking pin (Stowed inside grip handle behind rubber cap)
6.	Bar

NOTE

Before staking the joint pin, apply a small quantity of grease to the staking pin (5).


3A-10 Drive Chain / Drive Train / Drive Shaft:

- 2) Stake the joint pin by turning (approximately 7/8 turn) the pressure bolt [A] (3) with the bar (6) until the pin end diameter becomes the specified dimension.


NOTICE

- After joining of the chain has been completed, check to make sure that the link is smooth and no abnormal condition is found.
- Should any abnormal condition be found, reassemble the chain link using the new joint parts.

Pin end diameter specification "a"
 RK: 5.45 – 5.85 mm (0.215 – 0.230 in)



I944H1310028-01



I649G1310036-03

- 3) Adjust the drive chain slack, after connecting it. Refer to "Drive Chain Inspection and Adjustment" in Section 0B (Page 0B-15).

Specifications

Service Data

Drive Chain

Unit: mm (in)

BENC11J13107001

Item	Standard		Limit
Final reduction ratio	3.133 (47/15)		—
Drive chain	Type	RK 525SMOZ8	—
	Links	118 links	—
	20-pitch length	—	319.4 (12.57)
Drive chain slack (On side-stand)	20 – 30 (0.8 – 1.2)		—

Tightening Torque Specifications

BENC11J13107002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Engine sprocket nut	145	14.5	105.0	☞(Page 3A-3)
Speed sensor rotor bolt	28	2.8	20.5	☞(Page 3A-3)
Speed sensor mounting bolt	4.5	0.45	3.3	☞(Page 3A-3)
Engine sprocket cover bolt	5.5	0.55	4.0	☞(Page 3A-3)
Rear sprocket nut	60	6.0	43.5	☞(Page 3A-5)

NOTE

The tightening torque(s) also specified in:
 "Drive Chain Related Components" (Page 3A-1)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J13108001





Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE "A" or equivalent	P/No.: 99000-25010	☞(Page 3A-4) / ☞(Page 3A-4) / ☞(Page 3A-6) / ☞(Page 3A-6) / ☞(Page 3A-7)
Thread lock cement	Thread Lock Cement Super 1303 or equivalent	P/No.: 99000-32030	☞(Page 3A-3)

NOTE

Required service material(s) also described in:
 "Drive Chain Related Components" (Page 3A-1)

Special Tool

BENC11J13108002

09913-50121 Oil seal remover ☞(Page 3A-6)		09913-70210 Bearing installing set (10 – 75 Φ) ☞(Page 3A-6)	
09921-20240 Bearing remover set ☞(Page 3A-6)		09922-22711 Drive chain cutting and joint tool set ☞(Page 3A-7)	

Section 4

Brakes

CONTENTS

Precautions	4-1	Repair Instructions	4B-1
Precautions	4-1	Front Brake Components	4B-1
Precautions for Brake System	4-1	Front Brake Pad Inspection.....	4B-2
Brake Fluid Information.....	4-1	Front Brake Pad Replacement.....	4B-2
Brake Control System and Diagnosis ...	4A-1	Front Brake Caliper Removal and Installation.....	4B-3
Schematic and Routing Diagram	4A-1	Front Brake Caliper Disassembly and	
Front Brake Hose Routing Diagram.....	4A-1	Assembly.....	4B-4
Rear Brake Hose Routing Diagram.....	4A-3	Front Brake Caliper Parts Inspection	4B-6
Diagnostic Information and Procedures	4A-4	Front Brake Disc Removal and Installation	4B-6
Brake Symptom Diagnosis.....	4A-4	Front Brake Disc Inspection	4B-7
Repair Instructions	4A-4	Specifications	4B-8
Brake Pedal Height Inspection and		Service Data.....	4B-8
Adjustment	4A-4	Tightening Torque Specifications.....	4B-8
Front Brake Light Switch Inspection	4A-4	Special Tools and Equipment	4B-9
Rear Brake Light Switch Inspection	4A-5	Recommended Service Material	4B-9
Rear Brake Light Switch Inspection and		Special Tool	4B-9
Adjustment.....	4A-5	Rear Brakes	4C-1
Brake Fluid Level Check	4A-5	Repair Instructions	4C-1
Brake Hose Inspection.....	4A-5	Rear Brake Components.....	4C-1
Air Bleeding from Brake Fluid Circuit	4A-5	Rear Brake Pad Inspection	4C-2
Brake Fluid Replacement.....	4A-7	Rear Brake Pad Replacement	4C-2
Front Brake Master Cylinder Components.....	4A-9	Rear Brake Caliper Removal and Installation	4C-3
Front Brake Master Cylinder Assembly		Rear Brake Caliper Disassembly and	
Removal and Installation.....	4A-10	Assembly.....	4C-4
Front Brake Master Cylinder / Brake Lever		Rear Brake Caliper Parts Inspection	4C-6
Disassembly and Assembly	4A-11	Rear Brake Disc Removal and Installation.....	4C-6
Front Brake Master Cylinder Parts Inspection ..	4A-12	Rear Brake Disc Inspection.....	4C-7
Rear Brake Master Cylinder Components	4A-13	Specifications	4C-8
Rear Brake Master Cylinder Assembly		Service Data.....	4C-8
Removal and Installation.....	4A-14	Tightening Torque Specifications.....	4C-8
Rear Brake Master Cylinder Disassembly and		Special Tools and Equipment	4C-9
Assembly	4A-15	Recommended Service Material	4C-9
Rear Brake Master Cylinder Parts Inspection ...	4A-16	Special Tool	4C-9
Front Brake Hose Removal and Installation.....	4A-16	ABS	4E-1
Rear Brake Hose Removal and Installation	4A-17	Precautions	4E-1
Specifications	4A-18	Precautions for ABS.....	4E-1
Service Data	4A-18	ABS Information	4E-1
Tightening Torque Specifications.....	4A-18	General Description	4E-1
Special Tools and Equipment	4A-19	Wheel Speed Sensor Description	4E-1
Recommended Service Material.....	4A-19	ABS Control Unit Description	4E-1
Special Tool	4A-19	Hydraulic Unit (HU) Description	4E-3
Front Brakes	4B-1	Self-diagnosis Function and ABS Indicator	
		Light Description	4E-4

4-ii Table of Contents

Fail-safe Function Description.....	4E-5	DTC "47" (C1647): Supply Voltage (Increased).....	4E-44
Schematic and Routing Diagram	4E-6	DTC "48" (C1648): Supply Voltage (Decreased).....	4E-46
ABS Wiring Diagram.....	4E-6	DTC "55" (C1655): ABS Control Unit Malfunction.....	4E-48
ABS Control Unit / HU Diagram.....	4E-7	DTC "61" (C1661): ABS Solenoid Malfunction ..	4E-50
Front Wheel Speed Sensor Routing Diagram.....	4E-8	Repair Instructions	4E-51
Rear Wheel Speed Sensor Routing Diagram.....	4E-9	ABS Control Unit / HU Cover Construction.....	4E-51
Component Location	4E-10	ABS Control Unit Coupler Disconnect and Connect.....	4E-51
ABS Components Location.....	4E-10	Front Wheel Speed Sensor Removal and Installation.....	4E-52
Diagnostic Information and Procedures	4E-11	Rear Wheel Speed Sensor Removal and Installation.....	4E-53
ABS Troubleshooting.....	4E-11	Front Wheel Speed Sensor Rotor Removal and Installation.....	4E-54
Pre-diagnosis Inspection.....	4E-13	Rear Wheel Speed Sensor Rotor Removal and Installation.....	4E-54
ABS Indicator Light Inspection.....	4E-15	Wheel Speed Sensor and Sensor Rotor Inspection.....	4E-55
DTC (Diagnostic Trouble Code) Output.....	4E-18	ABS Control Unit / HU Removal and Installation.....	4E-56
DTC (Diagnostic Trouble Code) Deleting.....	4E-22	Specifications	4E-57
SDS Check.....	4E-25	Tightening Torque Specifications.....	4E-57
Active Control Inspection.....	4E-26	Special Tools and Equipment	4E-58
DTC Table.....	4E-30	Special Tool.....	4E-58
DTC "25" (C1625): Wheel Speed Sensor Related Malfunction.....	4E-31		
DTC "35" (C1635): ABS Motor Malfunction.....	4E-33		
DTC "41" (C1641): Wheel Speed Sensor Signal Malfunction (F).....	4E-35		
DTC "42" (C1642): Wheel Speed Sensor Circuit Open (F).....	4E-36		
DTC "44" (C1644): Wheel Speed Sensor Signal Malfunction (R).....	4E-40		
DTC "45" (C1645): Wheel Speed Sensor Circuit Open (R).....	4E-41		

Precautions

Precautions

Precautions for Brake System

BENC11J14000001

Refer to "General Precautions" in Section 00 (Page 00-1).

Brake Fluid Information

BENC11J14000002

▲ WARNING

- This brake system is filled with an ethylene glycol-based DOT 4 brake fluid. Do not use or mix different types of fluid, such as silicone-based or petroleum-based.
- Do not use any brake fluid taken from old, used or unsealed containers. Never reuse brake fluid left over from the last servicing or which has been stored for long periods of time.
- When storing brake fluid, seal the container completely and keep it away from children.
- When replenishing brake fluid, take care not to get dust into the fluid.
- When washing brake components, use new brake fluid. Never use cleaning solvent.
- A contaminated brake disc or brake pad reduces braking performance. Discard contaminated pads and clean the disc with high quality brake cleaner or neutral detergent.

NOTICE


Immediately and completely wipe off any brake fluid contacting any part of the motorcycle. The brake fluid reacts chemically with paint, plastics and rubber materials, etc., and will damage them severely.

Brake Control System and Diagnosis

Schematic and Routing Diagram

Front Brake Hose Routing Diagram



BENC11J1410200



IC11J1410026-4

1. Front brake hose No. 1	"A": Pass the brake hose through the hose clamp.
2. Front brake hose No. 2	(a) : 23 N·m (2.3 kgf-m, 16.5 lbf-ft)
3. ABS control unit/HU	(b) : 7.5 N·m (0.75 kgf-m, 5.5 lbf-ft)
4. Stopper : After the brake hose union has contacted the stopper, tighten the union bolt.	(c) : 39 N·m (3.9 kgf-m, 28.0 lbf-ft)
5. Clamp : Insert the clamp to the hole of the front fender fully.	(d) : 16 N·m (1.6 kgf-m, 11.5 lbf-ft)
6. Clamp : Clamp the brake hose firmly.	"a": 40°
7. Hose guide : Fit the grommet sleeve on the brake hose to the hose guide properly.	"b": 10°
8. Stopper : After positioning the clamp with the stopper, tighten the clamp bolt.	"c": 0°
9. Clamp : Clamp the brake pipes at the marking on them.	"d": 15°

Rear Brake Hose Routing Diagram



<p>1. Stopper : After the brake hose union has contacted the stopper, tighten the union bolt.</p>	<p>"A": Face the white paint marking to outside</p>
<p>2. Brake hose clamp : Brake hose clamp ends should face forward.</p>	<p>"B": Pass the rear brake pipe No.2 under the front brake pipe No.1</p>
<p>3. Brake hose clamp : Brake hose clamp ends should face backward.</p>	<p>"C": Insert the reservoir hose firmly.</p>
<p>4. ABS control unit/HU</p>	<p>"D": Outside</p>
<p>5. Front brake pipe No. 1</p>	<p>"a": 42°</p>
<p>6. Front brake pipe No. 2</p>	<p>(a) : 23 N·m (2.3 kgf-m, 16.5 lbf-ft)</p>
<p>7. Rear brake hose No. 1</p>	<p>(b) : 6 N·m (0.6 kgf-m, 4.3 lbf-ft)</p>
<p>8. Rear brake hose No. 2</p>	<p>(c) : 27 N·m (2.7 kgf-m, 19.5 lbf-ft)</p>
<p>9. Rear wheel speed sensor lead wire</p>	<p>(d) : 16 N·m (1.6 kgf-m, 11.5 lbf-ft)</p>
<p>10. Stopper : After positioning the clamp with the stopper, tighten the clamp bolt.</p>	

Diagnostic Information and Procedures

Brake Symptom Diagnosis

BENC11J14104001

Condition	Possible cause	Correction / Reference Item
Insufficient brake power	Leakage of brake fluid from hydraulic system.	Repair or replace.
	Worn pads and disc.	Replace.
	Oil adhesion on friction surface of pads.	Clean disc and pads.
	Air in hydraulic system.	Bleed air.
	Not enough brake fluid in the reservoir.	Replenish.
Brake squeaking	Carbon adhesion on pad surface.	Repair surface with sandpaper.
	Tilted pad.	Correct pad fitting or replace.
	Damaged wheel bearing.	Replace.
	Loose front-wheel axle or rear-wheel axle.	Tighten to specified torque.
	Worn pads and disc.	Replace.
	Foreign material in brake fluid.	Replace brake fluid.
	Clogged return port of master cylinder.	Disassemble and clean master cylinder.
Excessive brake lever stroke	Air in hydraulic system.	Bleed air.
	Insufficient brake fluid.	Replenish fluid to specified level, bleed air.
	Improper quality of brake fluid.	Replace with correct fluid.
Leakage of brake fluid	Insufficient tightening of connection joints.	Tighten to specified torque.
	Cracked hose.	Replace.
	Worn piston and cup.	Replace piston and cup.
	Worn piston seal and dust seal.	Replace piston seal and dust seal.
Brake drags	Rusty part.	Clean and lubricate.
	Insufficient brake lever or brake pedal pivot lubrication.	Lubricate.

Repair Instructions

Brake Pedal Height Inspection and Adjustment

BENC11J14106001

Refer to "Brake System Inspection" in Section 0B (Page 0B-17).

Front Brake Light Switch Inspection

BENC11J14106002

Inspect the front brake light switch in the following procedures:

- 1) Disconnect the front brake light switch coupler (1).



IC11J1410001-01

- 2) Inspect the switch for continuity with a tester.

If any abnormality is found, replace the front brake light switch with a new one. Refer to "Front Brake Master Cylinder / Brake Lever Disassembly and Assembly" (Page 4A-11).

Special tool

 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•))

Color Position	Terminal (B/R)	Terminal (B/BI)
OFF		
ON	○	○

IC11J1410002-01

- 3) Connect the front brake light switch coupler.

4A-5 Brake Control System and Diagnosis:

Rear Brake Light Switch Inspection

BENC11J14106003

Inspect the rear brake light switch in the following procedures:

- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 2) Disconnect the rear brake light switch lead wire coupler (1).



IC11J1410003-01

- 3) Inspect the switch for continuity with a tester. If any abnormality is found, replace the rear brake light switch with a new one.



Special tool

 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•)))

Rear brake light switch

Color Position	Terminal (O)	Terminal (W/B)
ON		
OFF		


IS44H1410002-02

- 4) Connect the rear brake light switch lead wire coupler.
- 5) Reinstall the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).

Rear Brake Light Switch Inspection and Adjustment

BENC11J14106004

Check the rear brake light switch so that the brake light will come on just before pressure is felt when the brake pedal is depressed. If the brake light switch adjustment is necessary, turn the adjuster nut (1) in or out while holding the brake pedal.



IC11J1410004-01

Brake Fluid Level Check

BENC11J14106005

Refer to "Brake System Inspection" in Section 0B (Page 0B-17).

Brake Hose Inspection

BENC11J14106006

Refer to "Brake System Inspection" in Section 0B (Page 0B-17).

Air Bleeding from Brake Fluid Circuit

BENC11J14106007

Air trapped in the brake fluid circuit acts like a cushion to absorb a large proportion of the pressure developed by the master cylinder and thus interferes with the full braking performance of the brake caliper. The presence of air is indicated by "sponginess" of the brake lever and also by lack of braking force. Considering the danger to which such trapped air exposes the machine and rider, it is essential that after remounting the brake and restoring the brake system to the normal condition, the brake fluid circuit be purged of air in the following manner:

NOTICE

Spilled brake fluid can damage painted surfaces and plastic parts.

Be careful not to spill any fluid when filling the brake fluid reservoir. Wipe spilled fluid up immediately.


Front Brake

- 1) Fill the master cylinder reservoir to the top of the inspection window. Place the reservoir cap to prevent dirt from entering.




IC11J1410005-01

- 2) Attach a hose to the air bleeder valve, and insert the free end of the hose into a receptacle.
- 3) Squeeze and release the brake lever several times in rapid succession and squeeze the lever fully without releasing it.



IC11J1410006-01

- 4) Loosen the air bleeder valve by turning it a quarter of a turn so that the brake fluid runs into the receptacle, this will remove the tension of the brake lever causing it to touch the handlebar grip.



IC11J1410007-01

- 5) Close the air bleeder valve, pump and squeeze the lever, and open the valve.
- 6) Repeat this process until the fluid flowing into the receptacle no longer contains air bubbles.

NOTE


While bleeding the brake system, replenish the brake fluid in the reservoir as necessary. Make sure that there is always some fluid visible in the reservoir.

- 7) Close the air bleeder valve and disconnect the hose.

Tightening torque

Air bleeder valve (Front brake): 7.5 N·m (0.75 kgf-m, 5.5 lbf-ft)

- 8) Fill the reservoir with brake fluid to the upper line of the reservoir.



IC11J1410008-01

- 9) Install the reservoir cap.

Rear Brake

Bleed air from the rear brake system as the same manner of front brake. Pay attention to following points:


- Remove the right frame side cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).

NOTE

The only difference of bleeding operation from the front brake is that the rear master cylinder is actuated by a pedal.

Tightening torque

Air bleeder valve (Rear brake): 6 N·m (0.6 kgf-m, 4.3 lbf-ft)




IC11J1410009-01



IC11J1410010-01

4A-7 Brake Control System and Diagnosis:

- Fill the reservoir with brake fluid to the upper mark of the reservoir.



IC11J1410011-01

- Install the right frame side cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).

Brake Fluid Replacement

BENC11J14106008

NOTICE

Spilled brake fluid can damage painted surfaces and plastic parts. Be careful not to spill any fluid when filling the brake fluid reservoir. Wipe spilled fluid up immediately.

Front Brake

- 1) Place the motorcycle on a level surface and keep the handlebars straight.
- 2) Remove the brake fluid reservoir cap and diaphragm.
- 3) Suck up the old brake fluid as much as possible.




IC11J1410012-01

- 4) Fill the reservoir with new brake fluid.


BF: Brake fluid (DOT 4)

- 5) Connect a clear hose to the air bleeder valve and insert the other end of the hose into a receptacle.



IC11J1410013-01

- 6) Loosen the air bleeder valve and pump the brake lever until the old brake fluid flows out of the brake system.



IC11J1410006-01

- 7) Close the air bleeder valve and disconnect the clear hose.


Tightening torque

Air bleeder valve (Front brake) (a): 7.5 N·m (0.75 kgf-m, 5.5 lbf-ft)



IC11J1410015-01

- 8) Fill the reservoir with brake fluid to the upper line reservoir.



IC11J1410008-01

- 9) Install the reservoir cap.

Rear Brake

Replace the brake fluid from the rear brake system as the same manner of front brake.

- 1) Place the motorcycle on a level surface.
- 2) Remove the right rear frame cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Remove the brake fluid reservoir cap and diaphragm.
- 4) Suck up the old brake fluid as much as possible.



IC11J1410014-01


- 5) Fill the reservoir with new brake fluid.

BF: Brake fluid (DOT 4)

- 6) Connect a clear hose to the air bleeder valve and insert the other end of the hose into a receptacle.
- 7) Loosen the air bleeder valve and pump the brake pedal until the old brake fluid flows out of the brake system.



IC11J1410016-01




IC11J1410009-01

- 8) Close the air bleeder valve and disconnect the clear hose.

Tightening torque

Air bleeder valve (Rear brake) (a): 6 N·m (0.6 kgf-m, 4.3 lbf-ft)



IC11J1410017-02


- 9) Fill the reservoir with brake fluid to the upper mark reservoir.



IC11J1410011-01

- 10) Install the reservoir cap.

Front Brake Master Cylinder Components



1. Reservoir cap	7. Brake lever	(b) : 10 N·m (1.0 kgf-m, 7.0 lbf-ft)
2. Plate	8. Brake lever pivot bolt	(c) : 6 N·m (0.6 kgf-m, 4.3 lbf-ft)
3. Diaphragm	9. Brake lever pivot bolt lock-nut	(BF) : Apply brake fluid.
4. Master cylinder	10. Master cylinder holder bolt	(SH) : Apply silicone grease.
5. Piston / Cup set	11. Protector	(X) : Do not reuse.
6. Brake hose union bolt	(a) : 23 N·m (2.3 kgf-m, 16.5 lbf-ft)	

Front Brake Master Cylinder Assembly Removal and Installation

BENC11J14106011


Removal

- 1) Remove the right rear view mirror (1).
- 2) Drain brake fluid. Refer to "Brake Fluid Replacement" (Page 4A-7).
- 3) Disconnect the front brake light switch coupler (2).
- 4) Place a clean rag underneath the brake hose union bolt (3) on the master cylinder to catch any spilt brake fluid.

NOTICE

Spilled brake fluid can damage painted surfaces and plastic parts. Be careful not to spill any fluid when filling the brake fluid reservoir. Wipe spilled fluid up immediately.

- 5) Remove the brake hose union bolt (3) and disconnect the brake hose.
- 6) Remove the master cylinder holder bolts (4).



IC11J1410018-01


Installation

Install the front brake master cylinder in the reverse order of removal. Pay attention to the following points:


- When installing the master cylinder (1) onto the handlebars (2), align the master cylinder holder's mating surface "A" with the punch mark "B" on the handlebars (2) and tighten the upper holder bolt first.

Tightening torque

Master cylinder holder bolt (Upper and Lower) (a): 10 N·m (1.0 kgf·m, 7.0 lbf·ft)



IC11J1410019-01




IG44H1410037-01

"C": Up mark	"a": Clearance
--------------	----------------

- Install the new seal washers.
- After setting the brake hose union to the stopper, tighten the union bolt to the specified torque.

Tightening torque

Brake hose union bolt (b): 23 N·m (2.3 kgf·m, 16.5 lbf·ft)



IC11J1410020-01


- Bleed air from the brake system. Refer to "Air Bleeding from Brake Fluid Circuit" (Page 4A-5).

Front Brake Master Cylinder / Brake Lever Disassembly and Assembly

BENC11J14106012


Disassembly

- 1) Remove the reservoir cap (1), plate (2) and diaphragm (3).



I944H1410022-01


- 2) Remove the brake lever (4) and brake light switch (5).




I944H1410023-01

- 3) Pull out the dust boot (6) and remove the snap ring (7).

Special tool

 : 09900-06108 (Snap ring pliers)



I944H1410024-01

- 4) Remove the following parts from the master cylinder.

- Piston (8)
- Secondary cup (9)
- Primary cup (10)
- Spring (11)



I649G1410023-02

Assembly

Assemble the master cylinder in the reverse order of disassembly. Pay attention to the following points:

NOTICE

- Wash the master cylinder components with new brake fluid before reassembly.
- Do not wipe the brake fluid off after washing the components.
- When washing the components, use the specified brake fluid. Never use different types of fluid or cleaning solvents such as gasoline, kerosine, etc.
- Apply brake fluid to the master cylinder bore and all of the master cylinder component to be inserted into the bore.

BF: Brake fluid (DOT 4)




I649G1410024-02


When installing the brake light switch, align the projection on the switch with the hole in the master cylinder.



I944H1410025-01

Apply grease to the brake lever pivot bolt.
Apply grease to the contact point between piston and brake lever.

 **Grease 99000-25100 (SUZUKI Silicone Grease or equivalent)**




IC11J1410028-01

Tighten the pivot bolt (1) and lock-nut (2) to the specified torque.

Tightening torque

Brake lever pivot bolt (a): 6 N·m (0.6 kgf-m, 4.3 lbf-ft)

Brake lever pivot bolt lock-nut (b): 6 N·m (0.6 kgf-m, 4.3 lbf-ft)




IC11J1410029-01

Front Brake Master Cylinder Parts Inspection

BENC11J14106013

Master Cylinder

Inspect the master cylinder bore for any scratches or other damage.




I649G1410027-02

Piston

Inspect the piston surface for any scratches or other damage.

Rubber Parts


Inspect the primary cup, secondary cup and dust boot for wear or damage.



I944H1410028-01

Rear Brake Master Cylinder Components

BENC11J141060



IC11J1410025-01


1. Reservoir tank	5. Brake hose connector	9. Rear brake master cylinder mounting bolt	: Apply silicone grease.
2. Diaphragm	6. Piston/Cup set	: 23 N·m (2.3 kgf-m, 16.5 lbf-ft)	: Apply brake fluid.
3. Brake hose union bolt	7. Push rod	: 18 N·m (1.8 kgf-m, 13.0 lbf-ft)	: Do not reuse.
4. Master cylinder	8. Rear brake master cylinder rod lock-nut	: 10 N·m (1.0 kgf-m, 7.0 lbf-ft)	

Rear Brake Master Cylinder Assembly Removal and Installation

BENC11J14106015

Removal

- 1) Remove the right frame side cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Drain brake fluid. Refer to "Brake Fluid Replacement" (Page 4A-7).
- 3) Remove the reservoir mounting bolt (1).




IC11J1410021-01

- 4) Place a clean rag underneath the brake hose union bolt (2) on the master cylinder to catch any spilt brake fluid.

NOTICE

Spilled brake fluid can damage painted surfaces and plastic parts. Be careful not to spill any fluid when filling the brake fluid reservoir. Wipe spilled fluid up immediately.

- 5) Remove the brake hose union bolt (2) and disconnect the brake hose.
- 6) Loosen the lock-nut (3).
- 7) Remove the master cylinder mounting bolts (4).
- 8) Remove the master cylinder along with the reservoir by turning the push rod (5).



IC11J1410022-02

Installation

Install the rear brake master cylinder in the reverse order of removal. Pay attention to the following points:

- Install the new seal washers.

- Tighten the master cylinder mounting bolts (1) to the specified torque.

Tightening torque

Rear brake master cylinder mounting bolt (a): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)

- Tighten the lock-nut (2) to the specified torque.


Tightening torque

Rear brake master cylinder rod lock-nut (b): 18 N·m (1.8 kgf-m, 13.0 lbf-ft)

- After setting the brake hose union to the stopper, tighten the union bolt (3) to the specified torque.

Tightening torque

Brake hose union bolt (c): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



IC11J1410023-01

- Bleed air from the system after reassembling the master cylinder. Refer to "Brake System Inspection" in Section 0B (Page 0B-17).
- Adjust the brake pedal height. Refer to "Brake System Inspection" in Section 0B (Page 0B-17).

Rear Brake Master Cylinder Disassembly and Assembly


BENC11J14106016

Disassembly


- 1) Disconnect the reservoir hose (1).



- 2) Remove the lock-nut (2).
- 3) Remove the snap ring (3).





- 4) Remove the brake hose connector (4) and O-ring (5).




- 5) Pull out the dust boot (6) and remove the snap ring (7).

Special tool

 : 09900-06108 (Snap ring pliers)



- 6) Remove the push rod (8), piston/cup set (9) and spring (10).



Assembly

Assemble the master cylinder in the reverse order of disassembly. Pay attention to the following points:

NOTICE


- Wash the master cylinder components with new brake fluid before reassembly.
- Do not wipe the brake fluid off after washing the components.
- When washing the components, use the specified brake fluid. Never use different types of fluid or cleaning solvents such as gasoline, kerosine, etc.
- Apply brake fluid to the master cylinder bore and all of the master cylinder component to be inserted into the bore.


BF: Brake fluid (DOT 4)



I649G1410036-02

- Apply grease to the push rod end.

 Grease 99000-25100 (SUZUKI Silicone Grease or equivalent)



I944H1410034-01

- Install the new O-ring (1).



I837H1410049-01

Rear Brake Master Cylinder Parts Inspection

BENC11J14106017

Master Cylinder

Inspect the master cylinder bore for any scratches or other damage.




I649G1410038-02

Piston

Inspect the piston surface for any scratches or other damage.

Rubber Parts

Inspect the primary cup, secondary cup and dust boot for wear or damage.



I837H1410050-01

Front Brake Hose Removal and Installation

BENC11J14106018

NOTICE

- This brake system is filled with an ethylene glycol-based DOT 4 brake fluid. Do not mix different types of fluid such as silicone-based or petroleum-based.
- Do not use any brake fluid taken from old, used or unsealed containers. Never reuse brake fluid left over from the last servicing or stored for long periods.
- Handle brake fluid with care: the fluid reacts chemically with paint, plastics, rubber materials etc., and will damage them severely.

Removal

- 1) Remove the front brake hoses as shown in the front brake hose routing diagram. Refer to "Front Brake Hose Routing Diagram" (Page 4A-1).

Installation

▲ CAUTION

The seal washers should be replaced with the new ones to prevent fluid leakage.

- 1) Install the front brake hoses as shown in the front brake hose routing diagram and front wheel speed sensor routing diagram. Refer to "Front Brake Hose Routing Diagram" (Page 4A-1) and "Front Wheel Speed Sensor Routing Diagram" in Section 4E (Page 4E-8).
- 2) Bleed air from the front brake system. Refer to "Air Bleeding from Brake Fluid Circuit" (Page 4A-5).
- 3) Reinstall the removed parts.

Rear Brake Hose Removal and Installation

BENC11J14106018

NOTICE

- This brake system is filled with an ethylene glycol-based DOT 4 brake fluid. Do not mix different types of fluid such as silicone-based or petroleum-based.
- Do not use any brake fluid taken from old, used or unsealed containers. Never reuse brake fluid left over from the last servicing or stored for long periods.
- Handle brake fluid with care: the fluid reacts chemically with paint, plastics, rubber materials etc., and will damage them severely.

Removal

- 1) Remove the battery holder right ABS unit/HU cover. Refer to "ABS Control Unit / HU Cover Construction" in Section 4E (Page 4E-51).
- 2) Drain brake fluid. Refer to "Brake Fluid Replacement" (Page 4A-7).
- 3) Remove the rear brake hoses as shown in the rear brake hose routing diagram. Refer to "Rear Brake Hose Routing Diagram" (Page 4A-3).

Installation

- 1) Install the rear brake hoses as shown in the rear brake hose routing diagram and rear wheel speed sensor routing diagram. Refer to "Rear Brake Hose Routing Diagram" (Page 4A-3) and "Rear Wheel Speed Sensor Routing Diagram" in Section 4E (Page 4E-9).
- 2) Bleed air from the rear brake system. Refer to "Air Bleeding from Brake Fluid Circuit" (Page 4A-5).
- 3) Reinstall the removed parts.

Specifications

Service Data

BENC11J14107001

Brake

Unit: mm (in)

Item	Standard		Limit
Rear brake pedal height	23 – 33 (0.9 – 1.3)		—
Master cylinder bore	Front	Approx. 14.0 (0.55)	—
	Rear		—
Master cylinder piston diam.	Front	Approx. 14.0 (0.55)	—
	Rear		—

Oil

Item	Specification	Note
Brake fluid type	DOT 4	

Tightening Torque Specifications

BENC11J14107002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Air bleeder valve (Front brake)	7.5	0.75	5.5	☞(Page 4A-6) / ☞(Page 4A-7)
Air bleeder valve (Rear brake)	6	0.6	4.3	☞(Page 4A-6) / ☞(Page 4A-8)
Master cylinder holder bolt (Upper and Lower)	10	1.0	7.0	☞(Page 4A-10)
Brake hose union bolt	23	2.3	16.5	☞(Page 4A-10) / ☞(Page 4A-14)
Brake lever pivot bolt	6	0.6	4.3	☞(Page 4A-12)
Brake lever pivot bolt lock-nut	6	0.6	4.3	☞(Page 4A-12)
Rear brake master cylinder mounting bolt	10	1.0	7.0	☞(Page 4A-14)
Rear brake master cylinder rod lock-nut	18	1.8	13.0	☞(Page 4A-14)

NOTE

The tightening torque(s) also specified in:

“Front Brake Hose Routing Diagram” (Page 4A-1)

“Rear Brake Hose Routing Diagram” (Page 4A-3)

“Front Brake Master Cylinder Components” (Page 4A-9)

“Rear Brake Master Cylinder Components” (Page 4A-13)

Reference:

For the tightening torques of fasteners not specified in this section, refer to “Tightening Torque List” in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J14108001

Material	SUZUKI recommended product or Specification	Note
Brake fluid	DOT 4	☞(Page 4A-7) / ☞(Page 4A-8) / ☞(Page 4A-11) / ☞(Page 4A-16)
Grease	SUZUKI Silicone Grease or equivalent	P/No.: 99000-25100 ☞(Page 4A-12) / ☞(Page 4A-16)

NOTE



Required service material(s) also described in:

“Front Brake Master Cylinder Components” (Page 4A-9)

“Rear Brake Master Cylinder Components” (Page 4A-13)

Special Tool

BENC11J14108002


09900-06108 Snap ring pliers (Close type) ☞(Page 4A-11) / ☞(Page 4A-15)		09900-25008 Multi circuit tester set ☞(Page 4A-4) / ☞(Page 4A-5)	
--	---	---	---

Front Brakes

Repair Instructions

Front Brake Components

BENC11J14206001



IC11J1420010-01

1. Caliper holder	8. Pad mounting pin	: 23 N·m (2.3 kgf-m, 16.5 lbf-ft)
2. Front brake caliper mounting bolt	9. Air bleeder bolt	: Apply silicone grease to sliding surface.
3. Rubber boots	10. Pad set	: Apply thread lock to thread part.
4. Piston	11. Brake disc bolt	: Apply brake fluid.
5. Piston seal	12. Front brake disc	: Do not reuse.
6. Dust seal	: 39 N·m (3.9 kgf-m, 28.0 lbf-ft)	
7. Caliper	: 7.5 N·m (0.75 kgf-m, 5.5 lbf-ft)	


Front Brake Pad Inspection

BENC11J14206002

The extent of brake pads wear can be checked by observing the grooved limit line "A" on the pads. When the wear exceeds the grooved limit line, replace the pads with new ones. Refer to "Front Brake Pad Replacement" (Page 4B-2).

NOTE

Replace the brake pad as a set, otherwise braking performance will be adversely affected.



IC11J1420001-01


Front Brake Pad Replacement

BENC11J14206003

- 1) Remove the caliper (1) by removing its bolts (2).


NOTICE

Do not operate the brake lever while dismantling the pads.



IC11J1420002-02

- 2) Remove the clip (3).
- 3) Remove the brake pads (4) by removing the pad mounting pin (5).




I944H1420002-01

- 4) Clean up the caliper especially around the caliper pistons.
- 5) Install the outer pad with the detentes "A" of pad fitted to the detentes "B" on the caliper holder.


NOTE

Replace the brake pads as a set, otherwise braking performance will be adversely affected.



I944H1420003-01


- 6) Install the inner pad by aligning the projection "C" of the inner pad with plate "D" of the pad spring.



IC11J1420003-01

7) Install the pad mounting pin (6).

8) Install the clip (7) securely.




IC11J1420004-01

9) Remount the caliper.

10) Tighten the caliper mounting bolts (8) to the specified torque.

Tightening torque

Front brake caliper mounting bolt (a): 39 N·m (3.9 kgf-m, 28.0 lbf-ft)



IC11J1420005-01

NOTE

After replacing the brake pads, pump the brake lever several times to check for proper brake operation and then check the brake fluid level.

Front Brake Caliper Removal and Installation

BENC11J14206004


Removal

- 1) Drain brake fluid. Refer to "Brake Fluid Replacement" in Section 4A (Page 4A-7).
- 2) Remove the brake hoses from the caliper by removing the union bolt (1) and catch the brake fluid in a suitable receptacle.

NOTE

Place a clean rag underneath the union bolt on the brake caliper to catch any spilt brake fluid.

3) Remove the brake caliper by removing the caliper mounting bolts (2).



IC11J1420006-01

Installation

Install the brake caliper in the reverse order of removal. Pay attention to the following points:

- Tighten each bolt to the specified torque.


Tightening torque

Front brake caliper mounting bolt (a): 39 N·m (3.9 kgf-m, 28.0 lbf-ft)

- Install the new seal washers.
- After setting the brake hose union to the stopper, tighten the union bolt to the specified torque.

Tightening torque

Front brake hose union bolt (b): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



IC11J1420007-01

- Bleed air from the brake system after installing the caliper. Refer to "Brake System Inspection" in Section 0B (Page 0B-17).
- Check the brake fluid leakage and brake operation.

▲ WARNING

Brake fluid, if it leaks, will interfere with safe running and discolor painted surfaces. Check the brake hose and hose joints for cracks and fluid leakage.

Front Brake Caliper Disassembly and Assembly

BENC11J14206005

NOTE

The right and left calipers are installed symmetrically and therefore the disassembly procedure for one side is the same as that for the other side.


Disassembly

- 1) Remove the brake pads. Refer to "Front Brake Pad Replacement" (Page 4B-2).
- 2) Remove the caliper holder (1).




1944H1420010-01

- 3) Remove the rubber boots (2) and (3).
- 4) Remove the pad spring (4).



1944H1420011-01

- 5) Remove the pad guide (5).



1944H1420012-01

- 6) Place a clean rag over the pistons to prevent it from popping out and then force out the pistons using compressed air.

▲ WARNING

Fingers can get caught between piston and caliper body when removing the piston. Do not place your fingers on the piston when removing the piston.


NOTICE

Do not use high pressure air to prevent piston damage.



1944H1420013-01

- 7) Remove the dust seals (6) and piston seals (7).



1944H1420014-01

Assembly
 Assemble the caliper in the reverse order of disassembly. Pay attention to the following points:

Wash the caliper bores and pistons with specified brake fluid. Particularly wash the dust seal grooves and piston seal grooves.

BF: Brake fluid (DOT 4)

▲ CAUTION

- Wash the caliper components with fresh brake fluid before reassembly. Never use cleaning solvent or gasoline to wash them.
- Do not wipe the brake fluid off after washing the components.
- When washing the components, use the specified brake fluid. Never use different types of fluid or cleaning solvent such as gasoline, kerosine or the others.




1649G1420012-02

Apply the brake fluid to the new piston seals (1) and dust seals (2).


BF: Brake fluid (DOT 4)

Install the piston seals as shown.




1649G1420013-02

- Install the pad guide (3) and pad spring (4).



1944H1420015-01


- Install the rubber boots (5) and (6).



1944H1420016-01


- Apply grease to the caliper holder sliding pins.

⚠ : Grease 99000-25100 (SUZUKI SILICONE GREASE or equivalent)



1944H1420017-01

- Set the boots onto the sliding pins securely.



1944H1420018-01


4B-6 Front Brakes:

Front Brake Caliper Parts Inspection

BENC11J14206006

Brake Caliper Cylinder


Inspect the brake caliper cylinder wall for nicks, scratches or other damage. If any damage is found, replace the caliper with a new one.



I944H1420019-01

Brake Caliper Piston


Inspect the brake caliper piston surface for any scratches or other damage. If any damage is found, replace the piston with a new one.



I944H1420020-01

Brake Caliper Holder Sliding Pin


Inspect the brake caliper holder sliding pins for wear and other damage. If any damage is found, replace the brake caliper holder with a new one.



I944H1420021-01

Brake Pad Spring and Pad Guide


Inspect the brake pad spring and pad guide for damage and excessive bend. If any defects are found, replace them with new ones.



I944H1420022-01

Rubber Boot

Inspect the rubber boots for damage. If any defects are found, replace them with the new ones.




I944H1420023-01

Front Brake Disc Removal and Installation

BENC11J14206007

Removal

- 1) Remove the front wheel assembly. Refer to "Front Wheel Assembly Removal and Installation" in Section 2D (Page 2D-4).
- 2) Remove the front brake disc (1) by removing its bolts (2).




IC11J1420008-01

Installation


Install the front brake disc in the reverse order of removal. Pay attention to the following points:

- Make sure that the brake discs are clean and free of any grease.
- Apply thread lock to the brake disc bolts and tighten them to the specified torque.

 : Thread lock cement 99000-32130 (Thread Lock Cement Super 1360 or equivalent)

Tightening torque

Brake disc bolt (a): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



IC11J1420009-01

Front Brake Disc Inspection


BENC11J14206008

Brake Disc Thickness

Check the brake disc for damage or cracks and measure the thickness using the micrometer.


Replace the brake disc if the thickness is less than the service limit or if defect is found.

Special tool

 (A): 09900-20205 (Micrometer (0 – 25 mm))

Brake disc thickness

Service limit (Front): 4.5 mm (0.18 in)





I649G1420019-03

Brake Disc Runout

- 1) Remove the front brake caliper. Refer to "Front Brake Caliper Removal and Installation" (Page 4B-3).
- 2) Measure the runout using the dial gauge. Replace the disc if the runout exceeds the service limit.


Special tool

 (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

 : 09900-20701 (Magnetic stand)

Brake disc runout

Service limit: 0.30 mm (0.012 in)



I649G1420020-03

- 3) Install the front brake caliper. Refer to "Front Brake Caliper Removal and Installation" (Page 4B-3).

Specifications

Service Data

BENC11J14207001

Brake

Unit: mm (in)

Item	Standard		Limit
Brake disc thickness	Front	4.8 – 5.2 (0.19 – 0.20)	4.5 (0.18)
Brake disc runout		—	0.30 (0.012)
Brake caliper cylinder bore	Front	Approx. 27.0 (1.06)	—
Brake caliper piston diam.	Front	Approx. 27.0 (1.06)	—

Oil

Item	Specification	Note
Brake fluid type	DOT 4	

Tightening Torque Specifications

BENC11J14207002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Front brake caliper mounting bolt	39	3.9	28.0	☞ (Page 4B-3) / ☞ (Page 4B-3)
Front brake hose union bolt	23	2.3	16.5	☞ (Page 4B-3)
Brake disc bolt	23	2.3	16.5	☞ (Page 4B-7)

NOTE

The tightening torque(s) also specified in:
 "Front Brake Components" (Page 4B-1)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J14208001




Material	SUZUKI recommended product or Specification		Note
Brake fluid	DOT 4	—	☞ (Page 4B-5) / ☞ (Page 4B-5)
Grease	SUZUKI SILICONE GREASE or equivalent	P/No.: 99000-25100	☞ (Page 4B-5)
Thread lock cement	Thread Lock Cement Super 1360 or equivalent	P/No.: 99000-32130	☞ (Page 4B-7)

NOTE

Required service material(s) also described in:
 "Front Brake Components" (Page 4B-1)

Special Tool

BENC11J14208002


09900-20205 Micrometer (0 – 25 mm) ☞ (Page 4B-7) 	09900-20607 Dial gauge ☞ (Page 4B-7) 
09900-20701 Dial gauge chuck ☞ (Page 4B-7) 	

Rear Brakes

Repair Instructions

Rear Brake Components

BENC11J14306001



IC11J1430015-01

1. Rear caliper bracket	6. Rear brake disc	(a) : 23 N·m (2.3 kgf-m, 16.5 lbf-ft)
2. Piston	(b) : 6 N·m (0.6 kgf-m, 4.3 lbf-ft)	SH : Apply silicone grease to sliding surface.
3. Piston seal	(c) : 27 N·m (2.7 kgf-m, 19.5 lbf-ft)	BR : Apply thread lock to thread part.
4. Dust seal	(d) : 17 N·m (1.7 kgf-m, 12.5 lbf-ft)	BR : Apply brake fluid.
5. Rear brake pad set	(e) : 2.5 N·m (0.25 kgf-m, 1.8 lbf-ft)	X : Do not reuse.


Rear Brake Pad Inspection

BENC11J14306002

The extent of brake pads wear can be checked by observing the grooved limit line "A" on the pads. When the wear exceeds the grooved limit line, replace the pads with new ones. Refer to "Rear Brake Pad Replacement" (Page 4C-2).

NOTE

Replace the brake pad as a set, otherwise braking performance will be adversely affected.



IC11J1430001-01

Rear Brake Pad Replacement

BENC11J14306003

- 1) Remove the plug (1).




IC11J1430002-02

- 2) Remove the pad mounting pin (2).
- 3) Remove the caliper mounting bolt (3).

▲ CAUTION

Do not operate the brake pedal while dismantling the pads.




IC11J1430003-02

- 4) Remove the brake pads with the rear caliper pivoted up.

NOTE

When removing the pads, push the piston all the way into brake caliper.




IC11J1430004-02

- 5) Clean up the caliper especially around the caliper piston.
- 6) Install the new brake pads.

NOTE

- Replace the brake pads as a set, otherwise braking performance will be adversely affected.
- Make sure that the detente of the pad is seated onto the retainer on the caliper bracket.



IC11J1430005-02

4C-3 Rear Brakes:

- 7) Tighten the caliper mounting bolt (4) and pad mounting pin (5) to the specified torque.

Tightening torque

Rear brake caliper mounting bolt (a): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)

Rear brake pad mounting pin (b): 17 N·m (1.7 kgf-m, 12.5 lbf-ft)



IC11J1430006-02

- 8) Install the plug (6) to the specified torque.

Tightening torque

Pad pin plug (c): 2.5 N·m (0.25 kgf-m, 1.8 lbf-ft)

NOTE

After replacing the brake pads, pump the brake pedal few times to check for proper brake operation and then check the brake fluid level.



IC11J1430007-02

Rear Brake Caliper Removal and Installation

BENC11J14306004

Removal

- 1) Drain brake fluid. Refer to "Brake Fluid Replacement" in Section 4A (Page 4A-7).
- 2) Remove the brake hose from the caliper by removing the union bolt (1) and catch the brake fluid in a suitable receptacle.


NOTE

- Place a clean rag underneath the union bolt on the brake caliper to catch any spilt brake fluid.
- Slightly loosen the sliding pin (2) to facilitate later disassembly, if necessary.



IC11J1430008-02

- 3) Remove the brake pads. Refer to "Rear Brake Pad Replacement" (Page 4C-2).
- 4) Pivot the caliper up and remove the caliper from the caliper bracket.



IC11J1430009-02

Installation


Install the brake caliper in the reverse order of removal.

Pay attention to the following points:

- Install the caliper to the caliper bracket (1).
- Set the boot onto the sliding pin securely.
- Install the brake pads. Refer to "Rear Brake Pad Replacement" (Page 4C-2).

▲ CAUTION

Confirm that there is a brake pad spring (2) when installing the brake pads.



IC11J1430010-02

- Tighten the sliding pin (3) to the specified torque.


Tightening torque

Rear brake caliper sliding pin (a): 27 N·m (2.7 kgf-m, 19.5 lbf-ft)

- Install the new seal washers.
- After setting the brake hose union to the stopper, tighten the union bolt (4) to the specified torque.

Tightening torque

Brake hose union bolt (b): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



IC11J1430011-02

- Bleed air from the brake system after installing the caliper. Refer to "Brake System Inspection" in Section 0B (Page 0B-17).
- Check the brake fluid leakage and brake operation.

▲ WARNING


Brake fluid, if it leaks, will interfere with safe running and discolor painted surfaces. Check the brake hose and hose joints for cracks and fluid leakage.

Rear Brake Caliper Disassembly and Assembly

BENC11J14306005

Disassembly

- 1) Remove the pad spring (1) and rubber boot (2).



IC11J1430012-01


- 2) Remove the pad spring (3).



IC11J1430016-01

- 3) Remove the spacer (4) and rubber boot (5) from the caliper.

- 4) Remove the slide pin (6).



IC11J1430017-01

4C-5 Rear Brakes:

- 5) Place a clean rag over the piston to prevent it from popping out and then force out the piston using compressed air.


▲ CAUTION

Do not use high pressure air to prevent piston damage.



1944H1430016-01

- 6) Remove the dust seal (7) and piston seal (8).



1944H1430017-01

Assembly

Assemble the caliper in the reverse order of disassembly. Pay attention to the following points:

- Wash the caliper bore and piston with specified brake fluid. Particularly wash the dust seal groove and piston seal groove.

BF: Brake fluid (DOT 4)

▲ CAUTION

- Wash the caliper components with fresh brake fluid before reassembly. Never use cleaning solvent or gasoline to wash them.
- Do not wipe the brake fluid off after washing the components.
- When washing the components, use the specified brake fluid. Never use different types of fluid or cleaning solvent such as gasoline, kerosine or the others.




1649G1430015-02

- Apply the brake fluid to the new piston seal (1) and dust seal (2).

BF: Brake fluid (DOT 4)

- Install the piston seals as shown.




1649G1420013-02

- Apply grease to the inside of the boot.

Ⓐ: Grease 99000-25100 (SUZUKI Silicone Grease or equivalent)

- Temporarily tighten the sliding pin (3) and apply grease to the sliding pin.

Ⓐ: Grease 99000-25100 (SUZUKI Silicone Grease or equivalent)




1C11J1430016-01

Rear Brake Caliper Parts Inspection

BENC11J14306006

Brake Caliper Cylinder


Inspect the brake caliper cylinder wall for nicks, scratches or other damage. If any damage is found, replace the caliper with a new one.



I944H1430019-01

Brake Caliper Piston

Inspect the brake caliper piston surface for any scratches or other damage. If any damage is found, replace the piston with a new one.



I944H1430020-01

Brake Caliper Sliding Pin


Inspect the brake caliper sliding pin for wear and other damage. If any damage is found, replace the sliding pin with a new one.



IC11J1430019-01

Boot and Spacer


Inspect the boots and spacer for damage and wear. If any defects are found, replace them with new ones.



I944H1430022-01

Brake Pad Spring

Inspect the brake pad springs for damage and excessive bend. If any defects are found, replace them with new ones.




I944H1430023-02

Rear Brake Disc Removal and Installation

BENC11J14306007

Removal

- 1) Remove the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation" in Section 2D (Page 2D-11).
- 2) Remove the rear brake disc (1) by removing its bolts (2).




IC11J1430013-01

4C-7 Rear Brakes:

Installation


Install the rear brake disc in the reverse order of removal. Pay attention to the following points:

- Make sure that the brake discs are clean and free of any grease.
- Apply thread lock to the brake disc bolts and tighten them to the specified torque.

 : Thread lock cement 99000-32130 (Thread Lock Cement Super 1360 or equivalent)

Tightening torque

Brake disc bolt (a): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



IC11J1430014-01

Rear Brake Disc Inspection


BENC11J14306008

Brake Disc Thickness

Check the brake disc for damage or cracks and measure the thickness using the micrometer.


Replace the brake disc if the thickness is less than the service limit or if defect is found.

Special tool

 (A): 09900-20205 (Micrometer (0 - 25 mm))

Brake disc thickness

Service limit (Rear): 4.5 mm (0.18 in)



I649G1430027-03

Brake Disc Runout

- 1) Remove the rear brake caliper. Refer to "Rear Brake Caliper Removal and Installation" (Page 4C-3).
- 2) Measure the runout using the dial gauge. Replace the brake disc if the runout exceeds the service limit.


Special tool

 (A): 09900-20607 (Dial gauge (1/100 mm, 10 mm))

 : 09900-20701 (Magnetic stand)

Brake disc runout

Service limit: 0.30 mm (0.012 in)



I649G1430025-03

- 3) Install the rear brake caliper. Refer to "Rear Brake Caliper Removal and Installation" (Page 4C-3).

Specifications

Service Data

BENC11J14307001

Brake

Unit: mm (in)

Item		Standard	Limit
Brake disc thickness	Rear	4.8 – 5.2 (0.19 – 0.20)	4.5 (0.18)
Brake disc runout		—	0.30 (0.012)
Brake caliper cylinder bore	Rear	Approx. 38.2 (1.50)	—
Brake caliper piston diam.	Rear	Approx. 38.2 (1.50)	—

Oil

Item	Specification	Note
Brake fluid type	DOT 4	

Tightening Torque Specifications

BENC11J14307002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Rear brake caliper mounting bolt	23	2.3	16.5	☞(Page 4C-3)
Rear brake pad mounting pin	17	1.7	12.5	☞(Page 4C-3)
Pad pin plug	2.5	0.25	1.8	☞(Page 4C-3)
Rear brake caliper sliding pin	27	2.7	19.5	☞(Page 4C-4)
Brake hose union bolt	23	2.3	16.5	☞(Page 4C-4)
Brake disc bolt	23	2.3	16.5	☞(Page 4C-7)

NOTE

The tightening torque(s) also specified in:
 "Rear Brake Components" (Page 4C-1)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J14308001




Material	SUZUKI recommended product or Specification		Note
Brake fluid	DOT 4	—	☞ (Page 4C-5) / ☞ (Page 4C-5)
Grease	SUZUKI Silicone Grease or equivalent	P/No.: 99000-25100	☞ (Page 4C-5) / ☞ (Page 4C-5)
Thread lock cement	Thread Lock Cement Super 1360 or equivalent	P/No.: 99000-32130	☞ (Page 4C-7)

NOTE

Required service material(s) also described in:
 “Rear Brake Components” (Page 4C-1)

Special Tool

BENC11J14308001

09900-20205 Micrometer (0 – 25 mm) ☞ (Page 4C-7) 	09900-20607 Dial gauge ☞ (Page 4C-7) 
09900-20701 Dial gauge chuck ☞ (Page 4C-7) 	

ABS

Precautions

Precautions for ABS

BENC11J14500001

Refer to "Precautions for Electrical Circuit Service" in Section 00 (Page 00-2) and "Precautions for ABS" in Section 00 (Page 00-7).

ABS Information

BENC11J14500002

▲ WARNING

- Be sure to bleed air from the brake fluid circuit when the brake is felt spongy or when a brake relating part is replaced.
- Never ride the motorcycle before bleeding the air.

- Be sure to route the brake hoses correctly.
- The ABS does not shorten the motorcycle's braking distance. When riding down slopes or on wet or bumpy roads the braking distance is lengthened as compared to a motorcycle without ABS. In addition, braking distance increases more, when the road is slippery.
- The ABS does not control slides which may occur when braking while turning. As with a motorcycle that does not have ABS, it is best not apply the brakes while turning.
- The brake lever and pedal may move by themselves when they are applied. This is not a malfunction.
- Only use the specified tires.


General Description

Wheel Speed Sensor Description

BENC11J14501001


Wheel speed sensor consists of wheel speed sensor (1) and sensor rotor (2).

Front



IC11J1450074-01

Rear




IC11J1450075-01

ABS Control Unit Description

BENC11J14501002

ABS control unit (1) calculates signals input from each one of front and rear wheel speed sensors, monitors the slipping conditions of the wheels and, at the same time, sends control signal to Hydraulic Unit (HU) (2).


This ABS control unit/HU can not be disassembled.



IC11J1450071-02

ABS Control Unit Calculating Process


The ABS controls and its calculations, in addition to the self-diagnosing and the fail-safe processes, occur during the ABS control unit calculating process. In addition, if a malfunction is detected by the self-diagnosis function, the brake stops being controlled by the ABS and a diagnostic trouble code is stored.



Hydraulic Unit (HU) Description

BENC11J14501003

The hydraulic unit operates the solenoid valves based upon the signal which is output from the ABS control unit. The hydraulic pressure is then adjusted accordingly. The hydraulic unit controls the front and rear brake systems individually by operating separate components for the front and the rear, except for the pump drive motor, which is shared by both systems.



Self-diagnosis Function and ABS Indicator Light Description


BENC11J14501004

The ABS control unit performs the self-diagnosis and can store any electronically detected malfunctions as diagnostic trouble codes. If a malfunction has occurred, the indicator light lights up to inform the rider of the malfunction. The special tool, when connected to the mode select coupler, enables the ABS indicator light to display the diagnostic trouble codes.

ABS Indicator Light

The ABS indicator light (1) informs the rider of any ABS malfunctions. If a malfunction occurred, the ABS indicator light flashes, during the self-diagnosis, to indicate the diagnostic trouble code so that the correct part can be repaired.

- When the ignition switch is turned to ON, the ABS indicator light (1) lights up even if no malfunction has occurred, to indicate that the LED is not burnt out. It will go off after the motorcycle is ridden at more than 5 km/h (3.1 mile/h).
- If an ABS malfunction has occurred, the ABS indicator light (1) keeps lighting up.



IC11J1450001-03

NOTE

When a malfunction has occurred in the ABS, connect the special tool to the mode select coupler to display the diagnostic trouble code on the ABS indicator light. Refer to "DTC (Diagnostic Trouble Code) Output" (Page 4E-18).

Special tool

 (A): 09930-82710 (Mode select switch)




IC11J1450002-02

ABS Operation and ABS Indicator Light

The ABS indicator light (1) shows the ABS operating condition. During normal operation, the ABS indicator light lights up when the ignition switch is turned to ON and goes off after the motorcycle is ridden at more than 5 km/h (3.1 mile/h). If a malfunction has occurred, the ABS indicator light (1) keeps lighting up.

The ABS indicator light goes off when the motorcycle is ridden at more than 5 km/h (3.1 mile/h).	The ABS is normally activated.
The ABS indicator light keeps lighting up even though the motorcycle is ridden at more than 5 km/h (3.1 mile/h).	One or more malfunction has been found and ABS activation been hanged up.
The ABS indicator light does not light up when turning the ignition switch ON.	Check the wire harness and combination meter. Refer to "ABS Indicator Light Inspection" (Page 4E-15).




IC11J1450001-03

Schematic and Routing Diagram

ABS Wiring Diagram

Refer to "Country and Area Codes" in Section 0A (Page 0A-7).

BENC11J1450200






IC11J1450004-03

ABS Control Unit / HU Diagram

BENC11J14502002

Refer to "Country and Area Codes" in Section 0A (Page 0A-7).




IC11J1450003-03

"A": Rear brake solenoid OUT	"B": Rear brake solenoid IN	"C": Front brake solenoid OUT	"D": Front brake solenoid IN
------------------------------	-----------------------------	-------------------------------	------------------------------

Front Wheel Speed Sensor Routing Diagram

BENC11J14502003

ABS Wiring Diagram



IC11J1450073-01

1. Front wheel speed sensor	☑ "D": Cut of the excess of the clamp.
"A": Outside marking.	☑ "E": Clamp the marking of brake hose and sensor lead wire.
☑ "B": Clamp the sensor lead wire to right side of brake hose.	☑ "F": Clamp the sensor lead wire inside of the brake hose.
☑ "C": Clamp the sensor lead wire behind the brake hose.	☑ "G": Pass the sensor lead wire to inside of the boss of front fork.


Rear Wheel Speed Sensor Routing Diagram

BENC11J14502004

ABS Troubleshooting

Many of the ABS malfunctions are performed by checking the accuracy of wheel speed sensor assembly. The proper beginning any repair, the Service Manual. The ABS is equipped with a self-diagnostic system which will detect malfunctions in the ABS system.

Diagnostic trouble codes will be stored in the ABS control module.








IC11J1450072-02

<ul style="list-style-type: none"> 1. Rear wheel speed sensor lead wire : Pass the rear wheel speed sensor lead wire to inside of the guide. 	<ul style="list-style-type: none"> "B": Clamp the brake hose at white marking position. Clamp the sensor lead wire outside of brake hose.
<ul style="list-style-type: none"> 2. Rear wheel speed sensor 	<ul style="list-style-type: none"> "C": Clamp the sensor lead wire outside of brake pipe.
<ul style="list-style-type: none"> "A": Outside mark 	<ul style="list-style-type: none"> "D": Cut of the excess of the clamp.

Component Location

ABS Components Location

BENC11J14



IC11J14

1. ABS control unit/HU	3. Mode selection switch/SDS coupler	5. Front wheel speed sensor rotor	7. Rear wheel speed sensor rotor
2. Mode select coupler	4. Front wheel speed sensor	6. Rear wheel speed sensor	

Diagnostic Information and Procedures

ABS Troubleshooting

BENC11J14504001

Many of the ABS malfunction diagnosing operations are performed by checking the wiring continuity. Quick and accurate detection of malfunctions within the complex circuitry assures the proper operation of the ABS. Before beginning any repairs, thoroughly read and understand this Service Manual.

The ABS is equipped with a self-diagnosis function. The detected malfunction is stored as a diagnostic trouble code which causes the ABS indicator light to light up or flash in set patterns to indicate the malfunction.

Diagnostic trouble codes are stored even when the ignition switch is turned to OFF and they can only be erased manually. In order to repair the ABS correctly, ask the customer for the exact circumstances under which the malfunction occurred, then check the ABS indicator light and the output diagnostic trouble codes. Explain to the customer that depending on how the motorcycle is operated (e.g., if the front wheel is off the ground), the ABS indicator light may light up even though the ABS is operating correctly.

Troubleshooting Procedure

Troubleshooting should be proceed as follows. If the order is performed incorrectly or any part is omitted, an error in misdiagnosis may result.

- 1) Gather information from the customer.
- 2) Perform the pre-diagnosis inspection. Refer to "Pre-diagnosis Inspection" (Page 4E-13).
- 3) Inspect the ABS indicator light. Refer to "ABS Indicator Light Inspection" (Page 4E-15).
- 4) Output the DTCs stored in the ABS control unit. Refer to "DTC (Diagnostic Trouble Code) Output" (Page 4E-18).

- 5) Perform appropriate troubleshooting procedures according to the DTCs output. Refer to "DTC Table" (Page 4E-30).


If troubleshooting procedures cannot be performed, try to determine the cause of the malfunction according to the information gathered in 1) through 4) and inspect the wiring. Refer to "ABS Wiring Diagram" (Page 4E-6) and "ABS Control Unit / HU Diagram" (Page 4E-7).

▲ CAUTION

- When disconnecting couplers and turning the ignition switch ON, disconnect the ABS control unit coupler in order to prevent a DTC from being stored.
- Each time a resistance is measured, the ignition switch should be set to OFF.

- 6) Inspect the ABS components. Refer to "Wheel Speed Sensor and Sensor Rotor Inspection" (Page 4E-55).
- 7) Delete the DTCs and check the brake operation. Refer to "DTC (Diagnostic Trouble Code) Deleting" (Page 4E-22).

Basic Troubleshooting Diagram



Information Gathering

To properly diagnose a malfunction, one must not make guesses or assumptions about the circumstances that caused it. Proper diagnosis and repair require duplicating the situation in which the malfunction occurred. If a diagnosis is made without duplicating the malfunction, even an experienced service technician may make a misdiagnosis and not perform the servicing procedure correctly, resulting in the malfunction not being repaired. For example, a malfunction that occurs only while braking on slippery surfaces will not occur if the motorcycle is ridden on a non-slippery surface. Therefore, in order to properly diagnose and repair the motorcycle, the customer must be questioned about the conditions at the time that the malfunction occurred making "Information gathering" very important. In order that the information obtained from the customer to be used as a reference during troubleshooting, it is necessary to ask certain important questions concerning the malfunction. Therefore, a questionnaire has been created to improve the information-gathering procedure.

EXAMPLE: CUSTOMER PROBLEM INSPECTION FORM

User name:	Model:	VIN:	Date of issue:
Date Reg.	Date of problem:	Mileage:	

PROBLEM SYMPTOMS	
ABS operation	Past malfunctions and repairs
ABS does not work	
ABS works so often with	
Too long stopping distance	
Other	

CONDITION WHEN MALFUNCTION OCCURRED	
ABS indicator light	Riding conditions
Does not light up	While stopping
Lights up	Over 5 km/h (3.1 mile/h)
Goes off after running over 5 km/h (3.1 mile/h): Yes / No	When turning
Flashes	Others
Tires	Brake operating conditions
Abnormal air pressure	Usual braking
Less thread depth	Quick/hard braking
No specified tires installed	
	Interface
Road surface	Too big pulsations at brake lever and pedal
Paved road:	Too large brake lever and pedal strokes
Dry / Wet / Others	Others
Unpaved road:	
Gravel / Muddy / Uneven / Others	Others
	Abnormal noise from the ABS control unit/HU
	Skid noise from the calipers
	Vibration at the brake lever and pedal
NOTE:	

NOTE

This form is a standard sample. The form should be modified according to conditions and characteristic of each market.

Pre-diagnosis Inspection

BENC11J14504002

The mechanical and hydraulic components of the brake system should be inspected prior to performing any electrical checks. These inspections may find problems that the ABS could not detect; thus, shortening repair time.

Brake

Brake fluid level check

Refer to "Brake System Inspection" in Section 0B (Page 0B-17).

Brake pad inspection

Refer to "Brake System Inspection" in Section 0B (Page 0B-17).

Brake fluid circuit air bleeding

Refer to "Air Bleeding from Brake Fluid Circuit" in Section 4A (Page 4A-5).

Tire

Tire type

Tire type

Front: BRIDGESTONE: TW101 J

Rear: BRIDGESTONE: TW152 F

Tire pressure

Refer to "Tire Inspection" in Section 0B (Page 0B-19).

NOTICE

- The standard tire fitted on this motorcycle is 110/80R19M/C 59H for front and 150/70R17M/C 69H for rear. The use of tires other than those specified may cause instability. It is highly recommended to use a SUZUKI Genuine Tire.
- Replace the tire as a set, otherwise the DTC "25" (C1625) may be stored.

Wheel


Refer to "Front Wheel Related Parts Inspection" in Section 2D (Page 2D-6) and "Rear Wheel Related Parts Inspection" in Section 2D (Page 2D-12).

Battery

Battery voltage inspection

- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Measure the voltage between the (+) and (-) battery terminals using the multi circuit tester. If the voltage is less than 12.0 V, charge or replace the battery and inspect the charging system. Refer to "Battery Runs Down Quickly" in Section 1J (Page 1J-2).

Special tool


 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Voltage (---)

Battery voltage

12.0 V or more



IC11J1450006-01


- 4) Install the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).

ABS Component

Wheel speed sensor – sensor rotor clearance inspection

Inspect the clearance between the wheel speed sensor and sensor rotor for each wheel using the thickness gauge.

Special tool

 (A): 09900-20804 (Thickness gauge)


 (B): 09900-20806 (Thickness gauge)

Wheel speed sensor – Sensor rotor clearance

Front: 0.26 – 1.67 mm (0.010 – 0.066 in)


Rear: 0.26 – 1.47 mm (0.010 – 0.058 in)

Front



IC11J1240010-02


Rear



IC11J1240026-02


ABS control unit/HU ground wire inspection

- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Disconnect the battery (-) lead wire (1).



IC11J1450007-02

- 4) Disconnect the ABS control unit coupler (2). Refer to "ABS Control Unit Coupler Disconnect and Connect" (Page 4E-51).



IC11J1450008-02



- 5) Check for continuity between "9" (B/W) at the coupler and the battery (-) terminal, also "18" (B) at the coupler and the battery (-) terminal.

Special tool

- (A): 09900-25008 (Multi circuit tester set)
 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity test (•||))



- 6) Install the removed parts.

ABS Indicator Light Inspection

BENC11J14504003


Wiring Diagram

Refer to "ABS Control Unit / HU Diagram" (Page 4E-7).

Troubleshooting

Step 1

- 1) Check if the ABS indicator light (1) lights up when turning the ignition switch ON.



Does the ABS indicator light up?

- Yes Go to Step 2.
 No Go to Step 3.

Step 2

(The ABS indicator light lights up)

- 1) Ride the motorcycle at more than 5 km/h (3.1 mile/h).



Does the ABS indicator light go off?

- Yes Normal (No DTC exists)
 No
- DTC output (Refer to "DTC (Diagnostic Trouble Code) Output" (Page 4E-18).)
 - If DTC can not be output (the ABS indicator light does not flash), go to Step 6.

Step 3**(The ABS indicator light does not light up)**


- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Open the fuse box and inspect the signal fuse (1).

NOTE

If a fuse is blown, find the cause of the problem and correct it before replacing the fuse.

Signal fuse

15 A



IC11J1450012-01

Is the signal fuse OK?

- Yes Go to Step 4.
No Replace the signal fuse.

Step 4

- 1) Turn the ignition switch OFF.
- 2) Disconnect the ABS control unit coupler. Refer to "ABS Control Unit Coupler Disconnect and Connect" (Page 4E-51).

- 3) Turn the ignition switch ON with the ABS control unit coupler disconnected, measure the voltage between "11" (Br) and "9" (B/W) at the coupler.

Special tool

(A): 09900-25008 (Multi circuit tester set)


(B): 09900-25009 (Needle-point probe set)

Tester knob indication

Voltage (V)

Normal value ("11" - "9")

7.5 - 9.5 V



IC11J1450013-02

Is the voltage between "11" and "9" normal?

- Yes Go to Step 5.
No
- Inspect the wire harness. (Faulty ignition or ground wire)
 - Faulty combination meter.

Step 5

- 1) Turn the ignition switch OFF.
- 2) Check for continuity between "9" (B/W) at the coupler and body ground.


Special tool

(A): 09900-25008 (Multi circuit tester set)

(B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity (••))



IC11J1450067-02

Is the continuity between "9" and body ground?


- Yes Replace the ABS control unit/HU. Refer to "ABS Control Unit / HU Removal and Installation" (Page 4E-56).
No Inspect the wire harness. (Faulty ground wire)

Step 6**(The ABS indicator light does not go off)**

- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Open the fuse box and inspect the ignition fuse (1).

NOTE

If a fuse is blown, find the cause of the problem and correct it before replacing the fuse.

Ignition fuse**10 A**

IC11J1450014-01

Is the ignition fuse OK?

- Yes Go to Step 7.
No Replace the ignition fuse.


Step 7

- 1) Turn the ignition switch OFF and disconnect the ABS control unit coupler.

- 2) Turn the ignition switch ON with the ABS control unit coupler disconnected, measure the voltage between "6" (O/Y) terminal and "9" (B/W) terminal at the coupler.

Special tool

- (A): 09900-25008 (Multi circuit tester set)
 (B): 09900-25009 (Needle-point probe set)

Tester knob indication**Voltage (---)****Normal value ("6" – "9")****Battery voltage (12.0 V or more)**

IC11J1450068-02

Is the voltage between "6" and "9" normal?


- Yes Go to Step 8.
No Inspect the wire harness. (Faulty ignition wire or ground wire)

Step 8

- 1) Turn the ignition switch ON with the ABS control unit coupler disconnected, measure the voltage between "11" (Br) terminal and "9" (B/W) terminal at the coupler.

Special tool

- (A): 09900-25008 (Multi circuit tester set)
 (B): 09900-25009 (Needle-point probe set)

Tester knob indication**Voltage (---)****Normal value ("11" – "9")****7.5 – 9.5 V**

IC11J1450013-03

Is the voltage between "11" and "9" normal?


- Yes Go to Step 9.
No Inspect the wire harness. (Faulty indicator light wire or ground wire)

Step 9

- 1) Turn the ignition switch OFF.
- 2) Remove the left frame cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Short the mode select coupler terminals (O – B/W) using the special tool.

Special tool


 (A): 09930-82710 (Mode select switch)




IC11J1450015-02

- 4) Check for continuity between "3" (O) and "9" (B/W) at the coupler.


Special tool

 (A): 09900-25008 (Multi circuit tester set)

 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity test (•))



IC11J1450016-02

Is the continuity between "3" and "18"?

- Yes Replace the ABS control unit/HU. Refer to "ABS Control Unit / HU Removal and Installation" (Page 4E-56).
- No Inspect the wire harness. (Faulty mode select switch wire)

DTC (Diagnostic Trouble Code) Output

BENC11J14504004

NOTE

- If there is a DTC recorded, the ABS indicator light repeatedly flashes in a cyclic manner. (However, when five minutes have elapsed from the start of self-diagnosis mode, the output of the DTC will be interrupted.)
- If no DTC is recorded, the light repeats flashing for 3.6 seconds in a cyclic manner.
- In the case that the mode select switch is turned OFF or the vehicle speed (both wheels) exceeds 10 km/h (6.2 mile/h), the output of DTC will be interrupted.
- Don't disconnect couplers from ABS HU, the battery cable from the battery, ABS HU ground wire harness from the engine or main fuse before confirming the malfunction code (self-diagnostic trouble code) stored in memory. Such disconnection will erase the memorized information in ABS HU memory.
- Be sure to read "Precautions for Electrical Circuit Service" in Section 00 (Page 00-2) and "Precautions for ABS" in Section 00 (Page 00-7) before inspection and observe what is written there.
- After carrying out DTC deleting and ABS operation check, explain to the customer that the ABS is operating correctly. Refer to "DTC (Diagnostic Trouble Code) Deleting" (Page 4E-22).

Use of Mode Select Switch


Connect the special tool to the mode select coupler to output the memorized DTCs on the ABS indicator light.

- 1) Turn the ignition switch OFF.
- 2) Remove the left frame cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).

- 3) Connect the special tool to the mode select coupler (1).

Special tool

 (A): 09930-82710 (Mode select switch)



IC11J1450017-02



IC11J1450002-02

- 4) Switch the special tool to ON.




I718H1450040-02

- 5) Turn the ignition switch ON.
The ABS indicator light (2) starts flashing to indicate the DTC. Refer to "DTC Table" (Page 4E-30).

NOTE

- If there is a DTC, the ABS indicator light keeps flashing cyclically and repeatedly.
- If there is no DTC, the ABS indicator light keeps lighting on.
- If the DTCs are to be output for a long time, remove the HEAD-LO fuse in order to prevent the battery from discharging.



IC11J1450018-02

- 6) Turn the ignition switch OFF and disconnect the special tool.
7) Install the left frame cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).

NOTE


- Not only is SDS used for detecting Diagnostic Trouble Codes but also for reproducing and checking an abnormal failure condition as described by customers using the trigger.
- How to Use Trigger: (Refer to the SDS operation manual for further details.)

- 4) Close the SDS cover and turn the ignition switch OFF.
5) Install the wheel. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).

Understanding the DTC (Diagnostic Trouble Code)

A two-digit DTC is shown through the flashing pattern of the ABS indicator light. A number between 1 and 9 is represented by the number of times that the ABS indicator light lights up in interval of 0.4 seconds and the separation between the tens and ones are indicated by the light staying off for 1.6 seconds. In addition, the separation between the start code and the DTC is indicated by the light being off for 3.6 seconds. After the start code is displayed, DTCs appear from the smallest number code.

If no DTC is recorded, the light repeats flashing for 3.6 seconds in a cyclic manner.



"a": Initial minimum light ON time (About 2 seconds)	"e": Main-sub code interval (1.6 seconds)
"b": Error code interval (About 3.6 seconds)	"f": Sub code light ON time (0.4 seconds)
"c": Main code light ON time (0.4 seconds)	"g": Sub code light OFF time (0.4 seconds)
"d": Main code light OFF time (0.4 seconds)	"h": About 3.6 seconds


Use of SDS


NOTE


- Don't disconnect couplers from ABS HU, the battery cable from the battery, ABS HU ground wire harness from the engine or main fuse before confirming the malfunction code (self-diagnostic trouble code) stored in memory. Such disconnection will erase the memorized information in ABS HU memory.
- DTC stored in ABS HU memory can be checked by the SDS.
- Be sure to read "Precautions for Electrical Circuit Service" in Section 00 (Page 00-2) and "Precautions for ABS" in Section 00 (Page 00-7) before inspection and observe what is written there.

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Set up the SDS tool. (Refer to the SDS operation manual for further details.)


Special tool

 (A): 09904-41010 (SUZUKI Diagnostic system set)

 (B): 99565-01010-024 (CD-ROM Ver.24)



IC11J1110010-01



I705H1110116-03

- 3) Read the DTC (Diagnostic Trouble Code) and show data when trouble (displaying data at the time of DTC) according to instructions displayed on SDS.

NOTE

- Not only is SDS used for detecting Diagnostic Trouble Codes but also for reproducing and checking on screen the failure condition as described by customers using the trigger.
- How to use trigger. (Refer to the SDS operation manual for further details.)

- 4) Close the SDS tool and turn the ignition switch OFF.
- 5) Install the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).

DTC (Diagnostic Trouble Code) Deleting

BENC11J14504005


Use of Mode Select Switch


NOTE

- The previous malfunction history code (Past DTC) still remains stored in the ABS HU. Therefore, erase the history code memorized in the ABS HU using SDS tool. Refer to "Use of SDS" (Page 4E-23).
- The DTC is memorized in the ABS HU also when the wire coupler of any sensor is disconnected. Therefore, when a wire coupler has been disconnected at the time of diagnosis, erase the stored malfunction history code using SDS. Refer to "Use of SDS" (Page 4E-23).

- 1) Remove the left frame cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Connect the special tool to the mode select coupler (1) and output the DTCs.

Special tool

 (A): 09930-82710 (Mode select switch)



IC11J1450017-02



IC11J1450002-02

- 3) Switch the special tool to ON and turn the ignition switch ON.
- 4) While the DTCs are being output, set the special tool to OFF.

NOTE

The DTC deletion mode starts 12.5 seconds after the switch is set to OFF.



I718H1450050-01

- 5) In the DTC deletion mode, switch the ABS test switch from OFF to ON three times, each time leaving it at ON for more than 1 second.


NOTE

After deleting DTC with the mode select switch in ON position, the system resumes the self-diagnosis mode again and outputs the DTC.



I718H1450051-01

DTC Deleting Diagram



1823H3450030-01

- 6) After deleting the DTCs, repeat the code output procedure and make sure that no DTCs remain (the ABS indicator light no longer flashes).

NOTE

If any DTCs remain, perform the appropriate procedures, then delete the codes. If DTCs are left stored, confusion may occur and unnecessary repairs may be made.

- 7) Turn the ignition switch OFF and disconnect the mode select switch.
 8) Install the removed parts.
 9) Afterwards, ride the motorcycle at more than 30 km/h (18.6 mile/h) and quickly apply the brakes to check that the ABS activates correctly.



IC11J1450011-01

Use of SDS**NOTE**

- The previous malfunction history code (Past DTC) still remains stored in the ABS HU. Therefore, erase the history code memorized in the ABS HU using SDS tool.
- The DTC is memorized in the ABS HU also when the wire coupler of any sensor is disconnected. Therefore, when a wire coupler has been disconnected at the time of diagnosis, erase the stored malfunction history code using SDS.


- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) After repairing the trouble, turn OFF the ignition switch.
- 3) Turn ON the ignition switch.
- 4) Set up the SDS tool. (Refer to the SDS operation manual for further details.)

Special tool

: 09904-41010 (SUZUKI Diagnostic system set)

: 99565-01010-024 (CD-ROM Ver.24)

5) Click the ABS button (1).



6) Click the "DTC inspection" button (2).





7) Check the DTC.

8) Click "Clear" (3) to delete history code (Past DTC).

File View Tool Help	
Help	Clear (3)
Code	Description & trouble position
Current DTC - 1	
C1645	Wheel speed sensor circuit open(R)
Past DTC - 2	
C1642	Wheel speed sensor circuit open (F)
C1661	ABS solenoid malfunction

1718H1450056-01

9) Follow the displayed instructions.



10) Check that both "Current DTC" (4) and "Past DTC" (5) are deleted (NIL).

File View Tool Help	
Help	Clear (4)
Code	Description & trouble position (5)
Current DTC - NIL	
Past DTC - NIL	

1718H1450057-01

11) Close the SDS tool and turn the ignition switch OFF.

12) Disconnect the SDS tool and install the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).

13) Ride the motorcycle at more than 30 km/h (18.6 mile/h) and quickly apply the brakes to check that the ABS activates correctly.



SDS Check

BENC11J14504006


Using SDS, take the sample of data from the new motorcycle and at the time of periodic maintenance at your dealer. Save the data in the computer or by printing and filing the hard copies. The saved or filed data are useful for troubleshooting as they can be compared periodically with changes over time or failure conditions of the motorcycle. For example, when a motorcycle is brought in for service but the troubleshooting is difficult, comparison with the normal data that have been saved or filed can allow the specific ABS failure to be determined.


- 1) Remove the right frame cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Set up the SDS tool. (Refer to the SDS operation manual for further details.)

NOTE


- Before taking the sample of data, check and clear the Past DTC. Refer to "DTC (Diagnostic Trouble Code) Deleting" (Page 4E-22).
- A number of different data under a fixed condition as shown should be saved or filed as sample.

Special tool

 : 09904-41010 (SUZUKI Diagnostic system set)

 : 99565-01010-024 (CD-ROM Ver.24)

DATA sampled from ABS HU system




IC11J1450077-02

Active Control Inspection


BENC11J14504007

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Set up the SDS tool. (Refer to the SDS operation manual for further details.)
- 3) Click "ABS" (1).




I905H1450084-06

- 4) Click "Active control" (2).





I718H1450058-01

- 5) Click "ABS HU operating" (3).



I718H1450059-01


5) Click "Next" according to the screen indication.



I718H1450060-02

NOTE


Skip this screen as this vehicle is not equipped with parking brake.



I718H1450121-01

NOTE


- If the front wheel is selected, lift the front wheel off the ground using a jack.
- Two operators are needed in this work; One should apply a rotational force to the front wheel.



I718H1450061-01

NOTE

- In normal cases, the front brake lever feels a reaction force and the front wheel turns discontinuously. At the same time, the ABS HU operating sound will be heard.
- The ABS HU motor operates for 6 seconds and then stops automatically.



I718H1450062-01

NOTE

- Inspect the rear brake in the same manner of front brake.
- If the ABS does not function, the cause may lie in the ABS control unit/HU.
- In checking the rear brake at the time of pressure reduction drive (4/7), "brake lever" appears on the screen. This is because the present screen shares with other model having front brake only. Therefore, in the case of rear brake pedal equipped vehicle, ignore this instruction and operate the rear brake pedal.

7) Close the SDS tool and turn the ignition switch OFF.

8) Disconnect the SDS tool and install the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).

Step 4

- 1) Inspect the clearances of the front and rear wheel speed sensor – sensor rotor using the thickness gauge.

Special tool

 (A): 09900-20804 (Thickness gauge)


 (B): 09900-20806 (Thickness gauge)

Wheel speed sensor – Sensor rotor clearance

Front: 0.26 – 1.67 mm (0.010 – 0.066 in)


Rear: 0.26 – 1.47 mm (0.010 – 0.058 in)

Front



IC11J1240010-02

Rear



IC11J1240026-02

Are the clearances OK?

- Yes Replace the ABS control unit/HU. Refer to "ABS Control Unit / HU Removal and Installation" (Page 4E-56).
- No Adjust the clearance.

DTC "35" (C1635): ABS Motor Malfunction

BENC11J14504014

Possible Cause

Motor relay circuit open or short, broken fuse for motor relay, pump motor circuit open or short, faulty motor relay, faulty ABS motor, faulty ABS control unit, etc.

Wiring Diagram

Refer to "ABS Control Unit / HU Diagram" (Page 4E-7).

Troubleshooting

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "DTC (Diagnostic Trouble Code) Deleting" (Page 4E-22).

Step 1

- 1) Inspect if the pump motor (1) makes turning noise by setting the ignition switch to ON from OFF when the vehicle stands still.



IC11J1450021-01

Does the pump motor make any turning noise?

- Yes
- Faulty HU motor
 - Replace the ABS control unit/HU. Refer to "ABS Control Unit / HU Removal and Installation" (Page 4E-56).
- No Go to Step 2.

Step 2


- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Inspect the ABS motor fuse (2).

▲ CAUTION

If a fuse is blown, find the cause of the problem and correct it before replacing the fuse.

ABS motor fuse

25 A




IC11J1450022-03

Is the ABS motor fuse OK?

- Yes Go to Step 3.
- No Replace the ABS motor fuse.

Step 3

- 1) Remove the battery holder. Refer to "ABS Control Unit Coupler Disconnect and Connect" (Page 4E-51).
- 2) Check the ABS control unit coupler (3) for loose or poor contacts. If OK, then disconnect the ABS control unit coupler. Refer to "ABS Control Unit Coupler Disconnect and Connect" (Page 4E-51).



IC11J1450023-02

- 3) Measure the voltage between "10" (R/B) and "18" (B) at the coupler.

Special tool


- (A): 09900-25008 (Multi circuit tester set)
- (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Voltage ()

Normal value ("10" – "18")

Battery voltage (12.0 V or more)



IC11J1450024-02

Is the voltage between "10" and "18" normal?

- Yes Replace the ABS control unit/HU. Refer to "ABS Control Unit / HU Removal and Installation" (Page 4E-56).
- No Inspect the wire harness. (Faulty motor power supply or ground wire)

DTC "41" (C1641): Wheel Speed Sensor Signal Malfunction (F)

BENC11J14504015

Possible Cause

Too great air gap, worn or missing teeth, noise, interference between lines, loose contact in wheel speed sensor connector, wheel speed sensor not securely fastened, input amplifier in wheel speed sensor connector, wheel speed sensor not securely fastened, input amplifier in ABS control unit failure, etc.

Troubleshooting

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "DTC (Diagnostic Trouble Code) Deleting" (Page 4E-22).

Step 1


- 1) Inspect the clearance between the front wheel speed sensor and sensor rotor using the thickness gauge.

Special tool

 (A): 09900-20804 (Thickness gauge)

 (B): 09900-20806 (Thickness gauge)

Wheel speed sensor – Sensor rotor clearance
0.26 – 1.67 mm (0.010 – 0.066 in)



IC11J1240010-02

Is the clearance OK?

- Yes Go to Step 2.
No Adjust the clearance.

Step 2

- 1) Inspect the front wheel speed sensor rotor for damage and check that no foreign objects are caught in the rotor openings.




I718H1450064-01

Is the sensor rotor OK?

- Yes Go to Step 3.
No Clean or replace the sensor rotor. Refer to "Front Wheel Speed Sensor Rotor Removal and Installation" (Page 4E-54).

Step 3

- 1) Check that the front wheel speed sensor (1) is mounted securely.



IC11J1450025-01

Is the sensor mounted securely?

- Yes Go to DTC "42" (C1642). (Refer to "DTC "42" (C1642): Wheel Speed Sensor Circuit Open (F)" (Page 4E-36).)
No Tighten the mounting bolt.

DTC "42" (C1642): Wheel Speed Sensor Circuit Open (F)

BENC11J14504016

Possible Cause

Wheel speed sensor circuit open or short, loosen contact in wheel speed sensor connector, input amplifier in ABS control unit failure, etc.

Wiring Diagram

Refer to "ABS Control Unit / HU Diagram" (Page 4E-7).


Troubleshooting

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "DTC (Diagnostic Trouble Code) Deleting" (Page 4E-22).

Step 1

- 1) Turn ignition switch OFF.
- 2) Remove the battery holder. Refer to "ABS Control Unit Coupler Disconnect and Connect" (Page 4E-51).
- 3) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 4) Check the ABS control unit coupler (1) and front wheel speed sensor coupler (2) for loose or poor contacts. If OK, then disconnect the ABS control unit coupler. Refer to "ABS Control Unit Coupler Disconnect and Connect" (Page 4E-51).



IC11J1450026-03

- 5) Check for continuity between "16" (W/R) and "7" (B/R) at the ABS control unit coupler.

Special tool


- TOOL (A): 09900-25008 (Multi circuit tester set)
- TOOL (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity test (•)))

Normal value ("16" – "7")

No continuity



IC11J1450027-02


Is the continuity between "16" (W/R) and "7" (B/R) OK?


- Yes Go to Step 2.
- No
 - Inspect the wire harness. (Faulty sensor wire)
 - Faulty front wheel speed sensor. Refer to "Front Wheel Speed Sensor Removal and Installation" (Page 4E-52).

Step 2

- 1) Check for continuity between "16" (W/R) and ground at the ABS control unit coupler.

Special tool

 (A): 09900-25008 (Multi circuit tester set)


 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity test (•)))

Normal value ("16" – Ground)

No continuity



Is the continuity between "16" and ground OK?


Yes Go to Step 4.


No Go to Step 3.

Step 4

- 1) Check for continuity between "7" (B/R) and ground at the ABS control unit coupler.

Special tool

 (A): 09900-25008 (Multi circuit tester set)


 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity test (•)))

Normal value ("7" – Ground)

No continuity



Is the continuity between "7" and ground OK?


Yes Go to Step 6.

No Go to Step 5.

Step 3

- 1) Disconnect the front wheel speed sensor coupler.
- 2) Check for continuity between "A" (W) and ground at the front wheel speed sensor coupler.

Special tool


 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity test (•)))

Normal value ("A" – Ground)

No continuity



Is the continuity between "A" and ground OK?


Yes Inspect the wire harness. (Faulty W/R wire)

No Faulty front wheel speed sensor. Refer to "Front Wheel Speed Sensor Removal and Installation" (Page 4E-52).

Step 5

- 1) Disconnect the front wheel speed sensor coupler.
- 2) Check for continuity between "B" (B) and ground at the front wheel speed sensor coupler.

Special tool


 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity test (•)))

Normal value ("B" – Ground)

No continuity



Is the continuity between "B" and ground OK?



Yes Inspect the wire harness. (Faulty B/R wire)

No Faulty front wheel speed sensor. Refer to "Front Wheel Speed Sensor Removal and Installation" (Page 4E-52).

Step 6

- 1) Disconnect the front wheel speed sensor coupler.
- 2) Check for continuity between "16" (W/R) on the ABS control unit coupler and "C" (W/R) on the front wheel speed sensor coupler.

Special tool


-  (A): 09900-25008 (Multi circuit tester set)
 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity test (•)))

Normal value ("16" – "C")

Continuity (•)))



IC11J1450030-02

Is the continuity between "16" and "C"?



Yes Go to Step 7.

No Inspect the wire harness. (W/R wire open)

Step 7

- 1) Check for continuity between "7" (B/R) on the ABS control unit coupler and "D" (B/R) on the front wheel speed sensor coupler.

Special tool


-  (A): 09900-25008 (Multi circuit tester set)
 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity test (•)))

Normal value ("7" – "D")

Continuity (•)))



IC11J1450031-02

Is the continuity between "7" and "D"?

Yes Go to Step 8.


No Inspect the wire harness. (B/R wire open)


Step 8

- 1) Connect the front wheel speed sensor coupler.
- 2) Connect three 1.5 V dry cells "a" in series as shown and make sure that their total voltage is more than 4.5 V.

Measure the current between (+) dry cell terminal and "16" (W/B) on the ABS control unit coupler.

Special tool

 (A): 09900-25008 (Multi circuit tester set)


 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Current ( , 20 mA)

Normal value

5.9 – 16.8 mA

**Is the current OK?**

- Yes Replace the ABS control unit/HU. Refer to "ABS Control Unit / HU Removal and Installation" (Page 4E-56).
- No Faulty front wheel speed sensor. Refer to "Front Wheel Speed Sensor Removal and Installation" (Page 4E-52).

DTC "44" (C1644): Wheel Speed Sensor Signal Malfunction (R)

BENC11J14504018

Possible Cause

Too great air gap, worn or missing teeth, noise, interference between lines, loose contact in wheel speed sensor connector, wheel speed sensor not securely fastened, input amplifier in ABS control unit failure, etc.

Troubleshooting


NOTE


After repairing the trouble, clear the DTC using SDS tool. Refer to "DTC (Diagnostic Trouble Code) Deleting" (Page 4E-22).

Step 1


- 1) Inspect the clearance between the rear wheel speed sensor and sensor rotor using the thickness gauge.

Special tool

 (A): 09900-20804 (Thickness gauge)

 (B): 09900-20806 (Thickness gauge)

Wheel speed sensor – Sensor rotor clearance
0.26 – 1.47 mm (0.010 – 0.058 in)



IC11J1240026-02

Is the clearance OK?

- Yes Go to Step 2.
No Adjust the clearance.

Step 2

- 1) Inspect the rear wheel speed sensor rotor for damage and check that no foreign objects are caught in the rotor openings.




I718H1450064-01

Is the sensor rotor OK?

- Yes Go to Step 3.
No Clean or replace the sensor rotor. Refer to "Rear Wheel Speed Sensor Rotor Removal and Installation" (Page 4E-54).

Step 3

- 1) Check that the rear wheel speed sensor (1) is mounted securely.



IC11J1450033-02

Is the sensor mounted securely?

- Yes Go to DTC "45" (C1645). (Refer to "DTC "45" (C1645): Wheel Speed Sensor Circuit Open (R)" (Page 4E-41).)
No Tighten the mounting bolt.

DTC "45" (C1645): Wheel Speed Sensor Circuit Open (R)

BENC11J14504019

Possible Cause

Wheel speed sensor circuit open or short, loosen contact in wheel speed sensor connector, input amplifier in ABS control unit failure, etc.

Wiring Diagram

Refer to "ABS Control Unit / HU Diagram" (Page 4E-7).


Troubleshooting

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "DTC (Diagnostic Trouble Code) Deleting" (Page 4E-22).

Step 1

- 1) Turn ignition switch OFF.
- 2) Remove the battery holder. Refer to "ABS Control Unit Coupler Disconnect and Connect" (Page 4E-51).
- 3) Check the ABS control unit coupler (1) and rear wheel speed sensor coupler (2) for loose or poor contacts. If OK, then disconnect the ABS control unit coupler. Refer to "ABS Control Unit Coupler Disconnect and Connect" (Page 4E-51).



IC11J1450034-04

- 4) Check for continuity between "15" (W/Y) and "14" (B/Y) at the ABS control unit coupler.

Special tool


- (A): 09900-25008 (Multi circuit tester set)
 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity test (•||)

Normal value ("15" – "14")

No continuity



IC11J1450035-02



Is the continuity between "15" (W/Y) and "14" (B/Y) OK?

- Yes Go to Step 2.
 No Inspect the wire harness. (Faulty sensor wire)
 Faulty rear wheel speed sensor.

Step 2

- 1) Check for continuity between "15" (W/Y) and ground at the ABS control unit coupler.

Special tool


-  (A): 09900-25008 (Multi circuit tester set)
 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity test (•)))

Normal value ("15" – Ground)

No continuity



IC11J1450036-02


Is the continuity between "15" and ground OK?

- Yes Go to Step 4.
 No Go to Step 3.

Step 3

- 1) Disconnect the rear wheel speed sensor coupler.
- 2) Check for continuity between "A" (W) and ground at the rear wheel speed sensor coupler.

Special tool


-  (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity test (•)))

Normal value ("A" – Ground)

No continuity



I944H3450034-01



Is the continuity between "A" and ground OK?

- Yes Inspect the wire harness. (Faulty W/Y wire)
 No Replace the rear wheel speed sensor. Refer to "Rear Wheel Speed Sensor Removal and Installation" (Page 4E-53).

Step 4

- 1) Check for continuity between "14" (B/Y) and ground at the ABS control unit coupler.

Special tool


-  (A): 09900-25008 (Multi circuit tester set)
 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity test (•)))

Normal value ("14" – Ground)

No continuity



IC11J1450037-02


Is the continuity between "14" and ground OK?

- Yes Go to Step 6.
 No Go to Step 5.

Step 5

- 1) Disconnect the rear wheel speed sensor coupler.
- 2) Check for continuity between "B" (B) and ground at the rear wheel speed sensor coupler.

Special tool


-  (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity test (•)))

Normal value ("B" – Ground)

No continuity



I944H3450046-02



Is the continuity between "B" and ground OK?

- Yes Inspect the wire harness. (Faulty B/Y wire)
 No Replace the rear wheel speed sensor. Refer to "Rear Wheel Speed Sensor Removal and Installation" (Page 4E-53).

Step 6

- 1) Disconnect the rear wheel speed sensor coupler.
- 2) Check for continuity between "15" (W/Y) on the ABS control unit coupler and "C" (W/Y) on the rear wheel speed sensor coupler.

Special tool


-  (A): 09900-25008 (Multi circuit tester set)
 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity test (•))

Normal value ("15" – "C")

Continuity (•))



IC11J1450038-02

Is the continuity between "15" and "C"?



Yes Go to Step 7.

No Inspect the wire harness. (W/Y wire open)

Step 7

- 1) Check for continuity between "14" (B/Y) on the ABS control unit coupler and "D" (B/Y) on the rear wheel speed sensor coupler.

Special tool


-  (A): 09900-25008 (Multi circuit tester set)
 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Continuity test (•))

Normal value ("14" – "D")

Continuity (•))



IC11J1450039-02

Is the continuity between "14" and "D"?



Yes Go to Step 7.

No Inspect the wire harness. (B/Y wire open)

Step 8

- 1) Connect the rear wheel speed sensor coupler.
- 2) Connect three 1.5 V dry cells "a" in series as shown and make sure that their total voltage is more than 4.5 V. Measure the current between (+) dry cell terminal and "15" (W/Y) on the ABS control unit coupler.

Special tool


-  (A): 09900-25008 (Multi circuit tester set)
 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Current (---, 20 mA)

Normal value

5.9 – 16.8 mA



IC11J1450040-03

Is the current OK?

Yes Replace the ABS control unit/HU. Refer to "ABS Control Unit / HU Removal and Installation" (Page 4E-56).

No Replace the rear wheel speed sensor. Refer to "Rear Wheel Speed Sensor Removal and Installation" (Page 4E-53).

DTC "47" (C1647): Supply Voltage (Increased)

BENC11J14504021

Possible Cause

- Faulty regulator/rectifier
- Faulty battery
- Faulty ABS control unit
- Faulty wire harness, etc.

Wiring Diagram

Refer to "ABS Control Unit / HU Diagram" (Page 4E-7).


Troubleshooting**NOTE**

- After repairing the trouble, clear the DTC using SDS tool. Refer to "DTC (Diagnostic Trouble Code) Deleting" (Page 4E-22).
- When the voltage resumes the normal level, the ABS indicator light will go off.

Step 1

- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Measure the voltage between the (+) and (-) battery terminals using the multi circuit tester.

Special tool

 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Voltage (---)

Battery voltage

12.0 V or more




IC11J1450006-01

Step 2

- 1) Start the engine at 5 000 r/min with the dimmer switch set to HI.
- 2) Measure the voltage between the (+) and (-) battery terminals.

Special tool

 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Voltage (---)

Regulated voltage

14.0 – 15.5 V at 5 000 r/min

Is the voltage 14.0 – 15.5 V?


- Yes Go to Step 3.
- No Inspect the regulator/rectifier. Refer to "Regulator / Rectifier Inspection" in Section 1J (Page 1J-8).

Is the voltage over 12 V?

- Yes Go to Step 2.
- No Charge or replace the battery.

Step 3


- 1) Turn the ignition switch OFF.
- 2) Remove the battery holder. Refer to "ABS Control Unit Coupler Disconnect and Connect" (Page 4E-51).
- 3) Check the ABS control unit coupler (1) for loose or poor contacts. If OK, then disconnect the ABS control unit coupler.




IC11J1450041-03

- 4) Start the engine at 5 000 r/min with the dimmer switch set to HI.
- 5) Measure the voltage between "6" (O/Y) and "9" (B/W) at the coupler.


Special tool

 (A): 09900-25008 (Multi circuit tester set)

 (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Voltage (---)



ABS control unit coupler
(Harness end)

IC11J1450042-02

Is the voltage same as Step 2?

- Yes** Replace the ABS control unit/HU. Refer to "ABS Control Unit / HU Removal and Installation" (Page 4E-56).
- No** Inspect the wire harness. (Faulty ignition or ground wire)

DTC "48" (C1648): Supply Voltage (Decreased)**Possible Cause**

- Faulty generator or regulator/rectifier
- Faulty battery
- Faulty ABS control unit
- Faulty wire harness, etc.

Wiring Diagram

Refer to "ABS Control Unit / HU Diagram" (Page 4E-7).


Troubleshooting**NOTE**

- After repairing the trouble, clear the DTC using SDS tool. Refer to "DTC (Diagnostic Trouble Code) Deleting" (Page 4E-22).
- When the voltage resumes the normal level, the ABS indicator light will go off.

Step 1

- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Measure the voltage between the (+) and (-) battery terminals using the multi circuit tester.

Special tool

 (A): 09900-25008 (Multi circuit tester set)

Tester knob indication

Voltage (---)

Battery voltage

12.0 V or more



IC11J1450006-01

Is the voltage over 12 V?

- Yes Go to Step 2.
No Charge or replace the battery.

Step 2

- 1) Start the engine at 5 000 r/min with the dimmer switch set to HI.
- 2) Measure the voltage between the (+) and (-) battery terminals.

Special tool

 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Voltage (---)

Regulated voltage


14.0 – 15.5 V at 5 000 r/min

Is the voltage 14.0 – 15.5 V?

- Yes Go to Step 3.
No Inspect the generator and regulator/rectifier. Refer to "Generator Inspection" in Section 1J (Page 1J-4) and "Regulator / Rectifier Inspection" in Section 1J (Page 1J-8).

Step 3

- 1) Turn the ignition switch OFF.
- 2) Remove the battery holder. Refer to "ABS Control Unit Coupler Disconnect and Connect" (Page 4E-51).
- 3) Check the ABS control unit coupler (1) for loose or poor contacts. If OK, then disconnect the ABS control unit coupler.



IC11J1450041-03

- 4) Start the engine at 5 000 r/min with the dimmer switch set to HI.
- 5) Measure the voltage between "6" (O/Y) and "9" (B/W) at the coupler.


Special tool

TOOL (A): 09900-25008 (Multi circuit tester set)

TOOL (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Voltage (---)



ABS control unit coupler
(Harness end)

IC11J1450042-02

Is the voltage same as Step 2?

- Yes** Replace the ABS control unit/HU. Refer to "ABS Control Unit / HU Removal and Installation" (Page 4E-56).
- No** Inspect the wire harness. (Faulty ignition or ground wire)

DTC "55" (C1655): ABS Control Unit Malfunction

BENC11J14504023

Possible Cause
Faulty ABS control unit

Troubleshooting

NOTE


After repairing the trouble, clear the DTC using SDS tool. Refer to "DTC (Diagnostic Trouble Code) Deleting" (Page 4E-22).

Step 1

- 1) Inspect the clearances of the front and rear wheel speed sensor – sensor rotor using the thickness gauge.

Special tool

 (A): 09900-20804 (Thickness gauge)


 (B): 09900-20806 (Thickness gauge)

Wheel speed sensor – Sensor rotor clearance

Front: 0.26 – 1.67 mm (0.010 – 0.066 in)


Rear: 0.26 – 1.47 mm (0.010 – 0.058 in)

Front



IC11J1240010-02

Rear



IC11J1240026-02

Are the clearances OK?

Yes Go to Step 2.

No Adjust the clearance.

Step 2

- 1) Inspect both of the wheel speed sensor rotors for damage and check that no foreign objects are caught in the rotor openings.



I718H1450064-01


Are the rotors OK?

Yes Go to Step 3.

No Clean or replace the rotor. Refer to "Front Wheel Speed Sensor Rotor Removal and Installation" (Page 4E-54) and "Rear Wheel Speed Sensor Rotor Removal and Installation" (Page 4E-54).

Step 3

- 1) Check that the front and rear wheel speed sensors (1) are mounted securely.



IC11J1450043-01


Are the sensors mounted securely?

Yes Go to Step 4.

No Tighten the mounting bolts.

Step 4

- 1) Delete DTCs and repeat the code output procedure. Refer to "DTC (Diagnostic Trouble Code) Deleting" (Page 4E-22) and "DTC (Diagnostic Trouble Code) Output" (Page 4E-18).



IC11J1450044-02

Is the DTC "55" (C1655) output again?

- Yes Replace the ABS control unit/HU. Refer to "ABS Control Unit / HU Removal and Installation" (Page 4E-56).
- No Intermittent trouble.

Possible Cause
 When relay output open or short broken fuse for valve solenoid valve, failure output from ABS control unit, etc.

NOTE
 After repairing the trouble, clear the DTC using SIB tool. Refer to "DTC (Diagnostic Trouble Code) Clearing" (Page 4E-22).

- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Seat for Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Inspect the ABS valve fuse (1).

CAUTION
 If a fuse is blown, find the cause of the problem and correct it before replacing the fuse.

ABS valve fuse
 15 A



Is the ABS valve fuse OK?
 If OK, proceed to the next step.
 If not OK, replace the fuse.

Special tool
 (A) 09900-22008 (Multi circuit tester set)
 (B) 09900-22009 (Wiring diagram printer set)

ABS Control Unit Connector Disconnection and Connection
 Voltage (-)
 Normal value ("1" - "0")
 - Battery voltage (7.5V or more) (1)
 - Battery voltage (2.5V or more) (2)



Is the voltage between "1" and "2" normal?
 Yes Replace the ABS control unit/HU. Refer to "ABS Control Unit / HU Removal and Installation" (Page 4E-56).
 No Inspect the wire harness. (If only terminal or ground wire)

DTC "61" (C1661): ABS Solenoid Malfunction

BENC11J14504024

Possible Cause

Valve relay circuit open or short, broken fuse for valve relay, faulty valve relay, interruption of valve, failure output from ABS control unit, etc.

Troubleshooting

NOTE

After repairing the trouble, clear the DTC using SDS tool. Refer to "DTC (Diagnostic Trouble Code) Deleting" (Page 4E-22).

Step 1


- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Inspect the ABS valve fuse (1).

▲ CAUTION

If a fuse is blown, find the cause of the problem and correct it before replacing the fuse.

ABS valve fuse

15 A




IC11J1450045-03

Is the ABS valve fuse OK?

- Yes Go to Step 2.
No Replace the ABS valve fuse.

Step 2

- 1) Remove the battery holder. Refer to "ABS Control Unit Coupler Disconnect and Connect" (Page 4E-51).
- 2) Check the ABS control unit coupler (2) for loose or poor contacts.
If OK, then disconnect the ABS control unit coupler. Refer to "ABS Control Unit Coupler Disconnect and Connect" (Page 4E-51).



IC11J1450046-02

- 3) Measure the voltage between "1" (R) and "9" (B/W) at the coupler.

Special tool


- TOOL (A): 09900-25008 (Multi circuit tester set)
TOOL (B): 09900-25009 (Needle-point probe set)

Tester knob indication

Voltage (---)

Normal value ("1" - "9")

Battery voltage (12.0 V or more)



IC11J1450047-02


Is the voltage between "1" and "9" normal?

- Yes Replace the ABS control unit/HU. Refer to "ABS Control Unit / HU Removal and Installation" (Page 4E-56).
No Inspect the wire harness. (Faulty solenoid or ground wire)

Repair Instructions

ABS Control Unit / HU Cover Construction

BENC11J14506001



IC11J1450069-01

1. ABS control unit holder

2. ABS control unit cover

3. ABS control unit cover / HU


ABS Control Unit Coupler Disconnect and Connect

BENC11J14506002

Disconnect

- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).


- 3) Remove the battery (1). Refer to "Battery Removal and Installation" in Section 1J (Page 1J-12).
- 4) Remove the ECM (2), main fuse box (3), side turn signal relay (4), starter relay (5), TO sensor (6), ABS valve fuse (7), ABS motor fuse (8) and fuel pump relay (9).




IC11J1450051-02

4E-52 ABS:

- 5) Remove the battery holder (10) by removing the bolts (11), screws (12) and fastener (13).




IC11J1450052-01



IC11J1450053-01

- 6) Disconnect the ABS control unit coupler (14).



IC11J1450048-02

Connect

Connect the ABS control unit coupler in the reverse order of disconnect. Pay attention to the following points.



Front Wheel Speed Sensor Removal and Installation


BENC11J14506003

NOTICE

- The ABS is made up of many precision parts; never subject it to strong impacts or allow it to become dirty or dusty.
- The wheel speed sensor cannot be disassembled.


Removal

- 1) Turn the ignition switch OFF.
- 2) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 3) Disconnect the front wheel speed sensor lead wire coupler (1).



IC11J1450076-01

- 4) Remove the front wheel speed sensor (2) by removing the mounting bolt (3).



IC11J1450050-03


- 5) Remove the front wheel speed sensor as shown in the front wheel speed sensor routing diagram. Refer to "Front Wheel Speed Sensor Routing Diagram" (Page 4E-8).


Installation

Install the front wheel speed sensor in the reverse order of removal. Pay attention to the following points:

- Install the front wheel speed sensor as shown in the front wheel speed sensor routing diagram. Refer to "Front Wheel Speed Sensor Routing Diagram" (Page 4E-8).
- Check the clearance between the front wheel speed sensor and sensor rotor using the thickness gauge.

Special tool

 (A): 09900-20804 (Thickness gauge)

 (B): 09900-20806 (Thickness gauge)

Wheel speed sensor – Sensor rotor clearance

0.26 – 1.67 mm (0.010 – 0.066 in)



IC11J1240010-02

Rear Wheel Speed Sensor Removal and Installation

BENC11J14506004

NOTICE

- The ABS is made up of many precision parts; never subject it to strong impacts or allow it to become dirty or dusty.
- The wheel speed sensor cannot be disassembled.

Removal

- 1) Turn the ignition switch OFF.
- 2) Remove the right frame side cover. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Disconnect the rear wheel speed sensor lead wire coupler (1) and remove the clamp (2).




IC11J1450054-02



IC11J1450070-01

- 4) Remove the rear wheel speed sensor (3) by removing the mounting bolt (4).



IC11J1450055-03


- 5) Remove the rear wheel speed sensor as shown in the rear wheel speed sensor routing diagram. Refer to "Rear Wheel Speed Sensor Routing Diagram" (Page 4E-9).


Installation

Install the rear wheel speed sensor in the reverse order of removal. Pay attention to the following points:

- Install the rear wheel speed sensor as shown in the rear wheel speed sensor routing diagram. Refer to "Rear Wheel Speed Sensor Routing Diagram" (Page 4E-9).
- Check the clearance between the rear wheel speed sensor and sensor rotor using the thickness gauge.


Special tool

 (A): 09900-20804 (Thickness gauge)

 (B): 09900-20806 (Thickness gauge)

Wheel speed sensor – Sensor rotor clearance

0.26 – 1.47 mm (0.010 – 0.058 in)



IC11J1240026-02

Front Wheel Speed Sensor Rotor Removal and Installation

BENC11J14506005

NOTICE


- The ABS is made up of many precision parts; never subject it to strong impacts or allow it to become dirty or dusty.
- Do not hit the front wheel speed sensor rotor when dismantling the front wheel.

Removal

- 1) Remove the front wheel assembly. Refer to "Front Wheel Assembly Removal and Installation" in Section 2D (Page 2D-4).
- 2) Remove the front wheel speed sensor rotor (1) by removing the bolts (2).

NOTICE

When replacing the tire, make sure not to damage the sensor rotor.



IC11J1450056-01


Installation

Install the front wheel speed sensor rotor in the reverse order of removal. Pay attention to the following points:

- Install the wheel speed sensor rotor as the letters "50T" face outside.
- Tighten the front wheel speed sensor rotor bolts (1) to the specified torque.

Tightening torque

Wheel speed sensor rotor bolt (a): 6.5 N·m (0.65 kgf-m, 4.7 lbf-ft)



IC11J1450057-01

- Install the front wheel assembly. Refer to "Front Wheel Assembly Removal and Installation" in Section 2D (Page 2D-4).
- Check the clearance between the front wheel speed sensor and sensor rotor using the thickness gauge.

Special tool

- TOOL (A): 09900-20804 (Thickness gauge)
- TOOL (B): 09900-20806 (Thickness gauge)

Wheel speed sensor – Sensor rotor clearance
0.26 – 1.67 mm (0.010 – 0.066 in)



IC11J1240010-02

Rear Wheel Speed Sensor Rotor Removal and Installation

BENC11J14506006

NOTICE


- The ABS is made up of many precision parts; never subject it to strong impacts or allow it to become dirty or dusty.
- Do not hit the rear wheel speed sensor rotor when dismantling the rear wheel.

Removal

- 1) Remove the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation" in Section 2D (Page 2D-11).
- 2) Remove the rear wheel speed sensor rotor (1) by removing the bolts (2).

CAUTION

When replacing the tire, make sure not to damage the sensor rotor.



IC11J1450058-01


Installation

Install the rear wheel speed sensor rotor in the reverse order of removal. Pay attention to the following points:

- Install the wheel speed sensor rotor as the letters "50T" face outside.
- Tighten the rear wheel speed sensor rotor bolts (1) to the specified torque.

Tightening torque

Wheel speed sensor rotor bolt (a): 6.5 N·m (0.65 kgf·m, 4.7 lbf·ft)



IC11J1450059-01

- Install the rear wheel assembly. Refer to "Rear Wheel Assembly Removal and Installation" in Section 2D (Page 2D-11).
- Check the clearance between the rear wheel speed sensor and sensor rotor using the thickness gauge.


Special tool

 (A): 09900-20804 (Thickness gauge)

 (B): 09900-20806 (Thickness gauge)

Wheel speed sensor – Sensor rotor clearance

0.26 – 1.47 mm (0.010 – 0.058 in)




IC11J1240026-02

Wheel Speed Sensor and Sensor Rotor Inspection

BENC11J1450060P

Wheel Speed Sensor

- 1) Remove the wheel speed sensor. Refer to "Front Wheel Speed Sensor Removal and Installation" (Page 4E-52) and "Rear Wheel Speed Sensor Removal and Installation" (Page 4E-53).
- 2) Inspect the wheel speed sensor for damage. Clean the sensor if any metal particle or foreign material stuck on it.



IC11J1450060-01

- 3) After finishing the speed sensor inspection, install the wheel speed sensor. Refer to "Front Wheel Speed Sensor Removal and Installation" (Page 4E-52) and "Rear Wheel Speed Sensor Removal and Installation" (Page 4E-53).

Wheel Speed Sensor Rotor

- 1) Raise the wheel off the ground and support the motorcycle with a jack or wooden block.
- 2) Check that no wheel speed sensor rotor teeth are broken and that no foreign objects are caught in the wheel speed sensor.



I718H1450064-01

ABS Control Unit / HU Removal and Installation

BENC11J14506008

Removal


▲ WARNING

When storing the brake fluid, seal the container completely and keep away from children.

▲ CAUTION


- This brake system is filled with an ethylene glycol-based DOT 4 brake fluid. Do not mix different types of fluid such as silicone-based or petroleum-based.
- Do not use any brake fluid taken from old, used or unsealed containers. Never reuse brake fluid left over from the last servicing or stored for long periods.
- Handle brake fluid with care: the fluid reacts chemically with paint, plastics, rubber materials etc. and will damage them severely.
- The ABS is made up of many precision parts; never subject it to strong impacts or allow it to become dirty or dusty.
- The ABS control unit/HU cannot be disassembled.

- 1) Turn the ignition switch OFF.
- 2) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 3) Remove the battery (1). Refer to "Battery Removal and Installation" in Section 1J (Page 1J-12).
- 4) Remove the ECM (2), main fuse box (3), side turn signal relay (4), starter relay (5), TO sensor (6), ABS valve fuse (7), ABS motor fuse (8) and fuel pump relay (9).




IC11J1450051-02

- 5) Remove the battery holder (10) by removing the bolts (11), screws (12) and fastener (13).




IC11J1450052-01



IC11J1450053-01

- 6) Remove the ABS control unit cover (14) by removing the screw (15).




IC11J1450061-01

- 7) Drain the brake fluid. Refer to "Brake Fluid Replacement" in Section 4A (Page 4A-7).
- 8) Loosen the flare nuts (16) and disconnect the brake pipes.
- 9) Disconnect the ABS control unit coupler (17).




IC11J1450062-02

- 0) Remove the ABS control unit / HU (18) by removing the bolts (19).




IC11J1450063-01

- 1) Remove the control unit holder (20) by removing the bolts (21).



IC11J1450064-01



IC11J1450065-01

Installation

Installation is in the reverse order of removal. Pay attention to the following points:

▲ CAUTION

- Route the brake hoses correctly. Refer to "Front Brake Hose Routing Diagram" in Section 4A (Page 4A-1) or "Rear Brake Hose Routing Diagram" in Section 4A (Page 4A-3).
 - Make sure to hold the brake pipe when tightening the flare nut, or it may be misaligned.
- Tighten the brake pipe flare nuts (1) to the specified torque.

Tightening torque

Brake pipe flare nut (a): 16 N·m (1.6 kgf-m, 11.5 lbf-ft)



IC11J1450066-02

- Bleed air from the brake fluid circuit. Refer to "Air Bleeding from Brake Fluid Circuit" in Section 4A (Page 4A-5).

Specifications

Tightening Torque Specifications

BENC11J14507001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lbf-ft	
Wheel speed sensor rotor bolt	6.5	0.65	4.7	☞(Page 4E-54) / ☞(Page 4E-55)
Brake pipe flare nut	16	1.6	11.5	☞(Page 4E-57)





Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment

Special Tool

BENC11J14508001

<p>09900-20804</p> <p>Thickness gauge</p> <ul style="list-style-type: none"> ☞ (Page 4E-14) / ☞ (Page 4E-32) / ☞ (Page 4E-35) / ☞ (Page 4E-40) / ☞ (Page 4E-48) / ☞ (Page 4E-53) / ☞ (Page 4E-53) / ☞ (Page 4E-54) / ☞ (Page 4E-55) 	 <p>09900-20806</p> <p>Thickness gauge</p> <ul style="list-style-type: none"> ☞ (Page 4E-14) / ☞ (Page 4E-32) / ☞ (Page 4E-35) / ☞ (Page 4E-40) / ☞ (Page 4E-48) / ☞ (Page 4E-53) / ☞ (Page 4E-53) / ☞ (Page 4E-54) / ☞ (Page 4E-55) 
<p>09900-25008</p> <p>Multi circuit tester set</p> <ul style="list-style-type: none"> ☞ (Page 4E-13) / ☞ (Page 4E-15) / ☞ (Page 4E-16) / ☞ (Page 4E-16) / ☞ (Page 4E-17) / ☞ (Page 4E-17) / ☞ (Page 4E-17) / ☞ (Page 4E-18) / ☞ (Page 4E-34) / ☞ (Page 4E-36) / ☞ (Page 4E-37) / ☞ (Page 4E-37) / ☞ (Page 4E-37) / ☞ (Page 4E-37) / ☞ (Page 4E-38) / ☞ (Page 4E-38) / ☞ (Page 4E-39) / ☞ (Page 4E-41) / ☞ (Page 4E-42) / ☞ (Page 4E-42) / ☞ (Page 4E-42) / ☞ (Page 4E-42) / ☞ (Page 4E-42) / ☞ (Page 4E-42) / ☞ (Page 4E-43) / ☞ (Page 4E-43) / ☞ (Page 4E-43) / ☞ (Page 4E-44) / ☞ (Page 4E-44) / ☞ (Page 4E-45) / ☞ (Page 4E-46) / ☞ (Page 4E-46) / ☞ (Page 4E-47) / ☞ (Page 4E-50) 	<p>09900-25009</p> <p>Needle-point probe set</p> <ul style="list-style-type: none"> ☞ (Page 4E-15) / ☞ (Page 4E-16) / ☞ (Page 4E-16) / ☞ (Page 4E-17) / ☞ (Page 4E-17) / ☞ (Page 4E-18) / ☞ (Page 4E-34) / ☞ (Page 4E-36) / ☞ (Page 4E-37) / ☞ (Page 4E-37) / ☞ (Page 4E-38) / ☞ (Page 4E-38) / ☞ (Page 4E-39) / ☞ (Page 4E-41) / ☞ (Page 4E-42) / ☞ (Page 4E-42) / ☞ (Page 4E-43) / ☞ (Page 4E-43) / ☞ (Page 4E-43) / ☞ (Page 4E-45) / ☞ (Page 4E-47) / ☞ (Page 4E-50) 
<p>09904-41010</p> <p>SUZUKI Diagnostic system set</p> <ul style="list-style-type: none"> ☞ (Page 4E-21) / ☞ (Page 4E-23) / ☞ (Page 4E-25) 	<p>09930-82710</p> <p>Mode select switch</p> <ul style="list-style-type: none"> ☞ (Page 4E-4) / ☞ (Page 4E-18) / ☞ (Page 4E-19) / ☞ (Page 4E-22) 

-01010-024

DM Ver.24

(e 4E-21) /

(e 4E-23) /

(e 4E-25)



Section 5

Transmission / Transaxle

CONTENTS

Precautions	5-1
Specifications	5-1
Locations for Transmission / Transaxle	5-1
General Transmission	5B-1
Diagnostic Information and Procedures	5B-1
Transmission Symptom Diagnosis	5B-1
Repair Instructions	5B-2
Disassembly Components	5B-2
Disassembly: Input Shaft and Intermediate Shaft Construction	5B-3
Intermediate Gear / Output Shaft Gears	
Disassembly and Assembly	5B-5
Intermediate Bearing Parts Inspection	5B-5
Transmission Oil Seal: Timing Inspection	5B-5
Intermediate Oil Seal: Bearing Removal and Installation	5B-10
Input Position Switch Inspection	5B-12
Input Position Switch Removal and Installation	5B-12
Input Shaft Construction	5B-13
Input Shaft Removal and Installation	5B-13
Input Shaft Height Inspection and Adjustment	5B-14
Input Shaft / Gearshift Cam Plate Components	5B-14
Input Shaft Construction	5B-15
Input Shaft / Gearshift Cam Plate Inspection and Installation	5B-15
Input Shaft: Input Inspection	5B-16
Input Shaft Oil Seal Removal and Installation	5B-16
Specifications	5B-19
Service Data	5B-19

Tightening Torque Specifications	
Special Tools and Equipment	
Recommended Service Mating	
Special Tool	
Clutch	
Precautions	
Precaution for Clutch System	
Diagnostic Information and Procedures	
Clutch System Symptom Diagnosis	
Repair Instructions	
Clutch Lever Position Switch Inspection	
Clutch Cable Inspection and Adjustment	
Clutch Cable Removal and Installation	
Clutch Lever Components	
Clutch Lever Parting and Installation	
Clutch Push Rod (Left) / Clutch Release Component Removal and Installation	
Clutch Push Rod (Left) Inspection	
Clutch Components	
Clutch Removal	
Clutch Installation	
Clutch Part Inspection	
Primary Drive Gear Removal and Installation	
Primary Drive Gear Inspection	
Primary Drive Gear Disassembly and Assembly	
Specifications	
Service Data	
Tightening Torque Specifications	
Special Tools and Equipment	
Recommended Service Mating	
Special Tool	

Section 5

Transmission / Transaxle

CONTENTS

Precautions	5-1	Tightening Torque Specifications	5B-19
Precautions	5-1	Special Tools and Equipment	5B-20
Precautions for Transmission / Transaxle.....	5-1	Recommended Service Material	5B-20
Manual Transmission	5B-1	Special Tool	5B-20
Diagnostic Information and Procedures	5B-1	Clutch	5C-1
Manual Transmission Symptom Diagnosis.....	5B-1	Precautions	5C-1
Repair Instructions	5B-2	Precautions for Clutch System.....	5C-1
Transmission Components	5B-2	Diagnostic Information and Procedures	5C-1
Transmission Removal and Installation	5B-3	Clutch System Symptom Diagnosis	5C-1
Transmission Construction.....	5B-5	Repair Instructions	5C-2
Countershaft Gear / Driveshaft Gear		Clutch Lever Position Switch Inspection	5C-2
Disassembly and Assembly	5B-6	Clutch Cable Inspection and Adjustment	5C-2
Transmission Related Parts Inspection.....	5B-8	Clutch Cable Removal and Installation	5C-2
Transmission Oil Seal / Bearing Inspection	5B-9	Clutch Lever Components.....	5C-3
Transmission Oil Seal / Bearing Removal and		Clutch Lever Removal and Installation.....	5C-4
Installation.....	5B-10	Clutch Push Rod (Left) / Clutch Release	
Gear Position Switch Inspection	5B-12	Camshaft Removal and Installation	5C-4
Gear Position Switch Removal and		Clutch Push Rod (Left) Inspection	5C-5
Installation.....	5B-12	Clutch Components.....	5C-6
Gearshift Lever Construction	5B-13	Clutch Removal.....	5C-7
Gearshift Lever Removal and Installation	5B-13	Clutch Installation.....	5C-9
Gearshift Lever Height Inspection and		Clutch Parts Inspection	5C-13
Adjustment.....	5B-14	Primary Drive Gear Removal and Installation ...	5C-14
Gearshift Shaft / Gearshift Cam Plate		Primary Drive Gear Inspection	5C-15
Components.....	5B-14	Primary Drive Gear Disassembly and	
Gearshift Construction	5B-15	Assembly.....	5C-16
Gearshift Shaft / Gearshift Cam Plate		Specifications	5C-17
Removal and Installation.....	5B-15	Service Data.....	5C-17
Gearshift Linkage Inspection	5B-18	Tightening Torque Specifications	5C-17
Gearshift Shaft Oil Seal Removal and		Special Tools and Equipment	5C-18
Installation.....	5B-18	Recommended Service Material	5C-18
Specifications	5B-19	Special Tool	5C-18
Service Data	5B-19		

Manual Transmission

Diagnostic Information and Procedures

Manual Transmission Symptom Diagnosis


BENC11J15204001

Condition	Possible cause	Correction / Reference Item
Engine is noisy (Noise seems to come from the transmission).	Worn or rubbing gear.	<i>Replace.</i>
	Worn countershaft spline.	<i>Replace countershaft.</i>
	Worn driveshaft spline.	<i>Replace driveshaft.</i>
	Worn or rubbing primary gear.	<i>Replace.</i>
	Worn bearing.	<i>Replace.</i>
Transmission will not shift.	Broken gearshift cam.	<i>Replace.</i>
	Distorted gearshift fork.	<i>Replace.</i>
	Worn gearshift pawl.	<i>Replace.</i>
Transmission will not shift back.	Broken gearshift shaft return spring.	<i>Replace.</i>
	Rubbing or stuck gearshift shaft.	<i>Repair or replace.</i>
	Worn or distorted gearshift fork.	<i>Replace.</i>
Transmission jumps out of gear.	Worn shifting gears on driveshaft or countershaft.	<i>Replace.</i>
	Worn or distorted gearshift fork.	<i>Replace.</i>
	Weakened gearshift stopper spring.	<i>Replace.</i>
	Worn gearshift cam plate.	<i>Replace.</i>

Repair Instructions

Transmission Components

BENC11J1520



IC11J1520


1. 1st driven gear	11. 6th drive gear	: 13 N·m (1.3 kgf-m, 9.5 lbf-ft)
2. 5th driven gear	12. 2nd drive gear	: 19 N·m (1.9 kgf-m, 13.5 lbf-ft)
3. 4th driven gear	13. Gearshift fork No. 1	: 10 N·m (1.0 kgf-m, 7.0 lbf-ft)
4. 3rd driven gear	14. Gearshift fork No. 2	: 6.5 N·m (0.65 kgf-m, 4.7 lbf-ft)
5. 6th driven gear	15. Gearshift fork No. 3	: Apply oil.
6. 2nd driven gear	16. Gearshift shaft	: Apply molybdenum oil solution.
7. Driveshaft	17. Gearshift cam plate	: Apply grease to oil seal lip.
8. Countershaft/1st drive gear	18. Gearshift cam	: Apply thread lock to thread part.
9. 5th drive gear	19. Gear position switch	: Apply thread lock to thread part.
10. 3rd/4th drive gear	20. Gearshift cam stopper plate	: Do not reuse.

Transmission Removal and Installation

BENC11J15206002

Removal


- 1) Remove the engine assembly from the frame. Refer to "Engine Assembly Removal" in Section 1D (Page 1D-17).
- 2) Disassemble the engine top side. Refer to "Engine Top Side Disassembly" in Section 1D (Page 1D-27).
- 3) Separate the right and left crankcases. Refer to "Engine Bottom Side Disassembly" in Section 1D (Page 1D-59).
- 4) Remove the crankshaft (1).



I944H1520001-01

Gearshift cam / Gearshift fork


Remove the gearshift fork shafts (1), gearshift forks (2) and gearshift cam (3).



I944H1520002-01


Driveshaft assembly / Countershaft assembly

- 1) Remove the driveshaft assembly (1) and countershaft assembly (2).



I944H1520003-01

- 2) Remove the engine sprocket spacer (3) and O-ring (4).




I944H1520004-01

Installation

Install the transmission in the reverse order of removal. Pay attention to the following points:

Driveshaft assembly / Countershaft assembly

- Install the driveshaft assembly (1) and countershaft assembly (2).




I944H1520005-01


5B-4 Manual Transmission:

Gearshift cam / Gearshift fork

- Install the gearshift forks into the gearshifting grooves in the correct position and direction.



1944H1520006-01




1944H1520007-01

1. Gearshift fork No. 1	3. Gearshift fork No. 3
2. Gearshift fork No. 2	

- Install the gearshift cam (4) so that the pins "A" face upward (right crankcase side).
- Install the gearshift fork shafts (5).

NOTE

- After the gearshift fork shafts and gearshift forks have been fitted, make sure that the gears engage normally.
- Set the transmission gears to the neutral position.




1944H1520008-01

- Install the crankshaft (6).

NOTE

- Be sure to set the crankshaft in the proper direction.
- Of the two conrods, the one with the embossed letter marked should be brought to the rear cylinder.



1944H1520009-01

"B": Embossed letter


- Install the right crankcase. Refer to "Engine Bottom Side Reassembly" in Section 1D (Page 1D-66).
- Apply grease to the O-ring.

⚠ Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)

- Install the engine sprocket spacer (7).


NOTE

The grooved "C" side of the engine sprocket spacer (7) must face crankcase side.



1C11J1520019-01

- Assemble the engine. Refer to "Engine Bottom Side Reassembly" in Section 1D (Page 1D-66) and "Engine Top Side Reassembly" in Section 1D (Page 1D-32).
- Remount the engine assembly. Refer to "Engine Assembly Installation" in Section 1D (Page 1D-23).



IC11J1520002-01

1. Counter shaft	2. Drive shaft	 3. Snap ring : Assemble snap ring with sharp edge side out.
------------------	----------------	--

Countershaft Gear / Driveshaft Gear Disassembly and Assembly

BENC11J15208004

Disassembly

NOTE


Identify the position of each removed part. Organize the parts in their respective groups (i.e., drive or driven) so that they can be reinstalled in their original positions.

Disassemble the countershaft and driveshaft as shown in the transmission construction. Refer to "Transmission Construction" (Page 5B-5).

Pay attention to the following points:


Countershaft

- Remove the 6th drive gear snap ring (1) from its groove and slide it towards the 3rd/4th drive gears (2).




I944H1520012-01

- Slide the 6th (3) and 2nd (4) drive gears toward the 3rd/4th drive gears (2), then remove the 2nd drive gear circlip (5).
- Remove the 2nd drive gear (4), 6th drive gear (3), bushing and washer.




I944H1520013-01

- Remove the snap ring (6) and 3rd/4th drive gears (7).




I944H1520014-01

- Remove the snap ring (8), washer (9) and 5th drive gear (10).



I944H1520015-01


- Remove the 5th drive gear bushing (11).



I944H1520016-01


Driveshaft

- Remove the washer (1) and 1st driven gear (2).
- Remove the 1st driven gear bearing (3), washer (4) and 5th driven gear (5).




IC11J1520021-01

- Remove the snap ring (6), washer (7) and 4th driven gear (8).
- Remove the 4th driven gear bushing (9), lock washers (10) and 3rd driven gear (11).




I944H1520018-01

- Remove the 3rd driven gear bushing (12) and washer (13).



I944H1520019-01

- Remove the snap ring (14) and 6th driven gear (15).
- Remove the snap ring (16) and 2nd driven gear bushing (17).
- Remove the 2nd driven gear (18).




I944H1520020-01

Assembly

NOTE

- When reassembling the transmission gears, attention must be given to the locations and positions of washers and snap rings. The cross sectional view shows the correct position of the gears, bushings, washers and snap rings. Refer to "Transmission Construction" (Page 5B-5).
 - When installing a new snap rings, do not expand the end gap larger than required to slip the snap rings over the shaft.
 - After installing a snap rings, make sure that it is completely seated in its groove and securely fitted.
 - Rotate the bearing by hand to inspect for abnormal noises and smooth rotation. Replace the bearing if there is anything unusual.
 - Before installing the gears, apply engine oil to the driveshaft and countershaft.
- When installing a new snap ring (1), pay attention to its direction. Fit it to the side where the thrust is as shown in the illustration.




I649G1520049-02

1. Snap ring	"A": Thrust	"B": Sharp edge
--------------	-------------	-----------------

Driveshaft


- When install the 3rd driven gear bushing (1) onto the driveshaft, align the shaft oil hole "A" with the bushing oil hole "B".



I944H1520021-01


5B-8 Manual Transmission:

- After installing the 3rd driven gear (2) onto the driveshaft, install lock washer No. 2 (3) onto the driveshaft, and position it so it fits into the groove.




I944H1520022-01

- Then, fit lock washer No. 1 (4) into lock washer No. 2 (3).



I944H1520023-01


- When install the 4th driven gear bushing (5) onto the driveshaft, align the shaft oil hole "C" with the bushing oil hole "D".



I944H1520024-01

Countershaft

- When installing the 6th drive gear bushing (1) onto the countershaft, align the shaft oil hole "A" with the bushing hole "B".



I944H1520025-01

Transmission Related Parts Inspection

BENC11J15206005

Gearshift Fork to Groove Clearance

NOTE

The clearance for each gearshift fork plays an important role in the smoothness and positiveness of the shifting action.

Using a thickness gauge, check the gearshift fork clearance in the groove of its gear.

If the clearance checked is noted to exceed the limit specified, replace the fork or its gear, or both.


Special tool

 (A): 09900-20804 (Thickness gauge)

Shift fork to groove clearance

Standard: 0.1 – 0.3 mm (0.004 – 0.012 in)

Service limit: 0.5 mm (0.020 in)




I649G1520056-03

Gearshift Fork Groove Width

Measure the gearshift fork groove width using the vernier calipers.

Special tool

 (A): 09900-20102 (Vernier calipers (1/20 mm, 200 mm))

Gearshift fork groove width

Standard (No. 1, No. 2 & No. 3): 5.5 – 5.6 mm (0.217 – 0.220 in)




I649G1520057-03

Gearshift Fork Thickness


Measure the gearshift fork thickness using the vernier calipers.

Special tool

 (A): 09900-20102 (Vernier calipers (1/20 mm, 200 mm))

Gearshift fork thickness

Standard (No. 1, No. 2 & No. 3): 5.3 – 5.4 mm (0.209 – 0.213 in)




I649G1520058-03

Gearshift Cam Bearing

Inspect the gearshift cam bearings, left and right for abnormal noise and smooth rotation.


Replace the bearing if there is anything unusual. Refer to "Transmission Oil Seal / Bearing Removal and Installation" (Page 5B-10).



I944H1520026-01

Gearshift Cam

Inspect the gearshift cam groove for abnormal wear and damage. If any defects are found, replace the gearshift cam with a new one.



I944H1520027-01


Transmission Oil Seal / Bearing Inspection

BENC11J15206006

Refer to "Transmission Removal and Installation" (Page 5B-3).

Oil Seal

Inspect the oil seal lips for wear or damage. If any defects are found, replace the oil seal with new ones. Refer to "Transmission Oil Seal / Bearing Removal and Installation" (Page 5B-10).




I944H1520067-01

5B-10 Manual Transmission:

Bearing

Rotate the bearing inner race by finger to inspect for abnormal play, noise and smooth rotation while the bearings are in the crankcase.

Replace the bearing if there is anything unusual. Refer to "Transmission Oil Seal / Bearing Removal and Installation" (Page 5B-10).




I933H1520033-01

Transmission Oil Seal / Bearing Removal and Installation

BENC11J15206007

Removal

- 1) Remove the transmission assembly. Refer to "Transmission Removal and Installation" (Page 5B-3).
- 2) Remove the clutch push rod oil seal (1) and shift shaft oil seal (2).




I944H1520031-01

- 3) Remove the driveshaft oil seal (3) with the special tool.

Special tool


 (A): 09913-50121 (Oil seal remover)




I944H1520032-01


- 4) Remove the bearings from the left crankcase with the special tool.

Special tool

 (B): 09921-20240 (Bearing remover set)




I944H1520034-01



I944H1520033-01


- 5) Remove the bearing retainers (4) from right crankcase.





I944H1520035-01

- 5) Remove the bearings from right crankcase with the special tool.


Special tool

 (B): 09921-20240 (Bearing remover set)

 (C): 09913-70210 (Bearing installer set)



1944H1520036-01




1944H1520037-01

Installation


- 1) Install the new bearings with the special tool.

Special tool


 (A): 09913-70210 (Bearing installer set)

NOTE


- The stamped mark side of bearing "A" faces inside.
- The sealed side of the bearing "B" faces outside.



1944H1520038-01




1944H1520039-01



1944H1520040-01


- 2) Install the bearing retainers (1).




1944H1520041-01


3) Install the new oil seals (2) using the special tool.

Special tool

 (A): 09913-70210 (Bearing installer set)





1944H1520042-01



1944H1520043-01

4) Apply grease to the oil seal lips.

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



1944H1520044-01

5) Install the transmission assembly. Refer to "Transmission Removal and Installation" (Page 5B-3).

Gear Position Switch Inspection

BENC11J15206008


Refer to "Side-stand / Ignition Interlock System Parts Inspection" in Section 11 (Page 11-8).

Gear Position Switch Removal and Installation

BENC11J15206009


Removal

- 1) Turn the ignition switch OFF.
- 2) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).
- 3) Disconnect the gear position switch lead wire coupler (1).




IC11J190011-02

- 4) Remove the generator cover. Refer to "Generator Removal and Installation" in Section 1J (Page 1J-4).
- 5) Remove the oil seal retainer mounting bolts (2).
- 6) Remove the gear position switch mounting bolts (3).



1944H1520028-02

7) Move the oil seal retainer (4) as shown.



1944H1520029-02

8) Remove the gear position switch.


Installation


Install the gear position switch in the reverse order of removal. Pay attention to the following points:

- Apply grease to the new O-ring.

NOTE


Align the gear position switch pin "A" with the gearshift cam hole "B".

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)




IC11J1520004-01

- Apply thread lock to the gear position switch bolts (1) and tighten them to the specified torque.

 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER "1322" or equivalent)

Tightening torque

Gear position switch mounting bolt (a): 6.5 N·m (0.65 kgf-m, 4.7 lbf-ft)




IC11J1520005-01





- Route the gear position switch lead wire. Refer to "Wiring Harness Routing Diagram" in Section 9A (Page 9A-7).

Gearshift Lever Construction

BENC11J15206010



IC11J1520006-01

1. Gearshift link arm	"b": 59.6°
2. Gearshift link rod	"c": 91.87°
3. Gearshift lever	"d": 93.78°
4. Footrest	 : 40 N·m (4.0 kgf-m, 29.0 lbf-ft)
 5. Circlip : Face the sharp edge outside.	 : Apply thread lock to thread part.
"a": 20 - 30 mm (0.8 - 1.2 in)	 : Apply grease.

Gearshift Lever Removal and Installation

BENC11J15206011

Removal

- 1) Place the motorcycle on the center stand.
- 2) Remove the gearshift lever as shown in the gearshift lever construction. Refer to "Gearshift Lever Construction" (Page 5B-13).

Installation

Refer to "Gearshift Lever Construction" (Page 5B-13). Install the gearshift lever in the reverse order of removal. Pay attention to the following points:

- After installing the gearshift lever, check the gearshift lever height. Refer to "Gearshift Lever Height Inspection and Adjustment" (Page 5B-14).

Gearshift Lever Height Inspection and Adjustment


BENC11J15206012

Inspect and adjust the gearshift lever height in the following procedures:

- 1) Inspect the gearshift lever height "a" between the pedal top face and footrest.
Adjust the gearshift lever height if necessary.


Gearshift lever height "a"

Standard: 20 – 30 mm (0.8 – 1.2 in)



IC11J1140088-01


- 2) Loosen the lock-nuts (1).
- 3) Turn the gearshift link rod (2) until the gearshift lever is 20 – 30 mm (0.8 – 1.2 in) below the top of the footrest.
- 4) Tighten the lock-nuts securely.



IC11J1520007-02

Gearshift Shaft / Gearshift Cam Plate Components

BENC11J15206013




I944H1520072-01

1.	Gearshift shaft
2.	Gearshift cam drive plate
3.	Gearshift cam plate
4.	Gearshift cam stopper
(a)	: 10 N·m (1.0 kgf·m, 7.0 lbf·ft)
(b)	: 13 N·m (1.3 kgf·m, 9.5 lbf·ft)
(c)	: 19 N·m (1.9 kgf·m, 13.5 lbf·ft)
(N921)	: Apply thread lock to thread part.
(R221)	: Apply thread lock to thread part.
(AH)	: Apply grease to oil seal lip.
(X)	: Do not reuse.

Gearshift Construction

BENC11J15206014



IC11J1520008-01

1.	Gearshift shaft
2.	Snap ring
3.	Gearshift shaft return spring
4.	Gearshift plate return spring
(a)	: 10 N·m (1.0 kgf·m, 7.0 lbf·ft)
(b)	: 13 N·m (1.3 kgf·m, 9.5 lbf·ft)
(c)	: 19 N·m (1.9 kgf·m, 13.5 lbf·ft)
TOOL	: Apply thread lock to thread part.
TOOL	: Apply thread lock to thread part.
AX	: Apply grease to oil seal lip.
X	: Do not reuse.

Gearshift Shaft / Gearshift Cam Plate Removal and Installation


BENC11J15206015

Removal

- 1) Disengage the gearshift lever link arm (1) by removing the bolt.

NOTE

Mark the gearshift shaft head at which the gearshift link arm slit set for correct reinstallation.




IC11J1520009-02

- 2) Remove the engine sprocket outer cover. Refer to "Engine Sprocket Removal and Installation" in Section 3A (Page 3A-2).
- 3) Remove the clutch components. Refer to "Clutch Removal" in Section 5C (Page 5C-7).

- 4) Remove the snap ring (2) and washer (3) from the gearshift shaft.


Special tool

TOOL : 09900-06107 (Snap ring pliers)



IC11J1520010-01

- 5) Remove the gearshift shaft assembly (4) and washer (5).




IC11J1520020-01

- 6) Remove the following parts from the gearshift shaft (6).

- Snap ring (7)
- Gearshift return spring (8)
- Gearshift cam drive plate (9)
- Plate return spring (10)
- Washer (11)

Special tool

TOOL : 09900-06107 (Snap ring pliers)




I944H1520051-01

5B-16 Manual Transmission:

- 7) Remove the gearshift cam plate bolt (12) and gearshift cam plate (13).
- 8) Remove the gearshift cam stopper (14).


NOTE

Do not drop the each parts into the crankcase.



I944H1520052-01

- 9) Remove the gearshift arm stopper (15).




IC11J1520011-01

Installation


Install the gearshift shaft and gearshift cam plate in the reverse order of removal. Pay attention to the following points:

- Apply a small quantity of thread lock to the gearshift arm stopper (1) and tighten it to the specified torque.

 : Thread lock cement 99000-32030 (THREAD LOCK CEMENT SUPER 1303 or equivalent)

Tightening torque

Gearshift arm stopper (a): 19 N·m (1.9 kgf-m, 13.5 lbf-ft)



I944H1520054-02


- Install the gearshift cam stopper (2), bolt (3), washer (4) and return spring (5).
- Tighten the gearshift cam stopper bolt (3) to the specified torque.

NOTE


Hook the return spring end "A" to the stopper (2).

Tightening torque

Gearshift cam stopper bolt (b): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)



I944H1520055-01




I944H1520056-02

- Check the gearshift cam stopper moves smoothly.
- Locate the gearshift cam in the neutral position.
- Install the gearshift cam stopper plate (6).


NOTE

Align the gearshift cam pins "B" with the gearshift cam stopper plate holes "C".




IC11J1520012-01

- Apply a small quantity of thread lock to the gearshift cam stopper plate bolt (7) and tighten it to the specified torque.

 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER "1322" or equivalent)


Tightening torque

Gearshift cam stopper plate bolt (c): 13 N·m (1.3 kgf·m, 9.5 lbf·ft)



IC11J1520013-01

- When installing the gearshift shaft return spring, position the stopper "D" of gearshift arm between the shaft return spring ends "E".
- Install the new snap ring.




I944H1520059-01


- Install the gearshift shaft assembly (8) and washer (9) as shown.

NOTE

Pinch the gearshift arm stopper (10) with return spring ends "F".




IC11J1520014-01




I944H1520061-01

- Install the washer (11) and new snap ring (12).

Special tool

 : 09900-06107 (Snap ring pliers)



IC11J1520015-01

- After installing the gearshift lever, check the gearshift lever height. Refer to "Gearshift Lever Height Inspection and Adjustment" (Page 5B-14).

Gearshift Linkage Inspection

BENC11J15206016

Gearshift Shaft

Check the gearshift shaft for bend or wear.
Check the return spring for damage or fatigue.
If any defects are found, replace the defective part(-s).



1944H1520063-01

Gearshift Shaft Oil Seal

Inspect the gearshift shaft oil seal lip for damage or wear. If any defect is found, replace the oil seal with a new one.




IC11J1520016-01

Gearshift Shaft Oil Seal Removal and Installation

BENC11J15206017

Removal

- 1) Remove the gearshift shaft. Refer to "Gearshift Shaft / Gearshift Cam Plate Removal and Installation" (Page 5B-15).
- 2) Remove the gearshift shaft oil seal (1).



IC11J1520017-01

Installation

Install the oil seal in the reverse order of removal. Pay attention to the following points:


- Install the new oil seal (1) with the special tool.

Special tool

 (A): 09913-70210 (Bearing installer set)

- Apply grease to the oil seal lip.

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



IC11J1520018-01

Specifications

Service Data

BENC11J15207001

Transmission + Drive Chain

Unit: mm (in) Except ratio

Item		Standard	Limit
Primary reduction ratio		2.088 (71/34)	—
Final reduction ratio		3.133 (47/15)	—
Gear ratios	Low	2.461 (32/13)	—
	2nd	1.777 (32/18)	—
	3rd	1.380 (29/21)	—
	4th	1.125 (27/24)	—
	5th	0.961 (25/26)	—
	Top	0.851 (23/27)	—
Shift fork to groove clearance		No. 1, No. 2 & No. 3 0.1 – 0.3 (0.004 – 0.012)	0.5 (0.020)
Gearshift fork groove width		No. 1, No. 2 & No. 3 5.5 – 5.6 (0.217 – 0.220)	—
Gearshift fork thickness		No. 1, No. 2 & No. 3 5.3 – 5.4 (0.209 – 0.213)	—
Gearshift lever height		20 – 30 (0.8 – 1.2)	—

Tightening Torque Specifications

BENC11J15207002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Gear position switch mounting bolt	6.5	0.65	4.7	☞ (Page 5B-13)
Gearshift arm stopper	19	1.9	13.5	☞ (Page 5B-16)
Gearshift cam stopper bolt	10	1.0	7.0	☞ (Page 5B-16)
Gearshift cam stopper plate bolt	13	1.3	9.5	☞ (Page 5B-17)

NOTE

The tightening torque(s) also specified in:

- “Transmission Components” (Page 5B-2)
- “Gearshift Lever Construction” (Page 5B-13)
- “Gearshift Shaft / Gearshift Cam Plate Components” (Page 5B-14)
- “Gearshift Construction” (Page 5B-15)

Reference:

For the tightening torques of fasteners not specified in this section, refer to “Tightening Torque List” in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J15208001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE "A" or equivalent	P/No.: 99000-25010	☞ (Page 5B-4) / ☞ (Page 5B-12) / ☞ (Page 5B-13) / ☞ (Page 5B-18)
Thread lock cement	THREAD LOCK CEMENT SUPER 1303 or equivalent	P/No.: 99000-32030	☞ (Page 5B-16)
	THREAD LOCK CEMENT SUPER "1322" or equivalent	P/No.: 99000-32110	☞ (Page 5B-13) / ☞ (Page 5B-17)

NOTE

Required service material(s) also described in:

"Transmission Components" (Page 5B-2)







"Gearshift Lever Construction" (Page 5B-13)

"Gearshift Shaft / Gearshift Cam Plate Components" (Page 5B-14)

"Gearshift Construction" (Page 5B-15)

Special Tool

BENC11J15208002

09900-06107 Snap ring pliers (Open type) ☞ (Page 5B-15) / ☞ (Page 5B-15) / ☞ (Page 5B-17)		09900-20102 Vernier calipers (200 mm) ☞ (Page 5B-9) / ☞ (Page 5B-9)	
09900-20804 Thickness gauge ☞ (Page 5B-8)		09913-50121 Oil seal remover ☞ (Page 5B-10)	
09913-70210 Bearing installing set (10 – 75 Φ) ☞ (Page 5B-11) / ☞ (Page 5B-11) / ☞ (Page 5B-12) / ☞ (Page 5B-18)		09921-20240 Bearing remover set ☞ (Page 5B-10) / ☞ (Page 5B-11)	

Clutch

Precautions

Precautions for Clutch System

BENC11J15300001

Refer to "General Precautions" in Section 00 (Page 00-1).

Diagnostic Information and Procedures

Clutch System Symptom Diagnosis

BENC11J15304001

Condition	Possible cause	Correction / Reference Item
Engine is noisy (Noise seems to come from the clutch)	Worn countershaft spline.	<i>Replace countershaft.</i>
	Worn clutch hub spline.	<i>Replace clutch hub.</i>
	Worn clutch plate teeth.	<i>Replace clutch plate.</i>
	Distorted clutch plate, driven and drive.	<i>Replace.</i>
	Worn clutch release bearing.	<i>Replace.</i>
	Weakened clutch dampers.	<i>Replace primary driven gear.</i>
Clutch slips	Weakened clutch springs.	<i>Replace.</i>
	Worn or distorted clutch pressure plate.	<i>Replace.</i>
	Distorted clutch plates.	<i>Replace.</i>
	Clutch cable play out of adjustment.	<i>Adjust.</i>
Clutch drags	Clutch cable play out of adjustment.	<i>Adjust.</i>
	Some clutch springs are weak, while others are not.	<i>Replace.</i>
	Worn or distorted clutch pressure plates.	<i>Replace.</i>
	Distorted clutch plates.	<i>Replace.</i>


Repair Instructions

Clutch Lever Position Switch Inspection

BENC11J15306001

Inspect the clutch lever position switch in the following procedures:

- 1) Disconnect the clutch lever position switch coupler (1).



IC11J1530001-01

- 2) Inspect the clutch lever position switch for continuity with the tester.
If any abnormality is found, replace the switch with a new one.

Special tool

TOP : 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (••)

Color Position	B/W	B/Y
OFF		
ON	○	○

B944H1530002-01

- 3) Connect the clutch lever position switch lead wire.

Clutch Cable Inspection and Adjustment

BENC11J15306002


Refer to "Clutch System Inspection" in Section 0B (Page 0B-14).

Clutch Cable Removal and Installation

BENC11J15306003

Removal

- 1) Fully loosen the cable adjuster lock-nut (1) and adjuster (2).




IC11J1530002-02

- 2) Loosen the cable lock-nut (3) and adjuster (4).

NOTE


Align the clutch lever, cable lock-nut (3) and adjuster (4) with the cutaway.

- 3) Disconnect the clutch cable (5). (clutch lever side)



IC11J1530003-02

- 4) Disconnect the clutch cable (6). (engine side)



IC11J1530004-01

- 5) Remove the clutch cable as shown in the cable routing diagram. Refer to "Throttle Cable Routing Diagram" in Section 1D (Page 1D-2).


Installation

Install the clutch cable in the reverse order of removal. Pay attention to the following point:

- Install the clutch cable as shown in the cable routing diagram. Refer to "Throttle Cable Routing Diagram" in Section 1D (Page 1D-2).
- After install the removed parts, adjust the clutch cable play. Refer to "Clutch System Inspection" in Section 0B (Page 0B-14).

Clutch Lever Components

BENC11J15306004



IC11J1530005-01


1. Adjuster	5. Oil seal	9. Clutch push rod (left)
2. Lock-nut	6. Bearing	(a) : 6.5 N·m (0.65 kgf-m, 4.7 lbf-ft)
3. Clutch lever	7. Clutch release camshaft	AH : Apply grease.
4. Clutch lever position switch	8. Clutch push rod cap	X : Do not reuse.

Clutch Lever Removal and Installation

BENC11J15306005


Removal

- 1) Disconnect the clutch cable (1) (Clutch lever side). Refer to "Clutch Cable Removal and Installation" (Page 5C-2).
- 2) Remove the following parts from the left handle bar.
 - a) Rear view mirror (2)
 - b) Clutch lever position switch coupler (3)
 - c) Left handlebar switch box (4)
 - d) Handlebar balancer (5)
 - e) Grip rubber (6)
 - f) Clutch lever assembly (7)



IC11J1530006-01

- 3) Remove the clutch lever position switch (8) and clutch lever (9).





IC11J1530042-01

Installation

Install the clutch lever in the reverse order of removal. Pay attention to the following points:

- Apply grease to the clutch lever pivot bolt.

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



IC11J1530043-03


- Install the left handlebar components. Refer to "Handlebars Removal and Installation" in Section 6B (Page 6B-3).
- After install the removed parts, adjust the clutch cable play. Refer to "Clutch System Inspection" in Section 0B (Page 0B-14).

Clutch Push Rod (Left) / Clutch Release Camshaft Removal and Installation

BENC11J15306006


Removal

- 1) Remove the generator cover. Refer to "Generator Removal and Installation" in Section 1J (Page 1J-4).
- 2) Remove the clutch push rod (1).




IS44H1530010-01

- 3) Remove the clutch push rod cap (2).
- 4) Pull out the oil seal (3), bearing (4) with the clutch release camshaft (5).



I944H1530011-01

- 5) Remove the bearing (6) and oil seal (7).




I944H1530012-01

Installation


Install the clutch push rod (left) / clutch release camshaft in the reverse order of removal. Pay attention to the following points:

- Apply grease to the new bearings, new oil seals, release camshaft and clutch push rod cap.


 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)

NOTE

The stamped mark side of the bearing face upside.





I944H1530013-01



I944H1530014-01

- Apply a small quantity of grease to the clutch push rod.

 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



I944H1530015-02

- Install the generator cover. Refer to "Generator Removal and Installation" in Section 1J (Page 1J-4).

Clutch Push Rod (Left) Inspection

BENC11J15306007

Inspect the push rod in the following procedures:

- 1) Remove the clutch push rod (left). Refer to "Clutch Push Rod (Left) / Clutch Release Camshaft Removal and Installation" (Page 5C-4).
- 2) Inspect the clutch push rod (left) for wear or bend. If any defects are found, replace it with a new one.




I944H1530016-01

- 3) Reinstall the removed parts. Refer to "Clutch Push Rod (Left) / Clutch Release Camshaft Removal and Installation" (Page 5C-4).

Clutch Components

BENC11J15306008




IC11J1530007-01

1. Clutch pressure plate	9. Spring washer seat	: 10 N·m (1.0 kgf·m, 7.0 lbf·ft)
2. Thrust washer	10. Clutch sleeve hub nut lock washer	: 50 N·m (5.0 kgf·m, 36.0 lbf·ft)
3. Bearing	11. Clutch sleeve hub	: 5 N·m (0.5 kgf·m, 3.7 lbf·ft)
4. Clutch push piece	12. Thrust washer	: Apply engine oil.
5. No.1 drive plate	13. Primary driven gear assembly	: Apply grease.
6. Driven plate	14. Spacer	: Do not reuse.
7. No.2 drive plate	15. Clutch push rod (right)	
8. Spring washer	16. Oil seal	

Clutch Removal


BENC11J15306009

- 1) Drain engine oil and coolant. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10) and "Cooling System Inspection" in Section 0B (Page 0B-12).
- 2) Remove the rear brake light switch (1) and front footrest bracket (RH) (2).



IC11J1530008-01

- 3) Disconnect the radiator outlet hose (3), water bypass hose (4), oil cooler hose (5) and crankcase breather (PCV) hose (6).




IC11J1530009-02

- 4) Remove the clutch cover (7) by removing the bolts.



IC11J1530010-02

- 5) Remove the gasket (8) and dowel pins (9).




IC11J1530011-02

- 6) Remove the clutch springs and clutch pressure plate (10).


NOTE

Loosen the clutch spring set bolts little by little and diagonally.



IC11J1530012-02


- 7) Remove the clutch drive plates (11) and driven plates (12).



IC11J1530013-02


5C-8 Clutch:

- 8) Remove the spring washer (13) and spring washer seat (14).



IC11J1530014-02

- 9) Remove the thrust washer (15), bearing (16) and clutch push piece (17).




IC11J1530015-02

- 10) Remove the clutch push rod (right) (18).


NOTE

If it is difficult to pull out the push rod (right) (18), use a magnetic hand or a wire.



IC11J1530016-01


- 11) Flatten the clutch sleeve hub nut lock washer.




IC11J1530017-01

- 12) Hold the clutch sleeve hub with the special tool and remove the clutch sleeve hub nut.


Special tool

 (A): 09920-53740 (Clutch sleeve hub holder)




IC11J1530018-01

- 13) Remove the lock washer (19) and clutch sleeve hub (20).




IC11J1530019-02

- 14) Remove the thrust washer (21) and primary driven gear assembly (22).



IC11J1530020-01


- 15) Remove the spacer (23).




IC11J1530021-01

- 16) Remove the snap ring (24), oil pump drive gear (25) and pin (26).

Special tool

 : 09900-06107 (Snap ring pliers)




IC11J1530022-01

Clutch Installation

BENC11J15306010

- 1) Install the pin (1).
- 2) When installing the oil pump drive gear (2), align the pin (1) with the slot "A" with the flange side "B" of the oil pump drive gear facing the primary drive gear.




I944H1530031-02

- 3) Install the new snap ring (3).

▲ CAUTION

The removed snap ring (3) must be replaced with a new one.

Special tool

 : 09900-06107 (Snap ring pliers)



I944H1530032-01

- 4) Install the spacer (4) and apply engine oil to it.



IC11J1530023-01


5C-10 Clutch:

- 5) Install the primary driven gear assembly (5) onto the countershaft.


NOTE

When installing the primary driven gear assembly (5), align the teeth of the primary drive gears (6) by inserting a suitable bar to the holes of them.

Be sure to engage the oil pump driven gear (7) and oil pump drive gear (2), primary drive (6) and driven gears (8).




- 6) Install the thrust washer (9).



- 7) Install the clutch sleeve hub (10) and new lock washer (11).
8) Install the clutch sleeve hub nut (12).


NOTE

The chamfer side of clutch sleeve hub nut (12) faces outward.



- 9) Hold the clutch sleeve hub with the special tool and tighten the clutch sleeve hub nut (13) to the specified torque.

Special tool

 (A): 09920-53740 (Clutch sleeve hub holder)

Tightening torque

Clutch sleeve hub nut (a): 50 N·m (5.0 kgf-m, 36.0 lbf-ft)




- 10) Bend the lock washer to lock nut securely.




- 11) Install the clutch push rod (14) into the countershaft.
12) Install the clutch push piece (15), the bearing (16) and thrust washer (17) to the countershaft.

NOTE

Thrust washer is located between the pressure plate and bearing (16).



- 13) Install the spring washer seat (18) and spring washer (19) onto the clutch sleeve hub correctly.




I944H1530041-03

- 14) Apply engine oil to the clutch drive plates and driven plates.

- 15) Insert the clutch drive plates and driven plates one by one into the clutch sleeve hub in the prescribed order.



IC11J1530029-01




I944H1530043-02

20. No. 2 drive plate	22. Driven plate
21. No. 1 drive plate	"A": Direction of outside

NOTE

Two kinds of the drive plate (No. 1 and No. 2) are equipped in the clutch system, they can be distinguished by the inside diameter "B".



I944H1530044-03

Drive plate	I.D. "B"
No. 1 (21)	116 mm (4.6 in)
No. 2 (20)	122.5 mm (4.82 in)

- 16) Install the clutch pressure plate (23), clutch springs and washers.


- 17) Tighten the clutch spring set bolts to the specified torque.

NOTE

Tighten the clutch spring set bolts diagonally.

Tightening torque

Clutch spring set bolt (b): 10 N·m (1.0 kgf-m, 7.0 lbf-ft)



IC11J1530039-02

- 18) Loosen the lock-nut (24) and turn in the release screw (25) to feel resistance.

- 19) From that position, turn out the release screw (25) 1 turn and tighten the lock-nut (24) to the specified torque by holding the release screw (25).

Tightening torque

Release screw lock-nut (c): 5 N·m (0.5 kgf-m, 3.7 lbf-ft)




IC11J1530040-02

5C-12 Clutch:


- 20) Install the new gasket (26) and the dowel pins (27).
21) Install the clutch cover (28).

NOTE

When installing the clutch cover (28), align the teeth of water pump drive (29) with the water pump driven gear (30).



IC11J1530041-03



IC11J1530031-01

- 22) Tighten the clutch cover bolts.


NOTE

- Fit the clamp to the bolt "C".
- Route the drain hose "D". Refer to "Water Hose Routing Diagram" in Section 1F (Page 1F-3).




IC11J1530030-01

- 23) Connect the crankcase breather (PCV) hose (31), oil cooler hose (32), water bypass hose (33) and radiator outlet hose (34) securely. Refer to "Throttle Body Construction" in Section 1D (Page 1D-8) and "Water Hose Routing Diagram" in Section 1F (Page 1F-3).



IC11J1530032-01


- 24) Pour engine oil and coolant. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10) and "Cooling System Inspection" in Section 0B (Page 0B-12).
25) Install the front footrest bracket (RH) (35) and tighten the front footrest bracket bolts to the specified torque.

 : Thread lock cement 99000-32110 (THREAD LOCK CEMENT SUPER "1322" or equivalent)

Tightening torque

Front footrest bracket bolt (d): 26 N·m (2.6 kgf·m, 19.0 lbf·ft)

- 26) Install rear brake light switch (36).



IC11J1530033-02

- 27) Adjust rear brake light switch. Refer to "Rear Brake Light Switch Inspection and Adjustment" in Section 4A (Page 4A-5).

Clutch Parts Inspection

BENC11J15306011


Clutch Drive and Driven Plate

NOTE

Wipe off the engine oil from the drive and driven plates with a clean rag.

Measure the thickness of drive plates with a vernier calipers. If the drive plate thickness is found to have reached the limit, replace it with a new one.

Special tool

 (A): 09900-20102 (Vernier calipers (1/20 mm, 200 mm))

Clutch drive plate thickness


Service limit (No.1 and No.2): 2.62 mm (0.103 in)



I649G1530056-03


Measure the claw width of drive plates with a vernier calipers. Replace the drive plates found to have worn down to the limit.

Special tool

 (A): 09900-20102 (Vernier calipers (1/20 mm, 200 mm))

Clutch drive plate claw width

Service limit (No.1 and No.2): 12.9 mm (0.508 in)



I649G1530057-03

Measure each driven plate for distortion with a thickness gauge and surface plate.


Replace driven plates which exceed the limit.

Special tool

 (B): 09900-20804 (Thickness gauge)

Clutch driven plate distortion

Service limit: 0.10 mm (0.004 in)




I649G1530058-03

Clutch Spring


Measure the free length of each coil spring with a vernier calipers, and compare the length with the specified limit. Replace all the springs if any spring is not within the limit.

Special tool

 (A): 09900-20102 (Vernier calipers (1/20 mm, 200 mm))

Clutch spring free length

Service limit: 57.6 mm (2.27 in)



I718H1530062-01

Clutch Release Bearing

Inspect the clutch release bearing for any abnormality, especially cracks. When removing the bearing from the clutch, decide whether it can be reused or if it should be replaced.

Smooth engagement and disengagement of the clutch depends on the condition of this bearing.



I944H1530049-01

5C-14 Clutch:

Push Rod (Right)

Inspect the push rod for bend and damage. If any defects are found, replace the push rod with a new one.



1944H1530050-01

Clutch Sleeve Hub and Primary Driven Gear Assembly

Inspect the slot of the clutch sleeve hub and primary driven gear assembly for damage or wear caused by the clutch plates. If necessary, replace it with a new one. Inspect the primary driven gear bushing for any damage. Inspect the spring of primary driven gear for any damages. If necessary, replace it with a new one.



1944H1530051-01



1944H1530052-01

Primary Drive Gear Removal and Installation

BENC11J15306012

Removal


- 1) Remove the clutch cover. Refer to "Clutch Removal" (Page 5C-7).
- 2) Hold the clutch pressure plate with the special tool and loosen the primary drive gear bolt.

Special tool

 (A): 09930-40113 (Rotor holder)


NOTE

This bolt has left-hand thread.




IC11J1530034-01

- 3) Remove the clutch components (1). Refer to "Clutch Removal" (Page 5C-7).



IC11J1530035-01

- 4) Remove the primary drive gear bolt (2), water pump drive gear (3) and primary drive gear assembly (4).




IC11J1530036-01

Installation

CAUTION

This primary drive gear bolt has left-hand thread.

- 1) Install the primary drive gear assembly (1) and water pump drive gear (2).
- 2) Temporarily tighten the primary drive gear bolt (3).



IC11J1530037-01


- 3) Install the clutch components. Refer to "Clutch Installation" (Page 5C-9).
- 4) While holding the clutch pressure plate with the special tool, tighten the primary drive gear bolt (3) to the specified torque.

Special tool

(A): 09930-40113 (Rotor holder)

Tightening torque

Primary drive gear bolt (a): 70 N·m (7.0 kgf-m, 50.5 lbf-ft)



IC11J1530038-01

- 5) Install the clutch cover. Refer to "Clutch Installation" (Page 5C-9).

Primary Drive Gear Inspection

BENC11J15306013

Inspect the primary drive gear in the following procedures:

- 1) Remove the primary drive gear assembly. Refer to "Primary Drive Gear Removal and Installation" (Page 5C-14).
- 2) Visually inspect the gear teeth for wear and damage. If they are worn, replace the gear with a new one. Refer to "Primary Drive Gear Disassembly and Assembly" (Page 5C-16).



I944H1530059-01

- 3) Install the primary drive gear assembly. Refer to "Primary Drive Gear Removal and Installation" (Page 5C-14).



I944H1530059-01

NOTE

(1) Set the torque (1) into the groove.
(2) Insert the rotor gear (2).

NOTE

Align the hole of the primary drive gear with the hole of the rotor gear.



I944H1530059-01

Primary Drive Gear Disassembly and Assembly

BENC11J15306014


Disassembly

Remove the following parts from the primary drive gear.


- Snap ring (1)
- Spring washer (2)
- Scissors gear (3)
- Springs (4)
- Primary drive gear (5)

Special tool

TOOL : 09900-06107 (Snap ring pliers)



1944H1530060-01




1944H1530061-01

Reassembly

- 1) Set the springs (1) into the grooves.
- 2) Install the scissors gear (2).

NOTE

Align the hole of the primary drive gear with the hole of the scissors gear.




1944H1530062-01

- 3) Install the spring washer (3) not to cover the holes of the gears.

NOTE

The convex side of the spring washer (3) faces upward.



1944H1530063-01


- 4) Install the new snap ring (4).

Special tool

TOOL : 09900-06107 (Snap ring pliers)

NOTE

After installing a snap ring, always insure that it is completely seated in its groove and securely fitted.



1944H1530064-01

Specifications

Service Data

BENC11J15307001

Clutch

Unit: mm (in)

Item	Standard		Limit
Clutch cable play	10 – 15 (0.4 – 0.6)		—
Clutch release screw	1 turn back		—
Clutch drive plate thickness	No. 1, 2	2.92 – 3.08 (0.115 – 0.121)	2.62 (0.103)
Clutch drive plate claw width	No. 1, 2	13.7 – 13.8 (0.539 – 0.543)	12.9 (0.508)
Clutch driven plate distortion	—		0.10 (0.004)
Clutch spring free length	60.6 (2.39)		57.6 (2.27)

Tightening Torque Specifications

BENC11J15307002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Clutch sleeve hub nut	50	5.0	36.0	☞(Page 5C-10)
Clutch spring set bolt	10	1.0	7.0	☞(Page 5C-11)
Release screw lock-nut	5	0.5	3.7	☞(Page 5C-11)
Front footrest bracket bolt	26	2.6	19.0	☞(Page 5C-12)
Primary drive gear bolt	70	7.0	50.5	☞(Page 5C-15)

NOTE

The tightening torque(s) also specified in:

“Clutch Lever Components” (Page 5C-3)

“Clutch Components” (Page 5C-6)

Reference:

For the tightening torques of fasteners not specified in this section, refer to “Tightening Torque List” in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J15308001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE "A" or equivalent	P/No.: 99000-25010	☞ (Page 5C-4) / ☞ (Page 5C-5) / ☞ (Page 5C-5)
Thread lock cement	THREAD LOCK CEMENT SUPER "1322" or equivalent	P/No.: 99000-32110	☞ (Page 5C-12)

NOTE







Required service material(s) also described in:

"Clutch Lever Components" (Page 5C-3)

"Clutch Components" (Page 5C-6)

Special Tool

BENC11J15308002

09900-06107 Snap ring pliers (Open type) ☞ (Page 5C-9) / ☞ (Page 5C-9) / ☞ (Page 5C-16) / ☞ (Page 5C-16)		09900-20102 Vernier calipers (200 mm) ☞ (Page 5C-13) / ☞ (Page 5C-13) / ☞ (Page 5C-13)	
09900-20804 Thickness gauge ☞ (Page 5C-13)		09900-25008 Multi circuit tester set ☞ (Page 5C-2)	
09920-53740 Clutch sleeve hub holder ☞ (Page 5C-8) / ☞ (Page 5C-10)		09930-40113 Flywheel rotor holder ☞ (Page 5C-14) / ☞ (Page 5C-15)	

Section 6

Steering

CONTENTS

Precautions	6-1	Handlebars Inspection	6B-4
Precautions	6-1	Steering Components	6B-5
Precautions for Steering	6-1	Steering Removal and Installation	6B-5
Steering General Diagnosis	6A-1	Steering Related Parts Inspection.....	6B-8
Diagnostic Information and Procedures	6A-1	Steering System Inspection	6B-8
Steering Symptom Diagnosis.....	6A-1	Steering Stem Bearing Removal and Installation	6B-9
Steering / Handlebar	6B-1	Steering Tension Adjustment	6B-10
Repair Instructions	6B-1	Specifications	6B-10
Handlebars Components	6B-1	Tightening Torque Specifications	6B-10
Handlebar Construction	6B-2	Special Tools and Equipment	6B-11
Handlebars Removal and Installation	6B-3	Recommended Service Material	6B-11
		Special Tool	6B-11

Steering General Diagnosis

Diagnostic Information and Procedures

Steering Symptom Diagnosis

BENC11J16104001



Condition	Possible cause	Correction / Reference Item
Heavy Steering	Over tightened steering stem nut.	<i>Adjust.</i>
	Broken bearing in steering stem.	<i>Replace.</i>
	Distorted steering stem.	<i>Replace.</i>
	Not enough pressure in tires.	<i>Adjust.</i>
Wobbly Handlebars	Loss of balance between right and left front forks.	<i>Replace fork or adjust fork oil level or replace spring.</i>
	Distorted front fork.	<i>Repair or replace.</i>
	Distorted front axle or crooked tire.	<i>Replace.</i>
	Loose steering stem nut.	<i>Adjust.</i>
	Worn or incorrect tire or wrong tire pressure.	<i>Adjust or replace.</i>
	Worn bearing/race in steering stem.	<i>Replace.</i>

Steering / Handlebar

Repair Instructions

Handlebars Components

BENC11J16206001




IC11J1620024-01

1. Throttle grip	5. Handle outer expander	"A": Apply handle grip bond.
2. Handlebars	6. Handle balancer screw	: 5.5 N·m (0.55 kgf·m, 4.0 lbf·ft)
3. Grip rubber	7. Right handlebar switch box	
4. Handle inner expander	8. Left handlebar switch box	

Handlebar Construction

BENC11J16206002



IC11J1620025-01


1. Front brake master cylinder	"A": Punch mark	(a) : 10 N·m (1.0 kgf·m, 7.0 lbf·ft)
2. Handlebar holder	"B": UP mark	(b) : 23 N·m (2.3 kgf·m, 16.5 lbf·ft)
3. Washer : The conical side of washer faces outside.	"a": Clearance	

Handlebars Removal and Installation

BENC11J16206003

Removal

- 1) Disconnect the clutch cable (1) (Clutch lever side). Refer to "Clutch Cable Removal and Installation" in Section 5C (Page 5C-2).
- 2) Remove the following parts from the left handle bar.
 - a) Rear view mirror (2)
 - b) Clutch lever position switch coupler (3)
 - c) Left handlebar switch box (4)
 - d) Handlebar balancer (5)
 - e) Grip rubber (6)
 - f) Clutch lever assembly (7)




IC11J1530006-01

- 3) Remove the following parts from the right handlebar.
 - a) Rear view mirror (8)
 - b) Right handlebar switch box (9)
 - c) Handlebar balancer (10)
 - d) Throttle grip (11)
 - e) Front brake master cylinder/Front brake lever (12)


NOTE

Do not turn the front brake master cylinder upside down.



IC11J1620001-02

- 4) Remove the caps and handlebar holder bolts.




IC11J1620002-01

- 5) Remove the handlebars.

Installation


Install the handlebars in the reverse order of removal. Pay attention to the following points:

- Install the washers (1) and bolts (2) as shown in the handlebar construction. Refer to "Handlebar Construction" (Page 6B-2).



IC11J1620003-01

- Set the handlebars so that its punch mark "A" aligns with the mating surface of the left handlebar holder.
- Set the handlebar holders with their punch marks "B" forward.



IC11J1620004-01


- Tighten the handlebar holder bolts.

NOTE


First tighten the handlebar holder bolts (2) (front ones) to the specified torque.

Tightening torque

Handlebar holder bolt (a): 23 N·m (2.3 kgf-m, 16.5 lbf-ft)




- Install the front brake master cylinder. Refer to "Front Brake Master Cylinder Assembly Removal and Installation" in Section 4A (Page 4A-10).
- Apply grease to the end of the throttle cables and cable pulley.
 - 🔧 : Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)
- Insert the projection "C" of the right handlebar switch box into the hole of the handlebars.




- Apply a handle grip bond "D" onto the left handlebar before installing the handlebar grip.

🔧 : Handle grip bond (Handle Grip Bond (commercially available))



- Install the clutch lever assembly. Refer to "Clutch Lever Removal and Installation" in Section 5C (Page 5C-4).
- Insert the projection "E" of the left handlebar switch box into the hole of the handlebars.





- Route the wiring harness and cable routing. Refer to "Throttle Cable Routing Diagram" in Section 1D (Page 1D-2) and "Wiring Harness Routing Diagram" in Section 9A (Page 9A-7).
- After installing the steering, the following adjustments are required before driving.
 - Throttle cable play (Refer to "Throttle Cable Routing Diagram" in Section 1D (Page 1D-2))
 - Clutch cable play (Refer to "Throttle Cable Play Inspection and Adjustment" in Section 0B (Page 0B-12))
 - Throttle cable play (Refer to "Throttle Cable Play Inspection and Adjustment" in Section 0B (Page 0B-12))

Handlebars Inspection

BENC11J16206004

Inspect the handlebars for distortion and damage. If any defect is found, replace the handlebars with a new one.





IC11J1620026-01


1. Steering stem head nut	7. Washer	(a) : 23 N·m (2.3 kgf-m, 16.5 lbf-ft)
2. Handlebar holder bolt	8. Dust seal	(b) : 90 N·m (9.0 kgf-m, 65.0 lbf-ft)
3. Handlebar holder	9. Steering stem upper bearing	(c) : 80 N·m (8.0 kgf-m, 58.0 lbf-ft)
4. Steering stem upper bracket	10. Steering stem lower bearing	(d) : 45 N·m (4.5 kgf-m, 32.5 lbf-ft) → turn counterclockwise 1/4 – 1/2.
5. Steering stem lock-nut	11. Lower seal	AH : Apply grease.
6. Steering stem nut	12. Steering stem lower bracket	

Steering Removal and Installation

BENC11J16206006

Removal



- 1) Remove the front wheel assembly. Refer to "Front Wheel Assembly Removal and Installation" in Section 2D (Page 2D-4).
- 2) Remove the front forks. Refer to "Front Fork Removal and Installation" in Section 2B (Page 2B-2).
- 3) Remove the brake hose clamp (1).




IC11J1620007-01

- 4) Remove the ignition switch mounting bolts (2) with the special tools (for E-03, 24, 28, 33).


Special tool

-  (A): 09930-11920 (Torx® bit (JT40H))
 (B): 09930-11940 (Torx® bit holder (3/8 sq.))




IC11J1620008-01

- 5) Disconnect the ignition switch lead wire coupler (for E-21). Refer to "Ignition Switch Removal and Installation (for E-03, 24, 28, 33)" in Section 1H (Page 1H-11).
- 6) Remove the steering lock cover (for E-03, 28, 33) (3) or immobilizer antenna (for E-21, 24).



IC11J1620009-01

- 7) Remove the handlebars. Refer to "Handlebars Removal and Installation" (Page 6B-3).
- 8) Remove the steering stem head nut (4) and washer (5).
Remove the steering stem upper bracket (6).





IC11J1620010-01

- 9) Remove the steering stem lock-nut (7), washer and steering stem nut (8) with the special tools.


NOTE

When loosening the stem nut (8), hold the steering stem lower bracket to prevent it from falling.

Special tool


-  (C): 09940-14911 (Steering stem nut wrench)
 (D): 09940-14960 (Steering stem nut socket wrench)

- 10) Remove the steering stem lower bracket.




IC11J1620011-01

- 11) Remove the dust seal (9), upper bearing inner race (10) and bearing (11).



IC11J1620012-01


- 12) Remove the lower bearing (12).



IC11J1620013-01

6B-7 Steering / Handlebar:

- 13) Remove the ignition switch (for E-21). Refer to "Ignition Switch Removal and Installation (for E-03, 24, 28, 33)" in Section 1H (Page 1H-11).
- 14) Remove the clamps (13).



IC11J1620014-02


Installation

Install the steering in the reverse order of removal. Pay attention to the following points:

Bearing

- Apply grease to the bearings, races and dust seals before remounting the steering stem.

⚠ Grease 99000-25010 (SUZUKI SUPER GREASE "A" or equivalent)



IC11J1620015-01

Steering stem nut

- Tighten the steering stem nut (1) to the specified torque using the special tool.


Special tool

TOOL (A): 09940-14911 (Steering stem nut wrench)

TOOL (B): 09940-14960 (Steering stem nut socket wrench)

Tightening torque

Steering stem nut (a): 45 N·m (4.5 kgf·m, 32.5 lbf·ft) → turn counterclockwise 1/4 - 1/2.




IC11J1620016-01

- Turn the steering stem lower bracket about five or six times to the left and right so that the angular ball bearings seat properly.
- Loosen the steering stem nut 1/4 - 1/2 turn "a".


NOTE

This adjustment will vary from motorcycle to motorcycle.



1649G1620026-02



- When installing the washer (2), align the lug of the washer to the groove of the steering stem.



IC11J1620017-01


- Tighten the steering stem lock-nut (3) to the specified torque using the special tools.

Special tool

-  (A): 09940-14911 (Steering stem nut wrench)
-  (B): 09940-14960 (Steering stem nut socket wrench)

Tightening torque

Steering stem lock-nut (b): 80 N·m (8.0 kgf-m, 58.0 lbf-ft)



IC11J1620018-01

Steering stem upper bracket

Install the front forks and steering stem upper bracket in the following steps:

- 1) Temporarily install the upper bracket, washer and steering stem head nut (1).
- 2) Temporarily install the front forks.
- 3) Tighten the steering stem head nut (1).

Tightening torque

Steering stem head nut (a): 90 N·m (9.0 kgf-m, 65.0 lbf-ft)



IC11J1620019-02

- 4) Tighten the front fork upper and lower clamp bolts. Refer to "Front Fork Removal and Installation" in Section 2B (Page 2B-2).

Inspection After Installation

- Check the steering tension. Refer to "Steering Tension Adjustment" (Page 6B-10).

Steering Related Parts Inspection

BENC11J16206007

Refer to "Steering Removal and Installation" (Page 6B-5).


Inspect the removed parts for the following abnormalities.

- Distortion of the steering stem
- Bearing wear or damage
- Abnormal bearing noise
- Race wear or damage
- Bearing lower seal damage
- Rubber dust seal wear or damage

If any abnormal points are found, replace defective parts with new ones. Refer to "Ignition Switch Removal and Installation (for E-03, 24, 28, 33)" in Section 1H (Page 1H-11).



IC11J1620020-01



IC11J1620021-01

Steering System Inspection

BENC11J16206008


Refer to "Steering System Inspection" in Section 0B (Page 0B-20).

Steering Stem Bearing Removal and Installation

BENC11J16206009


Removal

- 1) Remove the dust seal and steering stem upper bearing. Refer to "Steering Removal and Installation" (Page 6B-5).
- 2) Remove the steering stem lower bearing and inner race using a chisel.



I649G1620033-02

- 3) Remove the steering stem upper and lower bearing races using the steel rod.



I837H1620033-01



Installation


Install the steering stem bearings in the reverse order of removal. Pay attention to the following points:

Outer race

- Press in the new upper and lower outer races using the special tool.

Special tool

-  (A): 09941-34513 (Steering race installer)
-  (B): 09913-70210 (Bearing installing set (10 - 75 Φ))





IC11J1620022-01

Inner race

- Press in the lower inner race and bearing using the special tool.

Special tool

-  (A): 09925-18011 (Bearing installer)



I649G1620036-03

- Install the steering. Refer to "Steering Removal and Installation" (Page 6B-5).

Steering Tension Adjustment

BENC11J16206010

Check the steering movement in the following procedures:


- 1) By supporting the motorcycle with a jack, lift the front wheel unit is off the floor 20 – 30 mm (0.8 – 1.2 in).
- 2) Check to make sure that the cables and wire harnesses are properly routed.
- 3) With the front wheel in the straight ahead state, hitch the spring scale (special tool) on one handlebar grip end as shown in the figure and read the graduation when the handlebar starts moving.

Initial force

200 – 500 grams

Special tool

 (A): 09940-92720 (Spring scale)





I649G1620040-02

- 4) Do the same on the other grip end.
- 5) If the initial force read on the scale when the handlebar starts turning is either too heavy or too light, adjust it till it satisfies the specification.

- a) First, loosen the front fork upper clamp bolts, steering stem head nut and steering stem lock-nut, and then adjust the steering stem nut by loosening or tightening it.

Special tool

 (B): 09910-60611 (Universal clamp wrench)



IC11J1620023-02

- b) Tighten the steering stem lock-nut, stem head nut and front fork upper and lower clamp bolts to the specified torque and recheck the initial force with the spring scale according to the previously described procedure.
- c) If the initial force is found within the specified range, adjustment has been completed.

NOTE

Hold the front fork legs, move them back and forth and make sure that the steering is not loose.

Specifications

Tightening Torque Specifications

BENC11J16207001

Fastening part	Tightening torque			Note
	N-m	kgf-m	lbf-ft	
Handlebar holder bolt	23	2.3	16.5	☞(Page 6B-4)
Steering stem nut	45 N-m (4.5 kgf-m, 32.5 lbf-ft) → turn counterclockwise 1/4 – 1/2.			☞(Page 6B-7)
Steering stem lock-nut	80	8.0	58.0	☞(Page 6B-8)
Steering stem head nut	90	9.0	65.0	☞(Page 6B-8)

NOTE

The tightening torque(s) also specified in:

“Handlebars Components” (Page 6B-1)

“Handlebar Construction” (Page 6B-2)

“Steering Components” (Page 6B-5)

Reference:

For the tightening torques of fasteners not specified in this section, refer to “Tightening Torque Specifications” in Section 0B (Page 0B-24).

Special Tools and Equipment

Recommended Service Material

BENC11J16208001










Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI SUPER GREASE "A" or equivalent	P/No.: 99000-25010	☞ (Page 6B-4) / ☞ (Page 6B-7)
Handle grip bond	Handle Grip Bond (commercially available)	—	☞ (Page 6B-4)

NOTE

Required service material(s) also described in:
 "Steering Components" (Page 6B-5)

Special Tool

BENC11J16208002

09910-60611 Universal clamp wrench ☞ (Page 6B-10)		09913-70210 Bearing installing set (10 – 75 Φ) ☞ (Page 6B-9)	
09925-18011 Bearing installer ☞ (Page 6B-9)		09930-11920 Torx® bit (JT40H) ☞ (Page 6B-6)	
09930-11940 Torx® bit holder (3/8 sq.) ☞ (Page 6B-6)		09940-14911 Steering stem nut socket wrench ☞ (Page 6B-6) / ☞ (Page 6B-7) / ☞ (Page 6B-8)	
09940-14960 Steering stem nut socket wrench ☞ (Page 6B-6) / ☞ (Page 6B-7) / ☞ (Page 6B-8)		09940-92720 Spring scale ☞ (Page 6B-10)	
09941-34513 Bearing installer ☞ (Page 6B-9)			

Torx® is the registered trademark of Camcar Division of Textron inc. U.S.A.

Section 9

Body and Accessories

CONTENTS

Precautions	9-1	Dimmer Switch Inspection.....	9B-13
Precautions	9-1	Specifications	9B-14
Precautions for Electrical System	9-1	Service Data.....	9B-14
Component Location	9-1	Tightening Torque Specifications.....	9B-14
Electrical Components Location	9-1	Special Tools and Equipment	9B-14
Wiring Systems	9A-1	Special Tool	9B-14
Schematic and Routing Diagram	9A-1	Combination Meter / Fuel Meter / Horn..	9C-1
Wiring Diagram	9A-1	General Description	9C-1
Wiring Harness Routing Diagram.....	9A-7	Combination Meter System Description.....	9C-1
Specifications	9A-10	Repair Instructions	9C-2
Service Data	9A-10	Combination Meter Components	9C-2
Tightening Torque Specifications.....	9A-10	Combination Meter Removal and Installation	9C-2
Special Tools and Equipment	9A-10	Combination Meter Disassembly and	
Recommended Service Material.....	9A-10	Assembly.....	9C-3
Lighting Systems	9B-1	Combination Meter Inspection	9C-3
Repair Instructions	9B-1	Engine Coolant Temperature Indicator Light	
Headlight Construction.....	9B-1	Inspection.....	9C-4
Headlight Components	9B-2	Engine Coolant Temperature Removal and	
Headlight Removal and Installation	9B-3	Installation	9C-6
Headlight Bulb and Position Light Bulb		Fuel Level Indicator Light Inspection.....	9C-6
Replacement.....	9B-3	Fuel Level Gauge Inspection	9C-6
Headlight Beam Adjustment	9B-4	Speedometer Inspection	9C-7
Rear Lighting System Construction.....	9B-5	Speed Sensor Removal and Installation	9C-7
Rear Combination Light Components.....	9B-6	Speed Sensor Inspection	9C-8
Rear Combination Light Removal and		Oil Pressure Indicator Inspection	9C-9
Installation.....	9B-7	Oil Pressure Switch Removal and Installation	9C-9
Rear Combination Light Bulb Replacement.....	9B-7	Ignition Switch Inspection.....	9C-9
License Plate Light Components	9B-8	Ignition Switch Removal and Installation.....	9C-9
License Plate Light Removal and Installation	9B-8	Horn Inspection	9C-10
License Plate Light Bulb Replacement	9B-9	Horn Removal and Installation	9C-10
Front Turn Signal Light Construction	9B-9	Freeze Indicator Light Inspection	9C-10
Turn Signal Light Components	9B-10	Ambient Air Temperature Sensor Removal	
Front Turn Signal Light Removal and		and Installation	9C-11
Installation.....	9B-10	Ambient Air Temperature Sensor Inspection	9C-11
Rear Turn Signal Light Removal and		Select Button Inspection	9C-11
Installation.....	9B-11	Specifications	9C-13
Turn Signal Light Bulb Replacement	9B-11	Service Data.....	9C-13
Turn Signal / Side-stand Relay Inspection.....	9B-12	Tightening Torque Specifications.....	9C-13
Turn Signal / Side-stand Relay Removal and		Special Tools and Equipment	9C-13
Installation.....	9B-12	Special Tool	9C-13
Hazard Switch Inspection	9B-12	Exterior Parts	9D-1
Turn Signal Switch Inspection.....	9B-12	Schematic and Routing Diagram	9D-1
Passing Light Switch Inspection	9B-13	Seat Lock Cable Routing Diagram.....	9D-1

Repair Instructions	9D-2	Body Structure	9E-1
Cowling Construction	9D-2	Repair Instructions	9E-1
Frame Cover Construction	9D-3	Body Frame Construction	9E-1
Rear Fender Construction	9D-3	Front Footrest Construction	9E-2
Sport Carrier Construction	9D-4	Pillion Footrest Construction	9E-2
Fastener Removal and Installation.....	9D-5	Side-stand Construction.....	9E-3
Exterior Parts Removal and Installation	9D-5	Specifications	9E-3
Specifications	9D-12	Tightening Torque Specifications	9E-3
Tightening Torque Specifications.....	9D-12	Special Tools and Equipment	9E-3
Special Tools and Equipment	9D-12	Recommended Service Material	9E-3
Recommended Service Material	9D-12		

Precautions

Precautions

Precautions for Electrical System

Refer to "General Precautions" in Section 00 (Page 00-1) and "Precautions for Electrical Circuit Service" in Section 00 (Page 00-2).

BENC11J19000001

Component Location

Electrical Components Location

Refer to "Electrical Components Location" in Section 0A (Page 0A-9).

BENC11J19003001

Wiring Systems


Schematic and Routing Diagram


Wiring Diagram

Refer to "Wire Color Symbols" in Section 0A (Page 0A-7).

BENC11J19102001

For E-03, 28





9A-3 Wiring Systems:


For E-21, 24


Schematic and Routing Diagram


Wiring Diagram


Routing "Wiring Only Symbols" in Symbols/PLI (page 124-7)

For E-21, 24











Wiring Harness Routing Diagram

BENC11J19102002



IC11J1910901-02


<p>1. Clamp : Clamp the ignition coil lead wire and generator lead wire.</p>	<p>8. Clamp : Clamp the reservoir tank inlet hose.</p>
<p>2. Clamp : Clamp the water drain hose, starter motor lead wire, wire harness, rear brake light switch lead wire and rear wheel speed sensor lead wire.</p>	<p>9. Clamp : Clamp the wire harness and regulator/rectifier lead wires.</p>
<p>3. Clamp : Clamp the wire harness.</p>	<p>10. Fixed clamp</p>
<p>4. Clamp : Clamp the wire harness and radiator inlet hose.</p>	<p>11. Speed sensor</p>
<p>5. Clamp : Clamp the wire harness and side-stand switch lead wire.</p>	<p>12. Clamp : Clamp the side-stand switch lead wires.</p>
<p>6. Clamp : Clamp the side-stand switch lead wire. Set the clamp between the crankcase and engine sprocket outer cover bolt.</p>	<p>*A*: Set the HO2 sensor lead wire coupler and ABS lead wire inside the frame side cover and rear fender (rear).</p>
<p>7. Clamp : Clamp the gear position switch lead wire, generator lead wire, side-stand switch lead wire and speed sensor lead wire.</p>	<p>(a) : 4.5 N·m (0.45 kgf-m, 3.3 lbf-ft)</p>



IC11J1910902-02

1. Ambient air temperature sensor	14. Clutch cable
2. Clamp : Clamp the right handlebar switch lead wire, immobilizer lead wire (E-21, 24) at the gray tape point and ignition switch lead wire.	15. 10 terminals coupler of left handlebar lead wire
3. Clamp : Clamp the right handlebar switch lead wire, immobilizer lead wire (E-21, 24) and ignition switch lead wire.	16. 4 terminals coupler of left handlebar lead wire
4. Clamp : Clamp the stator motor lead wire and oil pressure switch lead wire.	17. Immobilizer lead wire coupler (E-21, 24)
5. Clamp : Clamp the oil pressure switch lead wire.	18. Ignition switch lead wire coupler
6. Clamp : Clamp the right handlebar switch lead wire and grommet sleeve on the front brake hose No.1.	19. Right handlebar switch lead wire coupler
7. Clamp : Clamp the left handlebar switch lead wire and grommet sleeve on the clutch cable.	20. Front wheel speed sensor wire coupler
8. Fixed clamp	A: Pass the immobilizer lead wire, ignition switch lead wire, right handlebar switch lead wire under the front brake pipes.
9. Right handlebar switch lead wire	B: Pass the right handlebar switch lead wire through the guide.
10. Ignition switch lead wire	C: Pass the right handlebar switch lead wire in front of throttle cables. Pass the right handlebar switch lead wire inside throttle cables.
11. Immobilizer lead wire (E-21, 24)	D: Pass the ignition switch lead wire in front of immobilizer lead wire (E-21, 24).
12. Throttle cable	E: Do not twist the ignition switch lead wire.
13. Left handlebar switch lead wire	F: Pass the left handlebar switch lead wire through the guide.

Wiring Harness Routing Diagram



IC11J1910903-02

1. Starter motor lead wire	(a) : 6 N·m (0.6 kgf-m, 4.3 lbf-ft)	(h) : 10 N·m (1.0 kgf-m, 7.0 lbf-ft)
2. Oil pressure switch lead wire	(b) : 14 N·m (1.4 kgf-m, 10.0 lbf-ft)	"a": 90°
3. Battery (-) lead wire	(c) : 1.5 N·m (0.15 kgf-m, 1.1 lbf-ft)	"b": Max. 45°
4. Side-stand switch lead wire	(d) : 6.5 N·m (0.65 kgf-m, 4.7 lbf-ft)	"c": 45°
5. Speed sensor lead wire	(e) : 4.5 N·m (0.45 kgf-m, 3.3 lbf-ft)	"d": 15 – 25 mm (0.6 – 1.0 in)
6. Generator lead wire	(f) : 11 N·m (1.1 kgf-m, 8.0 lbf-ft)	"e": 40°
7. Gear position switch lead wire	(g) : 140 N·m (14.0 kgf-m, 101.5 lbf-ft)	(322) : Apply thread lock to thread part.

Specifications

Service Data

BENC11J1910S001

Electrical

Item		Specification	Note
Fuse size	Headlight	HI	15 A
		LO	15 A
	Ignition	10 A	
	Signal	15 A	
	Fan	15 A	
	Fuel	10 A	
	Main	30 A	
	ABS motor fuse	25 A	
	ABS valve fuse	15 A	

Tightening Torque Specifications

BENC11J1910S002

NOTE

The tightening torque(s) also specified in:
 "Wiring Harness Routing Diagram" (Page 9A-7)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J1910T001

NOTE


Required service material(s) also described in:
 "Wiring Harness Routing Diagram" (Page 9A-7)

Lighting Systems

Repair Instructions

Headlight Construction

BENC11J19206001




1. Body cowling	3. Cowling inner cover	5. Side cowling
2. Headlight	4. Meter front panel	6. Headlight brace

IC11J1920036-01

Headlight Components

BENC11J19206024



IC11J1920032-01

1. Headlight bulb (12 V 60/55 W, H4)

2. Position light bulb (12 V 5 W)


3. Bulb socket rubber cap

Headlight Removal and Installation

BENC11J19206003


Removal

- 1) Remove the body cowling assembly. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Remove the meter panel. Refer to "Combination Meter Removal and Installation" in Section 9C (Page 9C-2).
- 3) Disconnect the clamp (1), ambient air temperature sensor connector (2) and front turn signal light connectors (3).




IC11J1920025-01

- 4) Remove the headlight brace (4) by removing the bolts (5) and boss (6).




IC11J1920026-02

- 5) Disconnect the clamp (7) and remove the headlight (8) by removing the screws (9).



IC11J1920027-01

- 6) Disconnect the head light couplers (10), position light couplers (11) and clamps (12).



IC11J1920003-02

Installation

Installation is in the reverse order of removal. Pay attention to the following point:

- After installing, be sure to inspect the headlight beam. Refer to "Headlight Beam Adjustment" (Page 9B-4).

Headlight Bulb and Position Light Bulb Replacement

BENC11J19206004

▲ CAUTION

Remove the bulb when it gets cool, since it may be heated to an extremely high temperature when the headlight is turned ON.

NOTICE

When you touch the bulb with your bare hands, clean the bulb with a cloth moistened with alcohol or soapy water to prevent premature bulb failure.


NOTE

Do not use bulb other than those with predetermined wattage.

Headlight Bulb


Replace the headlight bulb in the following procedures:

- 1) Disconnect head light coupler (1).




IC11J1920004-01

- 2) Remove the bulb socket rubber cap (2).



IC11J1920005-01

- 3) Remove the headlight bulb (3) by unhooking the bulb holder spring (4).



IC11J1920006-01

- 4) Reinstall the removed parts.

NOTE

Properly fit the bulb socket rubber cap.

- 5) After installing be sure to inspect the headlight beam. Refer to "Headlight Beam Adjustment" (Page 9B-4).

Position Light Bulb


Replace the position light bulb in the following procedures:

- 1) Remove the meter panel. Refer to "Combination Meter Removal and Installation" in Section 9C (Page 9C-2).
- 2) Disconnect the position light coupler (1).




IC11J1920007-01

- 3) Remove the position light socket (2) by turning it counterclockwise.



IC11J1920008-01

- 4) Replace the position light bulb(-s) (3).



IC11J1920009-01

- 5) Reinstall the removed parts.

Headlight Beam Adjustment


BENC11J19206005

Adjust the headlight beam in the following procedures:

- 1) Remove the combination meter cover. Refer to "Combination Meter Removal and Installation" in Section 9C (Page 9C-2).

NOTE

Adjust the beam horizontally first, then vertically.




IC11J1920010-02

"A": Vertical adjuster

"B": Horizontal adjuster

Rear Lighting System Construction

BENC11J19206006




IC11J1920033-01

1. Rear combination light	4. Reflex reflector (For E-03, 28, 33)	(c) : 5.0 N·m (0.5 kgf-m, 3.7 lbf-ft)
2. License plate light	(a) : 1.8 N·m (0.18 kgf-m, 1.5 lbf-ft)	
3. Rear turn signal light	(b) : 2.3 N·m (0.23 kgf-m, 1.7 lbf-ft)	

Rear Combination Light Components

BENC11J19206007



IC11J1920028-01

1. Brake light/Tailight bulb (12 V 21/5 W)


2. Rear combination light mounting bolt

Rear Combination Light Removal and Installation

BENC11J19206008

Removal

- 1) Remove the rear fender rear. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Remove the rear turn signal lights (right and left). Refer to "Rear Turn Signal Light Removal and Installation" (Page 9B-11).
- 3) Remove the rear combination light (1) by removing the rear combination light screw (2).




IC11J1920011-03

Installation

Install the rear combination right in the reverse order of removal. Pay attention to the following point:

NOTE

Fix the clamp to the screw (1).



IC11J1920029-02

Rear Combination Light Bulb Replacement

BENC11J19206009

NOTICE

When you touch the bulb with your bare hands, clean the bulb with a cloth moistened with alcohol or soapy water to prevent premature bulb failure.

NOTE

Do not use bulb other than those with predetermined wattage.

Replace the rear combination light bulb in the following procedures:

- 1) Remove the seat. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Remove the bulb socket (1) by turning it counterclockwise.



IC11J1920012-01

- 3) Push in on the bulb (2), turn it counterclockwise, and pull it out.




IC11J1920013-01

- 4) Reinstall the removed parts.

License Plate Light Components

BENC11J19206010



IC11J1920030-01

1. License plate light bulb (12 V 5 W)

2. Lens


ⓐ : 5 N·m (0.5 kgf·m, 3.5 lbf·ft)

License Plate Light Removal and Installation

BENC11J19206011

Removal

- 1) Remove the license plate light assembly (1) by removing the nuts (2).



IC11J1920014-02


Installation

Install the license plate light in the reverse order of removal. Pay attention to the following point:

- Tighten the license plate light mounting nuts (1) to the specified torque.

Tightening torque

License plate light mounting nut (a): 5 N·m (0.5 kgf·m, 3.5 lbf·ft)



IC11J1920015-02

License Plate Light Bulb Replacement

BENC11J19206012

Replace the license plate light bulb in the following procedures:


NOTICE

When you touch the bulb with your bare hands, clean the bulb with a cloth moistened with alcohol or soapy water to prevent premature bulb failure.


NOTE

Do not use bulb other than those with predetermined wattage.

- 1) Remove the license plate light assembly. Refer to "License Plate Light Removal and Installation" (Page 9B-8).
- 2) Remove the lens (1) by removing the screws (2).




I944H1920022-01



I944H1920023-01

- 3) Push in on the bulb (3), turn it counterclockwise, and pull it out.




I944H1920024-01

- 4) Reinstall the removed parts.

Front Turn Signal Light Construction


BENC11J19206013





IC11J1920034-01

1. Front turn signal light	(a) : 1.5 N·m (0.15 kgf·m, 1.0 lbf·ft)
----------------------------	--

Turn Signal Light Components



IC11J1920035-03


1. Turn signal light bulb (12 V 21 W x 4)	3. Front turn signal light mounting nut	 : 1.5 N·m (0.15 kgf-m, 1.0 lbf-ft)
2. Lens	4. Rear turn signal light mounting nut	 : 2.3 N·m (0.23 kgf-m, 1.7 lbf-ft)

Front Turn Signal Light Removal and Installation

BENC11J19206015

Removal

- 1) Disconnect the front turn signal light coupler (1).
- 2) Remove the front turn signal light (2) by removing the nut (3).



IC11J1920016-02

Installation

Install the front turn signal light in the reverse order of removal. Pay attention to the following point:

- Tighten the front turn signal light mounting nut (1) to the specified torque.

Tightening torque

Front turn signal light mounting nut (a): 1.5 N·m (0.15 kgf-m, 1.0 lbf-ft)




IC11J1920017-02

Rear Turn Signal Light Removal and Installation

BENC11J19206016

Removal

- 1) Remove the rear fender rear. Refer to "Exterior Parts Removal and Installation" in Section 9D (Page 9D-5).
- 2) Disconnect the rear turn signal light coupler (1).
- 3) Remove the rear turn signal light (2) by removing the nut (3).



IC11J1920018-02


Installation

Install the rear turn signal light in the reverse order of removal. Pay attention to the following point:

- Tighten the rear turn signal light mounting nut (1) to the specified torque.

Tightening torque

Rear turn signal light mounting nut (a): 2.3 N·m (0.23 kgf-m, 1.7 lbf-ft)



IC11J1920019-02

Turn Signal Light Bulb Replacement

BENC11J19206017

NOTICE

When you touch the bulb with your bare hands, clean the bulb with a cloth moistened with alcohol or soapy water to prevent premature bulb failure.

NOTE

Do not use bulb other than those with predetermined wattage.

Replace the turn signal light bulb in the following procedures:

- 1) Remove the lens (1) by removing the screw (2).



IC11J1920020-01

- 2) Push in on the bulb (3), turn it counterclockwise, and pull it out.

- 3) Replace the bulb (3).



IC11J1920021-01

- 4) Reinstall the lens.

Turn Signal / Side-stand Relay Inspection

BENC11J19206018

NOTE**Make sure that the battery is fully charged.**

Before removing the turn signal/side-stand relay, check the operation of the turn signal light.

If the turn signal light does not illuminate, inspect the bulb, turn signal switch and circuit connection.

If the bulb, turn signal switch and circuit connection are OK, the turn signal relay may be faulty; therefore, replace the turn signal/side-stand relay with a new one. Refer to "Turn Signal / Side-stand Relay Removal and Installation" (Page 9B-12).

Turn Signal / Side-stand Relay Removal and Installation

BENC11J19206019

Refer to "Turn Signal / Side-stand Relay Removal and Installation" in Section 1I (Page 1I-8).

Hazard Switch Inspection

BENC11J19206020

Inspect the hazard switch in the following procedures:


- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Disconnect the left handlebar switch lead wire couplers (1).



IC11J1920022-02

- 3) Inspect the hazard switch for continuity with a tester. If any abnormality is found, replace the left handlebar switch assembly with a new one. Refer to "Handlebars Removal and Installation" in Section 6B (Page 6B-3).

Special tool

 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•••)

Color Position	B/R	Bl	Dg
OFF			
ON	○	○	○

IC11J1920023-02

- 4) After finishing the hazard switch inspection, reinstall the removed parts.

Turn Signal Switch Inspection

BENC11J19206021

Inspect the turn signal switch in the following procedures:


- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Disconnect the left handlebar switch lead wire coupler (1).



IC11J1920024-02

- 3) Inspect the turn signal switch for continuity with a tester. If any abnormality is found, replace the left handlebar switch assembly with a new one. Refer to "Handlebars Removal and Installation" in Section 6B (Page 6B-3).

Special tool

 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•••)

Color Position	Lg	Lbl	B
L		○	○
PUSH			
R	○	○	

I944H1920039-01


- 4) After finishing the turn signal switch inspection, reinstall the removed parts.

Passing Light Switch Inspection

BENC11J19206022

Inspect the passing light switch in the following procedures:


- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Disconnect the left handlebar switch lead wire coupler (1).



IC11J1920024-02

- 3) Inspect the passing light switch for continuity with a tester. If any abnormality is found, replace the left handlebar switch assembly with a new one. Refer to "Handlebars Removal and Installation" in Section 6B (Page 6B-3).

Special tool

 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•)))

Color Position	○	Y
•		
PUSH	○ ——— ○	○ ——— ○

IS44H1920041-01


- 4) After finishing the passing light switch inspection, reinstall the removed parts.

Dimmer Switch Inspection

BENC11J19206023

Inspect the dimmer switch in the following procedures:

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Disconnect the left handlebar switch lead wire coupler (1).



IC11J1920024-02

- 3) Inspect the dimmer switch for continuity with a tester. If any abnormality is found, replace the left handlebar switch assembly with a new one. Refer to "Handlebars Removal and Installation" in Section 6B (Page 6B-3).

Special tool

 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•)))

Color Position	W	Y	○
HI		○ ——— ○	○ ——— ○
LO	○ ——— ○	○ ——— ○	○ ——— ○

IS44H1920043-01

- 4) After finishing the dimmer switch inspection, reinstall the removed parts.

Specifications

Service Data

BENC11J19207001

Wattage

Unit: W

Item		Specification
Headlight	HI	60 x 2
	LO	55 x 2
Position/Parking light		5 x 2
Brake light/Taillight		21/5
Turn signal light		21 x 4
License plate light		5
Speedometer light		LCD
Tachometer light		LED
Turn signal indicator light		LED

Tightening Torque Specifications

BENC11J19207002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
License plate light mounting nut	5	0.5	3.5	☞ (Page 9B-8)
Front turn signal light mounting nut	1.5	0.15	1.0	☞ (Page 9B-10)
Rear turn signal light mounting nut	2.3	0.23	1.7	☞ (Page 9B-11)

NOTE

The tightening torque(s) also specified in:

- ☞ "Rear Lighting System Construction" (Page 9B-5)
- ☞ "License Plate Light Components" (Page 9B-8)
- ☞ "Front Turn Signal Light Construction" (Page 9B-9)
- ☞ "Turn Signal Light Components" (Page 9B-10)


Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment

Special Tool

BENC11J19208001

09900-25008 Multi circuit tester set ☞ (Page 9B-12) / ☞ (Page 9B-12) / ☞ (Page 9B-13) / ☞ (Page 9B-13)	
---	---

Combination Meter / Fuel Meter / Horn

General Description

Combination Meter System Description

BENC11J19301001

This combination meter mainly consists of the stepping motor, LCD (Liquid Crystal Display) and LED (Light Emitting Diode).


The rpm pointer is driven by the stepping motor.

The LCDs indicate Speed, Odo / Trip 1 / Trip 2 / Fuel reserve's trip / FI (DTC) / Instrument panel light brightness, Clock / Ambient air temperature, Fuel level indicator, Gear position, Engine coolant temperature and Oil pressure indicator respectively.

LED (Light Emitting Diode)

LED is used for the illumination light and each indicator light.

LED is maintenance free. LED is less electric-power consuming and stronger to vibration resistance compared to the bulb.




IC11J1930001-02

1. Adjust button	10. LCD (Clock / Ambient air temperature)
2. Select button	11. LCD (Oil pressure indicator)
3. Tachometer	12. LED (Turn signal indicator light)
4. LCD (Engine coolant temperature indicator)	13. LED (Freeze indicator light)
5. LCD (Gear position indicator)	14. LED (Neutral indicator light)
6. LCD (Speedometer)	15. LED (ABS indicator light)
7. LCD (Fuel level indicator)	16. LED (FI indicator light)
8. LCD (Odo / Trip 1 / Fuel consumption 1 / Trip 2 / Fuel consumption 2 / Instrument panel light brightness / FI (DTC))	17. LED (High-beam indicator light)
9. LCD (Engine coolant temperature indicator)	18. LED (Engine coolant temperature indicator light / Oil pressure indicator light)

Repair Instructions

Combination Meter Components

BENC11J19306001



1. Combination meter upper case	2. Combination meter unit	3. Combination meter lower case
---------------------------------	---------------------------	---------------------------------


IC11J1930024-01

Combination Meter Removal and Installation

BENC11J19306002

Removal

- 1) Remove the combination meter cover (1) by removing the screws (2) and clips (3).



IC11J1930002-02


- 2) Disconnect the combination meter coupler (4).



IC11J1930003-01

- 3) Remove the combination meter mounting bolts (5) and screws (6).

- 4) Remove the combination meter assembly (7).



IC11J1930004-01

Installation


Install the combination meter in the reverse order of removal. Pay attention to the following point.

- Tighten combination meter bolts (1) and screws (2) to the specified torque.

Tightening torque

Combination meter bolt (a): 4.5 N·m (0.45 kgf-m, 3.3 lbf-ft)


Combination meter screw (b): 1.5 N·m (0.15 kgf-m, 1.0 lbf-ft)



IC11J1930006-01

NOTE

Fix the boot (3) of the combination meter coupler properly.



IC11J1930005-01

Combination Meter Disassembly and Assembly

BENC11J19306003

Disassembly

Disassemble the combination meter as shown in the combination meter components. Refer to "Combination Meter Components" (Page 9C-2).

Assembly

Assemble the combination meter as shown in the combination meter components. Refer to "Combination Meter Components" (Page 9C-2).

Combination Meter Inspection


BENC11J19306004

LED Inspection

Check that the LEDs (FI indicator light, Oil pressure/ Engine coolant temperature indicator light, Fuel level indicator light, ABS indicator light, Freeze indicator light and Meter panel illumination) immediately light up when the ignition switch is turned to ON.

Check that other LEDs (Neutral indicator light, High-beam indicator light and Turn signal indicator lights) light up/go off by operating each switch.

If abnormal condition is found, replace the combination meter unit with a new one after checking its wire harness/coupler. Refer to "Combination Meter Removal and Installation" (Page 9C-2).




IC11J1930007-02

Stepping Motor Inspection and Adjustment

- 1) Check that the pointer calibrates itself immediately after turning the ignition switch on and stops at zero point.

If abnormal condition is found, replace the combination meter unit with a new one after checking its wire harness/coupler.




IC11J1930008-02

NOTE

- The pointer may not return to the proper position even turning the ignition switch on under low temperature condition. In that case, you can reset the pointer to the proper position by following the instruction.
- Complete the operation within 10 seconds after the ignition switch has been turned on.

- 2) With the adjuster switch (1) pressed, turn the ignition switch ON.
- 3) Keep pushing the adjuster switch (1) for more than 3 to 5 sec.



IC11J1930009-02

Time	Ignition switch	Adjuster button (1)
	OFF	PUSH
0	ON	↓
•		
•		
3 sec.		↓
•		
5 sec.		Release
•		
•		Push
•		
•		Push→Reset
10 sec.		

I837H1930023-03

- 4) Pointer will return to the starting point right after the completion of the operation. In the case of the pointer not returning to the proper position after doing above, replace the combination meter unit. Refer to "Combination Meter Removal and Installation" (Page 9C-2).
- 5) Turn the ignition switch OFF.

Engine Coolant Temperature Indicator Light Inspection

BENC11J19306005

Refer to "Electrical Components Location" in Section 0A (Page 0A-9).


Inspect the engine coolant temperature indicator light in the following procedures:

- 1) Disconnect the ECT sensor coupler (1).



IC11J1110020-02

- 2) Connect the variable resistor (2) between the terminals.





















I718H1930009-05

- 3) Turn the ignition switch ON.

9C-5 Combination Meter / Fuel Meter / Horn:


- 4) Check the LED (3) and LCD (4) operations when the resistance is adjusted to the specified values.
If either one or all indications are abnormal, replace the combination meter with a new one. Refer to "Combination Meter Removal and Installation" (Page 9C-2).

Engine coolant temperature indicator		Temperature and resistance
LED	LCD	
ON	Flicker 	 120 °C (248 °F) Approx. 126 Ω
OFF	ON 	 115 °C (239 °F) Approx. 129 Ω
OFF	ON 	 118 °C (244 °F) Approx. 126 Ω
OFF	ON 	 114 °C (237 °F) Approx. 143 Ω
OFF	ON 	 109 °C (228 °F) Approx. 432 Ω
OFF	ON 	 70 °C (158 °F) Approx. 441 Ω
OFF	ON 	 50 °C (122 °F) Approx. 839 Ω
OFF	ON 	 40 °C (104 °F) Approx. 1192 Ω
OFF	ON 	 49 °C (120 °F) Approx. 1156 Ω

A: When decreasing the temperature

B: When increasing the temperature

IB06J1930007-02



IC11J1930010-02

- 5) Connect the ECT sensor coupler.

- 2) Measure the resistance at each fuel level gauge float position. If the resistance is incorrect, replace fuel level gauge with a new one.


Special tool

 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Resistance (Ω)

Float position	Resistance
Full "a"	9 – 11 Ω
Empty "b"	213 – 219 Ω



IC11J1930012-02

"c": 275 mm (10.83 in)	"d": 95 mm (3.74 in)
------------------------	----------------------

- 3) Install the fuel pump assembly. Refer to "Fuel Pump Disassembly and Assembly" in Section 1G (Page 1G-9).

Speedometer Inspection

BENC11J19306009

If the speedometer, odometer or tripmeter does not function properly, inspect the speed sensor and the coupler connections. If the speed sensor and coupler connections are OK, replace the combination meter unit with a new one. Refer to "Combination Meter Removal and Installation" (Page 9C-2).


Speed Sensor Removal and Installation

BENC11J19306010

Removal


- 1) Lift and support the fuel tank. Refer to "Fuel Tank Removal and Installation" in Section 1G (Page 1G-6).

- 2) Remove the engine sprocket cover (1). Refer to "Engine Sprocket Removal and Installation" in Section 3A (Page 3A-2).



IC11J1930014-02


- 3) Disconnect the speed sensor coupler (2).



IC11J1930013-02

- 4) Disconnect the speed sensor lead wire from the clamp (3).

- 5) Remove the speed sensor (4).



IC11J1930015-03


Installation

Install the speed sensor in the reverse order of removal. Pay attention to the following points:

- Tighten the speed sensor mounting bolt (1) to the specified torque.

Tightening torque

Speed sensor mounting bolt (a): 4.5 N·m (0.45 kgf-m, 3.3 lbf-ft)




IC11J1930016-03

- Route the speed sensor lead wire. Refer to "Wiring Harness Routing Diagram" in Section 9A (Page 9A-7).
- Install the engine sprocket cover and tighten the engine sprocket cover bolts (2) to the specified torque.

Tightening torque

Engine sprocket cover bolt (b): 5.5 N·m (0.55 kgf-m, 4.0 lbf-ft)



IC11J1930017-02

Speed Sensor Inspection

BENC11J19306011

Inspect the speed sensor in the following procedures:


- 1) Remove the speed sensor. Refer to "Speed Sensor Removal and Installation" (Page 9C-7).
- 2) Connect a 12 V battery (between B and B/W), 10 k Ω resistor (between B/R and B) and multi-circuit tester (tester (+) probe to B and tester (-) probe to B/R) as shown.

Special tool

09900 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Voltage (---)




I717H1930018-01

1. Speed sensor

- 3) Move a screwdriver back and forth across the pick-up surface of the speed sensor. The voltage readings should cycle as follows (0 V \rightarrow 12 V or 12 V \rightarrow 0 V). If the voltage reading does not change, replace the speed sensor with a new one.

NOTE

While testing, the highest voltage reading should be the same as the battery voltage (12 V).



I649G1930017-02

- 4) Install the speed sensor. Refer to "Speed Sensor Removal and Installation" (Page 9C-7).

Oil Pressure Indicator Inspection

BENC11J19306012

Inspect the oil pressure indicator in the following procedures:

NOTE


Before inspecting the oil pressure switch, check if the engine oil level is correct. Refer to "Engine Oil and Filter Replacement" in Section 0B (Page 0B-10).

- 1) Disconnect the oil pressure switch lead wire (1) from the oil pressure switch.



IC11J1930018-01

- 2) Turn the ignition switch to ON.
- 3) Check if the oil pressure indicator (LED) "A" and (LCD) "B" will light up when grounding the lead wire (1).
If the oil pressure indicator does not light up, replace the combination meter unit with a new one after checking connection of couplers.



IC11J1930019-03

- 4) Connect the oil pressure switch lead wire. Refer to "Wiring Harness Routing Diagram" in Section 9A (Page 9A-7).

Oil Pressure Switch Removal and Installation

BENC11J19306013


Refer to "Oil Pressure Switch Removal and Installation" in Section 1E (Page 1E-8).

Ignition Switch Inspection

BENC11J19306014

Inspect the ignition switch in the following procedures:

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).
- 2) Disconnect the ignition switch lead wire coupler (1).



IC11J1180026-01

- 3) Inspect the ignition switch for continuity with a tester. If any abnormality is found, replace the ignition switch with a new one.

Special tool

TOOL : 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•••)

E-21, 24

Color	R	O	Gr	Br
Position				
ON	○—○	○—○	○—○	○—○
OFF				
LOCK				
P	○—○			○—○

IB14J1930018-01

E-03, 28, 33

Color	R	O	O/Y	Gr	Br
Position					
ON	○—○	○—○	○—○	○—○	○—○
OFF					
LOCK					
P	○—○				○—○


IB14J1930019-01

- 4) After finishing the ignition switch inspection, reinstall the removed parts.

Ignition Switch Removal and Installation

BENC11J19306015


Refer to "Ignition Switch Removal and Installation (for E-03, 24, 28, 33)" in Section 1H (Page 1H-11).



IC11J1930026-01


- 3) Turn the ignition switch ON.
- 4) Check the ambient air temperature meter (LCD) (3) and freeze indicator light (LED) (4) operations when the resistance is adjusted to the specified values. If either one or both indications are abnormal, replace the combination meter with a new one. Refer to "Combination Meter Removal and Installation" (Page 9C-2).

Resistance (2)	Ambient air temperature indicator (LCD) (4)	
	°C	°F
Approx. 1.7 kΩ	25.0	78.0
Approx. 4.3 kΩ	5.0	41.0
Approx. 9.7 kΩ	-10.0	14.0



IC11J1930027-02

"A": When increasing the temperature
 "B": When decreasing the temperature



IC11J1930028-02

- 5) Connect the ambient air temperature sensor coupler.

Ambient Air Temperature Sensor Removal and Installation

BENC11J19306018

Removal

- 1) Disconnect the ambient air temperature sensor coupler (1).
- 2) Remove the ambient air temperature sensor (2).



IC11J1930023-01

Installation

Install the ambient air temperature sensor in the reverse order of removal.

Ambient Air Temperature Sensor Inspection

BENC11J19306019

▲ CAUTION

- The ambient air temperature sensor operative temperature range is -30 - 80 °C (-22 - 176 °F).
- Do not heat the oil up to 80 °C (176 °F) or more for this inspection.

NOTE

Ambient air temperature sensor resistance measurement method is the same way as that of the ECT sensor. Refer to "ECT Sensor Inspection" in Section 1C (Page 1C-4).

Ambient air temperature sensor specification

Temperature	Standard resistance
-20 °C (-4 °F)	Approx. 16.235 kΩ
-10 °C (14 °F)	Approx. 9.282 kΩ
0 °C (32 °F)	Approx. 5.500 kΩ
10 °C (50 °F)	Approx. 3.365 kΩ
20 °C (68 °F)	Approx. 2.120 kΩ
25 °C (77 °F)	Approx. 1.700 kΩ
30 °C (86 °F)	Approx. 1.372 kΩ
40 °C (104 °F)	Approx. 0.910 kΩ

Select Button Inspection

BENC11J19306021

Inspect the select button in the following procedures:

- 1) Remove the air cleaner box. Refer to "Air Cleaner Box Removal and Installation" in Section 1D (Page 1D-6).

- 2) Disconnect the left handlebar switch lead wire coupler (1).



IC11J1930029-01



- 3) Inspect the select button for continuity with a tester. If any abnormality is found, replace the left handlebar switch assembly with a new one. Refer to "Handlebars Removal and Installation" in Section 6B (Page 6B-3).

Special tool

 : 09900-25008 (Multi circuit tester set)

Tester knob indication

Continuity (•||)

Color Position	Y/G	B/W
•		
PUSH		

IC11J1930030-01

- 4) After finishing the select button inspection, reinstall the removed parts.

Service Data

Warranty
Unit No.

Headlight

Position/Working Light

Brake Light (Left)

Turn Signal Light

License Plate Light

Speedometer Light

Indicator Light

Turn Signal Indicator Light

Horn (Left/Right)

Neutral Position Indicator Light

Oil Pressure/Engine Temperature Indicator Light

FI Indicator Light

Fuel Indicator Light

ABS Indicator Light

Tightening Torque Specifications

Part	Tightening Torque
Combination meter bolt	
Combination meter screw	
Speed sensor mounting bolt	
Engine access cover bolt	

Reference:

For the tightening torque of fasteners not specified in this section, refer to "Tightening Torque" (Page 9C-1).

Special Tools and Equipment

Special Tool

09900-25008

Multi circuit tester set

(Page 9C-1)

(Page 9C-5)

(Page 9C-11)

(Page 9C-16)

(Page 9C-17)



Specifications

Service Data

BENC11J19307001

Wattage

Unit: W

Item	Specification
Headlight	HI
	LO
Position/Parking light	5 x 2
Brake light/Taillight	21/5
Turn signal light	21 x 4
License plate light	5
Speedometer light	LCD
Tachometer light	LED
Turn signal indicator light	LED
High beam indicator light	LED
Neutral position indicator light	LED
Oil pressure/Engine coolant temperature indicator light	LED
FI indicator light	LED
Freeze indicator light	LED
ABS indicator light	LED

Tightening Torque Specifications

BENC11J19307002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lbf·ft	
Combination meter bolt	4.5	0.45	3.3	☞ (Page 9C-3)
Combination meter screw	1.5	0.15	1.0	☞ (Page 9C-3)
Speed sensor mounting bolt	4.5	0.45	3.3	☞ (Page 9C-8)
Engine sprocket cover bolt	5.5	0.55	4.0	☞ (Page 9C-8)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment

Special Tool

BENC11J19308001

09900-25008 Multi circuit tester set ☞ (Page 9C-7) / ☞ (Page 9C-8) / ☞ (Page 9C-9) / ☞ (Page 9C-10) / ☞ (Page 9C-12)	
--	---

Exterior Parts

Schematic and Routing Diagram

Seat Lock Cable Routing Diagram

BENC11J19402001



IC11J1940039-01

- | | |
|--------------------|--------------|
| 1. Seat lock cable | 2. Seat lock |
|--------------------|--------------|

Rear Fender

BENC11J19402002

Part Name	Part Number	Quantity	Notes
Seat lock cable	IC11J1940039-01	1	
Seat lock	BENC11J1940038-01	1	


© 2011 Honda

Always use proper tie-down technique. Always use proper tie-down technique. Always use proper tie-down technique.

Repair Instructions

Cowling Construction

BENC11J19406006




IC11J1940040-01

1. Windscreen	3. Cowling inner cover	5. Cowling inner cover	7. Meter panel
2. Side cowling	4. Body cowling	6. Meter front panel	8. Headlight brace

Frame Cover Construction


BENC11J19406001



IC11J1940041-01


Rear Fender Construction

BENC11J19406002



IC11J1940042-01

1. Rear front fender 2. Rear fender : Apply thread lock to the thread part.



IC11J1940038-02


1. Sport carrier	2. Sport carrier mat	: 29 N·m (2.9 kgf·m, 21.0 lbf·ft)	: Apply thread lock to the thread part.
------------------	----------------------	-----------------------------------	---

Fastener Removal and Installation

BENC11J19406003

Removal


- 1) Depress the head of fastener center piece (1).
- 2) Pull out the fastener (2).



I649G1940005-02

Installation

- 1) Let the center piece stick out toward the head so that the pawls "A" close.




I649G1940006-02

- 2) Insert the fastener into the installation hole.

NOTE

To prevent the pawl "A" from damage, insert the fastener all the way into the installation hole.

- 3) Push in the head of center piece until it becomes flush with the fastener outside face.



I649G1940007-02

Exterior Parts Removal and Installation

BENC11J19406004

Seat

Removal


- 1) Unlock the seat with the ignition key (1).
- 2) Remove the seat.



IC11J1940001-02

Installation

Slide the seat hooks into the seat hook retainers and push down firmly until the seat snaps into the locked position.




IC11J1940002-02

Sport Carrier

Removal

- 1) Remove the seat.
- 2) Remove the sport carrier mat (1).





IC11J1940003-01

"A": Hooked point

9D-8 Exterior Parts:

- 5) Remove the battery holder (10) by removing the bolts (11), screws (12) and fastener (13).



- 6) Disconnect the pre-load adjuster hose from the clamp (14).



- 7) Remove the frame cover and frame side cover.
8) Remove the rear reservoir tank bolt (15).



- 9) Remove the muffler assembly. Refer to "Exhaust Pipe / Muffler Removal and Installation" in Section 1K (Page 1K-3).

- 10) Remove the cooling fan relay (16).

- 11) Remove the rear fender (front) (17) by removing the bolts (18).




Installation

Install the rear fender (front) in the reverse order of removal. Pay attention to the following point:


- Rout the wiring harness. Refer to "Wiring Harness Routing Diagram" in Section 9A (Page 9A-7).

Fuel Tank Side Cover and Fuel Tank Front Cover Removal

- 1) Remove the seat.
- 2) Remove the fuel tank front cover (1) by removing the bolts (2) and fastener (3).



- 3) Remove the frame side covers (4) by removing the bolt (5).
- 4) Remove the fuel tank side cover (6) by removing the bolts (7).



"A": Guide

"B": Velcro fastening

Installation

Install the fuel tank side cover and fuel tank front cover in the reverse order of removal.

Body Cowling Assembly**Removal**

- 1) Remove the seat.
- 2) Remove the sport carrier mat and sport carrier.
- 3) Remove the frame covers and frame side covers.
- 4) Remove the fuel tank side covers and fuel tank front cover.
- 5) Disconnect the lead wire couplers (1) and clamp (2).



IC11J1940030-01

- 6) Remove the bolts (3).



IC11J1940032-02

- 7) Remove the body cowling assembly (4) by removing the bolts (5).



IC11J1940031-01


Installation

Install the body cowling assembly in the reverse order of removal. Pay attention to the following point:

- After installing, be sure inspect the headlight beam. Refer to "Headlight Beam Adjustment" in Section 9B (Page 9B-4).


Windscreen, Meter Panel, Body Cowling, Cowling Inner Cover, Meter Front Panel and Side Cowling Removal

- 1) Remove the seat.
- 2) Remove the sport carrier mat and sport carrier.
- 3) Remove the frame cover and frame side cover.
- 4) Remove the fuel tank side cover and fuel tank front cover.
- 5) Remove the windscreen (1) by removing the bolts (2).



IC11J1940018-01

- 6) Remove the nuts (3).




IC11J1940019-01


9D-10 Exterior Parts:

7) Remove the meter panel. Refer to "Combination Meter Removal and Installation" in Section 9C (Page 9C-2).


8) Remove the body cowling (4) by removing the screws (5) (6).





"B": Velcro fastening



9) Remove the meter front panel (7) by removing the screws (8).




10) Remove the cowling inner cover (9) by removing the screws (10) and fastener (11).



11) Remove the ambient air temp sensor (12). Refer to "Ambient Air Temperature Sensor Removal and Installation" in Section 9C (Page 9C-11).

12) Disconnect the turn signal lamp lead wire couplers (13) and clamps (14).



13) Remove the side cowlings (15) by removing the bolt (16).




IC11J1940027-02

"A": Guide

14) Remove the cowling inner cover (17) by removing the screws (18).

15) Remove front turn signal light (19). Refer to "Front Turn Signal Light Removal and Installation" in Section 9B (Page 9B-10).




IC11J1940028-02

Installation

Install the windscreen, meter panel, body cowling, cowling inner cover, meter front panel and side cowling in the reverse order of removal. Pay attention to the following points:


- Fit the clamp to the cowling inner cover screw (1). (left side only)



IC11J1940033-01

NOTE

Fix the boot (2) of the combination meter coupler properly.



IC11J1940034-01

- After installing, be sure inspect the headlight beam. Refer to "Headlight Beam Adjustment" in Section 9B (Page 9B-4).

Specifications

Tightening Torque Specifications

BENC11J19407001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lbf-ft	
Sport carrier bolt	29	2.9	21.0	^① (Page 9D-6)

NOTE

The tightening torque(s) also specified in:
 "Sport Carrier Construction" (Page 9D-4)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J19408001

Material	SUZUKI recommended product or Specification		Note
Thread lock cement	THREAD LOCK CEMENT SUPER "1322" or equivalent	P/No.: 99000-32110	^① (Page 9D-6) / ^② (Page 9D-7)

NOTE


Required service material(s) also described in:
 "Rear Fender Construction" (Page 9D-3)
 "Sport Carrier Construction" (Page 9D-4)

Body Structure

Repair Instructions

Body Frame Construction

BENC11J19506001




IC11J1950001-01

1. Frame	6. Engine mounting thrust adjuster lock-nut	(c) : 45 N·m (4.5 kgf·m, 32.5 lbf·ft)
2. Seat rail	7. Seat rail bolt	(d) : 50 N·m (5.0 kgf·m, 36.0 lbf·ft)
3. Engine mounting bracket	8. Engine mounting pinch bolt	(e) : 25 N·m (2.5 kgf·m, 18.0 lbf·ft)
4. Engine mounting bracket bolt		Apply thread lock to thread part.
5. Engine mounting thrust adjuster		

Front Footrest Construction

BENC11J19506002




IC11J1950002-02

1. Bank sensor bolt	(b) : 26 N·m (2.6 kgf-m, 19.0 lbf-ft)	X : Do not reuse.
2. Front footrest bracket bolt	AH : Apply grease to sliding surface.	
(a) : 18 N·m (1.8 kgf-m, 13.0 lbf-ft)	1322 : Apply thread lock to thread part.	

Pillion Footrest Construction

BENC11J19506004




IC11J1950003-02

1. Pillion footrest bracket	AH : Apply grease to sliding surface.	X : Do not reuse.
(a) : 23 N·m (2.3 kgf-m, 16.5 lbf-ft)	1322 : Apply thread lock to thread part.	

Side-stand Construction

BENC11J19508003



IC11J1950004-02

: 40 N·m (4.0 kgf·m, 29.0 lbf·ft)	: 100 N·m (10.0 kgf·m, 72.5 lbf·ft)	: Apply thread lock to thread part.
: 50 N·m (5.0 kgf·m, 36.0 lbf·ft)	: Apply grease to sliding surface.	

Specifications

Tightening Torque Specifications

BENC11J19507001

NOTE

The tightening torque(s) also specified in:
 "Body Frame Construction" (Page 9E-1)
 "Front Footrest Construction" (Page 9E-2)
 "Pillion Footrest Construction" (Page 9E-2)
 "Side-stand Construction" (Page 9E-3)

Reference:

For the tightening torques of fasteners not specified in this section, refer to "Tightening Torque List" in Section 0C (Page 0C-7).

Special Tools and Equipment

Recommended Service Material

BENC11J19508001

NOTE

Required service material(s) also described in:
 "Body Frame Construction" (Page 9E-1)
 "Front Footrest Construction" (Page 9E-2)
 "Pillion Footrest Construction" (Page 9E-2)
 "Side-stand Construction" (Page 9E-3)